1 Well

Si (p-type)	We start with a p-type silicon wafer
SiO2	
Si (p-type)	We grow an oxide layer of approximately 1000 angstrom thickness (see documentation)
Resist	
SiO2	
Si (p-type)	We thin film deposit a layer of resist