

```

44 xrq=xmq^2/(xq-xq2)
45 sigmae=1-xmd/xe
46 sigmaxd=1-xmd/xd
47 sigmard=1-xmd/xrd
48 % Computation of Fundamental parameters for LTSpice model
49 % Delete Formulas and overwrite with the values of
50 % Rs,Ls,RE,RDx,RDy,LDx,LDy,LE,R0,L0 below
51 Rs=rcu*ZBase % Rs
52 Ls=x1*ZBase/omega % Ls
53 Lmd=xmd*ZBase/omega % (Lhd3)
54 Lmq=xmq*ZBase/omega % (Lhq3)
55 Lfd=Lmd*sigmae % Le
56 Lkd=(xrd-xmd)*ZBase/omega % LDx
57 Lkq=(xrq-xmq)*ZBase/omega % LDy
58 Rkd=(xrd-xmd^2/xe)*ZBase/omega/Td02 % RDx
59 Rkq=(xrq*ZBase/omega/Tq02) % RDy
60 Re=Ue0/Ie0*2/3 % RE
61 Re0=Ue0/Ie0
62 g=Ue0/(UN*sqrt(2)*Re0/(Xd-omega*Ls))
63 Res=Re*g*g
64 R0=Rs % R0
65 L0=Ls % L0
66 Td01=Xd/Res/omega % Should be same as above
67 % If not change Ie0 to meet Td01
68
69

```