

```

.tran 0 22 1m 0.6m
.param tdv=1 tdt=1 fn1=60 omega_n={2*pi*fn1}
.options vntol=10 abstol=100m reltol=0.01

```

m=1 (linear transformer)
 because of starting simulation
 with full voltage -> transients
 of nonlinear core

SN=250e6 U1Nenn=230e3 U20=13.8e3 fN=60 N1=1000 m=1

