

User's Guide



Copyright © 2006, IntelliTools, Inc.

Copyright Notice

IntelliTools (and logo), IntelliKeys, IntelliMathics, IntelliPics, IntelliTalk (and logo), Overlay Maker (and logo), ReadyMade, SwitchIt!, and ClickIt! are registered trademarks of IntelliTools, Inc. All other IntelliTools product names and logos are trademarks or brand names of IntelliTools, Inc.

Co:Writer and Write:OutLoud logos and keyboard icons copyright © Don Johnston Incorporated. Other product names and logos contained herein (including Windows, Macintosh, QuickTime, Adobe Reader, Kurzweil 3000, Inspiration, Kidspiration, WYNN, TestTalker, AOL Instant Messenger, AOL Explorer, iTunes, Safari, PowerPoint, Clicker, Boardmaker, Speaking Dynamically Pro, and Writing With Symbols), and other brand and product names mentioned are registered trademarks, trademarks, or brand names of their respective holders and are hereby acknowledged.

Patents and Trademarks

IntelliKeys USB is protected by U.S. Patent D352,280. IntelliTools, IntelliKeys, IntelliKeys USB, and their respective logos and *IntelliTalk II*, *Overlay Maker*, *Overlay Printer*, *Overlay Sender*, *IntelliPics*, and *ClickIt!* are registered trademarks of IntelliTools, Inc. *IntelliMathics* is a trademark of IntelliTools, Inc.

Credits

The *Popular Software Overlays for IntelliKeys* were produced through the collaborative efforts of many staff members at IntelliTools, as well as a network of highly dedicated assistive technology professionals. We are also grateful for the enthusiasm and expertise of our collaborators: Adobe Systems, Inc., America Online, Inc. (AOL), Apple Computer, Inc., Crick Software Inc., Don Johnston, Inc., Freedom Scientific, Inc., Inspiration Software, Inc., Kurzweil Education Systems, Inc., Mayer-Johnson LLC, Microsoft Corporation.



Technical Support

Hours: 8 a.m. – 5 p.m. Pacific Time, Monday through Friday.

Phone: (800) 899-6687 (U.S. and Canada) (707) 773-2000 (local and international)

Fax: (707) 773-2001

Email: tech@intellitools.com (for technical information)

info@intellitools.com (for general information) World Wide Web: http://www.intellitools.com

MNL-PSO 4/06

Table of Contents

| Introduction | 1 |
|---|----|
| Minimum System Requirements | 2 |
| Package Contents | |
| Installing the Popular Software Overlays Software | |
| Using the Popular Software Overlays | |
| iTunes | 4 |
| Safari | 4 |
| Kurzweil 3000 | 6 |
| Kurzweil 3000 (Reading) | 7 |
| Microsoft Word | |
| Microsoft PowerPoint | Ç |
| TestTalker | 10 |
| WYNN | 11 |
| AOL Instant Messenger (AIM) | 12 |
| AOL Explorer | 13 |
| Co:Writer | 14 |
| Write:OutLoud | 15 |
| Inspiration | 16 |
| Kidspiration | 18 |
| Modifying Overlays | |
| Editing Overlays | 20 |
| Saving Overlays | 20 |
| Printing Overlays | 20 |
| Attaching Overlays | |
| Using Overlays with Mayer-Johnson Products | 20 |
| Adding Keyboard Shortcuts to Macintosh OS X | |
| Troubleshooting | 23 |

Introduction

Congratulations on choosing *Popular Software Overlays for IntelliKeys*.

This unique set of 7 double-sided overlays, when combined with IntelliKeys USB, provides unprecedented access to many popular software applications, including several educational programs used in schools.

Simply launch one of the popular software programs and slide the matching overlay into the IntelliKeys. The popular software overlays can be used on Windows (98 and above) and Macintosh OSX (10.1.x and above).

The Popular Software Overlays for IntelliKeys can also be modified to meet the diverse needs of your students. Using Overlay Maker 3 (sold separately) you can add or remove keys from the overlays, and then save and print your own customized overlays for use with popular software.

Follow the installation instructions below and then try out the overlays. This guide includes a description of each overlay and some tips on how to use it with the software.

There is also information included on how to modify and save your own versions of overlays. We hope that these overlays will inspire you to create IntelliKeys access to other programs your students are using.

Minimum System Requirements

Windows

- Computer (or powered hub) with an available USB port.
- Windows 98, 98SE, ME, 2000 or XP.
- 13 MB free hard drive space.
- 32 MB RAM (Win 98/ME): 64 MB (Win 2000/XP).
- CD-ROM drive.
- IntelliKeys USB (sold separately)

Macintosh

- Computer (or powered hub) with an available USB port.
- Mac OS 10.1.x or higher.
- 14 MB free hard drive space.
- 4.5 MB available RAM.
- CD-ROM drive.
- IntelliKeys USB (sold separately)

Package Contents

- 1 Popular Software Overlays CD.
- 7 double-sided Printed Overlays.
- 1 Popular Software Overlays for IntelliKeys User's Guide.

Installing the Popular Software Overlays Software

The *Popular Software Overlays* are installed along with version 3.0 of the IntelliKeys USB software. This version of the IntelliKeys USB software introduces the ability to attach overlays to almost any application installed on your computer.

On a Windows Computer

Follow these steps to install the *Popular Software Overlays* on a Windows computer:

- 1. Insert the *Popular Software Overlays* CD into the CD-ROM drive. On most PCs the program installation will start automatically and you can proceed directly to step 5. If your computer's CD-ROM drive is not set up for autorun (see your computer's operations manual regarding a setting called Auto insert notification), proceed to step 2.
- 2. Double-click the My Computer icon on your desktop. A CD-ROM icon named *Popular Software Overlays* CD will be listed in the content window that appears.
- 3. Right-click the IntelliKeys *Popular Software Overlays* CD-ROM icon and select Explore from the menu that appears. This action displays the contents of the *Popular Software Overlays* CD.
- 4. Double-click the *setup.EXE* icon in the content window that appears. This starts the automated installation process.
- 5. Follow the installation instructions that appear on-screen. Click Finish when the Installation Complete dialog box appears. Restart your computer when prompted.

 RESULT: The IntelliKeys USB program is stored in a folder labeled IntelliKeys USB. This folder is located in a folder labeled ITools (IntelliTools) on the computer's main drive. The IntelliKeys USB icon is added to the Taskbar in the lower right corner of your screen.

On a Macintosh Computer

Follow these steps to install the *Popular Software Overlays* on a Macintosh computer:


- 1. Insert the *Popular Software Overlays* CD into the CD-ROM drive. A CD-ROM icon labeled Popular Software Overlays will appear on the desktop along with an open folder labeled Popular Software Overlays CD.
- 2. Double-click the IKUSB PSO Installer/Uninstaller icon in the IntelliKeys USB folder. This starts the automated installation process.
- 3. Read the Read Me document and click Continue. Follow the on-screen instructions to complete the installation. Restart your computer when prompted.

RESULT: The IntelliKeys USB program is stored in a folder labeled IntelliKeys USB. This folder is located in a folder labeled IntelliTools on the computer's main hard drive (Mac OSX Applications: IntelliTools: IntelliKeys USB). The IntelliKeys USB icon is added to the menu bar in the upper right corner of your computer screen.

Once you have installed the Popular Software Overlays, proceed to Chapter 2 of the IntelliKeys USB Users Guide for instructions about connecting the IntelliKeys USB to your computer.

iTunes Overlay

The iTunes overlay is designed to operate common features found on iTunes, Apple's popular digital jukebox. This overlay was designed to work with iTunes versions 4.9 and 5.0 for Windows and Macintosh.



iTunes Overlay

How to Use

Launch iTunes and insert the iTunes overlay on your IntelliKeys USB. Press Play/Pause to begin playing the first song in your library. Press Next Song to play the next song in your library. Press Play/Pause again to pause the song. Press Previous Song to play the previous song. This overlay was designed to fit the 12 hole custom keyguard.

- Navigate navigates to open panes within iTunes.
- Up and Down Arrows used with the Navigate key to navigate items in the selected pane.
- Browse shows or hides the Genre, Artist and Album panes.
- Show/Hide Artwork shows or hides album artwork if present.
- Visualizer On/Off shows or hides the Visualizer.
- Volume Down, Volume Up lowers and raises the volume.

Safari Overlay

The Safari overlay is designed to provide access to common features found in Apple's Web browser. It includes Previous Page, Next Page, Reload, Stop, Home, Add Bookmark, Bookmarks, AutoFill, and Search. It also includes common parts of Internet Web addresses to save keystrokes when browsing. This overlay is for Macintosh computers only. This overlay was designed to work with Safari version 2.01.



Safari Overlay


How to Use

Launch Safari and insert the Safari overlay on your IntelliKeys USB. Press the Open Location key to place your cursor at the address bar. Press the IntelliTools key. Safari will be connected to the IntelliTools Web site.

- Open Location places your cursor at the address bar (the text box where you enter a World Wide Web address). Type in the address and press Enter.
- Apple.com connects to the Apple Web site.
- Print and Copy make it easy to access these common commands.
- Scroll Up and Scroll Down moves through a page one screen at a time.
- Tab navigates Safari's Address Bar and Bookmarks Bar as well as links on Web pages.
- Up and Down arrows scroll a page continuously.
- www., .com, .edu, .gov, .net, .org inserts these common parts of an Internet Web address in the address bar.
- AutoFill completes web forms using information from your Address Book card.
- Bookmarks shows all bookmarks. Use the arrow keys to select a bookmark and press the Space key to go to the Web page represented by the selected bookmark.
- Add Bookmarks adds the current Web page to your bookmarks.

Kurzweil 3000 Overlay

The Kurzweil 3000 overlay is designed to provide access to many features of the Kurzweil 3000 word processing program. It includes large reading keys on the bottom left for easy access to this commonly used feature. This overlay was designed to work with Kurzweil 3000 version 9. This overlay will only work with the Windows version of Kurzweil 3000.



Kurzweil 3000 Overlay


How to Use

Launch Kurzweil and insert the Kurzweil 3000 overlay on your IntelliKeys USB. Open a document and press the Read/Pause key to begin reading the document. Press the Read/Pause again to stop reading.

- Bookmark opens the Bookmarks dialog box. Use the Tab and arrow keys to navigate.
- Add adds a bookmark when the Bookmarks dialog box is open.
- Go To moves the cursor to the selected bookmark in the Bookmarks dialog box.
- Word Predict toggles Word Prediction on and off.
- Highlight (Yellow, Green, Cyan, and Magenta) toggles highlighting on and off.
- Erase toggles Erase on and off.
- Drag Right after pressing a Highlight or Erase key, use this key to highlight (or erase the highlight on) words to the right of the cursor.
- Footnote opens a text box on the bottom of the screen and creates a Footnote anchor at the cursor location. Press Close Dialog Box when you are finished typing the footnote.
- Magnify magnifies the spoken word.
- Close Dialog Box closes the Bookmark, Footnote, Spell, and Spell Check dialog boxes.
- Close Document closes open documents. (The Definition and Synonym keys open new documents which can be closed with this key.)

Kurzweil 3000 (Reading) Overlay

The Kurzweil 3000 (Reading) overlay is designed to provide simplified reading and navigation access to the Kurzweil 3000 word processing program. This overlay was designed to work with Kurzweil version 9 for Windows and Macintosh.



Kurzweil 3000 (Reading) Overlay

How to Use

Launch Kurzweil and insert the Kurzweil 3000 (Reading) overlay on your IntelliKeys USB. On Windows computers, the Kurzweil 3000 (Reading) overlay is attached to the Kurzweil program but it is not the default overlay that sends to IntelliKeys USB. To send the Kurzweil 3000 (Reading) overlay, open the IntelliKeys USB control panel and select the Applications tab. On the left side, select Kurzweil 3000. On the right side select the Kurzweil Reading overlay. Click Done to close the IntelliKeys USB control panel. This overlay was designed to fit the 3 hole custom keyguard.

- Read/Pause reads the text or pauses the reading.
- Previous Page goes back one page.
- Next Page advances one page.

Microsoft Word Overlay

The Microsoft Word overlay is designed to provide access to many of the common features in Microsoft Word. This overlay was designed to work with Microsoft Word 2002 (version 10) and 2003 (version 11) for Windows and Microsoft Word version X and 2004 for Macintosh.



Microsoft Word Overlay


How to Use

Launch Microsoft Word and insert the Microsoft Word overlay on your IntelliKeys USB. Press New to open a new blank document. Type a sentence. Press Center to center the text. Press Select All to select the text. Press Bold to change the text style to bold. Press the Spelling key to check the spelling and grammar in the document. Use the Tab and Arrow keys to navigate the Spelling and Grammar window, and use the Enter key to make your selection. Press the Close Dialog Boxes key to close the spelling Window.

- Header/Footer places the cursor in the document's header. Use the Down Arrow to go to the Footer. Press the Header/Footer key again to return to the document.
- AutoText shows a list of AutoText entries including common salutations and closings. Use the
 Up and Down arrows to navigate the list and the Enter key to add the selection to your document.
- Font opens the font dialog box. Press tab to go from Font to Font Style, Size, Color, etc. Use the Up and Down arrows to scroll through the selections. Use Enter to accept your selections and close the Font dialog box.
- Bullets/Numbers opens the Bullets and Numbering window. Use your Arrow keys to choose a bullet style, and then press the Enter key to add the bullets to your document.
- Close Dialog Boxes closes most dialog boxes including Print, Find, and Spelling.

Microsoft PowerPoint Overlay

The Microsoft PowerPoint overlay provides navigation access to PowerPoint slideshows. This overlay was designed to work with Microsoft PowerPoint 2002 (version 10) and 2003 (version 11) for Windows and Microsoft PowerPoint X and 2004 for Macintosh.




Microsoft PowerPoint Overlay

How to Use

Launch Microsoft PowerPoint, open a slideshow and insert the Microsoft PowerPoint overlay on your IntelliKeys. Press the Next Slide key to advance to the next slide. Press the Previous Slide key to go back to the previous slide. This overlay was designed to fit the 2 hole custom keyguard.

TestTalker Overlay

The TestTalker overlay provides access to Multiple Choice and True/False tests created in Freedom Scientific's TestTalker. This overlay is for use on Windows computers only and was designed to work with TestTalker version 1.1.



TestTalker Overlay

How to Use

Launch TestTalker student edition, open a Multiple Choice or True/False test, and insert the TestTalker overlay on your IntelliKeys. Use the Read key to read the first question. Press the Read key again to pause. Press the Next Answer key to navigate to the answer you wish to choose. Press the Select key to mark your answer.


Note: For Fill-in-the-Blank tests that require keyboard input, you can use the WYNN overlay which is already attached to the TestTalker application. On the Applications tab in the IntelliKeys USB control panel, select TestTalker from the list of applications. From the list of overlays on the right side, select the WYNN overlay and click done. All of the keys on the TestTalker overlay are also available on the WYNN overlay. Use Tab to navigate to the next answer and Shift+Tab to navigate to the previous answer. Use Space to select an answer.

This overlay was designed to fit the 9 hole custom keyguard.

- Save saves the document.
- Print prints the document.
- Previous Page goes back one page.
- Next page goes forward one page.
- Read Toggles Reading on and off.
- Last Answer highlights the previous answer.
- Next Answer highlights the next answer.
- Select selects the highlighted answer.

WYNN Overlay

The WYNN overlay is designed to provide access to all of the toolbar items in Freedom Scientific's WYNN literacy software. This overlay is for use on Windows computers only. This overlay was designed to work with WYNN 3.51 and WYNN 4.



WYNN Overlay


How to Use

Launch WYNN and insert the WYNN overlay on your IntelliKeys USB. Press the Next key to bring the focus to the Next button in WYNN. Press the Switch Toolbar key to change to the next colorcoded toolbar. Use the Arrow keys to move to the button you want. Press the Select key to activate the button. Use the Tab key to navigate the buttons in open tools and the Space key to activate the buttons.

- Read/Pause toggles reading on and off.
- Write toggles between Edit Mode and Read-Only Mode.
- Exact View toggles between Exact View and Text View.
- Scan begins scanning a page placed on your scanner.
- Go To Web opens WYNN's Web browser.
- Close Web closes WYNN's Web browser.
- Next highlights the Next Button.
- Switch Toolbar cycles through the toolbars when the Next button is active.
- Arrow Keys navigate to the various toolbar buttons.
- Select activates the selected toolbar button.
- Previous Page goes back one page.
- Next Page goes forward one page.
- Word Prediction toggles Word Prediction on and off.
- Function keys (F1-F6) use in conjunction with Word Prediction to select words.

AOL Instant Messenger (AIM) Overlay

The AOL Instant Messenger overlay is designed to provide access to common features of this popular messaging program. Large keys are included for creating and sending instant messages. This overlay was designed to work with AOL Instant Messenger version 5.9 for Windows and version 4.7 for Macintosh.



AOL Instant Messenger (AIM) Overlay

How to Use

Launch AOL Instant Messenger and insert the AOL Instant Messenger overlay on your IntelliKeys USB. Press the IM key to open the Instant Message window. Type the name of the user you wish to send a message to. Press the Tab key to move to the body of the message. Type the body of the message and press Send.

- Add Buddy opens the Setup Buddy List window and creates a new Buddy.
- Chat opens a new Chat window.
- Close Window closes the active window. Use to close the IM, Chat, or Setup Buddy List window.
- Tab navigates to items in open windows.
- Space or Enter activates selected items in open windows.

AOL Explorer Overlay

The AOL Explorer overlay is designed to provide access to common features found in AOL's Web browser. It includes Back, Forward, Stop, Refresh, Favorites and Add to Favorites. It also includes common parts of Internet Web addresses to save keystrokes when browsing. This overlay was designed to work with AOL Explorer version 1.1 for Windows only.



AOL Explorer Overlay

How to Use

Launch AOL Explorer and insert the AOL Explorer overlay on your IntelliKeys USB. Because AOL Explorer is installed to a unique location on every computer, you will need to find the AOL Explorer application. Open the IntelliKeys USB and IntelliSwitch Control Panel and click the Applications tab. In the list of applications, click AOL Explorer (not found), and then click Find. Browse to AOLServiceHost.exe and click Open. The path to the application will be similar to: c:\Program Files\Common files\AOL\1127266671\ AOLServiceHost.exe The numbered folder in this path will be unique on each computer.

- Open Location places your cursor at the address bar (the text box where you enter a World Wide Web address). Type in the address and press Enter.
- AOL.com connects to the AOL Web site.
- Print, Copy, and Paste make it easy to access these common commands.
- Scroll Up, Scroll Down moves through a page one screen at a time.
- Tab navigates the Address Bar and links on the web page.
- Up and Down arrows scroll a page continuously.
- www., .com, .edu, .gov, .net, .org inserts these common parts of an Internet Web address in the address bar.
- Favorites shows a list of all favorites. Use the arrow keys to select a favorite and press the Enter key to go to the Web page represented by the selected favorite.
- Add to Favorites adds the current Web page to your Favorites.

Co:Writer Overlay

The Co:Writer overlay is designed to provide access to Don Johnston's word prediction and vocabulary assistant program. This overlay was designed to work with Co:Writer Solo Edition, version 5.0 for Windows and Macintosh.



Co:Writer Overlay

How to Use

Launch Co: Writer and connect it to your Word processing program. Insert the Co: Writer overlay on your IntelliKeys USB. Begin typing and use the number keys to choose a word listed. Now press the Send key. The word will be typed in your word processor.

Note for Windows users: If you connect to Write:OutLoud, which already has an overlay attached, you may want to set the IntelliKeys USB control panel to send no overlay for Write:OutLoud. Open the IntelliKeys USB control panel. Click the Applications tab. Select Write:OutLoud in the application list, then click Send No Overlay. Click Done.

Note for Mac users: The Co:Writer overlay will not send automatically. You will need to attach the Co:Writer overlay to the word processor you use. See the section on Attaching Overlays to Applications. If you connect to Write:OutLoud, the Co:Writer overlay is already attached. All you need to do is to select the Co:Writer overlay as the overlay to send for Write:OutLoud on the Applications tab of the IntelliKeys USB control panel.

- Show and Hide shows or hides the Co:Writer window.
- True lets you type numbers instead of choosing a word in the prediction list.
- More shows more word choices in the word prediction list.
- Prefix and Suffix shows more word choices with prefixes or suffixes added.
- Speak Sentence speaks the current sentence.
- Send sends the text in the Co:Writer window to your word processor.
- Undo cancels the last change you made.
- Erase erases the previous word.
- 14 Popular Software Overlays for IntelliKeys User's Guide

Write:OutLoud Overlay

The Write:OutLoud overlay is designed to provide access to commonly used features of Don Johnston's talking word processor. The overlay includes keys for navigation, speech, spell check, and dictionary. This overlay was designed to work with Write:OutLoud Solo Edition version 4.0 for Windows and Macintosh.



Write:OutLoud Overlay

How to Use


Launch Write:OutLoud, open a document, and insert the Write:OutLoud overlay on your IntelliKeys USB. Press Select Sentence to select the sentence to the right of the cursor. Press Speak to have the selected sentence read.

Note: If you use Co:Writer with Write:Outloud, see the overlay description for Co:Writer.

- Save and Print make it easy to access these common commands.
- Beginning moves the cursor to the beginning of the document.
- Next Sentence moves the cursor to the beginning of the next sentence.
- Select Sentence Selects the sentence to the right of the cursor.
- End moves the cursor to the end of the document.
- Speak Speaks the current sentence.
- Repeat repeats the last sentence spoken.
- Spell Check, Dictionary, Homonym, Add Picture, and Bibliographer keys all open new windows. Use the Tab and arrow keys to navigate, and the Space key to select in these windows.
- Write More adds two blank lines after the cursor to give you room to write more.
- Add Picture opens the Picture Library window.

Inspiration Overlay

The Inspiration overlay is designed to provide access to most features of Inspiration, the premier tool to develop ideas and organize thinking. This overlay was designed to work with Inspiration version 7.6 for Windows and Macintosh.



Inspiration Overlay

How to Use

Launch Inspiration and insert the Inspiration overlay on your IntelliKeys USB. Press the Diagram/Outline key to toggle between Diagram View and Outline View. In Diagram View you can use any of the keys in the green area to create and arrange symbols. In Outline View you can use any of the keys in the yellow area to create and arrange topics. The keys in the orange area will work in both views.

Special Features/Additional Keys

Diagram View Keys

- RapidFire turns on RapidFire mode to quickly create new symbols.
- Arrange opens the Arrange diagram window. Use tab and arrow keys to navigate.
- Fit to Window sizes the diagram so it will fit on the screen.
- Show/Hide Subtopic shows or hides the selected subtopic.
- Scroll to Selection centers the selected symbol.
- 5 shape keys change the shape of the selected symbol.
- Create Left, Right, Up, Down creates a new symbol in the direction shown. You can begin typing in the symbol as soon as it is created. Press Cancel/Exit Text Editing when you are done typing.

Outline View Keys

- Topic adds a new topic.
- SubTopic adds a new subtopic to the selected topic.
- Move Left moves the selected topic left.
- Move Right moves the selected topic right.
- 16 Popular Software Overlays for IntelliKeys User's Guide

Inspiration Overlay Continued


- Flip Up moves the selected topic up in the outline order.
- Flip Down moves the selected topic down in the outline order.
- Promote moves all subtopics to the level of the selected topic.
- Demote makes all topics below the selected topic into subtopics.
- Show/Hide Subtopic shows or hides the selected subtopic.

Other Keys

- Diagram/Outline toggles between Diagram View and Outline View.
- Cancel/Exit Text Editing exits text editing and RapidFire modes.
- Note toggles note on and off.
- Spell checks the spelling in your document.
- Zoom Out, Zoom In makes the diagram or outline larger or smaller.
- Save saves the current document.

Kidspiration Overlay

The Kidspiration overlay is designed to provide access to the most common features of Kidspiration, the visual learning tool for K–5 learners. This overlay was designed to work with Kidspiration version 2 for Windows and Macintosh.



Kidspiration Overlay

How to Use

Launch Kidspiration and insert the Kidspiration overlay on your IntelliKeys USB. Press the Pictures/Writing key to toggle between Picture View and Writing View. In Picture View you can use any of the keys in the green area to create and arrange your picture. In Writing View you can use any of the keys in the yellow area to create and arrange your ideas. The keys in the orange area will work in both Views.

Special Features/Additional Keys

Picture View Keys

- Starter exits current document and returns to Starter menu. Use Tab to navigate the Starter menu and Enter to select.
- Link Symbols creates a new link. Use the arrow keys to move the link to a symbol and then press Enter.
- SuperGrouper adds a SuperGrouper shape to the diagram. Press the SuperGrouper key again to toggle through the default shapes.
- Shape keys change the shape of the selected symbol.
- Create Left, Right, Up, Down creates a new symbol in the direction shown.

Writing View Keys

- Add idea adds an idea in Writing View.
- Move Left moves the selected idea left.
- Move Right moves the selected idea right.

Kidspiration Overlay Continued

Other Keys

- Pictures/Writing toggles between Picture View and Writing View.
- Cancel/Exit Text Editing Use this key to exit text editing mode.
- Spell Check checks the spelling in your document.
- Clear removes the selected symbol or idea.
- Undo cancels the last change you made.
- Student Name opens the Student Name dialog box.
- Save saves the current document.

Modifying Overlays

The Popular Software Overlays are designed to provide access to most of the commonly used features in the software programs. In some instances it may be useful to edit an overlay to meet the needs of a particular student. For example, you might want to delete some keys that a student could find distracting, reposition some keys to make them easier to press, or change the color of a key to make it easier to see. Overlay Maker 3 allows you to easily edit any of the Popular Software Overlays right from the IntelliKeys USB and IntelliSwitch control panel. A trial version CD of Overlay Maker *3* is included with the *Popular Software Overlays*.

Editing Overlays

The Applications tab on the IntelliKeys USB and IntelliSwitch Control Panel lists all of the Popular Software applications for which overlays are installed. Click to select the application that has the overlay you wish to edit. The attached overlay(s) will be listed on the right. Click to select the overlay you wish to edit and then click the Edit button. If Overlay Maker 3 is not installed on your computer, the Edit button is grayed out and cannot be used. A free 45-day trial version of Overlay Maker 3 is included with every new IntelliKeys USB, allowing you to get a feel for the power and flexibility provided by overlay editing capability. Overlay Maker 3 Trial can also be downloaded for free online from the IntelliTools Web site. If you have Overlay Maker 3 installed on your computer, click the Edit button to open the selected overlay in Overlay Maker 3, allowing you to quickly edit, print, and save your changes. See the Overlay Maker 3 User's Guide included in PDF format on the Trial CD for more on how to customize overlays.

Saving Overlays

The Popular Software Overlays are template overlays. When you open an overlay to edit you will actually be editing a copy of the overlay. When you are done editing the overlay, go to the File menu and select Save. The default location to save is the overlays folder in *Overlay Maker 3*. You can save to the default or any other location; however you must note where you saved the overlay, so it can be attached to the application.

Printing Overlays

Once you have saved the new overlay you will want to print it and place it on the IntelliKeys USB. In Overlay Maker 3, click the File menu and select Print. Be sure your printer is set to legal size paper and Landscape mode.

Attaching Overlays

Now that the overlay is saved and printed, you will need to attach the overlay to the application. On the Applications tab in the IntelliKeys USB and IntelliSwitch control panel, select the application from the list of applications. On the right side of the Applications tab click Attach. Browse to the overlay you saved and click open. The default location for saved overlays is: Windows computers: C:\Program Files\IntelliTools\Overlay Maker 3\Overlays.

Macintosh computers: Hard Drive: Applications: IntelliTools: Overlay Maker 3: Overlays.


Using Overlays with Mayer-Johnson Products

If you wish to make and attach direct-select overlays to Boardmaker or Speaking Dynamically Pro, you can use a feature called Button Keys. With Button Keys, buttons on your boards can be selected by pressing specific keys on the keyboard. These keys can then be added to the key content on an overlay. See your Mayer-Johnson product manual for instructions on Button Keys. See your Overlay Maker 3 manual for instructions on creating overlays and adding key content.

Adding Keyboard Shortcuts to Macintosh OS X


Most Macintosh programs do not include keyboard shortcuts for all menu items. Macintosh OS 10.3 and 10.4 include the ability to add keyboard shortcuts to any menu item in any program installed on your computer. Once these shortcuts are made, they can be added to overlay keys using Overlay Maker 3.

From the Apple menu, select System Preferences. Click Keyboard & Mouse. On the Keyboard & Mouse System Preference, Click Keyboard Shortcuts.



Keyboard & Mouse System Preference

Click the Plus sign.




Define shortcuts within Applications

Click the All Applications pull-down and scroll down until you find your application.



Adding Menu Titles and Keyboard Shortcuts

Click in the Menu Title box and type the menu command from the program you want to create a keyboard shortcut for. Click in the Keyboard Shortcut box and press the keyboard keys that will make the keyboard shortcut. The shortcut above is Command+Control+1.



List of Shortcuts for Kurzweil 3000

Above is an example of Menu Items and their corresponding keyboard shortcuts created for Kurzweil 3000.

Troubleshooting

The application shows (not found) in the Applications window.

Probable cause 1: The software application is not installed on your computer.

Solution: Install the application to its default location on your computer.

Probable cause 2: The application is not installed to the default location on your computer.

Solution: Open the IntelliKeys USB and IntelliSwitch Control Panel and click the Applications tab. Click the application to highlight it, and then click Find. Browse to the application and click Open.

Probable cause 3: The version of your application does not match the version used to design the Popular Software Overlays.

Solution: Open the IntelliKeys USB and IntelliSwitch Control Panel and click the Applications tab. Click the application to highlight it, and then click Find. Browse to the application and click Open. Note: Because the overlays were designed for particular versions of the software, some keys may not work if you are using a different version. See the overlay description pages to see the version numbers of the popular software titles used to create the overlays.

The application shows in the Applications window but the overlay does not send.

Probable cause 1: The IntelliKeys USB and IntelliSwitch Control Panel, Advanced tab is set to be used "With only one overlay for all applications" or it is set to be used "As a switch with the following settings".

Solution: Change the setting on the Advanced tab to "With overlays attached to applications".

Probable cause 2: The IntelliKeys USB and IntelliSwitch Control Panel, Applications tab is set to send no overlay with your application.

Solution: On the Applications tab, highlight your application and choose "Send the selected overlay".

The overlay sends but some of the keys on the overlay do not work.

Probable cause 1: Keyboard shortcuts may change as software versions change. The version of your application does not match the version used to design the *Popular Software Overlays*. See the overlay description pages to see the version numbers of the Popular software titles used to create the overlays. Solution: See the Product's User Guide for a list of keyboard shortcuts. Edit the overlay keys to match the keyboard shortcut. See the Overlay Maker 3 User's Guide for instructions on editing overlays.

Probable cause 2: Some program functions only work when in a particular mode. Overlay keys designed for a particular mode may not work unless the program is in the correct mode.

Solution: See the Product's User Guide to learn what functions are tied to specific modes.

For additional troubleshooting solutions, see the IntelliKeys USB User's Guide.

IntelliTools, Inc. Software License Agreement

IMPORTANT: THIS SOFTWARE END USER LICENSE AGREEMENT ("EULA") IS A LEGAL AGREEMENT BETWEEN YOU (EITHER AN INDIVIDUAL OR, IF PURCHASED OR OTHERWISE ACQUIRED BY OR FOR AN ENTITY, AN ENTITY) AND INTELLITOOLS, INC. READ IT CAREFULLY BEFORE COMPLETING THE INSTALLATION PROCESS AND USING THE SOFTWARE. IT PROVIDES A LICENSE TO USE THE SOFTWARE AND CONTAINS WARRANTY INFORMATION AND LIABILITY DISCLAIMERS. BY SELECTING THE DOWNLOAD OR INSTALL NOW BUTTON AND USING THE SOFTWARE, YOU ARE CONFIRMING YOUR ACCEPTANCE OF THE SOFTWARE AND AGREEING TO BECOME BOUND BY THE TERMS OF THIS AGREEMENT. IF YOU DO NOT AGREE TO BE BOUND BY THESE TERMS, THEN DO NOT INSTALL THE SOFTWARE.

Ownership and License: IntelliTools, Inc. (IntelliTools), as licensor, is the sole owner of the computer code, documentation, and any other content on the enclosed diskette(s) or CD-ROM(s) or software download referred to as "the software". As licensee, you are granted the right to use the software as specified in this agreement. IntelliTools retains all rights not expressly granted to you in the agreement. This agreement does not constitute a waiver of IntelliTools' rights under U.S., international copyright, or other federal or state law.

Definitions:

Network License Key. A series of alphanumeric characters provided to a Network Purchaser that activates the licensed software product and the associated number of client workstations.

Network Purchaser. The person or institution that has legally purchased a license for a unit of Networked Software.

Networked Software. The software designed to run on a server computer and the client computers connected to the server over a local area network.

Single Purchaser. The person or institution that has legally purchased a license for a unit of Standalone Software.

IK USB Purchaser: The person or institution that has legally purchased IntelliKeys USB Keyboard and a license for IntelliKeys USB software.

All Purchasers: IK USB Purchasers and Single Purchasers and Network Purchasers.

Site License Agreement. The authorized IntelliTools Site License Program Agreement document and the associated Site License number provided by IntelliTools to the licensee.

Site License Purchaser. The person or institution that has legally purchased a license for one or more units of the software through a Site License Agreement.

Standalone Software. The software designed to run on a single computer.

Usage: (a) Right to Install and Use – IK USB Purchaser: You may install and use the IKUSB software on any number of computers. Single Purchaser: You may install and use one copy of the software on one computer. If you are part of an educational institution, the single-user/one computer use (above) is extended to use on one computer, at any one time, within the institutional site. Teachers affiliated with the institution are also granted the right to use this software on another computer, at home or school, for the purpose of creating activities for their students. The software may not be installed on a network server or made accessible via public network. Site License Purchaser: A Site License gives the licensee the right to install copies of the software on the number of machines specified in the Site License agreement, which is incorporated by reference in its entirety herein. The terms stated above apply to individual users under the Site License. Network Purchaser: A Network License gives the licensee the right to install a single copy of the software on a single Local Area Network server and the right to install to the number of workstations specified in the licensee's sales agreement.. (b) Right to Copy – All Purchasers: You may make one copy of the software for back-up and archival purposes provided the original(s) is kept in your possession and that installation and use does not exceed the limits set above. (c) Right to Modify - All Purchasers: Software may not in any manner be disassembled, de-compiled, unlocked, or reverse translated. (d) Right to Transfer – IK USB Purchaser and Single Purchaser: You may not sublicense, rent, lend, or lease the software beyond the terms of any agreement signed with the company. You may transfer your rights to another party along with this Software License Agreement, the software (including the most recent updates and all prior versions) and all accompanying written materials. The new owner assumes the rights and obligations outlined in this Agreement. As part of the transfer, you must destroy all copies of the software other than the original. Site License Purchaser, Network Purchaser; You may not sublicense, rent, lend, or lease the software beyond the terms of any agreement signed with the company. You may not transfer your rights to another party.

Limited Warranty: (a) Limited Warranty – IntelliTools stands behind the quality of its software and warrants that the product you ordered will perform substantially in accordance with the user documentation and that there are no defects in the media itself. Please examine this software carefully. (b) Exclusive Remedies – IK USB Purchaser and Single Purchaser: If you return the media within 30 days along with your receipt of purchase and all accompanying materials, IntelliTools will either fully refund the price of your purchase or replace the software or media. If replaced, the software will have the same 30-day warranty as the original. This limited warranty is void if failure of the software is caused by accident, abuse, or violation of this license agreement. Site License Purchaser: Initial Site License Purchases follow the same policy as under Single Purchaser above. Software purchased as part of a Site License after the initial purchase is not refundable. IntelliTools will replace defective media returned within 30 days of receipt as described above. Network Purchaser: Initial Network Purchases follow the same policy as under Single Purchaser above. Software purchased as part of a Network License after the initial purchase is not refundable. IntelliTools will replace defective media returned within 30 days of receipt as described above.

(c) Warranty Disclaimer and Limitation of Liability – INTELLITOOLS DOES NOT WARRANTY THAT THIS SOFTWARE WILL MEET YOUR COMPUTING REQUIREMENTS OR THAT IT WILL OPERATE ERROR-FREE. TO THE EXTENT ALLOWED BY LAW, WE EXPRESSLY DISCLAIM ALL WARRANTIES NOT STATED HERE AND ALL IMPLIED WARRANTIES INCLUDING MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. SOME STATES DO NOT ALLOW LIMITATION ON HOW LONG AN IMPLIED WARRANTY LASTS SO THE ABOVE LIMITATION MAY NOT APPLY TO YOU. THIS LIMITED WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, WHICH VARY FROM STATE TO STATE. INTELLITOOLS' LIABILITY TO YOU FOR ANY LOSSES SHALL BE LIMITED TO DIRECT DAMAGES AND SHALL NOT EXCEED THE AMOUNT ORIGINALLY PAID FOR THE SOFTWARE. IN NO EVENT WILL INTELLITOOLS BE LIABLE TO YOU FOR ANY INCIDENTAL, INDIRECT, SPECIAL OR CONSEQUENTIAL DAMAGES INCLUDING LOSS OF PROFITS OR ANY DATA OR INFORMATION THAT MAY BE LOST OR RENDERED INACCURATE EVEN IF WE HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES SO THE ABOVE LIMITATION OR EXCLUSION MAY NOT APPLY TO YOU.

Export Controls: This software is subject to the export control laws and regulations of the United States and any amendments thereof. On the basis of this agreement, you will not directly or indirectly transfer the software except in compliance with all applicable U.S. export laws and regulations.

Audit Provision: You agree that IntelliTools may audit your use of the Software for compliance with this EULA at any time, upon reasonable notice. In the event that such audit reveals any use of the Software by you other than in full compliance with the terms of this EULA, you shall reimburse IntelliTools for all reasonable expenses related to such audit in addition to any other liabilities you may incur as a result of such non-compliance.

Termination: This agreement is effective until terminated. This agreement may be terminated at any time by destroying all copies of the software in your possession or by returning all such copies to IntelliTools. This agreement and your right to use this software will automatically terminate if you fail to comply with any material provisions of the agreement. Upon termination you must stop all use of the software and destroy all copies in your possession. Your rights to use the software will also end upon expiration of the copyright to the software. IK USB Purchaser and Single Purchaser: Your license to use this software terminates if you assign the agreement to someone else.

Miscellaneous Provision: This agreement will be governed by the internal laws of the state of California, without giving effect to principles of conflict of laws. You hereby consent to the exclusive jurisdiction and venue of the state courts sitting in Sonoma County, CA or the federal courts in the Northern District of CA to resolve any disputes arising under this EULA. In each case this EULA shall be construed and enforced without regard to the United Nations Convention on the International Sale of Goods. This document represents the entire agreement between us as it relates to the software under discussion and supercedes any prior purchase order, communication, advertising or representations concerning the software. No change or modification of this agreement will be valid unless it is in writing and signed by an officer of IntelliTools. If any provision of this EULA shall be held by a court of competent jurisdiction to be contrary to law, that provision will be enforced to the maximum extent permissible and the remaining provisions of this EULA will remain in full force and effect. All questions concerning this EULA shall be directed to IntelliTools at the address below.

> IntelliTools, Inc. 1720 Corporate Circle, Petaluma, CA 94954 Phone: 707-773-2000 Fax: 707-773-2001 Email: info@intellitools.com