

Bridge Parts List

- Name: Thickness $\times$ Number of Pieces = Total Pieces
- Incline: $8 \times 4 = 32$ pieces
- Diagonal: $4 \times 4 = 16$ pieces
- Top Chord: $8 \times 2 = 16$ pieces
- Bottom Chord: $5 \times 2 = 10$ pieces
- Mid Vert: $8 \times 2 = 16$ pieces
- Side Vert: $3 \times 4 = 12$ pieces
- T-lats: $3 \times 3 = 9$ pieces
- T-mid/s: OMITTED = 0 pieces
- B-lats: $3 \times 5 = 15$ pieces
- B-mid/s: $3 \times 2 = 6$ pieces
- B-out/s: $3 \times 2 = 6$ pieces

Total: 135 pieces

Assembly Instructions

To assemble, use epoxy at all joints. Make sure to clamp well and allow to cure at more than room temperature for at least 24 hours. **DO NOT LEAVE IN THE COLD GARAGE OVERNIGHT.** Refer to the technical drawing for more information, or even better, to the SolidWorks model.