

 Home

</> Coding Ground

Jobs

□ Whiteboard

X Tools

In the field of Microwave engineering, there occurs many applications, as already stated in first chapter. Hence, while using different applications, we often come across the need of measuring different values such as Power, Attenuation, Phase shift, VSWR, Impedance, etc. for the effective usage.

In this chapter, let us take a look at the different measurement techniques.

Measurement of Power

The Microwave Power measured is the average power at any position in waveguide. Power measurement can be of three types.

Measurement of Low power 0.01 mWto10 mW

Example – Bolometric technique

Measurement of Medium power 10mWto1W

Example - Calorimeter technique

Measurement of High power > 10W

Example - Calorimeter Watt meter

Let us go through them in detail.

Measurement of Low Power


The measurement of Microwave power around 0.01mW to 10mW, can be understood as the measurement of low power.



- or example, a partacer has a positive compensatore occinicate misses resistance

increases with the increase in temperature. Thermistor has negative temperature coefficient whose resistance decreases with the increase in temperature.

Any of them can be used in the bolometer, but the change in resistance is proportional to Microwave power applied for measurement. This bolometer is used in a bridge of the arms as one so that any imbalance caused, affects the output. A typical example of a bridge circuit using a bolometer is as shown in the following figure.



The milliammeter here, gives the value of the current flowing. The battery is variable, which is varied to obtain balance, when an imbalance is caused by the behavior of the bolometer. This adjustment which is made in DC battery voltage is proportional to the Microwave power. The power handling capacity of this circuit is limited.

Measurement of Medium Power

The measurement of Microwave power around 10mW to 1W, can be understood as the measurement of medium power.

A special load is employed, which usually maintains a certain value of specific heat. The power to be measured, is applied at its input which proportionally changes the output temperature of the load that it already maintains. The difference in temperature rise, specifies the input Microwave power to the load.

The bridge balance technique is used here to get the output. The heat transfer method is used for the measurement of power, which is a Calorimetric technique.



the measurement of high power.

The High Microwave power is normally measured by Calorimetric watt meters, which can be of dry and flow type. The dry type is named so as it uses a coaxial cable which is filled with di-electric of high hysteresis loss, whereas the flow type is named so as it uses water or oil or some liquid which is a good absorber of microwaves.

The change in temperature of the liquid before and after entering the load, is taken for the calibration of values. The limitations in this method are like flow determination, calibration and thermal inertia, etc.

Measurement of Attenuation

In practice, Microwave components and devices often provide some attenuation. The amount of attenuation offered can be measured in two ways. They are — Power ratio method and RF substitution method.

Attenuation is the ratio of input power to the output power and is normally expressed in decibels.

$$Attenuation \ in \ dBs = 10 \ log rac{P_{in}}{P_{out}}$$

Where P_{in} = Input power and P_{out} = Output power

Power Ratio Method

In this method, the measurement of attenuation takes place in two steps.


Step 1 – The input and output power of the whole Microwave bench is done without the device whose attenuation has to be calculated.


Step 2 – The input and output power of the whole Microwave bench is done with the device whose attenuation has to be calculated.

The ratio of these powers when compared, gives the value of attenuation.

The following figures are the two setups which explain this.







Drawback – The power and the attenuation measurements may not be accurate, when the input power is low and attenuation of the network is large.


RF Substitution Method

In this method, the measurement of attenuation takes place in three steps.

- **Step 1** The output power of the whole Microwave bench is measured with the network whose attenuation has to be calculated.
- **Step 2** The output power of the whole Microwave bench is measured by replacing the network with a precision calibrated attenuator.
- **Step 3** Now, this attenuator is adjusted to obtain the same power as measured with the network.

The following figures are the two setups which explain this.






The adjusted value on the attenuator gives the attenuation of the network directly. The drawback in the above method is avoided here and hence this is a better procedure to measure the attenuation.

Measurement of Phase Shift

In practical working conditions, there might occur a phase change in the signal from the actual signal. To measure such phase shift, we use a comparison technique, by which we can calibrate the phase shift.


The setup to calculate the phase shift is shown in the following figure.



where abiffing

phase shifter.

The demodulated output is a 1 KHz sine wave, which is observed in the CRO connected. This phase shifter is adjusted such that its output of 1 KHz sine wave also matches the above. After the matching is done by observing in the dual mode CRO, this precision phase shifter gives us the reading of phase shift. This is clearly understood by the following figure.



This procedure is the mostly used one in the measurement of phase shift. Now, let us see how to calculate the VSWR.

Measurement of VSWR

In any Microwave practical applications, any kind of impedance mismatches lead to the formation of standing waves. The strength of these standing waves is measured by Voltage Standing Wave Ratio VSWR. The ratio of maximum to minimum voltage gives the VSWR, which is denoted by S.

$$S = rac{V_{max}}{V_{min}} = rac{1 +
ho}{1 -
ho}$$

Where,
$$ho = reflection\, co - efficient = rac{P_{reflected}}{P_{incident}}$$

The measurement of VSWR can be done in two ways, Low VSWR and High VSWR measurements.

Measurement of Low VSWR S < 10




adjacting the diction into and the attenuator in each a may that the DC

millivoltmeter shows a full scale reading as well as a minimum reading.

Now these two readings are calculated to find out the VSWR of the network.

Measurement of High VSWR S>10

The measurement of high VSWR whose value is greater than 10 can be measured by a method called the **double minimum method**. In this method, the reading at the minimum value is taken, and the readings at the half point of minimum value in the crest before and the crest after are also taken. This can be understood by the following figure.



Now, the VSWR can be calculated by a relation, given as -

$$VSWR = rac{\lambda_g}{\pi(d_2-d_1)}$$

Where, λ_g is the guided wavelength

$$\lambda_g = rac{\lambda_0}{\sqrt{1-(rac{\lambda_0}{\lambda_c})^2}} \quad where \, \lambda_0 \, = c/f$$

As the two minimum points are being considered here, this is called as double minimum method. Now, let us learn about the measurement of impedance.

Measurement of Impedance





Impedance Using the Slotted Line

In this method, impedance is measured using slotted line and load Z_L and by using this, V_{max} and V_{min} can be determined. In this method, the measurement of impedance takes place in two steps.

- **Step 1** Determining Vmin using load Z_L .
- **Step 2** Determining Vmin by short circuiting the load.


This is shown in the following figures.





When we try to obtain the values of V_{max} and V_{min} using a load, we get certain values. However, if the same is done by short circuiting the load, the minimum gets shifted, either to the right or to the left. If this shift is to the left, it means






By recording the data, an unknown impedance is calculated. The impedance and reflection coefficient ρ can be obtained in both magnitude and phase.

Impedance Using the Reflectometer

Unlike slotted line, the Reflectometer helps to find only the magnitude of impedance and not the phase angle. In this method, two directional couplers which are identical but differs in direction are taken.

These two couplers are used in sampling the incident power P_i and reflected power P_r from the load. The reflectometer is connected as shown in the following figure. It is used to obtain the magnitude of reflection coefficient ρ , from which the impedance can be obtained.





From the reflectometer reading, we have

$$ho = \sqrt{rac{P_r}{P_i}}$$

From the value of ρ , the VSWR, i.e. S and the impedance can be calculated by


$$S=rac{1+
ho}{1-
ho} \quad and \quad rac{z-z_g}{z+z_g}=
ho.$$


Where, z_g is known wave impedance and z is unknown impedance.

Though the forward and reverse wave parameters are observed here, there will be no interference due to the directional property of the couplers. The attenuator helps in maintaining low input power.

Measurement of Q of Cavity Resonator

Though there are three methods such as Transmission method, Impedance method, and Transient decay or Decrement method for measuring **Q** of a cavity resonator, the easiest and most followed method is the **Transmission Method**. Hence, let us take a look at its measurement setup.





From the setup above, the signal frequency of the microwave source is varied, keeping the signal level constant and then the output power is measured. The cavity resonator is tuned to this frequency, and the signal level and the output power is again noted down to notice the difference.

When the output is plotted, the resonance curve is obtained, from which we can notice the Half Power Bandwidth HPBW (2Δ) values.

$$2\Delta=\pmrac{1}{Q_L}$$

Where, Q_L is the loaded value

$$or \quad Q_L = \pm rac{1}{2\Delta} = \pm rac{w}{2(w-w_0)}$$

If the coupling between the microwave source and the cavity, as well the coupling between the detector and the cavity are neglected, then

$$Q_L = Q_0 \ (unloaded \ Q)$$

Drawback



We have covered many types of measurement techniques of different parameters. Now, let us try to solve a few example problems on these.

Kickstart Your Career

Get certified by completing the course

Get Started



Advertisements



Tutorials Point is a leading Ed Tech company striving to provide the best learning material on technical and nontechnical subjects.





About us

Terms of use

Terms

Free Library

Our Products

Our Team

Company

Privacy Policy

Articles

Careers

Refund Policy

Jobs

Coding Ground

Certifications

Cookies Policy

FAQ's

Courses

Affiliates

eBooks

Contact Us

Corporate Training

Free Web Graphics

Contact Us

Become a Teacher

Tutorials Point India Private Limited, Incor9 Building, Kavuri Hills, Madhapur, Hyderabad, Telangana - 500081, INDIA