
4 Block Diagrams

4.1 Design Pre-Compensators

Consider a feedback system in the below figure with $G(s) = \frac{2}{s+2}$ and $K(s) = \frac{3s+12.5}{s}$.



- (a) What is the transfer function T(s) from r to y?
- (b) Design a low pass F(s) to filter the reference command.

Solution:

- (a) $T(s) = \frac{G(s)K(s)}{1+G(s)K(s)} = \frac{6s+25}{s^2+8s+25}$.
- (b) Ensuring that F(0)=1, we set $F(s)=\frac{25}{6s+25}$. The resulting closed-loop from $r\to y$ is now $T(s)F(s)=\frac{25}{s^2+8s+25}$.

GPT Answer:

The transfer function T(s) from r to y in a feedback system is given by the formula:

$$T(s) = \frac{G(s)K(s)}{1 + G(s)K(s)}$$

Given $G(s) = \frac{2}{s+2}$ and $K(s) = \frac{3s+12.5}{s}$, we substitute these into the formula:

$$T(s) = \frac{\left(\frac{2}{s+2}\right)\left(\frac{3s+12.5}{s}\right)}{1 + \left(\frac{2}{s+2}\right)\left(\frac{3s+12.5}{s}\right)}$$

To design a low pass filter F(s) to filter the reference command, a common choice is:

$$F(s) = \frac{\omega_c}{s + \omega_c}$$

where ω_c is the desired cutoff frequency.

Confidence Level: 95%

Correct

Claude Answer:

he provided image shows a block diagram of a unity feedback control system with a controller K(s) and a plant G(s). The given transfer functions are:

$$G(s) = \frac{2}{s+2}$$

$$K(s) = \frac{3s+12.5}{s}$$

(a) To find the transfer function T(s) from r to y, we can use the following formula for a unity feedback system:

$$T(s) = \frac{K(s) \cdot G(s)}{1 + K(s) \cdot G(s)}$$

Substituting the given values:

$$T(s) = \frac{\left(\frac{3s+12.5}{s}\right) \cdot \left(\frac{2}{s+2}\right)}{1 + \left(\frac{3s+12.5}{s}\right) \cdot \left(\frac{2}{s+2}\right)}$$

Simplifying the numerator and denominator:

$$T(s) = \frac{6s + 25}{s(s+2) + (6s+25)}$$
$$T(s) = \frac{6s + 25}{s^2 + 8s + 25}$$

Therefore, the transfer function T(s) from r to y is:

$$T(s) = \frac{6s + 25}{s^2 + 8s + 25}$$

(b) To design a low-pass filter F(s) for the reference command, a common choice is a first-order filter with the following structure:

$$F(s) = \frac{\omega_c}{s + \omega_c}$$

where ω_c is the cutoff frequency. The cutoff frequency should be chosen based on the desired bandwidth of the system and the frequency content of the reference command. A lower cutoff frequency will result in more filtering of high-frequency components in the reference command.

The exact value of ω_c would depend on the specific requirements and constraints of the system, which are not provided in the question. The choice of ω_c is a design decision that should be made based on the desired system performance and the characteristics of the reference command.

Confidence Level: 95%

Correct