
임베디드 MCU 프로그래밍 실습 AURIX TC275 보드 프로젝트 생성

현대자동차 입문교육 박대진 교수






하드웨어-소프트웨어 통합된 임베디드 시스템








S/W H/W 구현 과정



임베디드 시스템 프로그래밍 → 0/1을 온칩에 임베딩


- Software is deeply injected into the hardware silicon
 - Your dirty software code ... is directly translated into the machine code.
 - So that performance degradation starts from inefficiency of my code.







임베디드 S/W가 칩 내부의 H/W를 구동함




System On Chip (Latest Processor Architecture)






Compilation

Tasks → **Executable Binary Code**



Installing Target-Specific Compiler



Cancel


AI-SOL Lad

HYUNDAI



3. click


Embedded System Programming 대상






: Template Generation

1. AURIX Development Studio를 실행하고 왼쪽 상단의 'File - New -New AURIX Project' 를 클릭한다.




: Project Name

2. 생성할 Project의 이름을 입력하고, 'Next'를 클릭한다.




: Target CPU, Target Board Selection

3. Device에서 'AURIX TC2xx - TC27XTP_D-Step - KIT_AURIX_TC275_ARD_SB' 를 선택하고, 다른 설정은 그대로 유지한 채 'Finish'를 클릭한다.



: Code Explorer


4. 왼쪽의 Project Explorer 창에서 프로젝트가 생성된 것을 확인한다.



Edit Project

: Source Code Editing

5. 왼쪽의 Project Explorer 창에서 **Project name**으로 생성된 파일인 **'CpuO_Main.c'** 파일을 더블 클릭하여 활성화한다.





Edit Project

: main function

6. 'Cpu0_Main.c' 파일은 **core0_main 함수를 포함**하고 있으며 이를 수정하여 보드의 동작을 설계한다.


AURIX - aaa/Cpu0 Main.c - AURIX Development Studio

```
File Edit Source Refactor Navigate Search Project Debug Window Help
                    2 * \file Cpu0 Main.c
    3 * \copyright Copyright (C) Infineon Technologies AG 2019
    5 * Use of this file is subject to the terms of use agreed between (i) you or the company in which ordinary course of
    6 | * business you are acting and (ii) Infineon Technologies AG or its licensees. If and as long as no such terms of use
       * are agreed, use of this file is subject to following:
   9 * Boost Software License - Version 1.0 - August 17th, 2003
   10 *
   11 * Permission is hereby granted, free of charge, to any person or organization obtaining a copy of the software and
   12 * accompanying documentation covered by this license (the "Software") to use, reproduce, display, distribute, execute,
   13 * and transmit the Software, and to prepare derivative works of the Software, and to permit third-parties to whom the
      * Software is furnished to do so, all subject to the following:
   15 *
   16 * The copyright notices in the Software and this entire statement, including the above license grant, this restriction
   17 * and the following disclaimer, must be included in all copies of the Software, in whole or in part, and all
   18 * derivative works of the Software, unless such copies or derivative works are solely in the form of
       * machine-executable object code generated by a source language processor.
   21 * THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE
   22 * WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, TITLE AND NON-INFRINGEMENT. IN NO EVENT SHALL THE
   * COPYRIGHT HOLDERS OR ANYONE DISTRIBUTING THE SOFTWARE BE LIABLE FOR ANY DAMAGES OR OTHER LIABILITY, WHETHER IN
   24 * CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS
   25 * IN THE SOFTWARE.
       *************
   27 #include "Ifx_Types.h"
   28 #include "IfxCpu.h'
   29 #include "IfxScuWdt.h"
   31 IfxCpu syncEvent g cpuSyncEvent = 0;
       int core0_main(void)
          IfxCpu enableInterrupts();
   36
          /* !!WATCHDOGØ AND SAFETY WATCHDOG ARE DISABLED HERE!!
   38
           * Enable the watchdogs and service them periodically if it is required
   39
           IfxScuWdt disableCpuWatchdog(IfxScuWdt getCpuWatchdogPassword());
          IfxScuWdt_disableSafetyWatchdog(IfxScuWdt_getSafetyWatchdogPassword());
   41
   42
   43
           /* Wait for CPU sync event */
   44
          IfxCpu_emitEvent(&g_cpuSyncEvent);
          IfxCpu waitEvent(&g cpuSyncEvent, 1);
   46
   47
           while(1)
   48
   49
           return (1);
```

Edit Project

: main functions for Tri Core

- AURIX TriCore TC275 MCU는 3개의 CPU를 갖고 있지만, 본 실습에서는 1개의 CPU만을 사용. (CPUO)
- Cpu1_Main.c 와 Cpu2_Main.c 파일들은 사용하지 않음.




AURIX TC27xT 32-bit TriCore Microcontrollers






Build


7. 상단의 메뉴에서 'Build' 버튼 또는 'Project – Build All'을 클릭하여 프로젝트를 Build한다.



8. (Build/Debug는 Active Project에 대해 수행 Build를 수행할 Project를 Active Project로 미리 설정해야 하다.

'Project Explorer' 에서 대상 프로젝트를 우클릭 한 뒤, 'Set Active Project'를 클릭하여 Active Project로 설정할 수 있다.)










: Configure Target Project for Debugging

- 9. 상단의 메뉴에서 'Debug' 버튼(벌레 모양)을 클릭하여 Debug를 실행한다.
 - 'Debug' 버튼을 처음으로 클릭하면 'Debug Configurations' 창이 활성화된다. 왼쪽 패널에서 'TASKING C/C++ Debugger – Project 이름' 을 확인하고 'Debug' 버튼을 클릭한다. (이후부터는 버튼 클릭 시 Debug가 바로 실행)




🔲 AI-SõC Lab 🕼 🏏 HYUNDAI

다시 'Debug Configurations' 창을 활성화하려면 'Debug' 버튼 오른쪽 화살표 클릭

→ 'Debug Configurations...' 버튼


- 10. 상단의 메뉴에서 'Debug' 버튼을 클릭하여 Debug를 실행한다.
 - 'Confirm Perspective Switch' 창이 뜨면 Switch를 눌러 디버그 창으로 전환.
 - ✓ (소스 코드 외에 편리한 디버깅을 위한 여러 가지 window 를 포함하는 layout 으로 전환 여부)





: Control Panel, Debugging Window Layout


11. 기본 Debug 화면 구성



HYUNDAI


: Start Debugging

- 12. Debug 결과 확인
 - ✓ 상단의 'Resume' 버튼을 클릭하여 디버깅을 위한 보드 동작 실행.
 - ✓ 현재 'Cpu0_Main.c' 파일에 코드를 작성하지 않았기 때문에 아무 출력이 없음.




HYUNDAI

- 13. Debug를 종료한다.
 - ✓ 상단의 'Terminate' 버튼을 클릭하여 Debug를 종료한다.
 (Debug 종료 시, 반드시 'Terminate' 버튼을 클릭하여 정상적으로 종료한다.)
 - ✓ Debug 종료 후, 소스코드 편집 layout으로 돌아가기 위해서는 우측 상단의 'C/C++' 클릭 (벌레모양 버튼 왼쪽)



Programmer(Downloader) vs Debug


Download Stage





Programmer(Downloader) vs Debug

Debugging Stage





감사합니다. 휴식~~

FAQ

- 처음 시작할때 Resume
- 디버깅 끝나고 다시 에디터로 돌아갈때 Terminate