


Hardware Architectures for Embedded and Edge Al

<u>Prof Manuel Roveri – manuel.roveri@polimi.it</u> <u>Massimo Pavan – massimo.pavan@polimi.it</u>

Exercise session 1 – Platform and firmware

Poll results and a disclaimer



Pre-requisites

- Intermediate/basic knowledge of python coding
- Basic knowledge of C coding

Nice to have, but will be revised togheter:

- Basic knowledge of Embedded systems
- Basic knowledge of Machine Learning or Deep Learning

Exercise sessions

- 1. Intro/review on Embedded Systems
- 2. Intro/review on Deep Learning with Tensorflow
- 3. TF lite optimizations: quantization and pruning
- 4. Training Keyword Spotting Microphone
- 5. Deploying Keyword Spotting Microphone
- 6. Training and Deploying Visual Wake Word Camera
- 7. Training and Deploying Anomaly detection Accelerometer
- 8. Data Collection and Engineering with Edge Impulse Camera
- 9. On-device learning of a Speaker Verification algorithm Microphone

Resources

- Books
- Online course
- For python and C coding: any online tutorial/crash course should do it, as long as you have taken at least one coding course

The Arduino IDE

https://www.arduino.cc/en/software

```
sketch_feb28a | Arduino IDE 2.0.5-nightly-20230228
                                                                                                                            File Edit Sketch Tools Help
                 Select Board
      sketch_feb28a.ino
              void setup() {
                // put your setup code here, to run once:
          4
              void loop() {
                // put your main code here, to run repeatedly:
          8
          9
         10
                                                                                                                               ■ 6
      Output
        Disinstallazione di arduino:bossac@1.9.1-arduino2, il tool non è più necessario.
        Disinstallazione di arduino:dfu-util@0.10.0-arduino1, il tool non è più necessario.
        Disinstallazione di arduino:rp2040tools@1.0.2, il tool non è più necessario.
        Il tool arduino:rp2040tools@1.0.2 è disinstallato
        Configurazione della piattaforma.
        La piattaforma arduino:mbed nano@3.5.4 è installata
                                                                                                     Ln 9, Col 2 × No board selected ♀ □
```

Embedded systems in a nutshell

An embedded system is a combination of hardware and software designed for a specific function.


The systems can be programmable or have fixed functionalities.

There are three distinct approaches to develop an Embedded system:

- ASIC (Application Specific Integrated Circuit)
- FPGA (Field-Programmable Gate Array)
- uC (Microcontroller)


ASIC – Application Specific Integrated Circuit

- designed for a particular application
- provide the best performance
- Extremely expensive to design and manufacture (this restrict them to very large volume applications)




FPGA – Field Programmable Gate Array

- A package integrated circuit with an array of gates and flip-flops,
- They can be connected by "programming" the device to produce the desired function
- This is specified using a hardware description language such as VHDL or Verilog



MCU - Microcontroller Units


- Have a fixed hardware built around a central processing unit (CPU)
- The CPU controls a range of peripherals, both digital and analog functions
- Small devices usually include both volatile and non-volatile memory on the chip
- Larger processors may need separate memory
- Usually programmed using a machine-language like Assembly or high-level language such as C




Microcontrollers are very interesting candidates for embedded systems, because their on-chip peripherals and memory enable the embedded system designers to save circuit space and overall dimensions, by not having to add these things on the board.

Microcontrollers vs Microprocessors

- A microcontroller contains:
 - A microprocessor (uP)
 - Program Memory
 - Data Memory
 - A number of internal peripherals devices (e.g., timers, serial ports, GPIO pins, ADC converters, etc. all inside a single silicon chip.
- A microprocessor (uP) is a silicon chip containing an advanced Central Processing Unit (CPU) that fetches program instructions from an external memory and executes them.





Memories

Volatile memories: loses their content when power is removed


- SRAM (Static Random Access Memory)
 - Fast but takes a lot of space (6 transistors)
- **DRAM** (Dynamic Random-Access Memory)
 - little space (1 transistor and 1 capacitor) but slow, requires periodic refresh

Non-volatile memories:

- Mask ROM (Read Only Memory)
 - contents are programmed during the IC manufacturing.
 - any change to the data requires a new mask to be produced at great expense.
- EPROM (Electrically Programmable ROM)
 - It can be programmed electrically, but cannot erase them. To clear the content, must be exposed to UV

Flash Memory

- Similar to the EPROM but flash can be electrically erased in blocks
- 2 types: NAND (smallest, sequential access) and NOR (larger, sequential or random access)
- Many microcontrollers use NOR flash, which is slower to write but permits random access







I/O Ports

- Input and Output ports are the simplest example of interface toward the outside the world.
- The single pin I/O can be an input(I) or an output (O) of the microcontroller depending on how the firmware sets the port.
- The single IO can be configured and used in different ways :
 - Digital Input: can be a normal CMOS input for example
 - Interrupt: Similar to the digital input, but it can also be enabled to generate an IRQ to the uC core
 - Analog Input: allow to acquire analog signals and send them to the on-chip Analog to Digital Converter (ADC) inside the uC
 - Digital Output: usually a CMOS levels, sometime open-drain

I/O ports on the Arduino nano BLE 33 sense



Serial Communication devices




UART (Universal Asynchronous Receiver/Transmitter)

UART is a hardware communication protocol that uses asynchronous serial communication with configurable speed.

Asynchronous means there is no clock signal to synchronize the output bits from the transmitting device going to the receiving end.

The UART use signals:

- TX Transmitter
- RX Receiver



UART: Data transmission

Start Bit Data Frame Parity Bit (1 bit) (5 to 8 Data bits) (0 to 1 bit) (1 to 2 bit)

• Start Bit

• To start the transfer of data, the transmitting UART pulls the transmission line from high to low for one (1) clock cycle. When the receiving UART detects the high to low voltage transition, it begins reading the bits in the data frame at the frequency of the **baud rate**

Data Frame

• The data frame contains the actual data being transferred. It can be five (5) bits up to eight (8) bits long if a parity bit is used, even 9 otherwise

Parity Bit


Parity describes the evenness or oddness of a number. The parity bit is a way for the receiving UART to tell
if any data has changed during transmission. Bits can be changed by electromagnetic radiation,
mismatched baud rates, or long- distance data transfers.


• Stop Bit

To signal the end of the data packet, the sending UART drives the data transmission line from a low voltage to a high voltage for one (1) to two (2) bit(s) duration.


RS-232 standard

 Map the digital value with two voltages level





Programming the board




Edit the C or C++ by using a text editor and save the file with ".c" or ".cpp" file extension


When using the C tools to create an executable file, there are actually two main steps involved: the first is called compiling and the second is called linking.

Most IDE take care of running the compiler and linker at the correct time, in just one step


Programming compiler and linker



The Arduino Nano 33 BLE sense




Sensors, Actuators, Microcontroller and communication scheme




Nordic nRF52840 block diagram

- CPU: ARM Cortex M4
- 64 MHz
- 1 MB flash
- 256 KB RAM
- Bluetooth v5.0



Sensors on the board


- The Arduino Nano 33 BLE Sense Board has some internal sensors such as IMU, a
 pressure sensor, a digital microphone, a humidity and temperature sensor, and a
 gesture sensor
- Most sensors chip are attached on I2C bus





TinyML kit



Building up the kit









The arduino Environment


```
void setup() {
   // put your setup code here, to run once:
}
```

Setup() is a function meant to be run only once, at the beginning

```
void loop() {
   // put your main code here, to run repeatedly:
}
```


- Loop() is a function that is executed continously and indefinetely by the board. Similar to a while(True) loop
- They are put inside of the «main» c file that constitute the «starting point» of the firmware

Compile and flash the firmware




Add the board from the board manager and enable it in tools






*It can happen that the process of selecting the board from tools needs to be repeated sometime.

Select the port



*It can happen that the process of selecting the port needs to be repeated sometime.

Install a new library



Then add it directly from the code with **include** ...

Examples

- Example 0 Blink
- Example 1 UART communication
- Example 2 Humidity and Temperature Test
- Example 3 IMU, accelerometer, gyroscope, magnetometer Tests
- Example 4 Microphone Test
- Example 5 Camera Test



Appendix

Links

https://colab.research.google.com/drive/1oX2STKatr6y0jtgDipQmjh1j932z 4fuq?usp=sharing

https://tinyml.seas.harvard.edu/assets/other/4D/22.03.11 Marcelo Rovai Handout.pdf

Libraries needed for the example:

- Built-in examples
- HTS221 (Arduino_HTS221)
- TinyMLx (Harvard_TinyMLx)

References

- "TinyML: Machine Learning with TensorFlow Lite on Arduino and Ultra-Low-Power Microcontrollers", Daniel Situnayake, Pete Warden, O'Reilly Media, Inc.
- Online course:
 - https://www.edx.org/professional-certificate/harvardx-tiny-machine-learning
- Tutorials with the board:
 - https://docs.arduino.cc/hardware/nano-33-ble-sense
- Deeper materials on the Hardware:
 - Course slide for "Embedded and Edge AI" Phd course @ Politecnico di Milano, material available on webeep of this course
- Example of python and c programming crash course (I take no responsibility on the completeness
 and correctness of this material, find what's best for you):
 - Python: https://www.youtube.com/watch?v=JJmcL1N2KQs&t=634s
 - C/C++: https://www.youtube.com/watch?v=1v-4dL8l8pQ
- A lot more material on TinyML:
 - http://tinyml.seas.harvard.edu/

LSM9DS1 (9 axis IMU) description

Accelerometer:

- used to measure the acceleration in m/s2 (meters per second per second) or g's (gravities [about 9.8 m/s2])
- its scale can be set to either \pm 2, \pm 4, \pm 8, or \pm 16

Gyroscope:

- used to measure the angular velocity in degrees per second (usually abbreviated to DPS or °/s).
- its scale can be set to either to \pm 245 \pm 500 or \pm 2000 DPS

Magnetometer:

- measures the power and direction of magnetic fields in units of gauss (Gs)
- its measurement scale to either \pm 4, \pm 8, \pm 12, or \pm 16 Gs.

