electronics-engineering: the Electronics Engineering program, user guide

electronics-engineering-ai999x 1.6.0, Rust build: command line, desktop app and browser. **Creator / engineer:** Ibnul Jaif Farabi · **Company:** AI999X · support@ai999x.com

Electronics Engineering covers semiconductors and pn junctions, diode circuits and rectifiers, BJT and MOSFET biasing and amplifiers, op-amp circuits, active filters, oscillators and 555 timers, ADCs and DACs, digital timing and power supplies. This guide is about `electronics-engineering`, the model as a self-contained program for Windows and Linux: 92 capabilities in 11 topics, answered on your own computer with no network, no Python and nothing else to install. The same compiled model runs in the AI999X desktop app and in the browser on the model's page (https://www.ai999x.com/models/electronics-engineering-ai999x/); the Python package (`pip install electronics-engineering-ai999x`) has its own guide. Every command output printed here is what the program printed.

Contents

- 1. Get it: desktop app, command line, browser, Python
- 2. Quick start
- 3. Writing inputs
- 4. Outcomes and exit codes
- 5. Scripts and agents: batch and JSON
- 6. Figures
- 7. In a web page or Node.js: WebAssembly
- 8. Every capability

1. Get it

Version 1.5.0 of the AI999X desktop app and of the command-line bundle. Checksums for every file: https://downloads.ai999x.com/desktop/1.5.0/SHA256SUMS; the newest version is always under https://downloads.ai999x.com/desktop/latest/. Full instructions: https://www.ai999x.com/desktop-cli/

what	system	download
Desktop app: Electronics Engineering	Windows x86-64	https://downloads.ai999x.com/desktop/1.5.0/ai999x-electronics-engineering-1.5.0-windows-x86_64.zip
Desktop app: Electronics Engineering	Linux x86-64	https://downloads.ai999x.com/desktop/1.5.0/ai999x-electronics-engineering-1.5.0-linux-x86_64.tar.gz
Desktop app: all models	Windows x86-64	https://downloads.ai999x.com/desktop/1.5.0/ai999x-1.5.0-windows-x86_64.zip
Desktop app: all models	Linux x86-64	https://downloads.ai999x.com/desktop/1.5.0/ai999x-1.5.0-linux-x86_64.tar.gz
Command line	Windows x86-64	https://downloads.ai999x.com/desktop/1.5.0/ai999x-cli-1.5.0-windows-x86_64.zip
Command line	Linux x86-64	https://downloads.ai999x.com/desktop/1.5.0/ai999x-cli-1.5.0-linux-x86_64.tar.gz

Desktop app

Electronics Engineering in its own app: search, questions in words, input forms, live figures and explanations. Windows: Download ai999x-electronics-engineering-1.5.0-windows-x86_64.zip, right-click it → Extract All, then open the folder and start ai999x-electronics-engineering.exe. If Windows SmartScreen asks, choose More info → Run anyway. Linux:

```
curl -LO https://downloads.ai999x.com/desktop/1.5.0/ai999x-electronics-engineering-1.5.0-linux-x86_64.tar.gz
curl -LO https://downloads.ai999x.com/desktop/1.5.0/SHA256SUMS
sha256sum -c --ignore-missing SHA256SUMS
tar xzf ai999x-electronics-engineering-1.5.0-linux-x86_64.tar.gz
./ai999x-electronics-engineering-1.5.0-linux-x86_64/ai999x-electronics-engineering
```

It opens on this model: type a question or pick a capability, fill in the form and press Compute. The AI999X desktop app with every model works the same way (choose the model first). Windows: Download ai999x-1.5.0-windows-x86_64.zip, right-click it → Extract All, then open the folder and start ai999x.exe. If Windows SmartScreen asks, choose More info → Run anyway. Linux:

```
curl -LO https://downloads.ai999x.com/desktop/1.5.0/ai999x-1.5.0-linux-x86_64.tar.gz
curl -LO https://downloads.ai999x.com/desktop/1.5.0/SHA256SUMS
sha256sum -c --ignore-missing SHA256SUMS
tar xzf ai999x-1.5.0-linux-x86_64.tar.gz
./ai999x-1.5.0-linux-x86_64/ai999x
```

Command line, Linux

The bundle holds one program per model; `electronics-engineering` is this one. The checksum line should print OK.

```
curl -LO https://downloads.ai999x.com/desktop/1.5.0/ai999x-cli-1.5.0-linux-x86_64.tar.gz
curl -LO https://downloads.ai999x.com/desktop/1.5.0/SHA256SUMS
sha256sum -c --ignore-missing SHA256SUMS
mkdir -p ~/.local/share && tar xzf ai999x-cli-1.5.0-linux-x86_64.tar.gz -C ~/.local/share
echo 'export PATH="$HOME/.local/share/ai999x-cli-1.5.0-linux-x86_64:$PATH"' >> ~/.bashrc &&
source ~/.bashrc
electronics-engineering --version
```

Command line, Windows (PowerShell)

The fourth line should print True.

```
$F = "ai999x-cli-1.5.0-windows-x86_64.zip"
Invoke-WebRequest "https://downloads.ai999x.com/desktop/1.5.0/$F" -OutFile $F
Invoke-WebRequest "https://downloads.ai999x.com/desktop/1.5.0/SHA256SUMS" -OutFile
SHA256SUMS
(Get-FileHash $F -Algorithm SHA256).Hash.ToLower() -eq ((Select-String -SimpleMatch $F
SHA256SUMS).Line -split ' ')[0]
Expand-Archive $F -DestinationPath "$env:LOCALAPPDATA\AI999X" -Force
$D = "$env:LOCALAPPDATA\AI999X\ai999x-cli-1.5.0-windows-x86_64"; $env:Path += ";$D"
[Environment]::SetEnvironmentVariable("Path", [Environment]::GetEnvironmentVariable("Path",
"User") + ";$D", "User")
electronics-engineering --version
```

In your browser

Open https://www.ai999x.com/models/electronics-engineering-ai999x/, choose a capability and press Compute in your browser: the same program runs on your device as WebAssembly; nothing is sent anywhere.

Python

```
pip install electronics-engineering-ai999x
```

2. Quick start

2.1 Check the install

Prints the model, its version and that this is the Rust build.

```
$ electronics-engineering --version
electronics-engineering-ai999x 1.6.0 (Rust build, ax-engine 1.6.0)
```

2.2 Find a capability

Search the capabilities by what you want to know; the first column is the id to pass to info and solve.

```
$ electronics-engineering search "bjt voltage-divider bias: exact q-point"
elx_bjt_voltage_divider_bias         BJT voltage-divider bias: exact Q-point  (BJT / DC
bias)
elx_mosfet_divider_bias              MOSFET voltage-divider bias with source resistor: Q-
point  (MOSFET / DC bias)
elx_bjt_collector_feedback_bias      BJT collector-feedback bias: Q-point  (BJT / DC bias)
elx_bjt_fixed_bias                   BJT fixed (base-resistor) bias: Q-point  (BJT / DC
bias)
elx_bjt_emitter_bias                 BJT dual-supply emitter bias: Q-point  (BJT / DC bias)
elx_diode_operating_point            Operating point of a diode in series with a resistor
(exact)  (diodes / operating point)
elx_bjt_cascode                      BJT cascode: output resistance, transconductance and
gain  (BJT / amplifiers)
elx_differential_pair                BJT differential pair: differential and common-mode
gain, CMRR  (BJT / differential amplifiers)
… 12 more
```

2.3 List the capabilities

Every capability the program answers: its id (what you pass to solve) and its name.

```
$ electronics-engineering list
elx_555_astable                          555 timer astable: frequency and duty cycle
elx_555_monostable                       555 timer monostable pulse width
elx_adc_code                             ADC output code, LSB and quantisation error
elx_adc_enob                             Effective number of bits (ENOB) from SINAD
elx_adc_quantization_snr                 ADC quantisation SNR with oversampling
elx_adjustable_regulator_output          Adjustable three-terminal regulator output voltage
elx_aperture_jitter_snr                  SNR limit from sampling-clock (aperture) jitter
elx_bjt_cascode                          BJT cascode: output resistance, transconductance
and gain
… 84 more
```

2.4 What a capability needs

The equation or method, every input and output with its SI unit. Read this before solve: it tells you the input names.

```
$ electronics-engineering info elx_bjt_voltage_divider_bias
BJT voltage-divider bias: exact Q-point
  VTH = VCC R2/(R1 + R2); RTH = R1 || R2; IB = (VTH - VBE)/(RTH + (beta + 1) RE); VCE = VCC
- IC RC - IE RE
  in   VCC      supply voltage [V]
  in   R1       upper divider resistor (supply to base) [ohm]
  in   R2       lower divider resistor (base to ground) [ohm]
  in   RC       collector resistor [ohm]
  in   RE       emitter resistor [ohm]
  in   beta     current gain [1]
  in   VBE      base-emitter voltage [V]
  out  VTH      Thevenin voltage of the divider [V]
  out  RTH      Thevenin resistance of the divider [ohm]
  out  IB       base current [A]
  out  IC       collector current [A]
  out  IE       emitter current [A]
  out  VB       base voltage [V]
  out  VE       emitter voltage [V]
  out  VC       collector voltage [V]
  out  VCE      collector-emitter voltage [V]
```

2.5 Solve

Inputs as name=value, each with any unit of the right kind. The answer lists every output, the method used, each input converted to SI, and the conditions the answer assumes.

```
$ electronics-engineering solve elx_bjt_voltage_divider_bias "VCC=12 V" "R1=47 kohm" "R2=10
kohm" "RC=2.2 kohm" "RE=470 ohm" beta=150.0 "VBE=0.7 V"
VTH = 2.105263158 V
RTH = 8245.614035 ohm
IB = 1.773972436e-05 A
IC = 0.002660958654 A
IE = 0.002678698378 A
VB = 1.958988238 V
VE = 1.258988238 V
VC = 6.145890962 V
VCE = 4.886902724 V
  by: BJT voltage-divider bias: exact Q-point  (VTH = VCC R2/(R1 + R2); RTH = R1 || R2; IB
= (VTH - VBE)/(RTH + (beta + 1) RE); VCE = VCC - IC RC - IE RE)
  VCC = 12 V
  R1 = 47000 ohm
  R2 = 10000 ohm
  RC = 2200 ohm
  RE = 470 ohm
  beta = 150
  VBE = 0.7 V
  assumes: VTH > VBE; active region: VCE >= 0.2 V
```

2.6 Machine-readable answer

--json prints the same answer as one line of JSON (values in SI): for scripts and other programs.

```
$ electronics-engineering solve elx_bjt_voltage_divider_bias "VCC=12 V" "R1=47 kohm" "R2=10
kohm" "RC=2.2 kohm" "RE=470 ohm" beta=150.0 "VBE=0.7 V" --json
{"outcome":"SOLVED","message":"","value":0.00266095865382,"unit":"A","solved_for":"IC","si":
[["VCC",12.0],["R1",47000.0],["R2",10000.0],["RC",2200.0],["RE",470.0],["beta",150.0],
["VBE",0.7]],"values":[["VTH",2.10526315789,"V"],["RTH",8245.61403509,"ohm"],
["IB",0.0000177397243588,"A"],["IC",0.00266095865382,"A"],["IE",0.00267869837818,"A"],
["VB",1.95898823774,"V"],["VE",1.25898823774,"V"],["VC",6.1458909616,"V"],
["VCE",4.88690272386,"V"]],"target":"IC","phrase":"Thevenin voltage of the
divider","assumptions":["VTH > VBE","active region: VCE >= 0.2 V"],"name":"BJT voltage-
divider bias: exact Q-point","equation":"VTH = VCC R2/(R1 + R2); RTH = R1 || R2; IB = (VTH
- VBE)/(RTH + (beta + 1) RE); VCE = VCC - IC RC - IE RE"}
```

2.7 When an input is missing

No number is guessed: the answer names what is missing, shows a complete call, and the program exits with status 1.

```
$ electronics-engineering solve elx_bjt_voltage_divider_bias "VCC=12 V" "R1=47 kohm" "R2=10
kohm" "RC=2.2 kohm" "RE=470 ohm" beta=150.0
NEEDS_INPUT: elx_bjt_voltage_divider_bias needs VBE (base-emitter voltage). Example:
solve('elx_bjt_voltage_divider_bias', VCC='12 V', R1='47000 ohm', R2='10000 ohm', RC='2200
ohm', RE='470 ohm', beta=150, VBE='0.7 V').
```

2.8 Many questions at once

One JSON request per line in, one JSON answer per line out, in order: for scripts, notebooks and agents (the program starts once). In PowerShell: Get-Content cases.jsonl | electronics-engineering batch

`cases.jsonl`:

```
{"key": "elx_bjt_voltage_divider_bias", "inputs": {"VCC": "12 V", "R1": "47 kohm", "R2":
"10 kohm", "RC": "2.2 kohm", "RE": "470 ohm", "beta": 150.0, "VBE": "0.7 V"}}
{"key": "elx_sallen_key_lowpass", "inputs": {"R1": "10 kohm", "R2": "10 kohm", "C1": "20
nF", "C2": "10 nF", "K": 1.0}}
```

```
$ electronics-engineering batch < cases.jsonl
{"outcome":"SOLVED","message":"","value":0.00266095865382,"unit":"A","solved_for":"IC","si":
[["VCC",12.0],["R1",47000.0],["R2",10000.0],["RC",2200.0],["RE",470.0],["beta",150.0],
["VBE",0.7]],"values":[["VTH",2.10526315789,"V"],["RTH",8245.61403509,"ohm"],
["IB",0.0000177397243588,"A"],["IC",0.00266095865382,"A"],["IE",0.00267869837818,"A"],
["VB",1.95898823774,"V"],["VE",1.25898823774,"V"],["VC",6.1458909616,"V"],
["VCE",4.88690272386,"V"]],"target":"IC","phrase":"Thevenin voltage of the
divider","assumptions":["VTH > VBE","active region: VCE >= 0.2 V"],"name":"BJT voltage-
divider bias: exact Q-point","equation":"VTH = VCC R2/(R1 + R2); RTH = R1 || R2; IB = (VTH
- VBE)/(RTH + (beta + 1) RE); VCE = VCC - IC RC - IE RE"}
{"outcome":"SOLVED","message":"","value":0.707106781187,"unit":"","solved_for":"Q","si":
[["R1",10000.0],["R2",10000.0],["C1",2e-8],["C2",1e-8],["K",1.0]],"values":
[["f0",1125.3953952,"Hz"],["Q",0.707106781187,""],["H0",1.0,""],
["peak_gain",0.707106781187,""]],"target":"Q","phrase":"natural frequency","assumptions":
["stable: R1 C2 + R2 C2 + R1 C1 (1 - K) > 0","ideal amplifier"],"name":"Sallen-Key low-pass
filter: f0, Q and gain","equation":"w0 = 1/sqrt(R1 R2 C1 C2); Q = sqrt(R1 R2 C1 C2)/(R1 C2
+ R2 C2 + R1 C1 (1 - K))"}
```

3. Writing inputs

Inputs are written `name=value`, one per argument; `electronics-engineering info <capability>` lists the names. Quote an argument that holds a space or brackets (bash, zsh and PowerShell all accept double quotes). The answer always states each input as it was read, converted to SI, so a misread unit is visible at once.

kind	example	how it is read
a number with a unit	`"R=0.128 nm"`	any unit of the same kind; converted to SI
a number in SI	`R=1.28e-10`	no unit means the SI unit shown by info
a choice	`structure=FCC`	one of the values info lists
a list or vector	`"v=[1, 2, 3]" or "v=1, 2, 3"`	brackets keep it a list
a matrix	`"A=[[1, 2], [3, 4]]"`	one list per row
true / false	`inclusive=true`	for yes/no options

An equation can be solved for any of its quantities: give the others and add `--target <symbol>`. Without `--target`, the program solves for the quantity the capability is named after.

4. Outcomes and exit codes

The program never guesses a number: when it cannot answer, it says why and exits with status 1, so a script can tell an answer from a refusal without reading the text.

outcome	meaning	exit status
SOLVED	the answer: every output with its unit, the method, the inputs in SI, the conditions assumed	0
NEEDS_INPUT	an input is missing; the message names it and shows a complete call	1
INVALID_INPUT	a value or unit of the wrong kind, an unknown input name, or a value outside the conditions	1
AMBIGUOUS	the inputs allow two different answers; say which one is meant	1
OUT_OF_SCOPE	the model has no capability for this, or the result would not be meaningful	1
(usage)	a command the program does not know: it prints its usage	2

5. Scripts and agents: batch and JSON

`electronics-engineering solve ... --json` prints one answer as one line of JSON. `electronics-engineering batch` reads one request per line on standard input and writes one JSON answer per line, in order, starting the program once for any number of requests. A request is `{"key": "<capability>", "inputs": {"name": "value", ...}, "target": null}`. In PowerShell, pipe the file in: `Get-Content cases.jsonl | electronics-engineering batch`. `electronics-engineering catalog` prints every capability with its inputs as JSON, to build forms or tool definitions.

answer field	meaning
outcome	one of the outcomes above
message	why there is no answer (empty when SOLVED)
value, unit	the main result in SI units
values	every output: [symbol, value, unit] (procedures)
target	the quantity solved for
si	each numeric input converted to SI: [symbol, value]
assumptions	the conditions the answer relies on
name, equation	the capability and its equation or method

```
import json, subprocess

reqs = [{"key": "<capability>", "inputs": {"name": "value"}}]
out = subprocess.run(["electronics-engineering", "batch"], input="\n".join(map(json.dumps,
reqs)),
                     capture_output=True, text=True, check=True).stdout
answers = [json.loads(line) for line in out.splitlines()]
```

6. Figures

`electronics-engineering figures <capability> name=value ... --out DIR` draws the live figures for those inputs and writes each as an SVG file into DIR (an existing folder); without `--out` the SVG text comes back as JSON. The desktop app and the model page draw the same figures as soon as you press Compute.

7. In a web page or Node.js: WebAssembly

The same model is a WebAssembly module, `electronics_engineering_ai999x.wasm` (https://www.ai999x.com/compute/rust/electronics_engineering_ai999x.wasm), with a small loader, `ax-`

`wasm.js` (https://www.ai999x.com/compute/rust/ax-wasm.js). It runs in a browser, a Web Worker or Node.js, with no server.

```
<script src="ax-wasm.js"></script>
<script>
  AXWasm.load("electronics_engineering_ai999x.wasm").then(function (m) {
    var a = m.solve({key: "<capability>", inputs: {name: "value"}});
    console.log(a.outcome, a.values || a.value);
    console.log(m.catalog().capabilities.length + " capabilities");
  });
</script>
```

8. Every capability

By topic. For each: what it does, what it needs and gives, when it applies, and a command with what the program printed for it. `electronics-engineering info <id>` shows the same inputs and outputs in the terminal.

Active filters (9)

Butterworth filter: Q of each second-order section, `elx_butterworth_section_q`

The quality factors of the cascaded second-order sections of an n-th order Butterworth filter (all at the cutoff frequency), and whether a first-order section is needed.

$$Q_k = \frac{1}{2\sin\left(\frac{(2k-1)\pi}{2n}\right)}$$

symbol		meaning	SI unit
`n`	in	filter order	,
`Q_max`	out	largest section Q	,
`Q`	out	section Q values, ascending	,
`sections`	out	number of second-order sections	,
`first_order`	out	1 if a first-order section is needed	,

Applies when: 2 <= n <= 20.

```
$ electronics-engineering solve elx_butterworth_section_q n=4
Q_max = 1.306562965
Q = [0.541196100146,1.30656296488]
sections = 2
first_order = 0
  by: Butterworth filter: Q of each second-order section  (Q_k = 1/(2 sin((2k - 1)
pi/(2n))), k = 1 .. floor(n/2))
  assumes: 2 <= n <= 20
```

What the worked example means: This calculation determines the quality factors for each second-order section in a cascaded Butterworth filter of order 4. The resulting values, listed as [0.541196, 1.30656], indicate

how sharply each stage peaks near the cutoff frequency. A higher Q implies greater sensitivity to component tolerances and potential instability. The number of stages is given by 2, while 0 signals whether an additional single-pole stage is necessary to complete the design when the filter order is odd.

Butterworth or Chebyshev low-pass filter order, `elx_filter_order`

The minimum order of a Butterworth or Chebyshev type I low-pass filter meeting a passband edge with at most Ap dB attenuation and a stopband edge with at least As dB.

$$n \geq \frac{\log_{10} D}{2 \log_{10}(f_s/f_p)}, \quad n \geq \frac{\cosh^{-1}\sqrt{D}}{\cosh^{-1}(f_s/f_p)}$$

symbol		meaning	SI unit
`ftype`	in	butterworth or chebyshev (type I)	,
`fp`	in	passband edge	Hz
`fs`	in	stopband edge	Hz
`Ap`	in	maximum passband attenuation (ripple) in dB	,
`As`	in	minimum stopband attenuation in dB	,
`n`	out	minimum filter order	,

Applies when: fs > fp; As > Ap > 0.

```
$ electronics-engineering solve elx_filter_order ftype=Butterworth "fp=1000 Hz" "fs=2500
Hz" Ap=1 As=40
n = 6
  by: Butterworth or Chebyshev low-pass filter order  (Butterworth: n >= log10(D)/(2
log10(fs/fp)); Chebyshev: n >= acosh(sqrt D)/acosh(fs/fp), D = (10^(As/10) - 1)/(10^(Ap/10)
- 1))
  fp = 1000 Hz
  fs = 2500 Hz
  Ap = 1
  As = 40
  ftype = Butterworth
  assumes: fs > fp; As > Ap > 0
```

What the worked example means: This calculation determines the minimum order required for a low-pass filter to meet specific attenuation constraints. Using the passband edge of 1000 Hz and stopband edge of 2500 Hz, along with maximum passband ripple of 1 and minimum stopband attenuation of 40, the result indicates that a filter of order 6 is necessary to satisfy these specifications.

Chebyshev type I filter: section Q and frequencies, `elx_chebyshev_sections`

The quality factors and natural frequencies (relative to the passband edge) of the second-order sections of an n-th order Chebyshev type I low-pass filter with a given passband ripple, and the real pole of an odd order.

$$p_k = -\sinh a \sin\theta_k + j \cosh a \cos\theta_k,\ a = \frac{1}{n}\sinh^{-1}\frac{1}{\varepsilon},\ Q_k = \frac{|p_k|}{2|\Re p_k|}$$

symbol		meaning	SI unit
`n`	in	filter order	,
`ripple`	in	passband ripple in dB	,
`Q_max`	out	largest section Q	,
`Q`	out	section Q values, ascending	,
`f0_ratio`	out	section natural frequencies / passband edge, in the same order	,
`sections`	out	number of second-order sections	,
`real_pole`	out	real pole / passband edge (0 for even n)	,

Applies when: 2 <= n <= 16; 0.001 dB <= ripple <= 6 dB.

```
$ electronics-engineering solve elx_chebyshev_sections n=4 ripple=0.5
Q_max = 2.940554174
Q = [0.705110236803,2.94055417439]
f0_ratio = [0.59700239512,1.03127040148]
sections = 2
real_pole = 0
  by: Chebyshev type I filter: section Q and frequencies  (eps = sqrt(10^(r/10) - 1); a =
asinh(1/eps)/n; poles -sinh a sin th_k + j cosh a cos th_k; Q = |p|/(2 |Re p|))
  ripple = 0.5
  assumes: 2 <= n <= 16; 0.001 dB <= ripple <= 6 dB
```

What the worked example means: This calculation determines the internal characteristics of a Chebyshev Type I low-pass filter based on its order 4 and passband ripple 0.5. It computes the quality factors for each second-order section, yielding values in [0.70511, 2.94055], along with their natural frequency ratios [0.597002, 1.03127]. The result indicates that there are 2 such sections. If the order is odd, a real pole exists at ratio 0; otherwise, this value is zero. These parameters describe how the filter distributes gain and phase response across its stages.

Equal-component Sallen-Key low-pass design, `elx_sallen_key_equal_component_design`

The resistor value and amplifier gain of an equal-component (R1 = R2 = R, C1 = C2 = C) Sallen-Key low-pass filter for a cutoff frequency and Q, with the non-inverting gain ratio Rf/Rg = K - 1.

$$R = \frac{1}{2\pi f_c C}, \quad K = 3 - \frac{1}{Q}$$

symbol		meaning	SI unit
`fc`	in	natural (cutoff) frequency	Hz
`Q`	in	quality factor (0.7071 for Butterworth)	,
`C`	in	chosen capacitor value	F
`R`	out	resistor value	ohm
`K`	out	amplifier gain	,
`Rf_over_Rg`	out	gain resistor ratio Rf/Rg	,

Applies when: 0.5 <= Q <= 20.

```
$ electronics-engineering solve elx_sallen_key_equal_component_design "fc=1000 Hz" Q=0.7071
"C=10 nF"
R = 15915.49431 ohm
K = 1.585772875
Rf_over_Rg = 0.5857728751
  by: Equal-component Sallen-Key low-pass design  (R = 1/(2 pi fc C); K = 3 - 1/Q; Rf/Rg =
K - 1)
  fc = 1000 Hz
  Q = 0.7071
  C = 1e-08 F
  assumes: 0.5 <= Q <= 20
```

What the worked example means: This calculation determines the component values for an equal-component Sallen-Key low-pass filter. Given a cutoff frequency of 1000 Hz, a quality factor of 0.7071, and a chosen capacitor value of 10 nF, the required resistance is computed as 15915.5 ohm. The necessary non-inverting amplifier gain is found to be 1.58577, which dictates that the feedback resistor should be 0.585773 times the ground resistor to achieve the desired response.

First-order active low-pass filter (inverting), `elx_first_order_active_lowpass`

The passband gain -Rf/R1, the cutoff frequency 1/(2 pi Rf C) and the gain at a frequency of an inverting op-amp low-pass filter with C across the feedback resistor.

$$H(j\omega) = -\frac{R_f/R_1}{1 + j\omega R_f C}, \quad f_c = \frac{1}{2\pi R_f C}$$

symbol		meaning	SI unit
`R1`	in	input resistor	ohm
`Rf`	in	feedback resistor	ohm
`C`	in	capacitor across Rf	F
`f`	in	frequency of interest	Hz
`H0`	out	passband gain	,
`fc`	out	cutoff frequency	Hz
`gain_f`	out	gain magnitude at f	,
`gain_dB`	out	gain at f in dB	,

Applies when: ideal op-amp.

```
$ electronics-engineering solve elx_first_order_active_lowpass "R1=10000 ohm" "Rf=100000
ohm" "C=1.59 nF" "f=1000 Hz"
H0 = -10
fc = 1000.974485 Hz
gain_f = 7.074510619
gain_dB = 16.99392806
  by: First-order active low-pass filter (inverting)  (H(s) = -(Rf/R1)/(1 + s Rf C); fc =
1/(2 pi Rf C))
  R1 = 10000 ohm
  Rf = 100000 ohm
  C = 1.59e-09 F
  f = 1000 Hz
  assumes: ideal op-amp
```

What the worked example means: This calculation determines the characteristics of an inverting active low-pass filter. Using the input resistor value of 10000 ohm ohms, the feedback resistor of 100000 ohm ohms, and the capacitor of 1.59 nF farads, this gives the DC passband gain as -10. The cutoff frequency, where the signal power drops by half, is found to be 1000.97 Hz Hz. At the specific frequency of interest, 1000 Hz Hz, the linear gain magnitude is 7.07451, which corresponds to 16.9939 decibels.

Multiple-feedback (MFB) band-pass filter, `elx_mfb_bandpass`

The centre frequency, quality factor, -3 dB bandwidth and peak (inverting) gain of a multiple-feedback band-pass filter.

$$\omega_0 = \sqrt{\frac{R_1 + R_2}{R_1 R_2 R_3 C_1 C_2}}, \quad Q = \frac{\omega_0 C_1 C_2 R_3}{C_1 + C_2}$$

symbol		meaning	SI unit
`R1`	in	input resistor	ohm
`R2`	in	resistor from the middle node to ground	ohm
`R3`	in	feedback resistor (inverting input to output)	ohm
`C1`	in	capacitor from the middle node to the inverting input	F
`C2`	in	capacitor from the middle node to the output	F
`f0`	out	centre frequency	Hz
`Q`	out	quality factor	,
`BW`	out	-3 dB bandwidth	Hz
`H_peak`	out	gain at the centre frequency	,

Applies when: ideal op-amp.

```
$ electronics-engineering solve elx_mfb_bandpass "R1=15900 ohm" "R2=1330 ohm" "R3=31800
ohm" "C1=10 nF" "C2=10 nF"
f0 = 2547.562384 Hz
Q = 2.54508224
BW = 1000.974485 Hz
H_peak = -1
  by: Multiple-feedback (MFB) band-pass filter  (w0 = sqrt((R1 + R2)/(R1 R2 R3 C1 C2)); Q =
w0 C1 C2 R3/(C1 + C2); H = -C1 R3/(R1 (C1 + C2)))
  R1 = 15900 ohm
  R2 = 1330 ohm
  R3 = 31800 ohm
  C1 = 1e-08 F
  C2 = 1e-08 F
  assumes: ideal op-amp
```

In the worked example, R1 = 15900 ohm, R2 = 1330 ohm, R3 = 31800 ohm, C1 = 10 nF, C2 = 10 nF go through the equation above and give f0 = 2547.562384 Hz, Q = 2.54508224, BW = 1000.974485 Hz, H_peak = -1. It applies only when ideal op-amp: outside that it says what is wrong instead of returning a number.

Multiple-feedback (MFB) low-pass filter, `elx_mfb_lowpass`

The natural frequency, quality factor and inverting passband gain -R2/R1 of a second-order multiple-feedback low-pass filter.

$$Q = \frac{\sqrt{R_2 R_3 C_1 C_2}}{C_2\left(R_2 + R_3 + R_2 R_3 / R_1\right)}, \quad H_0 = -\frac{R_2}{R_1}$$

symbol		meaning	SI unit
`R1`	in	input resistor	ohm
`R2`	in	feedback resistor (middle node to output)	ohm
`R3`	in	resistor from the middle node to the inverting input	ohm
`C1`	in	capacitor from the middle node to ground	F
`C2`	in	capacitor from the inverting input to the output	F
`f0`	out	natural frequency	Hz
`Q`	out	quality factor	,
`H0`	out	passband gain	,

Applies when: ideal op-amp.

```
$ electronics-engineering solve elx_mfb_lowpass "R1=10000 ohm" "R2=10000 ohm" "R3=5000 ohm"
"C1=47 nF" "C2=4.7 nF"
f0 = 1514.38839 Hz
Q = 1.118033989
H0 = -1
  by: Multiple-feedback (MFB) low-pass filter  (w0 = 1/sqrt(R2 R3 C1 C2); Q = sqrt(R2 R3 C1
C2)/(C2 (R2 + R3 + R2 R3/R1)); H0 = -R2/R1)
  R1 = 10000 ohm
  R2 = 10000 ohm
  R3 = 5000 ohm
  C1 = 4.7e-08 F
  C2 = 4.7e-09 F
  assumes: ideal op-amp
```

What the worked example means: This calculation determines the key characteristics of a second-order multiple-feedback low-pass filter using ideal op-amp assumptions. Based on the input resistor, feedback resistor, middle node resistor, and two capacitors, it computes the natural frequency, which sets the cutoff point, the quality factor, which describes the resonance peak sharpness, and the inverting passband gain. The resulting natural frequency is 1514.39 Hz, the quality factor is 1.11803, and the passband gain is -1.

Sallen-Key high-pass filter: f0, Q and gain, `elx_sallen_key_highpass`

The natural frequency, quality factor and high-frequency gain of a second-order Sallen-Key high-pass filter with any components and amplifier gain K.

$$Q = \frac{\sqrt{R_1 R_2 C_1 C_2}}{R_1(C_1 + C_2) + R_2 C_2 (1 - K)}$$

symbol		meaning	SI unit
`C1`	in	first series capacitor	F
`C2`	in	second series capacitor	F
`R1`	in	resistor from the middle node to the output (feedback)	ohm
`R2`	in	resistor from the amplifier input to ground	ohm
`K`	in	amplifier gain	,
`f0`	out	natural frequency	Hz
`Q`	out	quality factor	,
`H_inf`	out	high-frequency gain	,

Applies when: stable: R1 (C1 + C2) + R2 C2 (1 - K) > 0.

```
$ electronics-engineering solve elx_sallen_key_highpass "C1=10 nF" "C2=10 nF" "R1=11250
ohm" "R2=22500 ohm" K=1
f0 = 1000.351462 Hz
Q = 0.7071067812
H_inf = 1
  by: Sallen-Key high-pass filter: f0, Q and gain  (w0 = 1/sqrt(R1 R2 C1 C2); Q = sqrt(R1
R2 C1 C2)/(R1 (C1 + C2) + R2 C2 (1 - K)))
  C1 = 1e-08 F
  C2 = 1e-08 F
  R1 = 11250 ohm
  R2 = 22500 ohm
  K = 1
  assumes: stable: R1 (C1 + C2) + R2 C2 (1 - K) > 0
```

What the worked example means: This calculation determines the key performance metrics for a second-order Sallen-Key high-pass filter based on its passive components and amplifier configuration. Using the input values of 10 nF for the first series capacitor, 10 nF for the second series capacitor, 11250 ohm for the feedback resistor, 22500 ohm for the ground resistor, and 1 for the amplifier gain, the model computes the natural frequency as 1000.35 Hz, which defines where the filter begins to pass higher frequencies effectively. The resulting quality factor 0.707107 indicates the sharpness of the resonance peak near that frequency, while the high-frequency gain 1 represents the amplification level applied to signals well above the cutoff point.

Sallen-Key low-pass filter: f0, Q and gain, `elx_sallen_key_lowpass`

The natural frequency, quality factor, passband gain and the gain at f0 (K Q) of a second-order Sallen-Key low-pass filter with any components and amplifier gain K.

$$\omega_0 = \frac{1}{\sqrt{R_1 R_2 C_1 C_2}}, \quad Q = \frac{\sqrt{R_1 R_2 C_1 C_2}}{R_1 C_2 + R_2 C_2 + R_1 C_1 (1 - K)}$$

symbol		meaning	SI unit
`R1`	in	first series resistor	ohm
`R2`	in	second series resistor	ohm
`C1`	in	capacitor from the middle node to the output (feedback)	F
`C2`	in	capacitor from the amplifier input to ground	F
`K`	in	amplifier gain (1 for a unity-gain buffer)	,
`f0`	out	natural frequency	Hz
`Q`	out	quality factor	,
`H0`	out	passband gain	,
`peak_gain`	out	gain at f0, K Q	,

Applies when: stable: R1 C2 + R2 C2 + R1 C1 (1 - K) > 0; ideal amplifier.

```
$ electronics-engineering solve elx_sallen_key_lowpass "R1=10000 ohm" "R2=10000 ohm" "C1=20
nF" "C2=10 nF" K=1
f0 = 1125.395395 Hz
Q = 0.7071067812
H0 = 1
peak_gain = 0.7071067812
  by: Sallen-Key low-pass filter: f0, Q and gain  (w0 = 1/sqrt(R1 R2 C1 C2); Q = sqrt(R1 R2
C1 C2)/(R1 C2 + R2 C2 + R1 C1 (1 - K)))
  R1 = 10000 ohm
  R2 = 10000 ohm
  C1 = 2e-08 F
  C2 = 1e-08 F
  K = 1
  assumes: stable: R1 C2 + R2 C2 + R1 C1 (1 - K) > 0; ideal amplifier
```

What the worked example means: This calculation determines the key characteristics of a second-order Sallen-Key low-pass filter. Using the input resistors and capacitors along with the amplifier gain, it computes the natural frequency 1125.4 Hz where the filter response begins to roll off. The quality factor 0.707107 indicates the sharpness of the resonance peak near that frequency. The passband gain 1 represents the amplification level at frequencies well below the cutoff. Finally, the peak gain 0.707107 shows the maximum amplitude at the natural frequency.

BJT (16)

BJT beta cutoff and transition frequency fT, `elx_transition_frequency`

The beta cutoff frequency f_beta and the unity-current-gain (transition) frequency fT = gm/(2 pi (Cpi + Cmu)) of a bipolar transistor from its hybrid-pi capacitances.

$$f_T = \frac{g_m}{2\pi(C_\pi + C_\mu)}, \quad f_\beta = \frac{f_T}{\beta}$$

symbol		meaning	SI unit
`gm`	in	transconductance	S
`beta`	in	low-frequency current gain	,
`Cpi`	in	base-emitter capacitance	F
`Cmu`	in	base-collector capacitance	F
`r_pi`	out	r_pi = beta/gm	ohm
`f_beta`	out	beta cutoff frequency	Hz
`f_T`	out	transition frequency	Hz

Applies when: single-pole h_fe (the feed-forward zero through Cmu neglected).

```
$ electronics-engineering solve elx_transition_frequency "gm=40 mS" beta=100 "Cpi=10 pF"
"Cmu=2 pF"
r_pi = 2500 ohm
f_beta = 5305164.77 Hz
f_T = 530516477 Hz
  by: BJT beta cutoff and transition frequency fT  (f_beta = 1/(2 pi r_pi (Cpi + Cmu)); fT
= beta f_beta = gm/(2 pi (Cpi + Cmu)))
  gm = 0.04 S
  beta = 100
  Cpi = 1e-11 F
  Cmu = 2e-12 F
  assumes: single-pole h_fe (the feed-forward zero through Cmu neglected)
```

In the worked example, gm = 40 mS, beta = 100, Cpi = 10 pF, Cmu = 2 pF go through the equation above and give r_pi = 2500 ohm, f_beta = 5305164.77 Hz, f_T = 530516477 Hz. It applies only when single-pole h_fe (the feed-forward zero through Cmu neglected): outside that it says what is wrong instead of returning a number.

BJT cascode: output resistance, transconductance and gain, `elx_bjt_cascode`

The output resistance, the short-circuit transconductance and the voltage gain into a load of a cascode (common emitter driving common base) of two identical transistors at the same bias current.

$$R_{out} = r_o + (1 + g_m r_o)(r_o \parallel r_\pi), \quad A_v = -G_m(R_{out} \parallel R_L)$$

symbol		meaning	SI unit
`IC`	in	bias current of both transistors	A
`beta`	in	current gain	,
`VT`	in	thermal voltage	V
`VA`	in	Early voltage	V
`RL`	in	load resistance	ohm
`gm`	out	transconductance of each transistor	S
`r_o`	out	output resistance of each	ohm
`Rout`	out	output resistance of the cascode	ohm
`Gm`	out	short-circuit transconductance	S
`Av`	out	voltage gain into RL	,

Applies when: identical transistors, base of the upper one at signal ground.

```
$ electronics-engineering solve elx_bjt_cascode "IC=1 mA" beta=100 "VT=25 mV" "VA=100 V"
"RL=1000000 ohm"
gm = 0.04 S
r_o = 100000 ohm
Rout = 9858536.585 ohm
Gm = 0.03959426027 S
Av = -35947.88859
  by: BJT cascode: output resistance, transconductance and gain  (Rout = r_o + (1 + gm r_o)
(r_o || r_pi); Gm = gm (gm + 1/r_o)/(gm + 2/r_o + 1/r_pi); Av = -Gm (Rout || RL))
  IC = 0.001 A
  beta = 100
  VT = 0.025 V
  VA = 100 V
  RL = 1000000 ohm
  assumes: identical transistors, base of the upper one at signal ground
```

What the worked example means: This calculation determines the performance of a BJT cascode amplifier consisting of two identical transistors biased at the same current. It computes the small-signal parameters, starting with the individual transistor transconductance of 0.04 S and output resistance of 100000 ohm. These values are combined to find the total output resistance of the stack, which is 9.85854e+06 ohm, and the effective short-circuit transconductance, calculated as 0.0395943 S. Finally, the overall voltage gain into the load resistor is found to be -35947.9. This result indicates how effectively the circuit converts input voltage to output voltage while providing high isolation between input and output.

BJT collector-feedback bias: Q-point, `elx_bjt_collector_feedback_bias`

The Q-point of a transistor biased by a resistor from collector to base (collector feedback), with an optional emitter resistor.

$$I_B = \frac{V_{CC} - V_{BE}}{R_F + (\beta + 1)(R_C + R_E)}$$

symbol		meaning	SI unit
`VCC`	in	supply voltage	V
`RC`	in	collector resistor (carries IC + IB)	ohm
`RF`	in	feedback resistor, collector to base	ohm
`beta`	in	current gain	,
`VBE`	in	base-emitter voltage	V
`RE`	in	emitter resistor (default 0) (optional)	ohm
`IB`	out	base current	A
`IC`	out	collector current	A
`IE`	out	emitter current	A
`VC`	out	collector voltage	V
`VCE`	out	collector-emitter voltage	V

Applies when: active region: VCE >= 0.2 V.

```
$ electronics-engineering solve elx_bjt_collector_feedback_bias "VCC=10 V" "RC=4700 ohm"
"RF=250000 ohm" beta=90 "VBE=0.7 V"
IB = 1.372288623e-05 A
IC = 0.001235059761 A
IE = 0.001248782647 A
VC = 4.130721558 V
VCE = 4.130721558 V
  by: BJT collector-feedback bias: Q-point  (IB = (VCC - VBE)/(RF + (beta + 1)(RC + RE));
VC = VCC - IE RC)
  VCC = 10 V
  RC = 4700 ohm
  RF = 250000 ohm
  beta = 90
  VBE = 0.7 V
  assumes: active region: VCE >= 0.2 V
```

What the worked example means: This calculation determines the quiescent operating point for a bipolar junction transistor using collector-feedback bias. The base current, calculated as 1.37229e-05 A, flows through the feedback resistor and sets the emitter current to 0.00124878 A. This current causes a voltage drop across the collector resistor, yielding a collector voltage of 4.13072 V. The final collector-emitter voltage is 4.13072 V, which indicates whether the transistor remains in the active region.

BJT current mirror with finite beta, `elx_current_mirror`

The reference current and the output current of a basic two-transistor current mirror with a resistor to the supply, including the base-current error Iout = Iref beta/(beta + 2).

$$I_{out} = \frac{\beta}{\beta + 2} I_{ref}$$

symbol		meaning	SI unit
`VCC`	in	supply voltage	V
`R`	in	reference resistor	ohm
`VBE`	in	base-emitter voltage	V
`beta`	in	current gain of each (matched) transistor	,
`Iref`	out	current in the reference resistor	A
`Iout`	out	output (mirrored) current	A
`ratio`	out	Iout/Iref	,

Applies when: matched transistors, Early effect neglected.

```
$ electronics-engineering solve elx_current_mirror "VCC=10 V" "R=9300 ohm" "VBE=0.7 V"
beta=100
Iref = 0.001 A
Iout = 0.0009803921569 A
ratio = 0.9803921569
  by: BJT current mirror with finite beta  (Iref = (VCC - VBE)/R; Iout = Iref beta/(beta +
2))
  VCC = 10 V
  R = 9300 ohm
  VBE = 0.7 V
  beta = 100
  assumes: matched transistors, Early effect neglected
```

What the worked example means: This calculation determines the performance of a basic two-transistor BJT current mirror. First, the reference current 0.001 A is found by subtracting the base-emitter voltage 0.7 V from the supply voltage 10 V and dividing by the resistor 9300 ohm. Then, the actual output current 0.000980392 A is derived by applying the finite beta correction factor to the reference current. The resulting ratio 0.980392 indicates how closely the mirror replicates the input current, with values less than one reflecting the error caused by base currents.

BJT differential pair: differential and common-mode gain, CMRR, `elx_differential_pair`

The differential gain (differential and single-ended output), the common-mode gain and the common-mode rejection ratio of a resistively loaded BJT differential pair with a tail current source of finite resistance.

$$A_{cm} = -\frac{g_m R_C}{1 + 2R_{EE}(\beta+1)/r_\pi}, \quad \mathrm{CMRR} = \frac{1 + 2R_{EE}(\beta+1)/r_\pi}{2}$$

symbol		meaning	SI unit
`I_tail`	in	tail (bias) current	A
`beta`	in	current gain	,
`VT`	in	thermal voltage	V
`RC`	in	collector resistor of each side	ohm
`REE`	in	output resistance of the tail current source	ohm
`IC`	out	collector current of each transistor	A
`gm`	out	transconductance of each	S
`Ad_diff`	out	differential gain, differential output	,
`Ad_se`	out	differential gain, single-ended output	,
`Acm`	out	common-mode gain, single-ended output	,
`CMRR`	out	|Ad_se/Acm|	,
`CMRR_dB`	out	CMRR in dB	,

Applies when: matched transistors, r_o neglected.

```
$ electronics-engineering solve elx_differential_pair "I_tail=1 mA" beta=100 "VT=25 mV"
"RC=10000 ohm" "REE=100000 ohm"
IC = 0.000495049505 A
gm = 0.0198019802 S
Ad_diff = -198.019802
Ad_se = -99.00990099
Acm = -0.04949257735
CMRR = 2000.5
CMRR_dB = 66.02277111
  by: BJT differential pair: differential and common-mode gain, CMRR  (IC = alpha I/2; gm =
IC/VT; Ad = -gm RC (/2 single-ended); Acm = -gm RC/(1 + 2 REE (beta + 1)/r_pi); CMRR =
|Ad,se/Acm|)
  I_tail = 0.001 A
  beta = 100
  VT = 0.025 V
  RC = 10000 ohm
  REE = 100000 ohm
  assumes: matched transistors, r_o neglected
```

What the worked example means: This calculation determines the performance of a bipolar junction transistor differential pair. Using the tail current of 1 mA and collector resistors of 10000 ohm, each transistor carries a collector current of 0.00049505 A with a transconductance of 0.019802 S. The resulting differential voltage gain is -198.02 for double-ended output or -99.0099 for single-ended, while the common-mode gain is suppressed to -0.0494926. The ratio of these gains yields a common-mode rejection ratio of 2000.5, indicating how well the circuit rejects noise common to both inputs.

BJT dual-supply emitter bias: Q-point, `elx_bjt_emitter_bias`

The Q-point of a transistor with its base returned to ground through RB and its emitter returned to a negative supply -VEE through RE (emitter bias).

$$I_E = \frac{V_{EE} - V_{BE}}{R_E + R_B/(\beta + 1)}$$

symbol		meaning	SI unit
`VCC`	in	positive supply	V
`VEE`	in	magnitude of the negative supply	V
`RB`	in	base resistor to ground	ohm
`RC`	in	collector resistor	ohm
`RE`	in	emitter resistor to -VEE	ohm
`beta`	in	current gain	,
`VBE`	in	base-emitter voltage	V
`IB`	out	base current	A
`IC`	out	collector current	A
`IE`	out	emitter current	A
`VB`	out	base voltage	V
`VE`	out	emitter voltage	V

symbol		meaning	SI unit
`VC`	out	collector voltage	V
`VCE`	out	collector-emitter voltage	V

Applies when: VEE > VBE; active region: VCE >= 0.2 V.

```
$ electronics-engineering solve elx_bjt_emitter_bias "VCC=10 V" "VEE=10 V" "RB=10000 ohm"
"RC=4700 ohm" "RE=10000 ohm" beta=100 "VBE=0.7 V"
IB = 9.117647059e-06 A
IC = 0.0009117647059 A
IE = 0.0009208823529 A
VB = -0.09117647059 V
VE = -0.7911764706 V
VC = 5.714705882 V
VCE = 6.505882353 V
  by: BJT dual-supply emitter bias: Q-point  (IE = (VEE - VBE)/(RE + RB/(beta + 1)); VB = -
IB RB; VE = VB - VBE; VC = VCC - IC RC)
  VCC = 10 V
  VEE = 10 V
  RB = 10000 ohm
  RC = 4700 ohm
  RE = 10000 ohm
  beta = 100
  VBE = 0.7 V
  assumes: VEE > VBE; active region: VCE >= 0.2 V
```

What the worked example means: This calculation determines the quiescent operating point of a bipolar junction transistor in an emitter bias configuration. Using the supply voltages, resistor values, and transistor gain, the emitter current is found to be 0.000920882 A. This current establishes the base voltage at -0.0911765 V and the collector voltage at 5.71471 V, defining the DC conditions for signal amplification.

BJT fixed (base-resistor) bias: Q-point, `elx_bjt_fixed_bias`

The quiescent base and collector currents and the collector-emitter voltage of a common-emitter stage biased by a single base resistor from the supply.

$$I_B = \frac{V_{CC} - V_{BE}}{R_B}, \quad V_{CE} = V_{CC} - \beta I_B R_C$$

symbol		meaning	SI unit
`VCC`	in	supply voltage	V
`RB`	in	base resistor	ohm
`RC`	in	collector resistor	ohm
`beta`	in	current gain	,
`VBE`	in	base-emitter voltage (about 0.7 V)	V
`IB`	out	base current	A
`IC`	out	collector current	A
`IE`	out	emitter current	A

symbol		meaning	SI unit
`VCE`	out	collector-emitter voltage	V

Applies when: active region: VCE >= 0.2 V (otherwise refused as saturated).

```
$ electronics-engineering solve elx_bjt_fixed_bias "VCC=12 V" "RB=470000 ohm" "RC=2200 ohm"
beta=100 "VBE=0.7 V"
IB = 2.404255319e-05 A
IC = 0.002404255319 A
IE = 0.002428297872 A
VCE = 6.710638298 V
  by: BJT fixed (base-resistor) bias: Q-point  (IB = (VCC - VBE)/RB; IC = beta IB; VCE =
VCC - IC RC)
  VCC = 12 V
  RB = 470000 ohm
  RC = 2200 ohm
  beta = 100
  VBE = 0.7 V
  assumes: active region: VCE >= 0.2 V (otherwise refused as saturated)
```

What the worked example means: This calculation determines the DC operating point, or Q-point, for a bipolar junction transistor configured with fixed bias. The base current 2.40426e-05 A is derived from the supply voltage 12 V minus the base-emitter drop 0.7 V, divided by the base resistor 470000 ohm. This base current sets the collector current 0.00240426 A through the transistor's current gain 100. Consequently, the voltage at the collector relative to the emitter, 6.71064 V, is found by subtracting the voltage drop across the collector resistor 2200 ohm from the supply voltage. A stable Q-point ensures the amplifier operates in the active region.

BJT small-signal (hybrid-pi) parameters, `elx_bjt_small_signal_parameters`

The transconductance gm, the input resistance r_pi, the emitter resistance r_e, the output resistance r_o (Early voltage) and the intrinsic gain of a bipolar transistor at its bias current.

$$g_m = \frac{I_C}{V_T}, \quad r_\pi = \frac{\beta}{g_m}, \quad r_e = \frac{\alpha}{g_m}, \quad r_o = \frac{V_A}{I_C}$$

symbol		meaning	SI unit
`IC`	in	collector bias current	A
`beta`	in	current gain	,
`VT`	in	thermal voltage (25 or 26 mV)	V
`VA`	in	Early voltage	V
`gm`	out	transconductance	S
`r_pi`	out	base input resistance r_pi	ohm
`r_e`	out	emitter resistance r_e	ohm
`r_o`	out	output resistance	ohm
`A0`	out	intrinsic voltage gain gm r_o	,

Applies when: IC, beta, VT, VA > 0; active region.

```
$ electronics-engineering solve elx_bjt_small_signal_parameters "IC=1 mA" beta=100 "VT=25
mV" "VA=100 V"
gm = 0.04 S
r_pi = 2500 ohm
r_e = 24.75247525 ohm
r_o = 100000 ohm
A0 = 4000
  by: BJT small-signal (hybrid-pi) parameters  (gm = IC/VT; r_pi = beta/gm; r_e = alpha/gm;
r_o = VA/IC; A0 = VA/VT)
  IC = 0.001 A
  beta = 100
  VT = 0.025 V
  VA = 100 V
  assumes: IC, beta, VT, VA > 0; active region
```

What the worked example means: This calculation determines the small-signal hybrid-pi parameters for a bipolar junction transistor operating in the active region. By using the collector bias current 1 mA, current gain 100, thermal voltage 25 mV, and Early voltage 100 V, this gives key performance metrics. The transconductance 0.04 S indicates how effectively the base-emitter voltage controls the collector current. The base input resistance 2500 ohm represents the impedance seen looking into the base terminal. The emitter resistance 24.7525 ohm and output resistance 100000 ohm characterize internal resistances, while the intrinsic voltage gain 4000 reflects the maximum amplification capability of the device without external loading.

BJT terminal currents from beta, `elx_bjt_current_relations`

The collector and emitter currents and the common-base current gain alpha of a bipolar transistor in the active region from its base current and beta.

$$I_C = \beta I_B, \quad I_E = (\beta + 1) I_B, \quad \alpha = \frac{\beta}{\beta + 1}$$

symbol		meaning	SI unit
`IB`	in	base current	A
`beta`	in	common-emitter current gain (hFE)	,
`IC`	out	collector current	A
`IE`	out	emitter current	A
`alpha`	out	alpha = beta/(beta + 1)	,

Applies when: IB > 0, beta > 0; active region.

```
$ electronics-engineering solve elx_bjt_current_relations "IB=20 uA" beta=100
IC = 0.002 A
IE = 0.00202 A
alpha = 0.9900990099
  by: BJT terminal currents from beta  (IC = beta IB; IE = (beta + 1) IB; alpha =
beta/(beta + 1))
  IB = 2e-05 A
  beta = 100
  assumes: IB > 0, beta > 0; active region
```

What the worked example means: This calculation determines the collector current, emitter current, and common-base current gain for a bipolar junction transistor operating in the active region. Using the provided base current of 20 uA and the current gain factor of 100, the model computes the resulting currents and the derived alpha value. The collector current 0.002 A represents the main output flow controlled by the base, while the emitter current 0.00202 A reflects the total current entering the device. The parameter alpha 0.990099 indicates the fraction of emitter current that reaches the collector.

BJT voltage-divider bias: exact Q-point, `elx_bjt_voltage_divider_bias`

The Q-point (base, collector and emitter currents, node voltages and VCE) of a common-emitter stage with a base voltage divider and an emitter resistor, by the exact Thevenin analysis (base current included).

$$I_B = \frac{V_{TH} - V_{BE}}{R_{TH} + (\beta + 1) R_E}$$

symbol		meaning	SI unit
`VCC`	in	supply voltage	V
`R1`	in	upper divider resistor (supply to base)	ohm
`R2`	in	lower divider resistor (base to ground)	ohm
`RC`	in	collector resistor	ohm
`RE`	in	emitter resistor	ohm
`beta`	in	current gain	,
`VBE`	in	base-emitter voltage	V
`VTH`	out	Thevenin voltage of the divider	V
`RTH`	out	Thevenin resistance of the divider	ohm
`IB`	out	base current	A
`IC`	out	collector current	A
`IE`	out	emitter current	A
`VB`	out	base voltage	V
`VE`	out	emitter voltage	V
`VC`	out	collector voltage	V
`VCE`	out	collector-emitter voltage	V

Applies when: VTH > VBE; active region: VCE >= 0.2 V.

```
$ electronics-engineering solve elx_bjt_voltage_divider_bias "VCC=12 V" "R1=47000 ohm"
"R2=10000 ohm" "RC=2200 ohm" "RE=470 ohm" beta=150 "VBE=0.7 V"
VTH = 2.105263158 V
RTH = 8245.614035 ohm
IB = 1.773972436e-05 A
IC = 0.002660958654 A
IE = 0.002678698378 A
VB = 1.958988238 V
VE = 1.258988238 V
VC = 6.145890962 V
VCE = 4.886902724 V
  by: BJT voltage-divider bias: exact Q-point  (VTH = VCC R2/(R1 + R2); RTH = R1 || R2; IB
= (VTH - VBE)/(RTH + (beta + 1) RE); VCE = VCC - IC RC - IE RE)
  VCC = 12 V
  R1 = 47000 ohm
  R2 = 10000 ohm
  RC = 2200 ohm
  RE = 470 ohm
  beta = 150
  VBE = 0.7 V
  assumes: VTH > VBE; active region: VCE >= 0.2 V
```

What the worked example means: This calculation determines the exact quiescent operating point of a bipolar junction transistor in a common-emitter configuration with voltage-divider bias. By replacing the base resistors with their Thevenin equivalent, the base current is 1.77397e-05 A, which leads to a collector current of 0.00266096 A and an emitter current of 0.0026787 A. Consequently, the base voltage is 1.95899 V, the emitter voltage is 1.25899 V, and the collector voltage is 6.14589 V, resulting in a final collector-emitter voltage of 4.8869 V.

Common-base amplifier, `elx_common_base_amplifier`

The voltage gain (emitter to collector and source to load), the low input resistance and the output resistance of a common-base stage (hybrid-pi model, r_o neglected).

$$A_v = g_m(R_C \parallel R_L), \quad R_{in} = R_E \parallel r_e$$

symbol		meaning	SI unit
`IC`	in	collector bias current	A
`beta`	in	current gain	,
`VT`	in	thermal voltage	V
`RC`	in	collector resistor	ohm
`RL`	in	load resistor	ohm
`RE`	in	emitter bias resistor	ohm
`Rsig`	in	source resistance	ohm
`Av`	out	voltage gain emitter to output	,
`Rin`	out	input resistance (RE || r_e)	ohm
`Rout`	out	output resistance (RC)	ohm
`Gv`	out	overall gain from the source	,

Applies when: r_o neglected; base at signal ground.

```
$ electronics-engineering solve elx_common_base_amplifier "IC=1 mA" beta=100 "VT=25 mV"
"RC=5000 ohm" "RL=5000 ohm" "RE=10000 ohm" "Rsig=50 ohm"
Av = 100
Rin = 24.69135802 ohm
Rout = 5000 ohm
Gv = 33.05785124
  by: Common-base amplifier  (Av = gm (RC || RL); Rin = RE || r_e with r_e = alpha/gm; Gv =
Av Rin/(Rin + Rsig))
  IC = 0.001 A
  beta = 100
  VT = 0.025 V
  RC = 5000 ohm
  RL = 5000 ohm
  RE = 10000 ohm
  Rsig = 50 ohm
  assumes: r_o neglected; base at signal ground
```

What the worked example means: This calculation determines the performance of a common-base amplifier stage using the hybrid-pi model. The intrinsic emitter resistance is derived from the bias current, resulting in an input resistance of 24.6914 ohm, which is the parallel combination of the external emitter resistor and this intrinsic value. The voltage gain from the emitter to the collector is calculated as 100, driven by the transconductance and the parallel load at the collector. The overall source-to-load gain is 33.0579, accounting for signal loss across the source resistance. The output resistance looking into the collector is 5000 ohm, typically dominated by the collector resistor when neglecting the transistor's internal output resistance.

Common-collector (emitter-follower) amplifier, `elx_common_collector_amplifier`

The voltage gain, input resistance and output resistance of an emitter follower, including the source resistance reflected into the emitter (hybrid-pi model, r_o neglected).

$$A_v = \frac{(\beta+1)R'_E}{r_\pi + (\beta+1)R'_E}, \quad R_{out} = R_E \parallel \frac{r_\pi + R_{sig} \parallel R_B}{\beta+1}$$

symbol		meaning	SI unit
`IC`	in	collector bias current	A
`beta`	in	current gain	,
`VT`	in	thermal voltage	V
`RE`	in	emitter resistor	ohm
`RL`	in	load resistor	ohm
`RB`	in	bias resistance at the base	ohm
`Rsig`	in	source resistance	ohm
`Av`	out	voltage gain base to output	,
`Rin`	out	input resistance	ohm
`Rout`	out	output resistance	ohm
`Gv`	out	overall gain from the source	,

Applies when: r_o neglected.

```
$ electronics-engineering solve elx_common_collector_amplifier "IC=5 mA" beta=100 "VT=25
mV" "RE=1000 ohm" "RL=1000 ohm" "RB=100000 ohm" "Rsig=10000 ohm"
Av = 0.9901960784
Rin = 33774.83444 ohm
Rout = 86.7242088 ohm
Gv = 0.7639939486
  by: Common-collector (emitter-follower) amplifier  (Av = (beta + 1)(RE || RL)/(r_pi +
(beta + 1)(RE || RL)); Rout = RE || (r_pi + Rsig || RB)/(beta + 1))
  IC = 0.005 A
  beta = 100
  VT = 0.025 V
  RE = 1000 ohm
  RL = 1000 ohm
  RB = 100000 ohm
  Rsig = 10000 ohm
  assumes: r_o neglected
```

What the worked example means: This calculation determines the performance of a common-collector amplifier, also known as an emitter follower. Using the collector bias current, thermal voltage, and circuit resistances, it computes the voltage gain from base to output, which is 0.990196, and the overall source-to-load gain, which is 0.763994. It also finds the input resistance, 33774.8 ohm, and the output resistance, 86.7242 ohm. These values indicate how effectively the stage buffers the signal and drives the load.

Common-emitter amplifier: gain, input and output resistance, `elx_common_emitter_amplifier`

The voltage gain (base to collector and source to load), the input and output resistances of a common-emitter stage with an optional unbypassed emitter resistance, from the bias current (hybrid-pi model, r_o neglected).

$$A_v = -\frac{\beta\,(R_C \parallel R_L)}{r_\pi + (\beta+1)R_{E1}}$$

symbol		meaning	SI unit
`IC`	in	collector bias current	A
`beta`	in	current gain	,
`VT`	in	thermal voltage	V
`RC`	in	collector resistor	ohm
`RL`	in	load resistor	ohm
`RE1`	in	unbypassed emitter resistance (0 if fully bypassed)	ohm
`RB`	in	bias resistance seen at the base (R1 || R2)	ohm
`Rsig`	in	source resistance	ohm
`gm`	out	transconductance	S
`r_pi`	out	r_pi	ohm
`Av`	out	voltage gain base to output	,
`Rin`	out	input resistance (including RB)	ohm
`Rout`	out	output resistance (RC)	ohm

symbol		meaning	SI unit
`Gv`	out	overall gain from the source voltage	,

Applies when: r_o neglected; coupling and bypass capacitors short at signal frequency.

```
$ electronics-engineering solve elx_common_emitter_amplifier "IC=1 mA" beta=100 "VT=25 mV"
"RC=5000 ohm" "RL=10000 ohm" "RE1=0 ohm" "RB=20000 ohm" "Rsig=1000 ohm"
gm = 0.04 S
r_pi = 2500 ohm
Av = -133.3333333
Rin = 2222.222222 ohm
Rout = 5000 ohm
Gv = -91.95402299
  by: Common-emitter amplifier: gain, input and output resistance  (Av = -beta (RC ||
RL)/(r_pi + (beta + 1) RE1); Rin = RB || (r_pi + (beta + 1) RE1); Gv = Av Rin/(Rin + Rsig))
  IC = 0.001 A
  beta = 100
  VT = 0.025 V
  RC = 5000 ohm
  RL = 10000 ohm
  RE1 = 0 ohm
  RB = 20000 ohm
  Rsig = 1000 ohm
  assumes: r_o neglected; coupling and bypass capacitors short at signal frequency
```

In the worked example, IC = 1 mA, beta = 100, VT = 25 mV, RC = 5000 ohm, RL = 10000 ohm, RE1 = 0 ohm, RB = 20000 ohm, Rsig = 1000 ohm go through the equation above and give gm = 0.04 S, r_pi = 2500 ohm, Av = -133.3333333, Rin = 2222.222222 ohm. It applies only when r_o neglected; coupling and bypass capacitors short at signal frequency: outside that it says what is wrong instead of returning a number.

Common-emitter high-frequency cutoff: Miller effect and open-circuit time constants, `elx_miller_high_cutoff`

The Miller capacitance, the upper -3 dB frequency of a common-emitter (or common-source) stage by the Miller approximation, and the open-circuit time-constant estimate that also counts the output side of Cmu.

$$C_M = C_\mu(1 + g_m R'_L), \quad \tau_{oc} = C_\pi R'_\pi + C_\mu \left(R'_\pi + R'_L + g_m R'_\pi R'_L\right)$$

symbol		meaning	SI unit
`gm`	in	transconductance	S
`r_pi`	in	r_pi (use a very large value for a MOSFET)	ohm
`Cpi`	in	input capacitance Cpi (Cgs)	F
`Cmu`	in	feedback capacitance Cmu (Cgd)	F
`RLp`	in	total load at the collector (RC || RL || r_o)	ohm
`Rsigp`	in	source resistance seen at the base (Rsig || RB)	ohm
`A_mid`	out	gain across Cmu, -gm RL'	,
`C_M`	out	Miller capacitance	F
`R_pi_eq`	out	resistance seen by Cpi (r_pi || Rsig')	ohm

symbol		meaning	SI unit
`f_H_miller`	out	upper cutoff, Miller approximation	Hz
`tau_oc`	out	sum of open-circuit time constants	s
`f_H_octc`	out	upper cutoff, open-circuit time constants	Hz

Applies when: mid-band gain unchanged by the capacitors; dominant-pole estimate.

```
$ electronics-engineering solve elx_miller_high_cutoff "gm=40 mS" "r_pi=2500 ohm" "Cpi=10
pF" "Cmu=2 pF" "RLp=2500 ohm" "Rsigp=1000 ohm"
A_mid = -100
C_M = 2.02e-10 F
R_pi_eq = 714.2857143 ohm
f_H_miller = 1051023.209 Hz
tau_oc = 1.564285714e-07 s
f_H_octc = 1017428.86 Hz
  by: Common-emitter high-frequency cutoff: Miller effect and open-circuit time constants
(C_M = Cmu (1 + gm RL'); f_H = 1/(2 pi (r_pi || Rsig')(Cpi + C_M)); tau = Cpi R' + Cmu (R'
+ RL' + gm R' RL'))
  gm = 0.04 S
  r_pi = 2500 ohm
  Cpi = 1e-11 F
  Cmu = 2e-12 F
  RLp = 2500 ohm
  Rsigp = 1000 ohm
  assumes: mid-band gain unchanged by the capacitors; dominant-pole estimate
```

What the worked example means: This calculation determines the high-frequency response of a common-emitter amplifier stage. It first computes the mid-band gain -100 and the Miller capacitance 2.02e-10 F, which represents the feedback capacitor multiplied by one plus the magnitude of the gain. Using these values, the upper three-decibel cutoff frequency via the Miller approximation is found to be 1.05102e+06 Hz. Additionally, the open-circuit time constant method provides a more comprehensive estimate of 1.56429e-07 s seconds, resulting in a cutoff frequency of 1.01743e+06 Hz. This approach helps predict bandwidth limitations caused by internal transistor capacitances.

Common-emitter low-frequency cutoff by short-circuit time constants, `elx_low_frequency_cutoff`

The resistance seen by each coupling and bypass capacitor of a common-emitter amplifier and the lower -3 dB frequency estimated as the sum of the short-circuit pole frequencies (r_o neglected).

$$f_L \approx \sum_i \frac{1}{2\pi R_i C_i}$$

symbol		meaning	SI unit
`Rsig`	in	source resistance	ohm
`RB`	in	bias resistance at the base (R1 || R2)	ohm
`r_pi`	in	r_pi	ohm
`beta`	in	current gain	,
`RE`	in	emitter resistor (bypassed by CE)	ohm

symbol		meaning	SI unit
`RC`	in	collector resistor	ohm
`RL`	in	load resistor	ohm
`C1`	in	input coupling capacitor	F
`C2`	in	output coupling capacitor	F
`CE`	in	emitter bypass capacitor	F
`R_C1`	out	resistance seen by C1	ohm
`R_CE`	out	resistance seen by CE	ohm
`R_C2`	out	resistance seen by C2	ohm
`f_C1`	out	pole of C1	Hz
`f_CE`	out	pole of CE	Hz
`f_C2`	out	pole of C2	Hz
`f_L`	out	estimated lower cutoff	Hz

Applies when: short-circuit time-constant estimate; r_o neglected.

```
$ electronics-engineering solve elx_low_frequency_cutoff "Rsig=1000 ohm" "RB=20000 ohm"
"r_pi=2500 ohm" beta=100 "RE=1000 ohm" "RC=5000 ohm" "RL=10000 ohm" "C1=10 uF" "C2=10 uF"
"CE=100 uF"
R_C1 = 3222.222222 ohm
R_CE = 33.05219968 ohm
R_C2 = 15000 ohm
f_C1 = 4.939291337 Hz
f_CE = 48.15260244 Hz
f_C2 = 1.061032954 Hz
f_L = 54.15292673 Hz
  by: Common-emitter low-frequency cutoff by short-circuit time constants  (R_C1 = Rsig +
RB || r_pi; R_CE = RE || (r_pi + Rsig || RB)/(beta + 1); R_C2 = RC + RL; f_L = sum 1/(2 pi
R C))
  Rsig = 1000 ohm
  RB = 20000 ohm
  r_pi = 2500 ohm
  beta = 100
  RE = 1000 ohm
  RC = 5000 ohm
  RL = 10000 ohm
  C1 = 1e-05 F
  C2 = 1e-05 F
  CE = 0.0001 F
  assumes: short-circuit time-constant estimate; r_o neglected
```

What the worked example means: This calculation determines the low-frequency response of a common-emitter amplifier using the short-circuit time constant method. The resistance seen by the input coupling capacitor is 3222.22 ohm, while the emitter bypass capacitor sees 33.0522 ohm and the output coupling capacitor sees 15000 ohm. These resistances, combined with their respective capacitance values, yield individual pole frequencies of 4.93929 Hz, 48.1526 Hz, and 1.06103 Hz. Summing these poles provides an approximation for the overall lower cutoff frequency of 54.1529 Hz, which indicates where the gain drops to half power.

Wilson current mirror output current, `elx_wilson_current_mirror`

The output current of a three-transistor Wilson current mirror and its small base-current error, 2/(beta^2 + 2 beta + 2).

$$I_{out} = I_{ref}\left(1 - \frac{2}{\beta^2 + 2\beta + 2}\right)$$

symbol		meaning	SI unit
`Iref`	in	reference current	A
`beta`	in	current gain of each matched transistor	,
`Iout`	out	output current	A
`ratio`	out	Iout/Iref	,
`error`	out	relative error 1 - Iout/Iref	,

Applies when: matched transistors, Early effect neglected.

```
$ electronics-engineering solve elx_wilson_current_mirror "Iref=1 mA" beta=100
Iout = 0.00099980396 A
ratio = 0.99980396
error = 0.0001960399922
  by: Wilson current mirror output current  (Iout = Iref (1 - 2/(beta^2 + 2 beta + 2)))
  Iref = 0.001 A
  beta = 100
  assumes: matched transistors, Early effect neglected
```

What the worked example means: This calculation determines the output current and transfer ratio of a three-transistor Wilson current mirror. Given a reference current of 1 mA and a transistor beta of 100, the model computes the output current as 0.000999804 A. The resulting transfer ratio is 0.999804, indicating that the circuit exhibits a relative error of 0.00019604 due to base current losses. This error term quantifies the deviation from ideal unity gain, showing how closely the output mirrors the input.

CMOS (2)

CMOS gate propagation delay (switch-resistor model), `elx_cmos_propagation_delay`

The high-to-low and low-to-high propagation delays (50 % points) and their average for a CMOS gate modelled as switched equivalent resistances driving a load capacitance.

$$t_{pHL} = \ln 2\, R_n C_L, \quad t_{pLH} = \ln 2\, R_p C_L$$

symbol		meaning	SI unit
`Rn`	in	equivalent on-resistance of the pull-down network	ohm
`Rp`	in	equivalent on-resistance of the pull-up network	ohm
`CL`	in	load capacitance	F
`tpHL`	out	high-to-low delay	s

symbol		meaning	SI unit
`tpLH`	out	low-to-high delay	s
`tp`	out	average propagation delay	s

Applies when: step input, RC switch model.

```
$ electronics-engineering solve elx_cmos_propagation_delay "Rn=10000 ohm" "Rp=20000 ohm"
"CL=100 fF"
tpHL = 6.931471806e-10 s
tpLH = 1.386294361e-09 s
tp = 1.039720771e-09 s
  by: CMOS gate propagation delay (switch-resistor model)  (tpHL = ln 2 Rn CL; tpLH = ln 2
Rp CL; tp = (tpHL + tpLH)/2)
  Rn = 10000 ohm
  Rp = 20000 ohm
  CL = 1e-13 F
  assumes: step input, RC switch model
```

What the worked example means: This calculation determines the propagation delays for a CMOS gate using a switch-resistor model. It computes the time required for the output to transition from high to low, denoted as 6.93147e-10 s, and from low to high, denoted as 1.38629e-09 s. These values are derived from the equivalent on-resistances of the pull-down network 10000 ohm and pull-up network 20000 ohm, combined with the load capacitance 100 fF. The average propagation delay 1.03972e-09 s represents the typical switching speed of the gate under these conditions.

CMOS inverter switching threshold VM, `elx_cmos_switching_threshold`

The switching threshold of a CMOS inverter (input = output, both transistors saturated) from the supply, the two threshold voltages and the two transconductance parameters.

$$V_M = \frac{V_{tn} + r\,(V_{DD} - |V_{tp}|)}{1 + r}, \quad r = \sqrt{k_p / k_n}$$

symbol		meaning	SI unit
`VDD`	in	supply voltage	V
`Vtn`	in	NMOS threshold	V
`Vtp`	in	magnitude of the PMOS threshold	V
`kn`	in	NMOS mu_n Cox W/L	A/V^2
`kp`	in	PMOS mu_p Cox W/L	A/V^2
`r`	out	sqrt(kp/kn)	,
`VM`	out	switching threshold	V

Applies when: Vtn + |Vtp| < VDD; lambda neglected.

```
$ electronics-engineering solve elx_cmos_switching_threshold "VDD=2.5 V" "Vtn=0.4 V"
"Vtp=0.4 V" "kn=0.1 mA/V^2" "kp=0.1 mA/V^2"
r = 1
VM = 1.25 V
  by: CMOS inverter switching threshold VM  (VM = (Vtn + r (VDD - |Vtp|))/(1 + r), r =
sqrt(kp/kn))
  VDD = 2.5 V
  Vtn = 0.4 V
  Vtp = 0.4 V
  kn = 0.0001 A/V^2
  kp = 0.0001 A/V^2
  assumes: Vtn + |Vtp| < VDD; lambda neglected
```

What the worked example means: This calculation determines the CMOS inverter switching threshold, denoted as VM. The result of 1.25 V volts represents the input voltage level at which the output equals the input, assuming both transistors operate in saturation. This value is derived from the supply voltage 2.5 V, the NMOS threshold 0.4 V, the PMOS threshold magnitude 0.4 V, and the ratio of their conduction strengths defined by r = 1. A balanced inverter typically aims for a threshold near half the supply voltage to maximize noise margins.

Data converters (9)

ADC output code, LSB and quantisation error, `elx_adc_code`

The output code (decimal and binary) of an ideal unipolar truncating n-bit ADC for an input voltage, the LSB size, the voltage the code represents and the quantisation error.

$$D = \left\lfloor \frac{V_{in}}{V_{ref}} 2^n \right\rfloor, \quad \mathrm{LSB} = \frac{V_{ref}}{2^n}$$

symbol		meaning	SI unit
`Vin`	in	analog input	V
`Vref`	in	reference (full-scale) voltage	V
`n`	in	resolution in bits	,
`code`	out	output code (decimal)	,
`bits`	out	output code in binary	,
`LSB`	out	LSB = Vref/2^n	V
`V_code`	out	voltage of the code	V
`error`	out	quantisation error Vin - code LSB	V

Applies when: 0 <= Vin <= Vref; 1 <= n <= 16.

```
$ electronics-engineering solve elx_adc_code "Vin=3.2 V" "Vref=5 V" n=8
code = 163
bits = 10100011
LSB = 0.01953125 V
V_code = 3.18359375 V
error = 0.01640625 V
  by: ADC output code, LSB and quantisation error  (code = floor(Vin 2^n/Vref), at most 2^n
- 1; LSB = Vref/2^n)
  Vin = 3.2 V
  Vref = 5 V
  assumes: 0 <= Vin <= Vref; 1 <= n <= 16
```

What the worked example means: This calculation determines the digital output of an ideal n-bit analog-to-digital converter. The output code, shown here as 163, is derived by truncating the scaled input voltage. Each step in this quantization process corresponds to the least significant bit value, calculated as 0.0195312 V. Consequently, the specific binary representation 10100011 indicates that the converter maps the input range into discrete levels, where the nominal voltage associated with this code is 3.18359 V. The difference between the actual input and this nominal value constitutes the quantization error.

ADC quantisation SNR with oversampling, `elx_adc_quantization_snr`

The signal-to-quantisation-noise ratio of an ideal n-bit converter for a sine input (6.02 n + 1.76 dB at full scale), with an oversampling ratio and a reduced amplitude, and the in-band noise in LSB.

$$\mathrm{SNR} = 6.02\,n + 1.76 + 10\log_{10}\mathrm{OSR}\ \mathrm{dB}$$

symbol		meaning	SI unit
`n`	in	resolution in bits	,
`OSR`	in	oversampling ratio (default 1) (optional)	,
`A_frac`	in	sine amplitude as a fraction of full scale (default 1) (optional)	,
`SNR_dB`	out	signal-to-quantisation-noise ratio, dB	,
`noise_rms_lsb`	out	in-band noise rms in LSB	,
`SNR_full_scale_dB`	out	full-scale SNR without oversampling, dB	,

Applies when: uniform quantisation noise, white over Nyquist; OSR >= 1.

```
$ electronics-engineering solve elx_adc_quantization_snr n=12
SNR_dB = 74.00811155
noise_rms_lsb = 0.2886751346
SNR_full_scale_dB = 74.00811155
  by: ADC quantisation SNR with oversampling  (SNR = 20 log10(A 2^n sqrt(1.5)) + 10
log10(OSR) = 6.02 n + 1.76 + 20 log10 A + 10 log10 OSR)
  assumes: uniform quantisation noise, white over Nyquist; OSR >= 1
```

What the worked example means: The signal-to-quantisation-noise ratio is 74.0081 dB, with an in-band noise level of 0.288675 LSB.

Binary-weighted resistor DAC, `elx_dac_binary_weighted`

The output voltage and summing current of a binary-weighted resistor DAC with an inverting op-amp (MSB resistor R, each lower bit doubling it) and the largest resistor needed.

$$V_{out} = -V_{ref}\frac{R_f}{R}\sum_{k=0}^{n-1}\frac{b_k}{2^k} = -V_{ref}\frac{R_f}{R}\frac{D}{2^{n-1}}$$

symbol		meaning	SI unit
`n`	in	resolution in bits	,
`code`	in	input code (decimal)	,
`Vref`	in	reference voltage	V
`R`	in	MSB resistor	ohm
`Rf`	in	feedback resistor	ohm
`Vout`	out	output voltage	V
`I_total`	out	total current into the summing node	A
`R_LSB`	out	LSB resistor R 2^(n-1)	ohm

Applies when: ideal switches and op-amp.

```
$ electronics-engineering solve elx_dac_binary_weighted n=4 code=10 "Vref=5 V" "R=10000
ohm" "Rf=5000 ohm"
Vout = -3.125 V
I_total = 0.000625 A
R_LSB = 80000 ohm
  by: Binary-weighted resistor DAC  (I = Vref D/(R 2^(n-1)); Vout = -Rf I)
  Vref = 5 V
  R = 10000 ohm
  Rf = 5000 ohm
  assumes: ideal switches and op-amp
```

What the worked example means: This calculation determines the analog output voltage for a binary-weighted resistor digital-to-analog converter. By applying the input code to switches connected to resistors that double in value for each less significant bit, the circuit generates a proportional current at the summing node. The operational amplifier converts this current into a voltage using the feedback resistor. The resulting output voltage is -3.125 V, which reflects the magnitude of the digital input relative to the reference voltage 5 V. The total current flowing into the virtual ground is 0.000625 A, and the largest resistor required for the least significant bit is 80000 ohm.

DAC output voltage (R-2R or any binary DAC), `elx_dac_output`

The output voltage of an ideal n-bit unipolar DAC for a code, Vout = Vref D/2^n, its step size and its full-scale output.

$$V_{out} = V_{ref}\frac{D}{2^n}$$

symbol		meaning	SI unit
`n`	in	resolution in bits	,

symbol		meaning	SI unit
`code`	in	input code (decimal)	,
`Vref`	in	reference voltage	V
`Vout`	out	output voltage	V
`LSB`	out	step size Vref/2^n	V
`V_full_scale`	out	output for the all-ones code	V

Applies when: 0 <= code <= 2^n - 1.

```
$ electronics-engineering solve elx_dac_output n=8 code=200 "Vref=5 V"
Vout = 3.90625 V
LSB = 0.01953125 V
V_full_scale = 4.98046875 V
  by: DAC output voltage (R-2R or any binary DAC)  (Vout = Vref D/2^n; full scale Vref (2^n
- 1)/2^n)
  Vref = 5 V
  assumes: 0 <= code <= 2^n - 1
```

What the worked example means: This calculation determines the analog output voltage produced by an ideal n-bit digital-to-analog converter. Using the input code 200 and reference voltage 5 V, the resulting output is 3.90625 V. The resolution defines the smallest change in voltage, known as the least significant bit or LSB, which equals 0.0195312 V. The maximum possible output for this architecture, corresponding to the all-ones binary code, is 4.98047 V. These values characterize the performance limits and granularity of the conversion process.

Dual-slope integrating ADC, `elx_dual_slope_adc`

The fixed integration time, the de-integration time and count, and the peak integrator voltage of a dual-slope ADC.

$$T_2 = T_1 \frac{V_{in}}{V_{ref}}, \quad N_2 = N_1 \frac{V_{in}}{V_{ref}}$$

symbol		meaning	SI unit
`Vin`	in	input voltage (magnitude)	V
`Vref`	in	reference voltage (magnitude)	V
`N1`	in	fixed count of the integration phase	,
`fclk`	in	clock frequency	Hz
`R`	in	integrator resistor	ohm
`C`	in	integrator capacitor	F
`T1`	out	integration time N1/fclk	s
`T2`	out	de-integration time	s
`N2`	out	count of the de-integration phase (unrounded)	,
`V_peak`	out	peak integrator output	V

Applies when: 0 < Vin <= Vref.

```
$ electronics-engineering solve elx_dual_slope_adc "Vin=0.5 V" "Vref=1 V" N1=1000
"fclk=100000 Hz" "R=100000 ohm" "C=0.1 uF"
T1 = 0.01 s
T2 = 0.005 s
N2 = 500
V_peak = 0.5 V
  by: Dual-slope integrating ADC  (T1 = N1/fclk; T2 = T1 Vin/Vref; N2 = N1 Vin/Vref; V_peak
= Vin T1/(R C))
  Vin = 0.5 V
  Vref = 1 V
  fclk = 100000 Hz
  R = 100000 ohm
  C = 1e-07 F
  assumes: 0 < Vin <= Vref
```

What the worked example means: This calculation determines the timing and voltage characteristics of a dual-slope analog-to-digital converter. The fixed integration phase lasts for 0.01 s, which depends on the clock frequency and the initial count. During this phase, the integrator output rises to a peak value of 0.5 V. In the subsequent de-integration phase, the input voltage ratio dictates that the counter reaches 500 before the integrator returns to zero, establishing the digital result.

Effective number of bits (ENOB) from SINAD, `elx_adc_enob`

The effective number of bits of a converter from its measured SINAD (IEEE 1241: ENOB = (SINAD - 1.76)/6.02) and the bits lost against its nominal resolution.

$$\mathrm{ENOB} = \frac{\mathrm{SINAD} - 1.76}{6.02}$$

symbol		meaning	SI unit
`SINAD`	in	signal to noise and distortion ratio in dB	,
`n`	in	nominal resolution in bits	,
`ENOB`	out	effective number of bits	,
`bits_lost`	out	n - ENOB	,

Applies when: full-scale sine test.

```
$ electronics-engineering solve elx_adc_enob SINAD=74 n=14
ENOB = 12
bits_lost = 2
  by: Effective number of bits (ENOB) from SINAD  (ENOB = (SINAD - 1.76)/6.02)
  SINAD = 74
  assumes: full-scale sine test
```

What the worked example means: This calculation determines the actual performance of an analog-to-digital converter using its measured signal to noise and distortion ratio. By applying the standard formula, the effective number of bits is 12. This value represents the true dynamic range achieved during a full-scale sine wave test. When compared to the nominal resolution of 14 bits, the difference reveals that 2 bits of theoretical precision are compromised by noise and non-linear distortions in the system.

Sample-and-hold droop, `elx_sample_hold_droop`

The droop rate I/C of a sample-and-hold capacitor discharged by a leakage current, the droop over a hold time (in volts and LSB) and the longest hold that keeps the droop within half an LSB of an n-bit converter.

$$\frac{dV}{dt} = \frac{I_{leak}}{C}$$

symbol		meaning	SI unit
`I_leak`	in	leakage (bias) current	A
`C`	in	hold capacitor	F
`t_hold`	in	hold time	s
`Vref`	in	converter full scale	V
`n`	in	converter resolution in bits	,
`droop_rate`	out	droop rate I/C	V/s
`droop`	out	droop over the hold time	V
`droop_lsb`	out	droop in LSB	,
`t_max_half_lsb`	out	longest hold for half an LSB	s

Applies when: constant leakage current.

```
$ electronics-engineering solve elx_sample_hold_droop "I_leak=1 nA" "C=1 nF" "t_hold=10 us"
"Vref=5 V" n=12
droop_rate = 1 V/s
droop = 1e-05 V
droop_lsb = 0.008192
t_max_half_lsb = 0.0006103515625 s
  by: Sample-and-hold droop  (dV/dt = I/C; dV = I t/C; t_max = (Vref/2^(n+1)) C/I)
  I_leak = 1e-09 A
  C = 1e-09 F
  t_hold = 1e-05 s
  Vref = 5 V
  assumes: constant leakage current
```

What the worked example means: This calculation determines how quickly the voltage on the sample-and-hold capacitor falls due to leakage current. The droop rate, given as 1 V/s, is derived by dividing the leakage current by the capacitance. Over the specified hold time, this results in a total voltage loss of 1e-05 V. This value represents the error introduced into the signal before it is converted, which can be compared against the least significant bit size of the converter to assess accuracy.

SNR limit from sampling-clock (aperture) jitter, `elx_aperture_jitter_snr`

The SNR limit -20 log10(2 pi f tj) set by rms sampling-clock jitter for a full-scale sine, combined with the quantisation SNR of an n-bit converter into a total SNR and effective bits.

$$\mathrm{SNR}_j = -20\log_{10}(2\pi f t_j)$$

symbol		meaning	SI unit
`f`	in	input frequency	Hz
`tj`	in	rms clock jitter	s
`n`	in	converter resolution in bits	,
`SNR_jitter_dB`	out	jitter-limited SNR, dB	,
`SNR_quant_dB`	out	quantisation SNR, dB	,
`SNR_total_dB`	out	combined SNR, dB	,
`ENOB_total`	out	effective bits of the combination	,

Applies when: full-scale sine; jitter and quantisation noise uncorrelated.

```
$ electronics-engineering solve elx_aperture_jitter_snr "f=100000000 Hz" "tj=1 ps" n=14
SNR_jitter_dB = 64.03640263
SNR_quant_dB = 86.04931138
SNR_total_dB = 64.00916741
ENOB_total = 10.34039326
  by: SNR limit from sampling-clock (aperture) jitter  (SNR_j = -20 log10(2 pi f tj); SNR_q
= 6.02 n + 1.76; noise powers add)
  f = 100000000 Hz
  tj = 1e-12 s
  assumes: full-scale sine; jitter and quantisation noise uncorrelated
```

What the worked example means: This calculation determines the system performance by combining the noise limits imposed by sampling clock jitter and quantization. The jitter-limited signal-to-noise ratio is computed as 64.0364 dB based on the input frequency and rms clock jitter. Simultaneously, the quantization signal-to-noise ratio is established at 86.0493 dB for the converter resolution. Since these noise sources are uncorrelated, their powers add to produce a combined signal-to-noise ratio of 64.0092 dB, which translates to an effective number of bits of 10.3404.

Successive-approximation (SAR) ADC conversion, `elx_sar_conversion`

The bit-by-bit trial voltages, the final code (decimal and binary) and the DAC voltage of an ideal n-bit successive-approximation ADC converting an input.

$$b_k = \left[V_{in} \geq V_{DAC}(D_k + 2^k)\right]$$

symbol		meaning	SI unit
`Vin`	in	analog input	V
`Vref`	in	reference voltage	V
`n`	in	resolution in bits	,
`code`	out	final code	,
`bits`	out	final code in binary	,
`trials`	out	trial DAC voltages, MSB first (V)	,
`V_dac`	out	DAC voltage of the final code	V
`cycles`	out	comparison cycles	,

Applies when: 0 <= Vin < Vref.

```
$ electronics-engineering solve elx_sar_conversion "Vin=3.2 V" "Vref=5 V" n=4
code = 10
bits = 1010
trials = [2.5,3.75,3.125,3.4375]
V_dac = 3.125 V
cycles = 4
  by: Successive-approximation (SAR) ADC conversion  (for each bit from the MSB: set it,
keep it if Vin >= DAC(trial); LSB = Vref/2^n)
  Vin = 3.2 V
  Vref = 5 V
  assumes: 0 <= Vin < Vref
```

What the worked example means: This calculation determines the digital output of an ideal successive approximation register analog-to-digital converter. It processes the input voltage 3.2 V against the reference voltage 5 V over 4 resolution steps. The algorithm iteratively tests bit values, starting from the most significant bit, comparing the trial DAC voltage against the input. The final result is the digital code 10, represented in binary as 1010, along with the specific sequence of trial voltages [2.5, 3.75, 3.125, 3.4375] used during conversion. The settled DAC voltage corresponding to this code is 3.125 V, achieved after 4 comparison cycles.

Diodes (8)

Capacitor-input filter: ripple voltage and DC output, `elx_capacitor_filter_ripple`

The peak-to-peak ripple, the DC output, the RMS ripple and the ripple factor of a rectifier with a smoothing capacitor and resistive load (small-ripple approximation).

$$V_r = \frac{V_p}{f_r R_L C}, \quad V_{dc} = V_p - \frac{V_r}{2}$$

symbol		meaning	SI unit
`Vp`	in	peak rectified voltage (after the diode drops)	V
`f`	in	line frequency	Hz
`RL`	in	load resistance	ohm
`C`	in	filter capacitance	F
`circuit`	in	half-wave or full-wave rectification	,
`f_ripple`	out	ripple frequency	Hz
`Vr`	out	peak-to-peak ripple	V
`Vdc`	out	DC output voltage	V
`Vr_rms`	out	RMS ripple	V
`ripple_factor`	out	ripple factor	,

Applies when: Vr < Vp (small ripple).

```
$ electronics-engineering solve elx_capacitor_filter_ripple "Vp=16.3 V" "f=60 Hz" "RL=500
ohm" "C=1000 uF" circuit=full-wave
f_ripple = 120 Hz
Vr = 0.2716666667 V
Vdc = 16.16416667 V
Vr_rms = 0.07842341156 V
ripple_factor = 0.004851682934
  by: Capacitor-input filter: ripple voltage and DC output  (Vr = Vp/(f_r RL C); Vdc = Vp -
Vr/2; Vr,rms = Vr/(2 sqrt 3))
  Vp = 16.3 V
  f = 60 Hz
  RL = 500 ohm
  C = 0.001 F
  circuit = full-wave
  assumes: Vr < Vp (small ripple)
```

What the worked example means: This calculation determines the performance of a capacitor-input filter in a rectifier circuit. It computes the peak-to-peak ripple voltage, which is found to be 0.271667 V, and the resulting average direct current output voltage, calculated as 16.1642 V. These values indicate how effectively the smoothing capacitor reduces the pulsating nature of the rectified signal, with the ripple frequency being 120 Hz. The root mean square ripple is 0.0784234 V, providing a measure of the AC component's power relative to the DC level.

Diode current from the Shockley equation, `elx_shockley_diode_current`

The current of a pn-junction diode at a terminal voltage from its saturation current, ideality factor and temperature (forward or reverse).

$$I_D = I_S \left(e^{V_D / n V_T} - 1 \right)$$

symbol		meaning	SI unit
`Is`	in	saturation current	A
`n`	in	ideality (emission) factor, 1 to 2	,
`VD`	in	diode voltage (negative for reverse bias)	V
`T`	in	junction temperature	K
`ID`	out	diode current	A
`VT`	out	thermal voltage	V

Applies when: Is, n, T > 0.

```
$ electronics-engineering solve elx_shockley_diode_current "Is=1e-14 A" n=1 "VD=0.65 V"
"T=300 K"
ID = 0.0008308438348 A
VT = 0.02585199979 V
  by: Diode current from the Shockley equation  (ID = Is (exp(VD/(n VT)) - 1), VT = kT/q)
  Is = 1e-14 A
  n = 1
  VD = 0.65 V
  T = 300 K
  assumes: Is, n, T > 0
```

What the worked example means: This calculation determines the current flowing through a pn-junction diode using the Shockley equation. It takes the saturation current, ideality factor, applied voltage, and temperature to compute the resulting diode current and the intermediate thermal voltage. For the given inputs, the calculated diode current is 0.000830844 A and the thermal voltage is 0.025852 V, representing the expected behavior of the junction under these specific electrical and thermal conditions.

Diode voltage for a given current, `elx_diode_voltage`

The voltage across a pn-junction diode carrying a given current (the inverse of the Shockley equation).

$$V_D = nV_T \ln\left(1 + \frac{I_D}{I_S}\right)$$

symbol		meaning	SI unit
`ID`	in	diode current	A
`Is`	in	saturation current	A
`n`	in	ideality factor	,
`T`	in	junction temperature	K
`VD`	out	diode voltage	V
`VT`	out	thermal voltage	V

Applies when: ID > -Is; Is, n, T > 0.

```
$ electronics-engineering solve elx_diode_voltage "ID=0.001 A" "Is=1e-14 A" n=1 "T=300 K"
VD = 0.6547907227 V
VT = 0.02585199979 V
  by: Diode voltage for a given current  (VD = n VT ln(1 + ID/Is))
  ID = 0.001 A
  Is = 1e-14 A
  n = 1
  T = 300 K
  assumes: ID > -Is; Is, n, T > 0
```

What the worked example means: This calculation determines the voltage drop across a pn-junction diode, resulting in 0.654791 V, based on an input current of 0.001 A, a saturation current of 1e-14 A, an ideality factor of 1, and a junction temperature of 300 K Kelvin. The thermal voltage used in this computation is 0.025852 V. This value represents the specific operating point where the diode conducts the given current under these physical conditions.

LED series (current-limiting) resistor, `elx_led_series_resistor`

The current-limiting resistor for one LED or a string of LEDs in series at a chosen forward current, and the power in the resistor and in the LEDs.

$$R = \frac{V_S - n V_F}{I_F}$$

symbol		meaning	SI unit
`Vs`	in	supply voltage	V
`Vf`	in	forward voltage of one LED	V
`If`	in	LED forward current	A
`n`	in	number of LEDs in series (default 1) (optional)	,
`R`	out	series resistance	ohm
`P_R`	out	power in the resistor	W
`P_LED`	out	power in the LEDs	W

Applies when: Vs > n Vf; If > 0.

```
$ electronics-engineering solve elx_led_series_resistor "Vs=5 V" "Vf=2 V" "If=20 mA"
R = 150 ohm
P_R = 0.06 W
P_LED = 0.04 W
  by: LED series (current-limiting) resistor  (R = (Vs - n Vf)/If; P_R = If^2 R)
  Vs = 5 V
  Vf = 2 V
  If = 0.02 A
  assumes: Vs > n Vf; If > 0
```

What the worked example means: The required series resistance is 150 ohm and the power dissipated in that resistor is 0.06 W.

Operating point of a diode in series with a resistor (exact), `elx_diode_operating_point`

The current and voltage of a forward-biased diode fed from a DC source through a resistor, solving the Shockley equation and Kirchhoff's voltage law together (no constant-drop approximation).

$$V_S = I_D R + n V_T \ln\left(1 + \frac{I_D}{I_S}\right)$$

symbol		meaning	SI unit
`VS`	in	source voltage	V
`R`	in	series resistance	ohm
`Is`	in	saturation current	A
`n`	in	ideality factor	,
`T`	in	junction temperature	K

symbol		meaning	SI unit
`ID`	out	diode current	A
`VD`	out	diode voltage	V
`P_D`	out	power in the diode	W

Applies when: VS > 0 (forward bias); R, Is, n, T > 0.

```
$ electronics-engineering solve elx_diode_operating_point "VS=5 V" "R=1000 ohm" "Is=1e-14
A" n=1 "T=300 K"
ID = 0.004307456373 A
VD = 0.6925436275 V
P_D = 0.002983101461 W
  by: Operating point of a diode in series with a resistor (exact)  (solve VS = ID R + n VT
ln(1 + ID/Is) (bisection on VD))
  VS = 5 V
  R = 1000 ohm
  Is = 1e-14 A
  n = 1
  T = 300 K
  assumes: VS > 0 (forward bias); R, Is, n, T > 0
```

What the worked example means: This calculation determines the exact operating point of a forward-biased diode connected in series with a resistor to a DC source. By solving Kirchhoff's voltage law alongside the Shockley diode equation, for a source voltage of 5 V, resistance of 1000 ohm, saturation current of 1e-14 A, ideality factor of 1, and temperature of 300 K, the resulting diode current is 0.00430746 A and the diode voltage is 0.692544 V. This method avoids the common constant-voltage-drop approximation, providing a more precise analysis of the circuit behavior.

Rectifier output: average, RMS, ripple factor and PIV, `elx_rectifier_averages`

The DC (average) and RMS output voltage, ripple factor, peak inverse voltage and conduction angle of an unfiltered half-wave, bridge or centre-tapped full-wave rectifier with a constant diode drop (0 V for ideal diodes).

$$V_{dc} = \frac{k}{2\pi}[2V_m\cos\theta_1 - V(\pi - 2\theta_1)],\ \theta_1 = \arcsin\frac{V}{V_m}$$

symbol		meaning	SI unit
`Vm`	in	peak AC voltage of the (secondary) winding	V
`circuit`	in	half-wave, bridge or center-tapped (Vm per half of the winding)	,
`Von`	in	forward drop of one diode (0 V for ideal diodes)	V
`Vp_out`	out	peak output voltage	V
`Vdc`	out	average output voltage	V
`Vrms`	out	RMS output voltage	V
`ripple_factor`	out	ripple factor (AC rms / DC)	,
`PIV`	out	peak inverse voltage of a diode	V
`conduction_deg`	out	conduction angle per half cycle, degrees	,

Applies when: diode drops below Vm; resistive load, no filter.

```
$ electronics-engineering solve elx_rectifier_averages "Vm=10 V" circuit=half-wave "Von=0
V"
Vp_out = 10 V
Vdc = 3.183098862 V
Vrms = 5 V
ripple_factor = 1.211363323
PIV = 10 V
conduction_deg = 180
  by: Rectifier output: average, RMS, ripple factor and PIV  (output max(0, Vm|sin| - V)
with V = Von (2 Von for a bridge); averages integrated exactly; PIV Vm, Vm - Von, 2Vm -
Von)
  Vm = 10 V
  Von = 0 V
  circuit = half-wave
  assumes: diode drops below Vm; resistive load, no filter
```

What the worked example means: This calculation determines the average and RMS output voltages, ripple factor, and peak inverse voltage for a rectifier circuit using inputs such as the peak AC voltage 10 V, the diode forward drop 0 V, and the specific topology half-wave. The resulting average DC voltage is 3.1831 V, while the RMS value is 5 V, indicating the effective heating potential of the output. The peak inverse voltage across the non-conducting diodes is 10 V, which is critical for selecting components that can withstand reverse bias without breaking down.

Zener regulator design: series resistor and Zener rating, `elx_zener_series_resistor_design`

The largest series resistance that keeps a Zener regulator in regulation at the lowest input and largest load, and the resulting worst-case Zener current and power (highest input, smallest load) and resistor power.

$$R_S = \frac{V_{in,min} - V_Z}{I_{Z,min} + I_{L,max}}$$

symbol		meaning	SI unit
`Vin_min`	in	lowest input voltage	V
`Vin_max`	in	highest input voltage	V
`Vz`	in	Zener voltage	V
`IL_min`	in	smallest load current	A
`IL_max`	in	largest load current	A
`Iz_min`	in	minimum Zener current for regulation	A
`Rs_max`	out	largest series resistance	ohm
`Iz_max`	out	worst-case Zener current	A
`Pz_max`	out	worst-case Zener power	W
`PRs_max`	out	worst-case resistor power	W

Applies when: Vin_min > Vz; Vin_max >= Vin_min, IL_max >= IL_min >= 0.

```
$ electronics-engineering solve elx_zener_series_resistor_design "Vin_min=12 V" "Vin_max=15
V" "Vz=9.1 V" "IL_min=0 mA" "IL_max=50 mA" "Iz_min=5 mA"
Rs_max = 52.72727273 ohm
Iz_max = 0.1118965517 A
Pz_max = 1.018258621 W
PRs_max = 0.6601896552 W
  by: Zener regulator design: series resistor and Zener rating  (Rs = (Vin,min -
Vz)/(Iz,min + IL,max); Iz,max = (Vin,max - Vz)/Rs - IL,min; Pz = Vz Iz,max)
  Vin_min = 12 V
  Vin_max = 15 V
  Vz = 9.1 V
  IL_min = 0 A
  IL_max = 0.05 A
  Iz_min = 0.005 A
  assumes: Vin_min > Vz; Vin_max >= Vin_min, IL_max >= IL_min >= 0
```

What the worked example means: This calculation determines the maximum allowable value for the series resistor, which is 52.7273 ohm, to ensure the Zener diode remains in regulation under the most demanding conditions. Using this resistance, the worst-case Zener current reaches 0.111897 A, leading to a peak power dissipation of 1.01826 W in the diode and 0.66019 W in the resistor. These values are derived from the lowest input voltage, highest load current, and minimum required Zener current, ensuring the circuit functions safely across its operating range.

Zener shunt regulator: load voltage and currents, `elx_zener_regulator`

The output voltage and the source, load and Zener currents and the Zener power of a Zener shunt regulator (series resistor, Zener across the load), with an optional Zener resistance.

$$I_Z = \frac{V_{in} - V_Z}{R_S} - \frac{V_Z}{R_L}$$

symbol		meaning	SI unit
`Vin`	in	input voltage	V
`Rs`	in	series resistance	ohm
`Vz`	in	Zener (breakdown) voltage	V
`RL`	in	load resistance	ohm
`rz`	in	Zener resistance (0 for an ideal Zener) (optional)	ohm
`Vout`	out	load voltage	V
`I_s`	out	current in the series resistor	A
`I_L`	out	load current	A
`I_z`	out	Zener current	A
`P_z`	out	Zener power	W

Applies when: the Zener must be in breakdown: Vin RL/(Rs + RL) > Vz.

```
$ electronics-engineering solve elx_zener_regulator "Vin=20 V" "Rs=220 ohm" "Vz=10 V"
"RL=1000 ohm"
Vout = 10 V
I_s = 0.04545454545 A
I_L = 0.01 A
I_z = 0.03545454545 A
P_z = 0.3545454545 W
  by: Zener shunt regulator: load voltage and currents  (ideal: Vout = Vz, Iz = (Vin -
Vz)/Rs - Vz/RL; with rz: node equation at the load)
  Vin = 20 V
  Rs = 220 ohm
  Vz = 10 V
  RL = 1000 ohm
  assumes: the Zener must be in breakdown: Vin RL/(Rs + RL) > Vz
```

What the worked example means: This calculation determines the operating point of a Zener shunt regulator using an input voltage of 20 V, series resistance of 220 ohm, Zener voltage of 10 V, and load resistance of 1000 ohm. The resulting load voltage is 10 V, which is maintained by the Zener diode if it remains in breakdown. The total current drawn from the source through the series resistor is 0.0454545 A, split between the load current of 0.01 A and the Zener current of 0.0354545 A. The Zener dissipates 0.354545 W watts, a critical value for thermal management.

MOSFET (6)

Common-source amplifier with source degeneration and ro, `elx_common_source_amplifier`

The voltage gain, input and output resistances and overall gain of a common-source stage, exact with the transistor's output resistance ro and an optional unbypassed source resistor.

$$A_v = -\frac{g_m r_o R'_D}{R'_D + r_o + R_S(1 + g_m r_o)}$$

symbol		meaning	SI unit
`gm`	in	transconductance	S
`ro`	in	transistor output resistance	ohm
`RD`	in	drain resistor	ohm
`RL`	in	load resistor	ohm
`RS`	in	unbypassed source resistance (0 if bypassed)	ohm
`RG`	in	gate bias resistance	ohm
`Rsig`	in	source resistance	ohm
`Av`	out	voltage gain gate to output	,
`Rin`	out	input resistance	ohm
`Rout`	out	output resistance (excluding RL)	ohm
`Gv`	out	overall gain from the source	,

Applies when: gm, ro, RD, RL, RG, Rsig > 0; RS >= 0.

```
$ electronics-engineering solve elx_common_source_amplifier "gm=2 mS" "ro=100000 ohm"
"RD=10000 ohm" "RL=10000 ohm" "RS=0 ohm" "RG=1000000 ohm" "Rsig=10000 ohm"
Av = -9.523809524
Rin = 1000000 ohm
Rout = 9090.909091 ohm
Gv = -9.42951438
  by: Common-source amplifier with source degeneration and ro  (Av = -gm ro RD'/(RD' + ro +
RS (1 + gm ro)) with RD' = RD || RL; Rout = RD || (ro + RS(1 + gm ro)))
  gm = 0.002 S
  ro = 100000 ohm
  RD = 10000 ohm
  RL = 10000 ohm
  RS = 0 ohm
  RG = 1000000 ohm
  Rsig = 10000 ohm
  assumes: gm, ro, RD, RL, RG, Rsig > 0; RS >= 0
```

What the worked example means: This calculation determines the small-signal performance of a common-source amplifier stage that includes transistor output resistance and optional source degeneration. Using the transconductance, internal resistances, and external load values, the model computes the exact voltage gain from gate to drain as -9.52381, the input resistance seen at the gate as 1e+06 ohm, and the output resistance looking into the drain as 9090.91 ohm. The overall gain from the signal source is found to be -9.42951, reflecting the loading effects of the source and bias networks.

MOSFET drain current (cutoff, triode, saturation), `elx_mosfet_drain_current`

The operating region and drain current of an enhancement NMOS transistor by the square law: cutoff, triode or saturation with optional channel-length modulation (use magnitudes for PMOS).

$$I_D = \begin{cases} k_n \left(V_{OV} V_{DS} - \frac{1}{2} V_{DS}^2\right) & V_{DS} < V_{OV} \\ \frac{1}{2} k_n V_{OV}^2 (1 + \lambda V_{DS}) & V_{DS} \geq V_{OV} \end{cases}$$

symbol		meaning	SI unit
`kn`	in	process transconductance times aspect ratio, mu Cox W/L	A/V^2
`Vt`	in	threshold voltage	V
`VGS`	in	gate-source voltage	V
`VDS`	in	drain-source voltage	V
`lam`	in	channel-length modulation lambda (default 0) (optional)	1/V
`region`	out	cutoff, triode or saturation	,
`ID`	out	drain current	A
`VOV`	out	overdrive VGS - Vt	V
`VDS_sat`	out	saturation voltage	V

Applies when: kn, Vt > 0; VDS >= 0; long-channel square law.

```
$ electronics-engineering solve elx_mosfet_drain_current "kn=2 mA/V^2" "Vt=1 V" "VGS=3 V"
"VDS=5 V"
region = saturation
ID = 0.004 A
VOV = 2 V
VDS_sat = 2 V
  by: MOSFET drain current (cutoff, triode, saturation)  (cutoff VOV <= 0; triode VDS <
VOV: ID = kn (VOV VDS - VDS^2/2); saturation: ID = (kn/2) VOV^2 (1 + lambda VDS))
  kn = 0.002 A/V^2
  Vt = 1 V
  VGS = 3 V
  VDS = 5 V
  assumes: kn, Vt > 0; VDS >= 0; long-channel square law
```

What the worked example means: This calculation determines the operating state and drain current for an enhancement mode NMOS transistor. By comparing the gate source voltage to the threshold voltage, the overdrive voltage is 2 V. The saturation boundary occurs at 2 V. Since the actual drain source voltage is 5 V, the device falls into the saturation mode. Consequently, the resulting drain current is calculated as 0.004 A, reflecting the square law relationship modified by channel length modulation if applicable.

MOSFET small-signal gm, ro and intrinsic gain, `elx_mosfet_gm_ro`

The overdrive voltage, gate-source voltage, transconductance gm = sqrt(2 kn ID), output resistance ro = 1/(lambda ID) and intrinsic gain of a MOSFET in saturation at a drain current.

$$g_m = \sqrt{2 k_n I_D} = \frac{2 I_D}{V_{OV}}, \quad r_o = \frac{1}{\lambda I_D}$$

symbol		meaning	SI unit
`kn`	in	mu Cox W/L	A/V^2
`ID`	in	drain bias current	A
`lam`	in	channel-length modulation lambda	1/V
`Vt`	in	threshold voltage	V
`VOV`	out	overdrive voltage	V
`VGS`	out	gate-source voltage	V
`gm`	out	transconductance	S
`r_o`	out	output resistance	ohm
`A0`	out	intrinsic gain gm r_o	,

Applies when: saturation; ID taken without the (1 + lambda VDS) factor.

```
$ electronics-engineering solve elx_mosfet_gm_ro "kn=2 mA/V^2" "ID=1 mA" "lam=0.01 1/V"
"Vt=0.7 V"
VOV = 1 V
VGS = 1.7 V
gm = 0.002 S
r_o = 100000 ohm
A0 = 200
  by: MOSFET small-signal gm, ro and intrinsic gain  (VOV = sqrt(2 ID/kn); gm = sqrt(2 kn
ID) = 2 ID/VOV; ro = 1/(lambda ID))
  kn = 0.002 A/V^2
  ID = 0.001 A
  lam = 0.01 1/V
  Vt = 0.7 V
  assumes: saturation; ID taken without the (1 + lambda VDS) factor
```

What the worked example means: This calculation determines the small-signal parameters of a MOSFET biased in saturation. Using the drain current 1 mA and process parameter kn, the overdrive voltage VOV is found to be 1 V, leading to a gate-source voltage VGS of 1.7 V. The transconductance gm, representing the change in drain current per unit change in gate voltage, computes to 0.002 S. Simultaneously, the output resistance ro, which models the effect of channel-length modulation via lambda, is calculated as 100000 ohm. The product of these two values yields the intrinsic gain A0 of 200, indicating the maximum voltage amplification capability of the transistor without external load effects.

MOSFET threshold voltage with body effect, `elx_mosfet_body_effect`

The threshold voltage of a MOSFET whose source is above its body, Vt = Vt0 + gamma (sqrt(2 phiF + VSB) - sqrt(2 phiF)).

$$V_t = V_{t0} + \gamma \left(\sqrt{2\phi_F + V_{SB}} - \sqrt{2\phi_F} \right)$$

symbol		meaning	SI unit
`Vt0`	in	zero-bias threshold voltage	V
`gamma`	in	body-effect coefficient in V^0.5	,
`phi2F`	in	surface potential 2 phi_F (about 0.6 to 0.9 V)	V
`VSB`	in	source-body voltage	V
`Vt`	out	threshold voltage	V
`dVt`	out	threshold increase	V

Applies when: VSB >= 0; uniform substrate doping.

```
$ electronics-engineering solve elx_mosfet_body_effect "Vt0=0.7 V" gamma=0.4 "phi2F=0.7 V"
"VSB=3 V"
Vt = 1.134751352 V
dVt = 0.4347513519 V
  by: MOSFET threshold voltage with body effect  (Vt = Vt0 + gamma (sqrt(2 phiF + VSB) -
sqrt(2 phiF)))
  Vt0 = 0.7 V
  gamma = 0.4
  phi2F = 0.7 V
  VSB = 3 V
  assumes: VSB >= 0; uniform substrate doping
```

In the worked example, Vt0 = 0.7 V, gamma = 0.4, phi2F = 0.7 V, VSB = 3 V go through the equation above and give Vt = 1.134751352 V, dVt = 0.4347513519 V. It applies only when VSB >= 0; uniform substrate doping: outside that it says what is wrong instead of returning a number.

MOSFET voltage-divider bias with source resistor: Q-point, `elx_mosfet_divider_bias`

The Q-point (gate voltage, VGS, drain current, node voltages and VDS) of an NMOS stage with a gate divider and a source resistor, solving the square law and the gate loop (the physical root), with a saturation check.

$$V_{OV} = \frac{2(V_G - V_t)}{1 + \sqrt{1 + 2k_n R_S (V_G - V_t)}}, \quad I_D = \tfrac{1}{2} k_n V_{OV}^2$$

symbol		meaning	SI unit
`VDD`	in	supply voltage	V
`R1`	in	upper gate resistor	ohm
`R2`	in	lower gate resistor	ohm
`RD`	in	drain resistor	ohm
`RS`	in	source resistor (0 allowed)	ohm
`kn`	in	mu Cox W/L	A/V^2
`Vt`	in	threshold voltage	V
`VG`	out	gate voltage	V
`VGS`	out	gate-source voltage	V
`VOV`	out	overdrive	V
`ID`	out	drain current	A
`VS`	out	source voltage	V
`VD`	out	drain voltage	V
`VDS`	out	drain-source voltage	V

Applies when: VG > Vt; saturation: VDS >= VOV (otherwise refused); lambda neglected.

```
$ electronics-engineering solve elx_mosfet_divider_bias "VDD=15 V" "R1=1000000 ohm"
"R2=500000 ohm" "RD=3300 ohm" "RS=1000 ohm" "kn=2 mA/V^2" "Vt=1.5 V"
VG = 5 V
VGS = 2.936491673 V
VOV = 1.436491673 V
ID = 0.002063508327 A
VS = 2.063508327 V
VD = 8.190422521 V
VDS = 6.126914194 V
  by: MOSFET voltage-divider bias with source resistor: Q-point  (VG = VDD R2/(R1 + R2);
(kn RS/2) VOV^2 + VOV - (VG - Vt) = 0, positive root; ID = (kn/2) VOV^2)
  VDD = 15 V
  R1 = 1000000 ohm
  R2 = 500000 ohm
  RD = 3300 ohm
  RS = 1000 ohm
  kn = 0.002 A/V^2
  Vt = 1.5 V
  assumes: VG > Vt; saturation: VDS >= VOV (otherwise refused); lambda neglected
```

In the worked example, VDD = 15 V, R1 = 1000000 ohm, R2 = 500000 ohm, RD = 3300 ohm, RS = 1000 ohm, kn = 2 mA/V^2, Vt = 1.5 V go through the equation above and give VG = 5 V, VGS = 2.936491673 V, VOV = 1.436491673 V, ID = 0.002063508327 A. It applies only when VG > Vt; saturation: VDS >= VOV (otherwise refused); lambda neglected: outside that it says what is wrong instead of returning a number.

Source follower (common drain), `elx_source_follower`

The voltage gain, input resistance, output resistance and overall gain of a MOSFET source follower, including ro.

$$A_v = \frac{g_m R}{1 + g_m R}, \quad R_{out} = R_S \parallel r_o \parallel \frac{1}{g_m}$$

symbol		meaning	SI unit
`gm`	in	transconductance	S
`ro`	in	transistor output resistance	ohm
`RS`	in	source resistor	ohm
`RL`	in	load resistor	ohm
`RG`	in	gate bias resistance	ohm
`Rsig`	in	source resistance	ohm
`Av`	out	voltage gain gate to output	,
`Rin`	out	input resistance	ohm
`Rout`	out	output resistance	ohm
`Gv`	out	overall gain	,

Applies when: drain at signal ground.

```
$ electronics-engineering solve elx_source_follower "gm=2 mS" "ro=50000 ohm" "RS=2000 ohm"
"RL=2000 ohm" "RG=1000000 ohm" "Rsig=10000 ohm"
Av = 0.6622516556
Rin = 1000000 ohm
Rout = 396.8253968 ohm
Gv = 0.6556947085
  by: Source follower (common drain)  (Av = gm R/(1 + gm R) with R = RS || RL || ro; Rout =
RS || ro || 1/gm)
  gm = 0.002 S
  ro = 50000 ohm
  RS = 2000 ohm
  RL = 2000 ohm
  RG = 1000000 ohm
  Rsig = 10000 ohm
  assumes: drain at signal ground
```

What the worked example means: This calculation determines the small-signal characteristics of a MOSFET configured as a source follower. Using the transconductance, output resistance, source resistor, and load resistor, this gives the effective parallel resistance seen at the source. The voltage gain is found to be 0.662252, which is always slightly less than one because the gain formula divides the product of transconductance and resistance by that product plus one. The input resistance is 1e+06 ohm, primarily set by the gate bias resistor since the gate draws no DC current. The output resistance is calculated as 396.825 ohm, representing the parallel combination of the source resistor, the transistor's internal output resistance, and the inverse of the transconductance. Finally, the overall gain from the signal source to the load is 0.655695, which accounts for the voltage division between the signal source resistance and the amplifier's input resistance.

Op-amps (14)

Closed-loop bandwidth from the gain-bandwidth product, `elx_closed_loop_bandwidth`

The closed-loop gain, the noise gain 1 + Rf/R1 and the -3 dB bandwidth GBW/(noise gain) of an inverting or non-inverting amplifier built with a single-pole op-amp.

$$f_{3dB} = \frac{\mathrm{GBW}}{1 + R_f / R_1}$$

symbol		meaning	SI unit
`GBW`	in	gain-bandwidth product (unity-gain frequency)	Hz
`config`	in	inverting or non-inverting amplifier	,
`Rf`	in	feedback resistor	ohm
`R1`	in	input (or ground) resistor	ohm
`G0`	out	low-frequency closed-loop gain	,
`noise_gain`	out	noise gain 1 + Rf/R1	,
`f_3dB`	out	closed-loop -3 dB bandwidth	Hz

Applies when: single-pole op-amp with open-loop gain much larger than the closed-loop gain.

```
$ electronics-engineering solve elx_closed_loop_bandwidth "GBW=1000000 Hz" config=non-
inverting "Rf=90000 ohm" "R1=10000 ohm"
G0 = 10
noise_gain = 10
f_3dB = 100000 Hz
  by: Closed-loop bandwidth from the gain-bandwidth product  (f_3dB = GBW/(1 + Rf/R1) for
both configurations)
  GBW = 1000000 Hz
  Rf = 90000 ohm
  R1 = 10000 ohm
  config = non-inverting
  assumes: single-pole op-amp with open-loop gain much larger than the closed-loop gain
```

What the worked example means: This calculation determines the frequency at which the amplifier's response drops by three decibels. It uses the op-amp's gain-bandwidth product, given as 1e+06 Hz, divided by the circuit's noise gain. The noise gain is calculated as one plus the ratio of the feedback resistor 90000 ohm to the input resistor 10000 ohm. The resulting bandwidth is 100000 Hz. This value indicates how fast the amplifier can respond to changes in the input signal before its gain begins to roll off.

Inverting amplifier with finite open-loop gain, `elx_inverting_amplifier_finite_gain`

The exact closed-loop gain of an inverting amplifier built with an op-amp of finite open-loop gain A0, its relative gain error and output.

$$G = \frac{-R_f/R_1}{1 + \dfrac{1 + R_f/R_1}{A_0}}$$

symbol		meaning	SI unit
`Rf`	in	feedback resistor	ohm
`R1`	in	input resistor	ohm
`A0`	in	open-loop voltage gain (a ratio, not dB)	,
`Vin`	in	input voltage	V
`G`	out	closed-loop gain	,
`G_ideal`	out	ideal gain -Rf/R1	,
`Vout`	out	output voltage	V
`error`	out	relative gain error 1 - G/G_ideal	,

Applies when: A0 > 0 (ratio); infinite input resistance, zero output resistance.

```
$ electronics-engineering solve elx_inverting_amplifier_finite_gain "Rf=100000 ohm"
"R1=1000 ohm" A0=10000 "Vin=0.01 V"
G = -99.000099
G_ideal = -100
Vout = -0.99000099 V
error = 0.009999009999
  by: Inverting amplifier with finite open-loop gain  (G = -(Rf/R1)/(1 + (1 + Rf/R1)/A0))
  Rf = 100000 ohm
  R1 = 1000 ohm
  A0 = 10000
  Vin = 0.01 V
  assumes: A0 > 0 (ratio); infinite input resistance, zero output resistance
```

What the worked example means: This calculation determines the precise performance of an inverting amplifier when the operational amplifier's open-loop gain is finite rather than infinite. Using the feedback resistor value 100000 ohm, the input resistor value 1000 ohm, and the open-loop voltage gain ratio 10000, the model computes the actual closed-loop gain as -99.0001. This result is compared against the theoretical ideal gain of -100 to quantify the deviation, yielding a relative gain error of 0.00999901. The output voltage produced by this configuration for an input of 0.01 V is calculated as -0.990001 V.

Inverting op-amp amplifier, `elx_inverting_amplifier`

The closed-loop gain, output voltage and input resistance of an ideal inverting amplifier.

$$V_{out} = -\frac{R_f}{R_{in}} V_{in}$$

symbol		meaning	SI unit
`Rf`	in	feedback resistor	ohm
`Rin`	in	input resistor	ohm
`Vin`	in	input voltage	V
`G`	out	closed-loop gain -Rf/Rin	,
`Vout`	out	output voltage	V
`Zin`	out	input resistance	ohm

Applies when: ideal op-amp, output not saturated.

```
$ electronics-engineering solve elx_inverting_amplifier "Rf=100000 ohm" "Rin=10000 ohm"
"Vin=0.5 V"
G = -10
Vout = -5 V
Zin = 10000 ohm
  by: Inverting op-amp amplifier  (G = -Rf/Rin; Vout = G Vin; Zin = Rin)
  Rf = 100000 ohm
  Rin = 10000 ohm
  Vin = 0.5 V
  assumes: ideal op-amp, output not saturated
```

What the worked example means: This calculation determines the performance of an ideal inverting operational amplifier circuit. Using the feedback resistor value of 100000 ohm and the input resistor value of 10000 ohm, the closed-loop gain is found to be -10. When the input voltage is 0.5 V, the resulting output voltage is -5 V. The input resistance seen by the signal source is equal to the input resistor, calculated as 10000 ohm. These values assume the op-amp is operating within its linear region without saturation.

Inverting Schmitt trigger thresholds, `elx_schmitt_trigger`

The upper and lower switching thresholds, the hysteresis width and the centre of an inverting op-amp Schmitt trigger whose positive feedback divider (Rf from the output, R1 to a reference) sets the + input.

$$V_{TH,TL} = \frac{V_{sat} R_1 + V_{ref} R_f}{R_1 + R_f}$$

symbol		meaning	SI unit
`Rf`	in	resistor from the output to the + input	ohm
`R1`	in	resistor from the + input to Vref	ohm
`VsatH`	in	high output saturation voltage	V
`VsatL`	in	low output saturation voltage (negative for a split supply)	V
`Vref`	in	reference voltage (0 V for ground)	V
`V_TH`	out	upper threshold	V
`V_TL`	out	lower threshold	V
`hysteresis`	out	hysteresis width	V
`center`	out	centre of the hysteresis band	V

Applies when: VsatH > VsatL; input on the inverting terminal.

```
$ electronics-engineering solve elx_schmitt_trigger "Rf=90000 ohm" "R1=10000 ohm" "VsatH=12
V" "VsatL=-12 V" "Vref=0 V"
V_TH = 1.2 V
V_TL = -1.2 V
hysteresis = 2.4 V
center = 0 V
  by: Inverting Schmitt trigger thresholds  (V_T = (Vsat R1 + Vref Rf)/(R1 + Rf);
hysteresis = (VsatH - VsatL) R1/(R1 + Rf))
  Rf = 90000 ohm
  R1 = 10000 ohm
  VsatH = 12 V
  VsatL = -12 V
  Vref = 0 V
  assumes: VsatH > VsatL; input on the inverting terminal
```

What the worked example means: This calculation determines the switching points for an inverting Schmitt trigger using positive feedback. The upper threshold 1.2 V and lower threshold -1.2 V are derived from the saturation voltages, reference voltage, and resistor divider network. The difference between these thresholds defines the hysteresis band 2.4 V, which prevents rapid output toggling when the input signal contains noise or slowly crosses the decision boundary.

Inverting summing amplifier, `elx_summing_amplifier`

The output of an ideal inverting summing amplifier with several inputs, each through its own resistor, and the feedback current.

$$V_{out} = -R_f \sum_i \frac{V_i}{R_i}$$

symbol		meaning	SI unit
`V`	in	input voltages in volts	,
`R`	in	input resistors in kilohms, one per input	,
`Rf`	in	feedback resistor	ohm
`Vout`	out	output voltage	V
`I_f`	out	current through the feedback resistor	A

Applies when: one resistor per input; ideal op-amp.

```
$ electronics-engineering solve elx_summing_amplifier "V=[1, 2, -0.5]" "R=[10, 20, 5]"
"Rf=10000 ohm"
Vout = -1 V
I_f = 0.0001 A
  by: Inverting summing amplifier  (Vout = -Rf sum(Vi/Ri))
  Rf = 10000 ohm
  assumes: one resistor per input; ideal op-amp
```

What the worked example means: This calculation determines the behavior of an ideal inverting summing amplifier. Using the input voltages [1, 2, -0.5] and their corresponding input resistors [10, 20, 5], along with the feedback resistor 10000 ohm, the circuit produces a specific output voltage -1 V. The result represents the weighted sum of the inputs, inverted by the op-amp action, while the feedback current 0.0001 A reflects the total current flowing through the feedback path.

Negative feedback: closed-loop gain and bandwidth extension, `elx_negative_feedback`

The closed-loop gain A/(1 + A beta), the loop gain, the desensitivity factor (also in dB) and the extended bandwidth of a single-pole amplifier with negative feedback.

$$A_f = \frac{A}{1 + A\beta}, \quad f_{H,f} = f_H(1 + A\beta)$$

symbol		meaning	SI unit
`A`	in	open-loop gain (a ratio)	,
`beta`	in	feedback factor (a ratio)	,
`fH`	in	open-loop -3 dB bandwidth	Hz
`Af`	out	closed-loop gain	,
`loop_gain`	out	loop gain A beta	,
`desensitivity`	out	1 + A beta	,

symbol		meaning	SI unit
`desensitivity_dB`	out	amount of feedback in dB	,
`fH_closed`	out	closed-loop bandwidth	Hz

Applies when: single-pole open-loop response; frequency-independent beta.

```
$ electronics-engineering solve elx_negative_feedback A=10000 beta=0.01 "fH=1000 Hz"
Af = 99.00990099
loop_gain = 100
desensitivity = 101
desensitivity_dB = 40.08642748
fH_closed = 101000 Hz
  by: Negative feedback: closed-loop gain and bandwidth extension  (Af = A/(1 + A beta);
fH,f = fH (1 + A beta))
  A = 10000
  beta = 0.01
  fH = 1000 Hz
  assumes: single-pole open-loop response; frequency-independent beta
```

What the worked example means: This calculation determines the performance of a single-pole amplifier with negative feedback. Using an open-loop gain of 10000, a feedback factor of 0.01, and an open-loop bandwidth of 1000 Hz Hz, it computes the resulting closed-loop gain as 99.0099. The loop gain is 100, leading to a desensitivity factor of 101, which represents 40.0864 dB of feedback. Consequently, the -3 dB bandwidth increases to 101000 Hz Hz, demonstrating the classic trade-off where reduced gain yields wider frequency response.

Non-inverting op-amp amplifier, `elx_noninverting_amplifier`

The closed-loop gain 1 + Rf/Rg and the output voltage of an ideal non-inverting amplifier.

$$V_{out} = \left(1 + \frac{R_f}{R_g}\right) V_{in}$$

symbol		meaning	SI unit
`Rf`	in	feedback resistor	ohm
`Rg`	in	resistor from the inverting input to ground	ohm
`Vin`	in	input voltage	V
`G`	out	closed-loop gain	,
`Vout`	out	output voltage	V

Applies when: ideal op-amp.

```
$ electronics-engineering solve elx_noninverting_amplifier "Rf=90000 ohm" "Rg=10000 ohm"
"Vin=0.3 V"
G = 10
Vout = 3 V
  by: Non-inverting op-amp amplifier  (G = 1 + Rf/Rg; Vout = G Vin)
  Rf = 90000 ohm
  Rg = 10000 ohm
  Vin = 0.3 V
  assumes: ideal op-amp
```

What the worked example means: This calculation determines the performance of a non-inverting operational amplifier configuration. Using the feedback resistor value 90000 ohm and the resistor to ground 10000 ohm, the closed-loop gain 10 is derived as one plus the ratio of these resistances. This gain factor is then applied to the input signal 0.3 V to calculate the resulting output voltage 3 V. The positive sign indicates that the output signal maintains the same phase relationship as the input, while the magnitude reflects the amplification level set by the external resistor network.

Op-amp difference amplifier (with resistor mismatch), `elx_difference_amplifier`

The output of a one-op-amp difference amplifier with any four resistors, and its differential and common-mode gains (the common-mode gain is zero only when R4/R3 = R2/R1).

$$V_{out} = \frac{R_4}{R_3 + R_4}\left(1 + \frac{R_2}{R_1}\right)V_2 - \frac{R_2}{R_1}V_1$$

symbol		meaning	SI unit
`R1`	in	resistor from V1 to the inverting input	ohm
`R2`	in	feedback resistor	ohm
`R3`	in	resistor from V2 to the non-inverting input	ohm
`R4`	in	resistor from the non-inverting input to ground	ohm
`V1`	in	voltage at the inverting side	V
`V2`	in	voltage at the non-inverting side	V
`Vout`	out	output voltage	V
`Ad`	out	differential gain (per volt of V2 - V1)	,
`Acm`	out	common-mode gain	,

Applies when: ideal op-amp.

```
$ electronics-engineering solve elx_difference_amplifier "R1=10000 ohm" "R2=100000 ohm"
"R3=10000 ohm" "R4=100000 ohm" "V1=1 V" "V2=1.2 V"
Vout = 2 V
Ad = 10
Acm = 0
  by: Op-amp difference amplifier (with resistor mismatch)  (Vout = -(R2/R1) V1 + (R4/(R3 +
R4))(1 + R2/R1) V2; Ad = (a2 - a1)/2; Acm = a1 + a2)
  R1 = 10000 ohm
  R2 = 100000 ohm
  R3 = 10000 ohm
  R4 = 100000 ohm
  V1 = 1 V
  V2 = 1.2 V
  assumes: ideal op-amp
```

What the worked example means: This calculation determines the behavior of an operational amplifier configured as a difference amplifier. Using the input voltages 1 V and 1.2 V along with the four resistors 10000 ohm, 100000 ohm, 10000 ohm, and 100000 ohm, the circuit produces an output of 2 V. The result highlights the impact of resistor mismatch, yielding a differential gain of 10 and a non-zero common-mode gain of 0, which indicates that the circuit does not perfectly reject signals common to both inputs.

Op-amp differentiator: gain and output amplitude, `elx_opamp_differentiator`

The gain |H| = 2 pi f R C of an ideal inverting differentiator at a frequency and the peak output for a sinusoidal input of given amplitude.

$$|H(j\omega)| = \omega RC$$

symbol		meaning	SI unit
`R`	in	feedback resistor	ohm
`C`	in	input capacitor	F
`A`	in	peak input amplitude	V
`f`	in	input frequency	Hz
`gain`	out	gain magnitude	,
`Vout_peak`	out	peak output voltage	V
`gain_dB`	out	gain in dB	,

Applies when: ideal op-amp (no high-frequency limiting).

```
$ electronics-engineering solve elx_opamp_differentiator "R=10000 ohm" "C=10 nF" "A=1 V"
"f=1000 Hz"
gain = 0.6283185307
Vout_peak = 0.6283185307 V
gain_dB = -4.036402633
  by: Op-amp differentiator: gain and output amplitude  (|H| = 2 pi f R C; Vout,peak = |H|
A)
  R = 10000 ohm
  C = 1e-08 F
  A = 1 V
  f = 1000 Hz
  assumes: ideal op-amp (no high-frequency limiting)
```

What the worked example means: This calculation determines the frequency response of an ideal inverting operational amplifier differentiator. Using the feedback resistor value of 10000 ohm, the input capacitor value of 10 nF, and the input signal frequency of 1000 Hz, the system computes the dimensionless gain magnitude as 0.628319. For a sinusoidal input with a peak amplitude of 1 V, the resulting peak output voltage is found to be 0.628319 V. The gain expressed in decibels is -4.0364. These values indicate how much the circuit amplifies the input signal at the specified frequency, assuming the op-amp operates within its linear range without high-frequency limitations.

Op-amp integrator: output ramp and unity-gain frequency, `elx_opamp_integrator`

The output of an ideal inverting integrator after a time with a constant input, its ramp rate, and the frequency at which its gain is one.

$$V_{out}(t) = V_0 - \frac{1}{RC}\int_0^t V_{in}\,dt$$

symbol		meaning	SI unit
`R`	in	input resistor	ohm
`C`	in	feedback capacitor	F
`Vin`	in	constant input voltage	V
`t`	in	time since the start	s
`V0`	in	initial output voltage (default 0) (optional)	V
`Vout`	out	output voltage at t	V
`slope`	out	output ramp rate	V/s
`f_unity`	out	unity-gain frequency 1/(2 pi R C)	Hz

Applies when: ideal op-amp, output not saturated.

```
$ electronics-engineering solve elx_opamp_integrator "R=10000 ohm" "C=1 uF" "Vin=0.5 V"
"t=2 ms"
Vout = -0.1 V
slope = -50 V/s
f_unity = 15.91549431 Hz
  by: Op-amp integrator: output ramp and unity-gain frequency  (Vout = V0 - Vin t/(R C); f
= 1/(2 pi R C))
  R = 10000 ohm
  C = 1e-06 F
  Vin = 0.5 V
  t = 0.002 s
  assumes: ideal op-amp, output not saturated
```

What the worked example means: This calculation determines the behavior of an ideal inverting integrator. Given a constant input voltage, the output ramps linearly over time, resulting in a final voltage of -0.1 V and a rate of change of -50 V/s. The circuit's gain drops to one at the unity gain frequency of 15.9155 Hz, which is determined solely by the resistor and capacitor values.

Op-amp output offset from input offset voltage and bias currents, `elx_opamp_dc_offset`

The DC output error of an inverting or non-inverting amplifier (input grounded) caused by the input offset voltage and the input bias and offset currents, and the compensating resistor that cancels the bias-current error.

$$V_{out} = (V_{os} - I_{B+}R_p)\left(1 + \frac{R_f}{R_1}\right) + I_{B-}R_f$$

symbol		meaning	SI unit
`Vos`	in	input offset voltage (in series with the + input)	V
`IB`	in	average input bias current	A
`Ios`	in	input offset current IB- minus IB+	A
`Rf`	in	feedback resistor	ohm
`R1`	in	resistor from the inverting input to ground	ohm
`Rp`	in	resistor from the + input to ground (0 if none)	ohm
`Vout_Vos`	out	output error from Vos	V
`Vout_bias`	out	output error from the bias currents	V
`Vout_total`	out	total output error	V
`Rp_optimal`	out	bias-cancelling Rp = R1 || Rf	ohm

Applies when: currents flow into the inputs; IB- = IB + Ios/2, IB+ = IB - Ios/2.

```
$ electronics-engineering solve elx_opamp_dc_offset "Vos=2 mV" "IB=100 nA" "Ios=10 nA"
"Rf=100000 ohm" "R1=10000 ohm" "Rp=0 ohm"
Vout_Vos = 0.022 V
Vout_bias = 0.0105 V
Vout_total = 0.0325 V
Rp_optimal = 9090.909091 ohm
  by: Op-amp output offset from input offset voltage and bias currents  (Vout = Vos (1 +
Rf/R1) + IB- Rf - IB+ Rp (1 + Rf/R1))
  Vos = 0.002 V
  IB = 1e-07 A
  Ios = 1e-08 A
  Rf = 100000 ohm
  R1 = 10000 ohm
  Rp = 0 ohm
  assumes: currents flow into the inputs; IB- = IB + Ios/2, IB+ = IB - Ios/2
```

What the worked example means: This calculation determines the DC output error for an operational amplifier circuit with grounded inputs, caused by input offset voltage and bias currents. The result separates the error into two parts: the component due to the input offset voltage, which is amplified by the non-inverting gain factor, and the component due to the bias currents flowing through the feedback and compensation resistors. The optimal compensation resistor value, calculated as the parallel combination of the input and feedback resistors, is 9090.91 ohm, which minimizes the bias current error if the currents are equal.

Phase margin of a two-pole amplifier with feedback, `elx_two_pole_phase_margin`

The loop-gain crossover frequency and the phase margin of an amplifier with two real poles and a frequency-independent feedback factor, and its closed-loop DC gain.

$$PM = 180^\circ - \arctan\frac{f_c}{f_1} - \arctan\frac{f_c}{f_2}$$

symbol		meaning	SI unit
`A0`	in	DC open-loop gain (a ratio)	,
`f1`	in	first pole frequency	Hz
`f2`	in	second pole frequency	Hz
`beta`	in	feedback factor	,
`f_c`	out	loop-gain crossover frequency	Hz
`PM_deg`	out	phase margin in degrees	,
`Af`	out	closed-loop DC gain	,

Applies when: A0 beta > 1; two real left-half-plane poles.

```
$ electronics-engineering solve elx_two_pole_phase_margin A0=100000 "f1=10 Hz" "f2=1000000
Hz" beta=0.1
f_c = 99508.54868 Hz
PM_deg = 84.32304539
Af = 9.9990001
  by: Phase margin of a two-pole amplifier with feedback  (|A0 beta|^2 = (1 + (fc/f1)^2)(1
+ (fc/f2)^2) solved for fc^2; PM = 180 - atan(fc/f1) - atan(fc/f2))
  A0 = 100000
  f1 = 10 Hz
  f2 = 1000000 Hz
  beta = 0.1
  assumes: A0 beta > 1; two real left-half-plane poles
```

In the worked example, A0 = 100000, f1 = 10 Hz, f2 = 1000000 Hz, beta = 0.1 go through the equation above and give f_c = 99508.54868 Hz, PM_deg = 84.32304539, Af = 9.9990001. It applies only when A0 beta > 1; two real left-half-plane poles: outside that it says what is wrong instead of returning a number.

Slew-rate limit: full-power bandwidth, `elx_slew_rate_limit`

The full-power bandwidth SR/(2 pi Vp) of an op-amp, the largest undistorted amplitude at a frequency, the slope a sine wave needs and whether it is slew-limited.

$$f_{max} = \frac{SR}{2\pi V_p}$$

symbol		meaning	SI unit
`SR`	in	slew rate	V/s
`Vp`	in	peak output amplitude	V
`f`	in	signal frequency	Hz
`f_max`	out	full-power bandwidth at Vp	Hz
`Vp_max`	out	largest undistorted amplitude at f	V
`slope_needed`	out	maximum slope of the sine, 2 pi f Vp	V/s
`limited`	out	slew-limited or not slew-limited	,

Applies when: sinusoidal output.

```
$ electronics-engineering solve elx_slew_rate_limit "SR=0.5 V/us" "Vp=10 V" "f=20000 Hz"
f_max = 7957.747155 Hz
Vp_max = 3.978873577 V
slope_needed = 1256637.061 V/s
limited = slew-limited
  by: Slew-rate limit: full-power bandwidth  (f_max = SR/(2 pi Vp); Vp,max = SR/(2 pi f);
slope = 2 pi f Vp)
  SR = 500000 V/s
  Vp = 10 V
  f = 20000 Hz
  assumes: sinusoidal output
```

What the worked example means: This calculation determines the maximum frequency at which an operational amplifier can produce a sinusoidal output with a specific peak amplitude without being limited by its slew rate. By comparing the required slope for the signal, calculated as two pi times frequency times peak voltage, against the device's inherent slew rate, the full-power bandwidth is 7957.75 Hz. If the operating frequency exceeds this value, the output waveform will distort because the amplifier cannot change its output voltage fast enough to follow the input signal.

Three-op-amp instrumentation amplifier, `elx_instrumentation_amplifier`

The gain and output of the classic three-op-amp instrumentation amplifier: input stage gain 1 + 2 R1/RG times the difference stage gain R3/R2.

$$V_{out} = \left(1 + \frac{2R_1}{R_G}\right)\frac{R_3}{R_2}(V_2 - V_1)$$

symbol		meaning	SI unit
`R1`	in	feedback resistor of each input buffer	ohm
`RG`	in	gain-setting resistor between the buffers	ohm
`R2`	in	input resistors of the difference stage	ohm
`R3`	in	feedback and ground resistors of the difference stage	ohm
`V1`	in	input at the inverting side	V
`V2`	in	input at the non-inverting side	V
`G`	out	differential gain	,
`G_stage1`	out	gain of the input stage	,
`Vout`	out	output voltage	V

Applies when: ideal op-amps, matched resistors.

```
$ electronics-engineering solve elx_instrumentation_amplifier "R1=25000 ohm" "RG=1000 ohm"
"R2=10000 ohm" "R3=10000 ohm" "V1=1 V" "V2=1.01 V"
G = 51
G_stage1 = 51
Vout = 0.51 V
  by: Three-op-amp instrumentation amplifier  (G = (1 + 2 R1/RG)(R3/R2); Vout = G (V2 -
V1))
  R1 = 25000 ohm
  RG = 1000 ohm
  R2 = 10000 ohm
  R3 = 10000 ohm
  V1 = 1 V
  V2 = 1.01 V
  assumes: ideal op-amps, matched resistors
```

What the worked example means: This calculation determines the performance of a three-op-amp instrumentation amplifier. The input stage, composed of two buffers and a gain-setting resistor, provides a first-stage gain of 51. This is multiplied by the second-stage difference amplifier ratio to yield a total differential gain of 51. When applied to the voltage difference between the non-inverting input 1.01 V and the inverting input 1 V, the final output voltage is computed as 0.51 V.

Oscillators (9)

555 timer astable: frequency and duty cycle, `elx_555_astable`

The high and low times, period, frequency and duty cycle of a 555 timer in astable mode with resistors RA and RB and timing capacitor C.

$$t_H = \ln 2\,(R_A + R_B)C, \quad t_L = \ln 2\,R_B C, \quad f = \frac{1}{\ln 2\,(R_A + 2R_B)C}$$

symbol		meaning	SI unit
`RA`	in	resistor from Vcc to the discharge pin	ohm
`RB`	in	resistor from discharge to threshold/trigger	ohm
`C`	in	timing capacitor	F
`t_high`	out	output high time	s
`t_low`	out	output low time	s
`T`	out	period	s
`f`	out	frequency	Hz
`duty`	out	duty cycle (fraction high)	,

Applies when: thresholds Vcc/3 and 2Vcc/3.

```
$ electronics-engineering solve elx_555_astable "RA=1000 ohm" "RB=10000 ohm" "C=10 uF"
t_high = 0.07624618986 s
t_low = 0.06931471806 s
T = 0.1455609079 s
f = 6.869976385 Hz
duty = 0.5238095238
  by: 555 timer astable: frequency and duty cycle  (t_H = ln2 (RA + RB) C; t_L = ln2 RB C;
f = 1/(t_H + t_L))
  RA = 1000 ohm
  RB = 10000 ohm
  C = 1e-05 F
  assumes: thresholds Vcc/3 and 2Vcc/3
```

What the worked example means: This calculation determines the timing characteristics of a 555 timer configured in astable mode. Using the resistor values 1000 ohm and 10000 ohm, along with the capacitor value 10 uF, this gives the high time 0.0762462 s, low time 0.0693147 s, period 0.145561 s, frequency 6.86998 Hz, and duty cycle 0.52381. These values define how long the output stays high versus low, which is critical for applications like clock signals or pulse width modulation.

555 timer monostable pulse width, `elx_555_monostable`

The output pulse width T = ln 3 R C (about 1.1 R C) of a 555 timer in monostable (one-shot) mode.

$$T = \ln 3\,RC \approx 1.1\,RC$$

symbol		meaning	SI unit
`R`	in	timing resistor	ohm
`C`	in	timing capacitor	F
`T`	out	pulse width	s

Applies when: threshold at 2Vcc/3; trigger pulse shorter than T.

```
$ electronics-engineering solve elx_555_monostable "R=100000 ohm" "C=10 uF"
T = 1.098612289 s
  by: 555 timer monostable pulse width  (T = ln 3 R C)
  R = 100000 ohm
  C = 1e-05 F
  assumes: threshold at 2Vcc/3; trigger pulse shorter than T
```

What the worked example means: This calculation determines the duration of the output pulse, known as the pulse width 1.09861 s, for a 555 timer configured in monostable mode. The result is derived directly from the values of the timing resistor 100000 ohm and the timing capacitor 10 uF using the relationship where the time constant is approximately 1.1 times the product of resistance and capacitance. This value represents how long the output remains high after being triggered.

Colpitts oscillator frequency and feedback ratio, `elx_colpitts_oscillator`

The oscillation frequency of a Colpitts oscillator from its inductor and the series combination of its two tank capacitors, the feedback fraction C1/C2 and the minimum amplifier gain C2/C1.

$$f_0 = \frac{1}{2\pi\sqrt{L\,\frac{C_1 C_2}{C_1+C_2}}}, \quad A_{min} = \frac{C_2}{C_1}$$

symbol		meaning	SI unit
`L`	in	tank inductance	H
`C1`	in	capacitor across the amplifier output	F
`C2`	in	capacitor across the amplifier input (feedback side)	F
`C_eq`	out	series equivalent capacitance	F
`f0`	out	oscillation frequency	Hz
`beta`	out	feedback fraction C1/C2	,
`A_min`	out	minimum amplifier gain C2/C1	,

Applies when: lossless tank, amplifier does not load the tank.

```
$ electronics-engineering solve elx_colpitts_oscillator "L=100 uH" "C1=1 nF" "C2=10 nF"
C_eq = 9.090909091e-10 F
f0 = 527857.2298 Hz
beta = 0.1
A_min = 10
  by: Colpitts oscillator frequency and feedback ratio  (C_eq = C1 C2/(C1 + C2); f0 = 1/(2
pi sqrt(L C_eq)); beta = C1/C2)
  L = 0.0001 H
  C1 = 1e-09 F
  C2 = 1e-08 F
  assumes: lossless tank, amplifier does not load the tank
```

What the worked example means: This calculation determines the operating characteristics of a Colpitts oscillator based on its tank circuit components. The series equivalent capacitance is found to be 9.09091e-10 F F, which combines with the inductor value of 100 uH H to produce an oscillation frequency of 527857 Hz Hz. The feedback fraction beta is calculated as 0.1, indicating the proportion of output voltage fed back to the input. Consequently, the minimum amplifier gain required to sustain oscillations is determined to be 10, ensuring that the loop gain exceeds unity at the resonant frequency.

Hartley oscillator frequency, `elx_hartley_oscillator`

The oscillation frequency of a Hartley oscillator with a tapped (or two coupled) inductors and a tank capacitor, and the gain ratio (L1 + M)/(L2 + M).

$$f_0 = \frac{1}{2\pi\sqrt{(L_1 + L_2 + 2M)C}}$$

symbol		meaning	SI unit
`L1`	in	inductance of the output-side coil	H
`L2`	in	inductance of the feedback-side coil	H
`M`	in	mutual inductance (0 for uncoupled coils)	H
`C`	in	tank capacitance	F
`L_eq`	out	total inductance L1 + L2 + 2M	H
`f0`	out	oscillation frequency	Hz
`A_min`	out	minimum amplifier gain (L1 + M)/(L2 + M)	,

Applies when: series-aiding coils, lossless tank; M <= sqrt(L1 L2).

```
$ electronics-engineering solve elx_hartley_oscillator "L1=100 uH" "L2=20 uH" "M=0 uH" "C=1
nF"
L_eq = 0.00012 H
f0 = 459440.7462 Hz
A_min = 5
  by: Hartley oscillator frequency  (L_eq = L1 + L2 + 2M; f0 = 1/(2 pi sqrt(L_eq C)))
  L1 = 0.0001 H
  L2 = 2e-05 H
  M = 0 H
  C = 1e-09 F
  assumes: series-aiding coils, lossless tank; M <= sqrt(L1 L2)
```

What the worked example means: This calculation determines the operating point of a Hartley oscillator using two coupled inductors and a tank capacitor. The total equivalent inductance, found by summing the individual coil values and twice the mutual inductance, results in 0.00012 H. Using this value with the tank capacitance yields an oscillation frequency of 459441 Hz. Additionally, the feedback ratio dictates that the amplifier must provide a minimum gain of 5 to sustain oscillations.

Op-amp relaxation (astable) oscillator, `elx_opamp_relaxation_oscillator`

The period and frequency of a square-wave op-amp astable: an RC timing network on the inverting input and positive feedback R1/(R1 + R2) to the non-inverting input, symmetric supplies.

$$T = 2RC \ln \frac{1+\beta}{1-\beta}, \quad \beta = \frac{R_1}{R_1 + R_2}$$

symbol		meaning	SI unit
`R`	in	timing resistor (output to inverting input)	ohm
`C`	in	timing capacitor	F
`R1`	in	resistor from the + input to ground	ohm
`R2`	in	resistor from the output to the + input	ohm
`beta`	out	feedback fraction R1/(R1 + R2)	,
`T`	out	period	s
`f`	out	frequency	Hz

Applies when: symmetric output levels; ideal comparator action.

```
$ electronics-engineering solve elx_opamp_relaxation_oscillator "R=10000 ohm" "C=100 nF"
"R1=10000 ohm" "R2=10000 ohm"
beta = 0.5
T = 0.002197224577 s
f = 455.1196133 Hz
  by: Op-amp relaxation (astable) oscillator  (T = 2 R C ln((1 + beta)/(1 - beta)) = 2 R C
ln(1 + 2 R1/R2))
  R = 10000 ohm
  C = 1e-07 F
  R1 = 10000 ohm
  R2 = 10000 ohm
  assumes: symmetric output levels; ideal comparator action
```

What the worked example means: This calculation determines the oscillation period and frequency of an op-amp astable relaxation oscillator. It uses the timing resistor, capacitor, and feedback network resistors to find the feedback fraction, which dictates the threshold voltages for switching. The resulting period is 0.00219722 s seconds, corresponding to a frequency of 455.12 Hz hertz.

Quartz crystal: series and parallel resonance, Q, `elx_crystal_oscillator`

The series and parallel (anti-) resonant frequencies, their spacing and the quality factor of a quartz crystal from its Butterworth-Van Dyke equivalent circuit.

$$f_s = \frac{1}{2\pi\sqrt{L_m C_m}}, \quad f_p = f_s\sqrt{1 + \frac{C_m}{C_0}}$$

symbol		meaning	SI unit
`Lm`	in	motional inductance	H
`Cm`	in	motional capacitance	F
`Rm`	in	motional resistance	ohm
`C0`	in	shunt (holder) capacitance	F
`fs`	out	series resonance	Hz
`fp`	out	parallel resonance	Hz
`delta_f`	out	fp - fs	Hz
`Q`	out	quality factor	,

Applies when: resonances of the lossless circuit; Q from Rm.

```
$ electronics-engineering solve elx_crystal_oscillator "Lm=0.05 H" "Cm=20 fF" "Rm=20 ohm"
"C0=5 pF"
fs = 5032921.21 Hz
fp = 5042977.007 Hz
delta_f = 10055.79666 Hz
Q = 79056.9415
  by: Quartz crystal: series and parallel resonance, Q  (fs = 1/(2 pi sqrt(Lm Cm)); fp = fs
sqrt(1 + Cm/C0); Q = sqrt(Lm/Cm)/Rm)
  Lm = 0.05 H
  Cm = 2e-14 F
  Rm = 20 ohm
  C0 = 5e-12 F
  assumes: resonances of the lossless circuit; Q from Rm
```

What the worked example means: This calculation determines the resonant frequencies and quality factor of a quartz crystal using its Butterworth-Van Dyke equivalent circuit parameters. The series resonance frequency, where the motional inductance and capacitance cancel each other out, is found to be 5.03292e+06 Hz. The parallel resonance frequency, occurring when the crystal behaves as an open circuit due to the shunt capacitance, is calculated as 5.04298e+06 Hz. The difference between these two frequencies, known as the bandwidth or spacing, is 10055.8 Hz. Finally, the quality factor, which indicates the sharpness of the resonance and energy storage efficiency relative to dissipation, is determined to be 79056.9 based on the motional resistance.

RC phase-shift oscillator frequency and gain, `elx_rc_phase_shift_oscillator`

The oscillation frequency of a three-section RC phase-shift oscillator (high-pass ladder: series C, shunt R; or low-pass ladder) and the amplifier gain of 29 it needs.

$$f_0 = \frac{1}{2\pi\sqrt{6}\,RC}, \quad |A| \geq 29$$

symbol		meaning	SI unit
`R`	in	resistor of each section	ohm
`C`	in	capacitor of each section	F
`ladder`	in	highpass (series C, shunt R) or lowpass (series R, shunt C)	,
`f0`	out	oscillation frequency	Hz
`A_min`	out	minimum inverting amplifier gain	,
`beta`	out	feedback network attenuation at f0	,

Applies when: unloaded ladder (driven by a voltage source, feeding a high impedance).

```
$ electronics-engineering solve elx_rc_phase_shift_oscillator "R=10000 ohm" "C=10 nF"
ladder=high-pass
f0 = 649.7473344 Hz
A_min = 29
beta = 0.03448275862
  by: RC phase-shift oscillator frequency and gain  (high-pass ladder f = 1/(2 pi sqrt(6) R
C); low-pass ladder f = sqrt(6)/(2 pi R C); |beta| = 1/29)
  R = 10000 ohm
  C = 1e-08 F
  ladder = high-pass
  assumes: unloaded ladder (driven by a voltage source, feeding a high impedance)
```

What the worked example means: This calculation determines the operating point for an RC phase-shift oscillator using three identical sections. Given a resistance of 10000 ohm and capacitance of 10 nF, the network produces a total phase shift of one hundred eighty degrees at the frequency 649.747 Hz. To sustain stable oscillations, the amplifier must provide a voltage gain magnitude of at least 29, which corresponds to a feedback factor of 0.0344828. This result assumes an ideal unloaded ladder configuration where loading effects from the amplifier input or output are negligible.

Type-2 PLL with active PI loop filter: natural frequency and damping, `elx_pll_loop_dynamics`

The natural frequency and damping factor of a second-order (type-2) phase-locked loop with phase-detector gain Kd, VCO gain Ko and an active PI loop filter F(s) = (1 + s tau2)/(s tau1).

$$\omega_n = \sqrt{\frac{K_d K_o}{\tau_1}}, \quad \zeta = \frac{\tau_2 \omega_n}{2}$$

symbol		meaning	SI unit
`Kd`	in	phase-detector gain in V/rad	,
`Ko`	in	VCO gain in rad/(s V)	,
`tau1`	in	integrator time constant R1 C	s
`tau2`	in	zero time constant R2 C	s
`wn`	out	natural frequency	rad/s
`fn`	out	natural frequency in Hz	Hz
`zeta`	out	damping factor	,

Applies when: linear phase model, ideal integrator.

```
$ electronics-engineering solve elx_pll_loop_dynamics Kd=0.5 Ko=20000 "tau1=10 ms" "tau2=1
ms"
wn = 1000 rad/s
fn = 159.1549431 Hz
zeta = 0.5
  by: Type-2 PLL with active PI loop filter: natural frequency and damping  (H(s) = K (1 +
s tau2)/tau1 / (s^2 + s K tau2/tau1 + K/tau1), K = Kd Ko; wn = sqrt(K/tau1); zeta = tau2
wn/2)
  Kd = 0.5
  Ko = 20000
  tau1 = 0.01 s
  tau2 = 0.001 s
  assumes: linear phase model, ideal integrator
```

What the worked example means: This calculation determines the dynamic response characteristics of a second-order phase-locked loop. Using the phase detector gain, VCO gain, and filter time constants, the system's natural frequency is found to be 159.155 Hz Hz. The corresponding damping factor is calculated as 0.5, which indicates how oscillatory or stable the lock acquisition process will be.

Wien-bridge oscillator frequency and required gain, `elx_wien_bridge_oscillator`

The oscillation frequency of a Wien-bridge oscillator (series R1 C1, parallel R2 C2) and the non-inverting gain it needs (3 for equal components).

$$f_0 = \frac{1}{2\pi\sqrt{R_1 R_2 C_1 C_2}}, \quad A = 1 + \frac{R_1}{R_2} + \frac{C_2}{C_1}$$

symbol		meaning	SI unit
`R1`	in	series-arm resistor	ohm
`C1`	in	series-arm capacitor	F
`R2`	in	parallel-arm resistor	ohm
`C2`	in	parallel-arm capacitor	F
`f0`	out	oscillation frequency	Hz
`beta`	out	feedback fraction at f0	,
`A_min`	out	required amplifier gain	,
`Rf_over_Rg`	out	gain resistor ratio	,

Applies when: ideal amplifier.

```
$ electronics-engineering solve elx_wien_bridge_oscillator "R1=10000 ohm" "C1=16 nF"
"R2=10000 ohm" "C2=16 nF"
f0 = 994.7183943 Hz
beta = 0.3333333333
A_min = 3
Rf_over_Rg = 2
  by: Wien-bridge oscillator frequency and required gain  (f0 = 1/(2 pi sqrt(R1 R2 C1 C2));
A = 1 + R1/R2 + C2/C1)
  R1 = 10000 ohm
  C1 = 1.6e-08 F
  R2 = 10000 ohm
  C2 = 1.6e-08 F
  assumes: ideal amplifier
```

What the worked example means: This calculation determines the oscillation frequency and the minimum non-inverting amplifier gain required for a Wien-bridge oscillator circuit. Using the series resistor R1, series capacitor C1, parallel resistor R2, and parallel capacitor C2, the system computes the natural frequency where the phase shift is zero. The result shows that for the given components, the oscillator will run at 994.718 Hz, while the feedback network attenuates the signal such that the amplifier must provide a gain of at least 3 to sustain stable oscillations.

Power supplies (5)

Adjustable three-terminal regulator output voltage, `elx_adjustable_regulator_output`

The output voltage of an adjustable three-terminal regulator (LM317 type: reference between OUT and ADJ, R1 from OUT to ADJ, R2 from ADJ to ground), including the adjust-pin current.

$$V_{out} = V_{ref}\left(1 + \frac{R_2}{R_1}\right) + I_{adj}R_2$$

symbol		meaning	SI unit
`R1`	in	resistor from OUT to ADJ	ohm
`R2`	in	resistor from ADJ to ground	ohm
`Vref`	in	internal reference (1.25 V for the LM317 type)	V
`Iadj`	in	adjust-pin current (default 0) (optional)	A
`Vout`	out	output voltage	V
`I_R1`	out	current through R1	A

Applies when: regulator in regulation (input high enough).

```
$ electronics-engineering solve elx_adjustable_regulator_output "R1=240 ohm" "R2=720 ohm"
"Vref=1.25 V"
Vout = 5 V
I_R1 = 0.005208333333 A
  by: Adjustable three-terminal regulator output voltage  (Vout = Vref (1 + R2/R1) + Iadj
R2)
  R1 = 240 ohm
  R2 = 720 ohm
  Vref = 1.25 V
  assumes: regulator in regulation (input high enough)
```

What the worked example means: This calculation determines the output voltage of an adjustable three-terminal regulator using the formula involving the internal reference voltage, the ratio of the two external resistors, and the current flowing into the adjustment pin. Given the input values, the resulting output voltage is 5 V. The current through the first resistor is calculated as 0.00520833 A. This result indicates the regulated voltage level available at the output terminal when the regulator is operating within its specified range.

Heat-sink thermal path: junction, case and sink temperatures, `elx_heat_sink_temperatures`

The junction, case and heat-sink temperatures of a power device dissipating P through junction-to-case, case-to-sink (interface) and sink-to-ambient thermal resistances.

$$T_j = T_a + P\,(\theta_{jc} + \theta_{cs} + \theta_{sa})$$

symbol		meaning	SI unit
`P`	in	power dissipated	W
`Ta`	in	ambient temperature	K
`theta_jc`	in	junction-to-case thermal resistance	K/W
`theta_cs`	in	case-to-sink thermal resistance	K/W
`theta_sa`	in	sink-to-ambient thermal resistance	K/W
`Tj`	out	junction temperature	K
`Tc`	out	case temperature	K
`Ts`	out	sink temperature	K
`Tj_C`	out	junction temperature in degC	,
`theta_ja`	out	total junction-to-ambient resistance	K/W

Applies when: steady state, series thermal path.

```
$ electronics-engineering solve elx_heat_sink_temperatures "P=15 W" "Ta=25 degC"
"theta_jc=1.5 K/W" "theta_cs=0.5 K/W" "theta_sa=3 K/W"
Tj = 373.15 K
Tc = 350.65 K
Ts = 343.15 K
Tj_C = 100
theta_ja = 5 K/W
  by: Heat-sink thermal path: junction, case and sink temperatures  (Tj = Ta + P (theta_jc
+ theta_cs + theta_sa))
  P = 15 W
  Ta = 298.15 K
  theta_jc = 1.5 K/W
  theta_cs = 0.5 K/W
  theta_sa = 3 K/W
  assumes: steady state, series thermal path
```

What the worked example means: This calculation determines the steady-state temperatures at the semiconductor junction, case, and heat sink. It starts with the ambient temperature 25 degC and adds the voltage drop equivalent caused by the power dissipation 15 W flowing through the series thermal resistances. The junction-to-case resistance 1.5 K/W, case-to-sink resistance 0.5 K/W, and sink-to-ambient resistance 3 K/W are summed to find the total path resistance. The resulting junction temperature 373.15 K indicates how hot the active silicon region becomes, while the case temperature 350.65 K and sink temperature 343.15 K show the gradient along the cooling path. The total junction-to-ambient resistance 5 K/W summarizes the entire thermal impedance of the assembly.

Linear regulator dissipation and efficiency, `elx_linear_regulator_efficiency`

The input and output power, the dissipation in the pass element and the efficiency of a linear (series) regulator including its quiescent current.

$$P_D = (V_{in} - V_{out})I_L + V_{in}I_q, \quad \eta = \frac{V_{out}I_L}{V_{in}(I_L + I_q)}$$

symbol		meaning	SI unit
`Vin`	in	input voltage	V
`Vout`	in	regulated output voltage	V
`Iload`	in	load current	A
`Iq`	in	quiescent (ground-pin) current	A
`P_in`	out	input power	W
`P_out`	out	output power	W
`P_diss`	out	dissipation in the regulator	W
`efficiency`	out	efficiency	,
`efficiency_pct`	out	efficiency in per cent	,

Applies when: Vin > Vout.

```
$ electronics-engineering solve elx_linear_regulator_efficiency "Vin=12 V" "Vout=5 V"
"Iload=500 mA" "Iq=5 mA"
P_in = 6.06 W
P_out = 2.5 W
P_diss = 3.56 W
efficiency = 0.4125412541
efficiency_pct = 41.25412541
  by: Linear regulator dissipation and efficiency  (P_in = Vin (IL + Iq); P_out = Vout IL;
P_diss = P_in - P_out; eta = P_out/P_in)
  Vin = 12 V
  Vout = 5 V
  Iload = 0.5 A
  Iq = 0.005 A
  assumes: Vin > Vout
```

What the worked example means: This calculation determines the power dissipation and efficiency of a linear regulator. The input power is derived from the product of the input voltage and the sum of the load current and quiescent current, while output power equals the regulated voltage multiplied by the load current. The difference between these values represents the heat generated within the device, shown here as 3.56 W. The resulting efficiency ratio indicates how effectively the input energy is converted to useful output power.

Required heat-sink thermal resistance, `elx_heat_sink_required`

The largest sink-to-ambient thermal resistance (and total junction-to-ambient resistance) that keeps a device dissipating P below its maximum junction temperature.

$$\theta_{sa} \le \frac{T_{j,max} - T_a}{P} - \theta_{jc} - \theta_{cs}$$

symbol		meaning	SI unit
`P`	in	power dissipated	W
`Ta`	in	ambient temperature	K
`Tj_max`	in	maximum junction temperature	K
`theta_jc`	in	junction-to-case thermal resistance	K/W
`theta_cs`	in	case-to-sink thermal resistance	K/W
`theta_ja_max`	out	largest junction-to-ambient resistance	K/W
`theta_sa_max`	out	largest sink-to-ambient resistance	K/W

Applies when: a positive result (otherwise no heat sink suffices).

```
$ electronics-engineering solve elx_heat_sink_required "P=20 W" "Ta=40 degC" "Tj_max=150
degC" "theta_jc=1 K/W" "theta_cs=0.5 K/W"
theta_ja_max = 5.5 K/W
theta_sa_max = 4 K/W
  by: Required heat-sink thermal resistance  (theta_sa = (Tj,max - Ta)/P - theta_jc -
theta_cs)
  P = 20 W
  Ta = 313.15 K
  Tj_max = 423.15 K
  theta_jc = 1 K/W
  theta_cs = 0.5 K/W
  assumes: a positive result (otherwise no heat sink suffices)
```

What the worked example means: This calculation determines the largest heat-sink thermal resistance required to keep a device within safe operating limits. By taking the difference between the maximum junction temperature of 150 degC and the ambient temperature of 40 degC, then dividing by the power dissipation of 20 W, this gives the total junction-to-ambient budget. Subtracting the junction-to-case resistance of 1 K/W and the case-to-sink resistance of 0.5 K/W yields the final limit for the heat sink itself, which must be no greater than 4 K/W. If this value is positive, it indicates that a suitable heat sink exists; if negative, even an ideal heat sink would fail to prevent overheating.

Zener-referenced series-pass (emitter-follower) regulator, `elx_series_pass_regulator`

The output voltage, load, base, Zener and resistor currents and the pass-transistor dissipation of a regulator in which a Zener diode biased through Rs sets the base of an emitter-follower pass transistor.

$$V_{out} = V_Z - V_{BE}, \quad I_Z = \frac{V_{in} - V_Z}{R_S} - \frac{I_L}{\beta + 1}$$

symbol		meaning	SI unit
`Vin`	in	unregulated input	V
`Vz`	in	Zener voltage	V
`Rs`	in	Zener bias resistor	ohm
`RL`	in	load resistance	ohm
`beta`	in	current gain of the pass transistor	,
`VBE`	in	base-emitter voltage	V
`Vout`	out	output voltage Vz - VBE	V
`I_L`	out	load current	A
`I_B`	out	base current	A
`I_z`	out	Zener current	A
`I_Rs`	out	current in Rs	A
`P_Q`	out	pass-transistor dissipation	W

Applies when: Vin > Vz > VBE; the Zener stays in breakdown (Iz > 0).

```
$ electronics-engineering solve elx_series_pass_regulator "Vin=15 V" "Vz=10 V" "Rs=1000
ohm" "RL=100 ohm" beta=100 "VBE=0.7 V"
Vout = 9.3 V
I_L = 0.093 A
I_B = 0.0009207920792 A
I_z = 0.004079207921 A
I_Rs = 0.005 A
P_Q = 0.5248514851 W
  by: Zener-referenced series-pass (emitter-follower) regulator  (Vout = Vz - VBE; IB =
IL/(beta + 1); Iz = (Vin - Vz)/Rs - IB; P = (Vin - Vout) IC)
  Vin = 15 V
  Vz = 10 V
  Rs = 1000 ohm
  RL = 100 ohm
  beta = 100
  VBE = 0.7 V
  assumes: Vin > Vz > VBE; the Zener stays in breakdown (Iz > 0)
```

What the worked example means: This calculation determines the operating point of a Zener-referenced series-pass regulator. The output voltage, set at 9.3 V, is derived by subtracting the base-emitter drop from the Zener voltage. Currents are calculated based on the input voltage 15 V and component values, yielding a load current of 0.093 A and a Zener current of 0.00407921 A. The power dissipated by the pass transistor is found to be 0.524851 W, which depends on the voltage difference between the input and output multiplied by the collector current.

Semiconductors (9)

Built-in potential of a pn junction, `elx_builtin_potential`

The built-in (contact) potential of an abrupt pn junction from the doping on each side, the intrinsic concentration and the temperature.

$$V_{bi} = \frac{kT}{q} \ln \frac{N_A N_D}{n_i^2}$$

symbol		meaning	SI unit
`NA`	in	acceptor concentration on the p side	1/m^3
`ND`	in	donor concentration on the n side	1/m^3
`ni`	in	intrinsic carrier concentration	1/m^3
`T`	in	absolute temperature	K
`Vbi`	out	built-in potential	V

Applies when: NA, ND >= 100 ni; non-degenerate, complete ionisation.

```
$ electronics-engineering solve elx_builtin_potential "NA=1e+17 cm^-3" "ND=1e+16 cm^-3"
"ni=1.5e+10 cm^-3" "T=300 K"
Vbi = 0.7528794135 V
  by: Built-in potential of a pn junction  (Vbi = (kT/q) ln(NA ND / ni^2))
  NA = 1e+23 1/m^3
  ND = 1e+22 1/m^3
  ni = 1.5e+16 1/m^3
  T = 300 K
  assumes: NA, ND >= 100 ni; non-degenerate, complete ionisation
```

What the worked example means: This calculation determines the built-in potential of an abrupt pn junction using the formula Vbi equals kT over q times the natural log of NA ND divided by ni squared. The result, 0.752879 V, represents the voltage barrier that forms across the depletion region due to charge diffusion. It depends on the acceptor concentration 1e+17 cm^-3 on the p-side, the donor concentration 1e+16 cm^-3 on the n-side, the intrinsic carrier concentration 1.5e+10 cm^-3, and the absolute temperature 300 K. This potential balances the drift current caused by the electric field against the diffusion current caused by concentration gradients.

Conductivity and resistivity of a semiconductor, `elx_semiconductor_conductivity`

The conductivity sigma = q (n mu_n + p mu_p) and the resistivity of a semiconductor from its electron and hole concentrations and mobilities.

$$\sigma = q\,(n\mu_n + p\mu_p), \quad \rho = 1/\sigma$$

symbol		meaning	SI unit
`n`	in	electron concentration	1/m^3
`p`	in	hole concentration	1/m^3
`mu_n`	in	electron mobility	m^2/(V*s)
`mu_p`	in	hole mobility	m^2/(V*s)
`sigma`	out	conductivity	1/(ohm*m)
`rho`	out	resistivity	ohm*m
`rho_ohm_cm`	out	resistivity in ohm cm	,

Applies when: n, p >= 0 (not both zero); mobilities > 0.

```
$ electronics-engineering solve elx_semiconductor_conductivity "n=1e+16 cm^-3" "p=22500
cm^-3" "mu_n=1350 cm^2/(V*s)" "mu_p=480 cm^2/(V*s)"
sigma = 216.2938456 1/(ohm*m)
rho = 0.004623340055 ohm*m
rho_ohm_cm = 0.4623340055
  by: Conductivity and resistivity of a semiconductor  (sigma = q (n mu_n + p mu_p); rho =
1/sigma)
  n = 1e+22 1/m^3
  p = 2.25e+10 1/m^3
  mu_n = 0.135 m^2/(V*s)
  mu_p = 0.048 m^2/(V*s)
  assumes: n, p >= 0 (not both zero); mobilities > 0
```

What the worked example means: This calculation determines the electrical properties of a semiconductor based on its carrier concentrations and mobilities. Using the electron concentration 1e+16 cm^-3 and hole concentration 22500 cm^-3, along with their respective mobilities 1350 cm^2/(V*s) and 480 cm^2/(V*s), the model computes the total conductivity as 216.294 1/(ohm*m). The reciprocal of this value yields the resistivity 0.00462334 ohm*m, which represents the material's opposition to current flow, also expressed in practical units as 0.462334.

Depletion width, field and capacitance of an abrupt pn junction, `elx_depletion_width`

The depletion-region width (and its parts on each side), the peak electric field and the depletion capacitance per area of an abrupt pn junction at a reverse bias (negative VR for a forward bias below Vbi).

$$W = \sqrt{\frac{2\varepsilon(V_{bi} + V_R)}{q}\left(\frac{1}{N_A} + \frac{1}{N_D}\right)}$$

symbol		meaning	SI unit
`NA`	in	acceptor concentration (p side)	1/m^3
`ND`	in	donor concentration (n side)	1/m^3
`Vbi`	in	built-in potential	V
`VR`	in	reverse bias (negative for forward)	V
`eps_r`	in	relative permittivity of the semiconductor (11.7 for silicon)	,
`W`	out	depletion width	m
`W_um`	out	depletion width in micrometres	,
`xn`	out	width on the n side	m
`xp`	out	width on the p side	m
`Emax`	out	peak electric field (V/m)	N/C
`Cj_area`	out	depletion capacitance per area	F/m^2

Applies when: Vbi + VR > 0; abrupt junction, depletion approximation.

```
$ electronics-engineering solve elx_depletion_width "NA=1e+17 cm^-3" "ND=1e+16 cm^-3"
"Vbi=0.81 V" "VR=5 V" eps_r=11.7
W = 9.090996814e-07 m
W_um = 0.9090996814
xn = 8.264542558e-07 m
xp = 8.264542558e-08 m
Emax = 12781876.66 N/C
Cj_area = 0.0001139522976 F/m^2
  by: Depletion width, field and capacitance of an abrupt pn junction  (W = sqrt(2 eps (Vbi
+ VR)/q (1/NA + 1/ND)); xn = W NA/(NA+ND); Emax = q ND xn/eps; C' = eps/W)
  NA = 1e+23 1/m^3
  ND = 1e+22 1/m^3
  Vbi = 0.81 V
  VR = 5 V
  eps_r = 11.7
  assumes: Vbi + VR > 0; abrupt junction, depletion approximation
```

What the worked example means: This calculation determines the physical extent of the charge-free region at the interface between p-type and n-type semiconductor materials. Using the doping concentrations on each side, the built-in potential, and the applied reverse bias, it computes the total depletion width as 9.091e-07 m, which corresponds to 0.9091 micrometres. The result also breaks down this width into the portion extending into the n-side (8.26454e-07 m) and the p-side (8.26454e-08 m). Additionally, it finds the maximum electric field strength within the junction, reported here as 1.27819e+07 N/C, and the capacitance per unit area, given by 0.000113952 F/m^2. These values characterize how the junction stores charge and withstands voltage under the specified conditions.

Drift velocity and drift current in a semiconductor bar, `elx_drift_current`

The electric field, the carrier drift velocity, the drift current density and the current when a voltage is applied along a uniformly doped bar.

$$J = q\,n\,\mu\,E, \quad E = V/L$$

symbol		meaning	SI unit
`n`	in	concentration of the carriers that drift	1/m^3
`mu`	in	their mobility	m^2/(V*s)
`V`	in	voltage applied along the bar	V
`L`	in	bar length	m
`A`	in	cross-sectional area	m^2
`E`	out	electric field (V/m)	N/C
`v_d`	out	drift velocity	m/s
`J`	out	drift current density	A/m^2
`I`	out	current	A

Applies when: n, mu, L, A > 0; low field (constant mobility).

```
$ electronics-engineering solve elx_drift_current "n=1e+16 cm^-3" "mu=1350 cm^2/(V*s)" "V=5
V" "L=0.001 m" "A=1e-08 m^2"
E = 5000 N/C
v_d = 675 m/s
J = 1081469.228 A/m^2
I = 0.01081469228 A
  by: Drift velocity and drift current in a semiconductor bar  (E = V/L; v_d = mu E; J = q
n v_d; I = J A)
  n = 1e+22 1/m^3
  mu = 0.135 m^2/(V*s)
  V = 5 V
  L = 0.001 m
  A = 1e-08 m^2
  assumes: n, mu, L, A > 0; low field (constant mobility)
```

What the worked example means: This calculation determines the electrical behavior of a uniformly doped semiconductor bar under an applied voltage. Starting from the potential difference across the length, this gives the electric field as 5000 N/C. This field drives the carriers to move at a drift velocity of 675 m/s. The

resulting current density is 1.08147e+06 A/m^2, which yields a total current of 0.0108147 A flowing through the cross-sectional area.

Einstein relation and diffusion length, `elx_einstein_diffusion`

The diffusion coefficient D = mu kT/q of carriers from their mobility (Einstein relation) and the diffusion length L = sqrt(D tau) from the minority-carrier lifetime.

$$D = \mu \frac{kT}{q}, \quad L = \sqrt{D\tau}$$

symbol		meaning	SI unit
`mu`	in	carrier mobility	m^2/(V*s)
`T`	in	absolute temperature	K
`tau`	in	minority-carrier lifetime	s
`D`	out	diffusion coefficient	m^2/s
`D_cm2`	out	D in cm^2/s	,
`L_diff`	out	diffusion length	m
`L_um`	out	diffusion length in micrometres	,

Applies when: mu, T, tau > 0; non-degenerate material.

```
$ electronics-engineering solve elx_einstein_diffusion "mu=1350 cm^2/(V*s)" "T=300 K"
"tau=1 us"
D = 0.003490019971 m^2/s
D_cm2 = 34.90019971
L_diff = 5.907639098e-05 m
L_um = 59.07639098
  by: Einstein relation and diffusion length  (D = mu kT/q; L = sqrt(D tau))
  mu = 0.135 m^2/(V*s)
  T = 300 K
  tau = 1e-06 s
  assumes: mu, T, tau > 0; non-degenerate material
```

What the worked example means: This calculation determines the carrier diffusion coefficient D from mobility mu and temperature T using the Einstein relation, then finds the diffusion length L by combining D with the minority-carrier lifetime tau. The resulting diffusion coefficient is 0.00349002 m^2/s, while the diffusion length is 5.90764e-05 m. These values describe how far carriers spread due to thermal motion over their average lifetime.

Electron and hole concentrations of doped (compensated) material, `elx_doped_carrier_concentrations`

The equilibrium electron and hole concentrations of a semiconductor with donors and acceptors, from charge neutrality and the mass-action law (exact, so it also holds for light or compensated doping).

$$n = \frac{N_D - N_A}{2} + \sqrt{\left(\frac{N_D - N_A}{2}\right)^2 + n_i^2}, \quad p = \frac{n_i^2}{n}$$

symbol		meaning	SI unit
`ND`	in	donor concentration	1/m^3
`NA`	in	acceptor concentration	1/m^3
`ni`	in	intrinsic carrier concentration	1/m^3
`n`	out	electron concentration	1/m^3
`p`	out	hole concentration	1/m^3
`n_cm3`	out	n in cm^-3	,
`p_cm3`	out	p in cm^-3	,
`type`	out	n-type, p-type or intrinsic	,

Applies when: ND, NA >= 0; ni > 0; complete ionisation, non-degenerate.

```
$ electronics-engineering solve elx_doped_carrier_concentrations "ND=1e+16 cm^-3" "NA=0
cm^-3" "ni=1.5e+10 cm^-3"
n = 1e+22 1/m^3
p = 2.25e+10 1/m^3
n_cm3 = 1e+16
p_cm3 = 22500
type = n-type
  by: Electron and hole concentrations of doped (compensated) material  (n - p = ND - NA
and n p = ni^2: majority = |ND-NA|/2 + sqrt((ND-NA)^2/4 + ni^2), minority = ni^2/majority)
  ND = 1e+22 1/m^3
  NA = 0 1/m^3
  ni = 1.5e+16 1/m^3
  assumes: ND, NA >= 0; ni > 0; complete ionisation, non-degenerate
```

What the worked example means: This calculation determines the equilibrium electron and hole concentrations in a doped semiconductor by solving charge neutrality and the mass-action law simultaneously. Given a donor concentration of 1e+16 cm^-3 and an acceptor concentration of 0 cm^-3, with an intrinsic carrier concentration of 1.5e+10 cm^-3, the resulting electron density is 1e+22 1/m^3 and the hole density is 2.25e+10 1/m^3. These values classify the material as n-type, reflecting whether donors or acceptors dominate the net doping level.

Intrinsic carrier concentration, `elx_intrinsic_carrier_concentration`

The intrinsic carrier concentration ni = sqrt(Nc Nv) exp(-Eg/2kT) at a temperature, from the effective densities of states at 300 K (scaled as T^1.5) and the band gap; also the intrinsic level's offset from midgap.

$$n_i = \sqrt{N_c N_v}\, e^{-E_g/2kT}, \quad N_{c,v}(T) = N_{c,v}(300)\left(\tfrac{T}{300}\right)^{3/2}$$

symbol		meaning	SI unit
`Nc`	in	effective density of states in the conduction band at 300 K	1/m^3
`Nv`	in	effective density of states in the valence band at 300 K	1/m^3

symbol		meaning	SI unit
`Eg`	in	band gap energy	J
`T`	in	absolute temperature	K
`ni`	out	intrinsic carrier concentration	1/m^3
`ni_cm3`	out	ni in cm^-3	,
`Ei_minus_midgap_eV`	out	intrinsic Fermi level above midgap, eV	,
`Nc_T`	out	Nc at T	1/m^3
`Nv_T`	out	Nv at T	1/m^3

Applies when: Nc, Nv, Eg, T > 0; non-degenerate statistics, band gap independent of T.

```
$ electronics-engineering solve elx_intrinsic_carrier_concentration "Nc=2.8e+19 cm^-3"
"Nv=1.04e+19 cm^-3" "Eg=1.12 eV" "T=300 K"
ni = 6.67589872e+15 1/m^3
ni_cm3 = 6675898720
Ei_minus_midgap_eV = -0.01280189354
Nc_T = 2.8e+25 1/m^3
Nv_T = 1.04e+25 1/m^3
  by: Intrinsic carrier concentration  (Nc(T) = Nc (T/300)^1.5, Nv likewise; ni = sqrt(Nc
Nv) exp(-Eg/(2kT)); Ei - Emid = (kT/2) ln(Nv/Nc))
  Nc = 2.8e+25 1/m^3
  Nv = 1.04e+25 1/m^3
  Eg = 1.79443783e-19 J
  T = 300 K
  assumes: Nc, Nv, Eg, T > 0; non-degenerate statistics, band gap independent of T
```

What the worked example means: This calculation determines the intrinsic carrier concentration, denoted as ni, for a semiconductor material. It uses the effective densities of states in the conduction and valence bands at room temperature, scaled by the absolute temperature raised to the power of one and a half. The result, 6.6759e+15 1/m^3, represents the equilibrium concentration of electrons and holes in an undoped material. Additionally, the offset of the intrinsic Fermi level from midgap is calculated as -0.0128019, indicating the asymmetry between the band structures.

Junction (depletion) capacitance versus bias, `elx_junction_capacitance`

The depletion capacitance of a pn junction at a reverse bias from its zero-bias value, the built-in potential and the grading coefficient (1/2 abrupt, 1/3 linearly graded), as used for varactors.

$$C_j = \frac{C_{j0}}{(1 + V_R / V_{bi})^m}$$

symbol		meaning	SI unit
`Cj0`	in	zero-bias junction capacitance	F
`Vbi`	in	built-in potential	V
`VR`	in	reverse bias (negative for forward)	V
`m`	in	grading coefficient (0.5 abrupt, 0.33 linearly graded)	,
`Cj`	out	junction capacitance	F

symbol		meaning	SI unit
`ratio`	out	Cj/Cj0	,

Applies when: 0 < m < 1; VR > -Vbi.

```
$ electronics-engineering solve elx_junction_capacitance "Cj0=2 pF" "Vbi=0.75 V" "VR=5 V"
m=0.5
Cj = 7.223151185e-13 F
ratio = 0.3611575593
  by: Junction (depletion) capacitance versus bias  (Cj = Cj0 / (1 + VR/Vbi)^m)
  Cj0 = 2e-12 F
  Vbi = 0.75 V
  VR = 5 V
  m = 0.5
  assumes: 0 < m < 1; VR > -Vbi
```

What the worked example means: This calculation determines the depletion capacitance of a pn junction under reverse bias using the grading coefficient and built-in potential. Starting with the zero-bias junction capacitance of 2 pF, the model applies the voltage dependence defined by the reverse bias 5 V and the built-in potential 0.75 V. The resulting junction capacitance is 7.22315e-13 F, indicating that the capacitance has changed by a factor of 0.361158 compared to its initial state.

Thermal voltage kT/q, `elx_thermal_voltage`

The thermal voltage VT = kT/q at an absolute temperature (about 25.85 mV at 300 K), the voltage scale of every diode and transistor equation.

$$V_T = \frac{kT}{q}$$

symbol		meaning	SI unit
`T`	in	absolute temperature (degC is converted)	K
`VT`	out	thermal voltage	V
`VT_mV`	out	thermal voltage in millivolts	,

Applies when: T > 0 K.

```
$ electronics-engineering solve elx_thermal_voltage "T=300 K"
VT = 0.02585199979 V
VT_mV = 25.85199979
  by: Thermal voltage kT/q  (VT = k T / q)
  T = 300 K
  assumes: T > 0 K
```

What the worked example means: This calculation determines the thermal voltage, a fundamental parameter in semiconductor physics that sets the scale for diode and transistor behavior. It is computed by dividing Boltzmann's constant times the absolute temperature by the elementary charge. At the given temperature of 300 K, the resulting thermal voltage is 0.025852 V, which corresponds to 25.852 when expressed in millivolts.

Timing (5)

CMOS dynamic (switching) power, `elx_cmos_dynamic_power`

The dynamic power alpha C VDD^2 f of CMOS logic, the energy drawn from the supply per 0 -> 1 transition, the energy stored on the load and the average supply current.

$$P_{dyn} = \alpha C V_{DD}^2 f$$

symbol		meaning	SI unit
`alpha`	in	activity factor: probability of a 0 -> 1 transition per clock cycle	,
`C`	in	switched capacitance	F
`VDD`	in	supply voltage	V
`f`	in	clock frequency	Hz
`P`	out	dynamic power	W
`E_supply`	out	energy from the supply per transition, C VDD^2	J
`E_stored`	out	energy stored on C, C VDD^2/2	J
`I_avg`	out	average supply current	A

Applies when: 0 <= alpha <= 1; full-swing switching, short-circuit and leakage power not included.

```
$ electronics-engineering solve elx_cmos_dynamic_power alpha=0.1 "C=1000 pF" "VDD=1 V"
"f=1000000000 Hz"
P = 0.1 W
E_supply = 1e-09 J
E_stored = 5e-10 J
I_avg = 0.1 A
  by: CMOS dynamic (switching) power  (P = alpha C VDD^2 f)
  alpha = 0.1
  C = 1e-09 F
  VDD = 1 V
  f = 1000000000 Hz
  assumes: 0 <= alpha <= 1; full-swing switching, short-circuit and leakage power not
included
```

What the worked example means: This calculation determines the CMOS dynamic switching power using the formula P equals alpha times C times VDD squared times f. Given an activity factor of 0.1, a switched capacitance of 1000 pF, a supply voltage of 1 V, and a clock frequency of 1e+09 Hz, the resulting dynamic power is 0.1 W. This value represents the energy drawn from the supply per unit time due to charging and discharging the load capacitance during logic transitions, excluding leakage and short-circuit currents.

Elmore delay of an RC ladder (interconnect), `elx_elmore_delay`

The Elmore delay to every node of an RC ladder (a driver resistance and wire segments, each followed by a capacitance to ground), the delay at the far end and its 50 % estimate ln 2 tau.

$$\tau_D = \sum_i C_i \sum_{j \le i} R_j$$

symbol		meaning	SI unit
`R`	in	series resistances in ohms, from the driver outwards	,
`C`	in	node capacitances in picofarads, one after each resistor	,
`tau_D`	out	Elmore delay at the far end	s
`t50`	out	50 % delay estimate ln 2 tau_D	s
`delays`	out	Elmore delay at each node, seconds	,

Applies when: one capacitance per resistor; step input.

```
$ electronics-engineering solve elx_elmore_delay "R=[100, 50, 50]" "C=[0.1, 0.1, 0.2]"
tau_D = 6.5e-11 s
t50 = 4.505456674e-11 s
delays = [4e-11,5.5e-11,6.5e-11]
  by: Elmore delay of an RC ladder (interconnect)  (tau_k = sum_i C_i R(shared path of
nodes i and k))
  assumes: one capacitance per resistor; step input
```

What the worked example means: This calculation determines the Elmore delay for an RC ladder network, representing the time it takes for a signal to propagate through series resistances and node capacitances. The primary result, 6.5e-11 s, is the total delay at the final node, derived from the sum of each capacitance multiplied by the resistance shared between that node and the source. A common approximation for the actual switching threshold is provided as 4.50546e-11 s, which equals the natural logarithm of two times the Elmore delay. The intermediate values in [4e-11, 5.5e-11, 6.5e-11] show how the delay accumulates at each step along the interconnect.

Flip-flop setup and hold slack, maximum clock frequency, `elx_setup_hold_timing`

The setup slack, hold slack, maximum clock frequency and a verdict for a register-to-register path from clock-to-Q, logic delays, setup and hold times and clock skew (positive when the capture clock is late).

$$T \geq t_{cq} + t_{pd} + t_{su} - t_{skew}, \quad t_{ccq} + t_{cd} \geq t_h + t_{skew}$$

symbol		meaning	SI unit
`T`	in	clock period	s
`tcq`	in	maximum clock-to-Q delay	s
`tpd`	in	maximum logic delay	s
`tsu`	in	setup time	s
`tskew`	in	clock skew, capture minus launch	s
`tccq`	in	minimum (contamination) clock-to-Q	s
`tcd`	in	minimum (contamination) logic delay	s
`th`	in	hold time	s
`setup_slack`	out	setup slack	s
`hold_slack`	out	hold slack	s
`f_max`	out	maximum clock frequency	Hz
`verdict`	out	meets timing, setup violation, hold violation or both	,

Applies when: edge-triggered registers, single clock.

```
$ electronics-engineering solve elx_setup_hold_timing "T=5 ns" "tcq=0.3 ns" "tpd=3.5 ns"
"tsu=0.2 ns" "tskew=0.1 ns" "tccq=0.1 ns" "tcd=0.2 ns" "th=0.1 ns"
setup_slack = 1.1e-09 s
hold_slack = 1e-10 s
f_max = 256410256.4 Hz
verdict = meets timing
  by: Flip-flop setup and hold slack, maximum clock frequency  (setup slack = T + skew -
(tcq + tpd + tsu); hold slack = tccq + tcd - th - skew; f_max = 1/(tcq + tpd + tsu - skew))
  T = 5e-09 s
  tcq = 3e-10 s
  tpd = 3.5e-09 s
  tsu = 2e-10 s
  tskew = 1e-10 s
  tccq = 1e-10 s
  tcd = 2e-10 s
  th = 1e-10 s
  assumes: edge-triggered registers, single clock
```

What the worked example means: This calculation determines timing margins for a register-to-register path. Setup slack, computed as 1.1e-09 s, indicates how much time remains before data must be stable relative to the clock edge. Hold slack, shown as 1e-10 s, measures the margin preventing new data from overwriting old data too quickly. The maximum operating frequency is derived as 2.5641e+08 Hz, representing the fastest clock rate that satisfies both setup constraints.

RC delay, 10-90 % rise time and bandwidth, `elx_rc_delay_rise_time`

The time constant, the 50 % delay (ln 2 RC), the 10-90 % rise time (ln 9 RC = 2.2 RC), the -3 dB bandwidth and the rise-time-bandwidth product (0.35) of a first-order RC low-pass.

$$t_r = \ln 9\, RC \approx 2.2RC, \quad t_r f_{3dB} \approx 0.35$$

symbol		meaning	SI unit
`R`	in	resistance	ohm
`C`	in	capacitance	F
`tau`	out	time constant RC	s
`t50`	out	50 % delay	s
`t_rise`	out	10-90 % rise time	s
`f_3dB`	out	-3 dB bandwidth	Hz
`tr_times_bw`	out	rise time x bandwidth	,

Applies when: step input, first-order RC.

```
$ electronics-engineering solve elx_rc_delay_rise_time "R=1000 ohm" "C=10 pF"
tau = 1e-08 s
t50 = 6.931471806e-09 s
t_rise = 2.197224577e-08 s
f_3dB = 15915494.31 Hz
tr_times_bw = 0.3496991526
  by: RC delay, 10-90 % rise time and bandwidth  (t50 = ln 2 RC; tr = ln 9 RC; f = 1/(2 pi
RC); tr f = ln 9/(2 pi))
  R = 1000 ohm
  C = 1e-11 F
  assumes: step input, first-order RC
```

In the worked example, R = 1000 ohm, C = 10 pF go through the equation above and give tau = 1e-08 s, t50 = 6.931471806e-09 s, t_rise = 2.197224577e-08 s, f_3dB = 15915494.31 Hz. It applies only when step input, first-order RC: outside that it says what is wrong instead of returning a number.

Synchronizer metastability MTBF, `elx_metastability_mtbf`

The mean time between synchronizer failures MTBF = exp(tr/tau)/(T0 fclk fdata) from the resolution time allowed, the flip-flop's time constant and window, and the clock and data rates.

$$\mathrm{MTBF} = \frac{e^{t_r/\tau}}{T_0 f_{clk} f_{data}}$$

symbol		meaning	SI unit
`tr`	in	resolution time available	s
`tau`	in	metastability time constant	s
`T0`	in	metastability window T0	s
`fclk`	in	clock frequency	Hz
`fdata`	in	rate of asynchronous data changes	Hz
`MTBF_s`	out	MTBF	s
`MTBF_years`	out	MTBF in years (365.25 days)	,
`log10_MTBF_s`	out	log10 of MTBF in seconds	,

Applies when: tr/tau <= 700.

```
$ electronics-engineering solve elx_metastability_mtbf "tr=2 ns" "tau=50 ps" "T0=100 ps"
"fclk=500000000 Hz" "fdata=10000000 Hz"
MTBF_s = 4.707705337e+11 s
MTBF_years = 14917.81801
log10_MTBF_s = 11.67280927
  by: Synchronizer metastability MTBF  (MTBF = exp(tr/tau)/(T0 fclk fdata))
  tr = 2e-09 s
  tau = 5e-11 s
  T0 = 1e-10 s
  fclk = 500000000 Hz
  fdata = 10000000 Hz
  assumes: tr/tau <= 700
```

What the worked example means: This calculation determines the mean time between synchronizer failures using the resolution time available, the metastability time constant and window, and the clock and data frequencies. The resulting mean time between failures is 4.70771e+11 s seconds, equivalent to 14917.8 years. This metric indicates how long the circuit is expected to operate before a synchronization error occurs, with higher values representing greater reliability.

Questions and reports: support@ai999x.com. AI999X, The Future Is Self-Improving.