environmental-engineering: the Environmental Engineering program, user guide

environmental-engineering-ai999x 1.1.0, Rust build: command line, desktop app and browser. **Creator / engineer:** Ibnul Jaif Farabi · **Company:** AI999X · support@ai999x.com

Environmental Engineering covers Gaussian plume dispersion and plume rise, BOD and Streeter-Phelps oxygen sag, water and wastewater treatment design, activated sludge, disinfection CT, Henry's law and air stripping, noise and solid waste. This guide is about `environmental-engineering`, the model as a self-contained program for Windows and Linux: 99 capabilities in 7 topics, answered on your own computer with no network, no Python and nothing else to install. The same compiled model runs in the AI999X desktop app and in the browser on the model's page (https://www.ai999x.com/models/environmental-engineering-ai999x/); the Python package (`pip install environmental-engineering-ai999x`) has its own guide. Every command output printed here is what the program printed.

Contents

- 1. Get it: desktop app, command line, browser, Python
- 2. Quick start
- 3. Writing inputs
- 4. Outcomes and exit codes
- 5. Scripts and agents: batch and JSON
- 6. Figures
- 7. In a web page or Node.js: WebAssembly
- 8. Every capability

1. Get it

Version 1.5.0 of the AI999X desktop app and of the command-line bundle. Checksums for every file: https://downloads.ai999x.com/desktop/1.5.0/SHA256SUMS; the newest version is always under https://downloads.ai999x.com/desktop/latest/. Full instructions: https://www.ai999x.com/desktop-cli/

what	system	download
Desktop app: Environmental Engineering	Windows x86-64	https://downloads.ai999x.com/desktop/1.5.0/ai999x-environmental-engineering-1.5.0-windows-x86_64.zip
Desktop app: Environmental Engineering	Linux x86-64	https://downloads.ai999x.com/desktop/1.5.0/ai999x-environmental-engineering-1.5.0-linux-x86_64.tar.gz
Desktop app: all models	Windows x86-64	https://downloads.ai999x.com/desktop/1.5.0/ai999x-1.5.0-windows-x86_64.zip
Desktop app: all models	Linux x86-64	https://downloads.ai999x.com/desktop/1.5.0/ai999x-1.5.0-linux-x86_64.tar.gz
Command line	Windows x86-64	https://downloads.ai999x.com/desktop/1.5.0/ai999x-cli-1.5.0-windows-x86_64.zip
Command line	Linux x86-64	https://downloads.ai999x.com/desktop/1.5.0/ai999x-cli-1.5.0-linux-x86_64.tar.gz

Desktop app

Environmental Engineering in its own app: search, questions in words, input forms, live figures and explanations. Windows: Download ai999x-environmental-engineering-1.5.0-windows-x86_64.zip, right-click it → Extract All, then open the folder and start ai999x-environmental-engineering.exe. If Windows SmartScreen asks, choose More info → Run anyway. Linux:

```
curl -LO https://downloads.ai999x.com/desktop/1.5.0/ai999x-environmental-engineering-1.5.0-linux-x86_64.tar.gz
curl -LO https://downloads.ai999x.com/desktop/1.5.0/SHA256SUMS
sha256sum -c --ignore-missing SHA256SUMS
tar xzf ai999x-environmental-engineering-1.5.0-linux-x86_64.tar.gz
./ai999x-environmental-engineering-1.5.0-linux-x86_64/ai999x-environmental-engineering
```

It opens on this model: type a question or pick a capability, fill in the form and press Compute. The AI999X desktop app with every model works the same way (choose the model first). Windows: Download ai999x-1.5.0-windows-x86_64.zip, right-click it → Extract All, then open the folder and start ai999x.exe. If Windows SmartScreen asks, choose More info → Run anyway. Linux:

```
curl -LO https://downloads.ai999x.com/desktop/1.5.0/ai999x-1.5.0-linux-x86_64.tar.gz
curl -LO https://downloads.ai999x.com/desktop/1.5.0/SHA256SUMS
sha256sum -c --ignore-missing SHA256SUMS
tar xzf ai999x-1.5.0-linux-x86_64.tar.gz
./ai999x-1.5.0-linux-x86_64/ai999x
```

Command line, Linux

The bundle holds one program per model; `environmental-engineering` is this one. The checksum line should print OK.

```
curl -LO https://downloads.ai999x.com/desktop/1.5.0/ai999x-cli-1.5.0-linux-x86_64.tar.gz
curl -LO https://downloads.ai999x.com/desktop/1.5.0/SHA256SUMS
sha256sum -c --ignore-missing SHA256SUMS
mkdir -p ~/.local/share && tar xzf ai999x-cli-1.5.0-linux-x86_64.tar.gz -C ~/.local/share
echo 'export PATH="$HOME/.local/share/ai999x-cli-1.5.0-linux-x86_64:$PATH"' >> ~/.bashrc && source ~/.bashrc
environmental-engineering --version
```

Command line, Windows (PowerShell)

The fourth line should print True.

```
$F = "ai999x-cli-1.5.0-windows-x86_64.zip"
Invoke-WebRequest "https://downloads.ai999x.com/desktop/1.5.0/$F" -OutFile $F
Invoke-WebRequest "https://downloads.ai999x.com/desktop/1.5.0/SHA256SUMS" -OutFile SHA256SUMS
(Get-FileHash $F -Algorithm SHA256).Hash.ToLower() -eq ((Select-String -SimpleMatch $F SHA256SUMS).Line -split ' ')[0]
Expand-Archive $F -DestinationPath "$env:LOCALAPPDATA\AI999X" -Force
$D = "$env:LOCALAPPDATA\AI999X\ai999x-cli-1.5.0-windows-x86_64"; $env:Path += ";$D"
[Environment]::SetEnvironmentVariable("Path", [Environment]::GetEnvironmentVariable("Path", "User") + ";$D", "User")
environmental-engineering --version
```

In your browser

Open https://www.ai999x.com/models/environmental-engineering-ai999x/, choose a capability and press Compute in your browser: the same program runs on your device as WebAssembly; nothing is sent anywhere.

Python

```
pip install environmental-engineering-ai999x
```

2. Quick start

2.1 Check the install

Prints the model, its version and that this is the Rust build.

```
$ environmental-engineering --version
environmental-engineering-ai999x 1.5.0 (Rust build, ax-engine 1.5.0)
```

2.2 Ask in words

Write the question as you would say it: the program reads the quantities and their units, picks the capability and answers.

```
$ environmental-engineering ask "Streeter-Phelps oxygen deficit: kd = 0.23 1/d, ka = 0.46 1/d, L0 =
10 mg/L, D0 = 1 mg/L, t = 2 d, DOsat = 9.1 mg/L"
Read as: Streeter-Phelps oxygen deficit and dissolved oxygen at a travel time
D = 0.002726165085 kg/m^3
DO = 0.006373834915 kg/m^3
D_mgL = 2.726165085
DO_mgL = 6.373834915
  by: Streeter-Phelps oxygen deficit and dissolved oxygen at a travel time  (D = kd L0/(ka - kd)
(e^(-kd t) - e^(-ka t)) + D0 e^(-ka t); for ka = kd, D = (kd L0 t + D0) e^(-kd t))
  D0 = 0.001 kg/m^3
  DOsat = 0.0091 kg/m^3
  L0 = 0.01 kg/m^3
  ka = 5.324074074e-06 1/s
  kd = 2.662037037e-06 1/s
  t = 172800 s
  assumes: first-order deoxygenation and reaeration; plug flow; deficit stays below saturation
```

2.3 Find a capability

Search the capabilities by what you want to know; the first column is the id to pass to info and solve.

```
$ environmental-engineering search "streeter-phelps oxygen deficit and dissolved oxygen at a travel
time"
enveng_streeter_phelps_deficit       Streeter-Phelps oxygen deficit and dissolved oxygen at a
travel time  (water quality / oxygen sag)
enveng_oxygen_sag_distance           Dissolved oxygen at a distance downstream (Streeter-Phelps)
(water quality / oxygen sag)
enveng_streeter_phelps_critical_point Critical (minimum) dissolved oxygen of the oxygen sag  (water
quality / oxygen sag)
enveng_aeration_do_curve             Dissolved oxygen during aeration and the transfer rate
(wastewater / aeration)
enveng_do_saturation                 Dissolved oxygen saturation concentration (Benson-Krause)
(water quality / dissolved oxygen)
enveng_kla_two_point                 Overall oxygen transfer coefficient KLa from two DO readings
(wastewater / aeration)
enveng_theoretical_oxygen_demand     Theoretical oxygen demand of an organic compound  (water
quality / oxygen demand)
enveng_aeration_oxygen_requirement   Oxygen requirement of an activated-sludge process  (wastewater
/ activated sludge)
… 12 more
```

2.4 List the capabilities

Every capability the program answers: its id (what you pass to solve) and its name.

```
$ environmental-engineering list
enveng_activated_sludge_cstr_design      Activated sludge (complete mix) effluent substrate and
biomass (Lawrence-McCarty)
enveng_aeration_do_curve                 Dissolved oxygen during aeration and the transfer rate
enveng_aeration_oxygen_requirement       Oxygen requirement of an activated-sludge process
enveng_air_stripping_tower               Packed-tower air stripping: stripping factor, transfer
units and height
enveng_anaerobic_methane_yield           Methane production from COD removed (anaerobic digestion)
enveng_background_noise_correction       Source level after removing background noise
enveng_backwash_bed_expansion            Filter bed expansion during backwash
enveng_bod_dilution_test                 BOD from a dilution test (with optional seed correction)
… 91 more
```

2.5 What a capability needs

The equation or method, every input and output with its SI unit. Read this before solve: it tells you the input names.

```
$ environmental-engineering info enveng_streeter_phelps_deficit
Streeter-Phelps oxygen deficit and dissolved oxygen at a travel time
  D = kd L0/(ka - kd) (e^(-kd t) - e^(-ka t)) + D0 e^(-ka t); for ka = kd, D = (kd L0 t + D0) e^(-
kd t)
  in   kd       deoxygenation rate constant [1/s]
  in   ka       reaeration rate constant [1/s]
  in   L0       ultimate BOD of the mixed river water at the outfall [kg/m^3]
  in   D0       oxygen deficit at the outfall (DOsat - DO) [kg/m^3]
  in   t        travel time from the outfall [s]
  in   DOsat    saturation dissolved oxygen [kg/m^3]
  out  D        oxygen deficit at t [kg/m^3]
  out  DO       dissolved oxygen at t [kg/m^3]
  out  D_mgL    deficit in mg/L []
  out  DO_mgL   dissolved oxygen in mg/L []
```

2.6 Solve

Inputs as name=value, each with any unit of the right kind. The answer lists every output, the method used, each input converted to SI, and the conditions the answer assumes.

```
$ environmental-engineering solve enveng_streeter_phelps_deficit "kd=0.23 1/day" "ka=0.46 1/day"
"L0=10 mg/L" "D0=1 mg/L" "t=2 day" "DOsat=9.1 mg/L"
D = 0.002726165085 kg/m^3
DO = 0.006373834915 kg/m^3
D_mgL = 2.726165085
DO_mgL = 6.373834915
  by: Streeter-Phelps oxygen deficit and dissolved oxygen at a travel time  (D = kd L0/(ka - kd)
(e^(-kd t) - e^(-ka t)) + D0 e^(-ka t); for ka = kd, D = (kd L0 t + D0) e^(-kd t))
  kd = 2.662037037e-06 1/s
  ka = 5.324074074e-06 1/s
  L0 = 0.01 kg/m^3
  D0 = 0.001 kg/m^3
  t = 172800 s
  DOsat = 0.0091 kg/m^3
  assumes: first-order deoxygenation and reaeration; plug flow; deficit stays below saturation
```

2.7 Machine-readable answer

--json prints the same answer as one line of JSON (values in SI): for scripts and other programs.

```
$ environmental-engineering solve enveng_streeter_phelps_deficit "kd=0.23 1/day" "ka=0.46 1/day"
"L0=10 mg/L" "D0=1 mg/L" "t=2 day" "DOsat=9.1 mg/L" --json
{"outcome":"SOLVED","message":"","value":0.00637383491469,"unit":"kg/m^3","solved_for":"DO","si":
[["kd",2.662037037037037e-6],["ka",5.324074074074074e-6],["L0",0.01],["D0",0.001],["t",172800.0],
["DOsat",0.0091]],"values":[["D",0.00272616508531,"kg/m^3"],["DO",0.00637383491469,"kg/m^3"],
["D_mgL",2.72616508531,""],["DO_mgL",6.37383491469,""]],"target":"DO","phrase":"oxygen deficit at
t","assumptions":["first-order deoxygenation and reaeration","plug flow","deficit stays below
saturation"],"name":"Streeter-Phelps oxygen deficit and dissolved oxygen at a travel
time","equation":"D = kd L0/(ka - kd) (e^(-kd t) - e^(-ka t)) + D0 e^(-ka t); for ka = kd, D = (kd
L0 t + D0) e^(-kd t)"}
```

2.8 When an input is missing

No number is guessed: the answer names what is missing, shows a complete call, and the program exits with status 1.

```
$ environmental-engineering solve enveng_streeter_phelps_deficit "kd=0.23 1/day" "ka=0.46 1/day"
"L0=10 mg/L" "D0=1 mg/L" "t=2 day"
NEEDS_INPUT: enveng_streeter_phelps_deficit needs DOsat (saturation dissolved oxygen). Example:
solve('enveng_streeter_phelps_deficit', kd='2.66204e-06 1/s', ka='5.32407e-06 1/s', L0='0.01
kg/m^3', D0='0.001 kg/m^3', t='172800 s', DOsat='0.0091 kg/m^3').
```

2.9 Many questions at once

One JSON request per line in, one JSON answer per line out, in order: for scripts, notebooks and agents (the program starts once). In PowerShell: Get-Content cases.jsonl | environmental-engineering batch

`cases.jsonl`:

```
{"key": "enveng_streeter_phelps_deficit", "inputs": {"kd": "0.23 1/day", "ka": "0.46 1/day", "L0":
"10 mg/L", "D0": "1 mg/L", "t": "2 day", "DOsat": "9.1 mg/L"}}
{"key": "enveng_briggs_plume_rise", "inputs": {"vs": "15 m/s", "d": "3 m", "Ts": "420 K", "Ta":
"288 K", "u": "5 m/s", "hs": "100 m"}}
```

```
$ environmental-engineering batch < cases.jsonl
{"outcome":"SOLVED","message":"","value":0.00637383491469,"unit":"kg/m^3","solved_for":"DO","si":
[["kd",2.662037037037037e-6],["ka",5.324074074074074e-6],["L0",0.01],["D0",0.001],["t",172800.0],
["DOsat",0.0091]],"values":[["D",0.00272616508531,"kg/m^3"],["DO",0.00637383491469,"kg/m^3"],
["D_mgL",2.72616508531,""],["DO_mgL",6.37383491469,""]],"target":"DO","phrase":"oxygen deficit at
t","assumptions":["first-order deoxygenation and reaeration","plug flow","deficit stays below
saturation"],"name":"Streeter-Phelps oxygen deficit and dissolved oxygen at a travel
time","equation":"D = kd L0/(ka - kd) (e^(-kd t) - e^(-ka t)) + D0 e^(-ka t); for ka = kd, D = (kd
L0 t + D0) e^(-kd t)"}
{"outcome":"SOLVED","message":"","value":125.637535501,"unit":"m","solved_for":"dh","si":
[["vs",15.0],["d",3.0],["Ts",420.0],["Ta",288.0],["u",5.0],["hs",100.0]],"values":
[["F",104.0205375,""],["x_f",762.771747653,"m"],["dh",125.637535501,"m"],
["H",225.637535501,"m"]],"target":"dh","phrase":"buoyancy flux, m^4/s^3","assumptions":["Ts >
Ta","neutral or unstable air (classes A-D)","buoyancy-dominated plume"],"name":"Briggs plume rise
and effective stack height (neutral or unstable air)","equation":"F = g vs d^2 (Ts - Ta)/(4 Ts);
x_f = 49 F^(5/8) (F < 55) or 119 F^(2/5); dh = 1.6 F^(1/3) x_f^(2/3)/u"}
```

3. Writing inputs

Inputs are written `name=value`, one per argument; `environmental-engineering info <capability>` lists the names. Quote an argument that holds a space or brackets (bash, zsh and PowerShell all accept double quotes). The answer always states each input as it was read, converted to SI, so a misread unit is visible at once.

kind	example	how it is read
a number with a unit	`"R=0.128 nm"`	any unit of the same kind; converted to SI
a number in SI	`R=1.28e-10`	no unit means the SI unit shown by info

kind	example	how it is read
a choice	`structure=FCC`	one of the values info lists
a list or vector	`"v=[1, 2, 3]" or "v=1, 2, 3"`	brackets keep it a list
a matrix	`"A=[[1, 2], [3, 4]]"`	one list per row
true / false	`inclusive=true`	for yes/no options

An equation can be solved for any of its quantities: give the others and add `--target <symbol>`. Without `--target`, the program solves for the quantity the capability is named after.

4. Outcomes and exit codes

The program never guesses a number: when it cannot answer, it says why and exits with status 1, so a script can tell an answer from a refusal without reading the text.

outcome	meaning	exit status
SOLVED	the answer: every output with its unit, the method, the inputs in SI, the conditions assumed	0
NEEDS_INPUT	an input is missing; the message names it and shows a complete call	1
INVALID_INPUT	a value or unit of the wrong kind, an unknown input name, or a value outside the conditions	1
AMBIGUOUS	the inputs allow two different answers; say which one is meant	1
OUT_OF_SCOPE	the model has no capability for this, or the result would not be meaningful	1
(usage)	a command the program does not know: it prints its usage	2

5. Scripts and agents: batch and JSON

`environmental-engineering solve ... --json` prints one answer as one line of JSON. `environmental-engineering batch` reads one request per line on standard input and writes one JSON answer per line, in order, starting the program once for any number of requests. A request is `{"key": "<capability>", "inputs": {"name": "value", ...}, "target": null}`. In PowerShell, pipe the file in: `Get-Content cases.jsonl | environmental-engineering batch`. `environmental-engineering catalog` prints every capability with its inputs as JSON, to build forms or tool definitions.

answer field	meaning
outcome	one of the outcomes above
message	why there is no answer (empty when SOLVED)
value, unit	the main result in SI units
values	every output: [symbol, value, unit] (procedures)
target	the quantity solved for
si	each numeric input converted to SI: [symbol, value]
assumptions	the conditions the answer relies on
name, equation	the capability and its equation or method

```
import json, subprocess

reqs = [{"key": "<capability>", "inputs": {"name": "value"}}]
out = subprocess.run(["environmental-engineering", "batch"], input="\n".join(map(json.dumps,
reqs)),
                     capture_output=True, text=True, check=True).stdout
answers = [json.loads(line) for line in out.splitlines()]
```

6. Figures

`environmental-engineering figures <capability> name=value ... --out DIR` draws the live figures for those inputs and writes each as an SVG file into DIR (an existing folder); without `--out` the SVG text comes back as JSON. The desktop app and the model page draw the same figures as soon as you press Compute.

7. In a web page or Node.js: WebAssembly

The same model is a WebAssembly module, `environmental_engineering_ai999x.wasm` (https://www.ai999x.com/compute/rust/environmental_engineering_ai999x.wasm), with a small loader, `ax-wasm.js` (https://www.ai999x.com/compute/rust/ax-wasm.js). It runs in a browser, a Web Worker or Node.js, with no server.

```
<script src="ax-wasm.js"></script>
<script>
  AXWasm.load("environmental_engineering_ai999x.wasm").then(function (m) {
    var a = m.solve({key: "<capability>", inputs: {name: "value"}});
    console.log(a.outcome, a.values || a.value);
    console.log(m.catalog().capabilities.length + " capabilities");
  });
</script>
```

8. Every capability

By topic. For each: what it does, what it needs and gives, when it applies, and a command with what the program printed for it. `environmental-engineering info <id>` shows the same inputs and outputs in the terminal.

Air pollution (21)

Box model of an air basin (well-mixed, time-dependent), `enveng_box_model`

The concentration over a city treated as a well-mixed box: emission flux per area, wind through a box of length L under a mixing height, background air; the concentration after time t and at steady state.

$$C(t) = C_{ss} + (C_0 - C_{ss})e^{-ut/L}, \quad C_{ss} = C_b + \frac{qL}{uH_m}$$

symbol		meaning	SI unit
q	in	emission rate per unit ground area	kg/(m^2*s)

symbol		meaning	SI unit
`L`	in	box length along the wind	m
`u`	in	wind speed	m/s
`Hm`	in	mixing height	m
`Cb`	in	background (upwind) concentration	kg/m^3
`C0`	in	concentration at t = 0	kg/m^3
`t`	in	elapsed time	s
`C`	out	concentration at time t	kg/m^3
`C_ss`	out	steady-state concentration	kg/m^3
`C_ugm3`	out	concentration at t in micrograms per cubic metre	,

Applies when: well-mixed box; constant wind, mixing height and emissions.

```
$ environmental-engineering solve enveng_box_model "q=4 ug/(m^2*s)" "L=15000 m" "u=3 m/s" "Hm=600
m" "Cb=20 ug/m^3" "C0=20 ug/m^3" "t=2 h"
C = 4.543574138e-08 kg/m^3
C_ss = 5.333333333e-08 kg/m^3
C_ugm3 = 45.43574138
  by: Box model of an air basin (well-mixed, time-dependent)  (dC/dt = q/Hm - u (C - Cb)/L, so C =
Css + (C0 - Css) e^(-u t/L) with Css = Cb + q L/(u Hm))
  q = 4e-09 kg/(m^2*s)
  L = 15000 m
  u = 3 m/s
  Hm = 600 m
  Cb = 2e-08 kg/m^3
  C0 = 2e-08 kg/m^3
  t = 7200 s
  assumes: well-mixed box; constant wind, mixing height and emissions
```

What the worked example means: This calculation determines the pollutant concentration in a well-mixed air basin after a specific time. It uses the emission rate per area, box length, wind speed, mixing height, background concentration, initial concentration, and elapsed time. The result shows how the concentration approaches its steady state, with the final value being 4.54357e-08 kg/m^3.

Briggs dispersion coefficients sigma_y and sigma_z, `enveng_briggs_dispersion_coefficients`

The horizontal and vertical plume spreads (Pasquill-Gifford curves in Briggs' formulas) at a downwind distance for a stability class, open-country or urban.

$$\sigma_y = \frac{a_y x}{\sqrt{1 + b_y x}}, \quad \sigma_z = a_z x \, (1 + b_z x)^{p_z}$$

symbol		meaning	SI unit
`x`	in	downwind distance from the source	m
`cls`	in	Pasquill stability class A-F (urban: A and B share A-B, E and F share E-F)	,
`terrain`	in	rural (open country) or urban coefficients	,
`sigma_y`	out	horizontal (crosswind) dispersion coefficient	m

symbol		meaning	SI unit
`sigma_z`	out	vertical dispersion coefficient	m

Applies when: 100 m <= x <= 10 km.

```
$ environmental-engineering solve enveng_briggs_dispersion_coefficients "x=1000 m" cls=d
terrain=rural
sigma_y = 76.27700714 m
sigma_z = 37.94733192 m
  by: Briggs dispersion coefficients sigma_y and sigma_z  (Briggs (1973) interpolation formulas
sigma = a x (1 + b x)^p for each class and terrain)
  x = 1000 m
  cls = d
  terrain = rural
  assumes: 100 m <= x <= 10 km
```

What the worked example means: This calculation determines the dispersion coefficients for a plume traveling a specific distance. Using Briggs interpolation formulas, the model computes the horizontal crosswind spread as 76.277 m and the vertical spread as 37.9473 m. These values represent the standard deviations of the pollutant concentration distribution in the crosswind and vertical directions respectively, based on the atmospheric stability class and terrain type provided.

Briggs plume rise and effective stack height (neutral or unstable air), `enveng_briggs_plume_rise`

The buoyancy flux, the final plume rise by Briggs' 2/3 law (neutral or unstable air) and the effective stack height.

$$F = \frac{g v_s d^2 (T_s - T_a)}{4 T_s}, \quad \Delta h = \frac{1.6 F^{1/3} x_f^{2/3}}{u}$$

symbol		meaning	SI unit
`vs`	in	stack gas exit velocity	m/s
`d`	in	stack inside diameter at the exit	m
`Ts`	in	stack gas temperature	K
`Ta`	in	ambient air temperature	K
`u`	in	wind speed at the stack top	m/s
`hs`	in	physical stack height	m
`F`	out	buoyancy flux, m^4/s^3	,
`x_f`	out	distance to final rise	m
`dh`	out	plume rise	m
`H`	out	effective stack height hs + dh	m

Applies when: Ts > Ta; neutral or unstable air (classes A-D); buoyancy-dominated plume.

```
$ environmental-engineering solve enveng_briggs_plume_rise "vs=15 m/s" "d=3 m" "Ts=420 K" "Ta=288
K" "u=5 m/s" "hs=100 m"
F = 104.0205375
x_f = 762.7717477 m
dh = 125.6375355 m
H = 225.6375355 m
  by: Briggs plume rise and effective stack height (neutral or unstable air)  (F = g vs d^2 (Ts -
Ta)/(4 Ts); x_f = 49 F^(5/8) (F < 55) or 119 F^(2/5); dh = 1.6 F^(1/3) x_f^(2/3)/u)
  vs = 15 m/s
  d = 3 m
  Ts = 420 K
  Ta = 288 K
  u = 5 m/s
  hs = 100 m
  assumes: Ts > Ta; neutral or unstable air (classes A-D); buoyancy-dominated plume
```

What the worked example means: This calculation determines the effective stack height by combining the physical structure with the buoyancy-driven plume rise. The buoyancy flux, calculated as 104.021, drives the vertical ascent of the smoke column in neutral or unstable atmospheric conditions. Using Briggs' method for final rise distance and subsequent elevation gain, the total plume rise is found to be 125.638 m. Adding this to the physical stack height yields an effective release height of 225.638 m, which represents the altitude at which pollutants are effectively dispersed into the atmosphere.

Briggs plume rise in stable air, `enveng_briggs_stable_plume_rise`

The final rise of a buoyant plume in stable air (classes E, F) from the buoyancy flux, wind speed and potential-temperature gradient, and the effective stack height.

$$\Delta h = 2.6\left(\frac{F}{us}\right)^{1/3}, \quad s = \frac{g}{T_a}\frac{\partial\theta}{\partial z}$$

symbol		meaning	SI unit
`vs`	in	stack gas exit velocity	m/s
`d`	in	stack inside diameter at the exit	m
`Ts`	in	stack gas temperature	K
`Ta`	in	ambient air temperature	K
`u`	in	wind speed at the stack top	m/s
`dtheta`	in	potential temperature gradient d(theta)/dz	K/m
`hs`	in	physical stack height	m
`F`	out	buoyancy flux, m^4/s^3	,
`s`	out	stability parameter g/Ta dtheta/dz, 1/s^2	,
`dh`	out	plume rise	m
`H`	out	effective stack height	m

Applies when: Ts > Ta; stable air: dtheta/dz > 0.

```
$ environmental-engineering solve enveng_briggs_stable_plume_rise "vs=15 m/s" "d=3 m" "Ts=420 K"
"Ta=288 K" "u=4 m/s" "dtheta=0.02 K/m" "hs=100 m"
F = 104.0205375
s = 0.0006810173611
dh = 87.55352869 m
H = 187.5535287 m
  by: Briggs plume rise in stable air  (s = (g/Ta) dtheta/dz; dh = 2.6 (F/(u s))^(1/3))
  vs = 15 m/s
  d = 3 m
  Ts = 420 K
  Ta = 288 K
  u = 4 m/s
  dtheta = 0.02 K/m
  hs = 100 m
  assumes: Ts > Ta; stable air: dtheta/dz > 0
```

What the worked example means: This calculation determines the final vertical rise of a buoyant smoke plume under stable atmospheric conditions. It uses the buoyancy flux derived from the exit velocity 15 m/s, stack diameter 3 m, and temperature difference between the gas 420 K and ambient air 288 K. The stability parameter 0.000681017 reflects how strongly the atmosphere resists vertical motion based on the potential temperature gradient 0.02 K/m. The wind speed 4 m/s at the stack top dilutes the plume's momentum. The computed plume rise 87.5535 m is added to the physical stack height 100 m to find the total effective release height 187.554 m, which dictates how high pollutants are lifted before dispersing.

Cyclone cut diameter and fractional efficiency (Lapple), `enveng_cyclone_lapple`

The cut diameter (50 % efficiency) of a cyclone from the gas viscosity, inlet width, effective number of turns, inlet velocity and densities, and the collection efficiency of a particle size by Lapple's curve.

$$d_{50} = \sqrt{\frac{9\mu W}{2\pi N_e V_i(\rho_p - \rho_g)}}, \quad \eta = \frac{1}{1 + (d_{50}/d_p)^2}$$

symbol		meaning	SI unit
`mu`	in	gas viscosity	Pa*s
`W`	in	inlet width	m
`Ne`	in	effective number of turns	,
`Vi`	in	inlet gas velocity	m/s
`rho_p`	in	particle density	kg/m^3
`rho_g`	in	gas density	kg/m^3
`dp`	in	particle diameter	m
`d50`	out	cut diameter	m
`eta`	out	collection efficiency of particles of diameter dp	,

Applies when: rho_p > rho_g.

```
$ environmental-engineering solve enveng_cyclone_lapple "mu=1.8e-05 Pa*s" "W=0.25 m" Ne=6 "Vi=15
m/s" "rho_p=1500 kg/m^3" "rho_g=1.2 kg/m^3" "dp=10 um"
d50 = 6.912648602e-06 m
eta = 0.6766599842
  by: Cyclone cut diameter and fractional efficiency (Lapple)  (d50 = sqrt(9 mu W/(2 pi Ne Vi
(rho_p - rho_g))); eta = 1/(1 + (d50/dp)^2))
  mu = 1.8e-05 Pa*s
  W = 0.25 m
  Ne = 6
  Vi = 15 m/s
  rho_p = 1500 kg/m^3
  rho_g = 1.2 kg/m^3
  dp = 1e-05 m
  assumes: rho_p > rho_g
```

What the worked example means: This calculation determines the cyclone's cut diameter, which is the particle size collected with fifty percent efficiency. Using Lapple's method, the result depends on gas viscosity, inlet width, number of turns, inlet velocity, and density differences. For the specified particle size of 10 um, the predicted fractional efficiency is 0.67666. A smaller cut diameter generally indicates higher separation capability for fine particles.

Electrostatic precipitator efficiency (Deutsch-Anderson), `enveng_esp_efficiency`

The collection efficiency and penetration of an electrostatic precipitator from the drift velocity, collecting area and gas flow.

$$\eta = 1 - e^{-wA/Q}$$

symbol		meaning	SI unit
`w`	in	effective drift (migration) velocity	m/s
`A`	in	collecting plate area	m^2
`Q`	in	gas flow rate	m^3/s
`eta`	out	collection efficiency (fraction)	,
`penetration`	out	fraction passing (1 - eta)	,

Applies when: w, A, Q > 0.

```
$ environmental-engineering solve enveng_esp_efficiency "w=0.1 m/s" "A=5000 m^2" "Q=200 m^3/s"
eta = 0.9179150014
penetration = 0.08208499862
  by: Electrostatic precipitator efficiency (Deutsch-Anderson)  (eta = 1 - exp(-w A/Q))
  w = 0.1 m/s
  A = 5000 m^2
  Q = 200 m^3/s
  assumes: w, A, Q > 0
```

What the worked example means: This calculation determines the electrostatic precipitator performance using the Deutsch-Anderson equation. It takes the effective drift velocity of particles, the total collecting plate area, and the gas flow rate as inputs. The result shows that with a drift velocity of 0.1 m/s, an area of 5000

m^2, and a flow of 200 m^3/s, the device achieves a collection efficiency of 0.917915, meaning only 0.082085 of the particulate matter passes through uncollected.

Electrostatic precipitator plate area for a target efficiency, `enveng_esp_area`

The collecting plate area an electrostatic precipitator needs to reach a stated efficiency (Deutsch-Anderson).

$$A = -\frac{Q}{w}\ln(1-\eta)$$

symbol		meaning	SI unit
`w`	in	effective drift velocity	m/s
`Q`	in	gas flow rate	m^3/s
`eta`	in	required collection efficiency (fraction or %)	,
`A`	out	required collecting area	m^2

Applies when: 0 < eta < 1.

```
$ environmental-engineering solve enveng_esp_area "w=0.1 m/s" "Q=200 m^3/s" eta=0.99
A = 9210.340372 m^2
  by: Electrostatic precipitator plate area for a target efficiency  (A = -Q ln(1 - eta)/w)
  w = 0.1 m/s
  Q = 200 m^3/s
  eta = 0.99
  assumes: 0 < eta < 1
```

What the worked example means: This calculation determines the collecting plate area needed for an electrostatic precipitator to achieve a specific efficiency. Using the gas flow rate of 200 m^3/s, the effective drift velocity of 0.1 m/s, and the target collection efficiency of 0.99, the model applies the Deutsch-Anderson equation. The resulting required area is 9210.34 m^2, which represents the physical surface size necessary to capture the desired fraction of particulate matter from the gas stream.

Gas concentration: mass concentration to ppm (by volume), `enveng_mass_concentration_to_ppm`

The volume mixing ratio (ppm and ppb) of a gaseous pollutant from its mass concentration, molar mass, temperature and pressure (ideal gas).

$$\mathrm{ppm} = \frac{CRT}{PM} \times 10^6$$

symbol		meaning	SI unit
`C`	in	mass concentration	kg/m^3
`M`	in	molar mass	kg/mol
`T`	in	air temperature	K
`P`	in	air pressure	Pa
`ppm`	out	volume mixing ratio in ppm	,
`ppb`	out	volume mixing ratio in ppb	,

Applies when: ideal gas.

```
$ environmental-engineering solve enveng_mass_concentration_to_ppm "C=100 ug/m^3" "M=46.006 g/mol"
"T=298.15 K" "P=101.325 kPa"
ppm = 0.05317872386
ppb = 53.17872386
  by: Gas concentration: mass concentration to ppm (by volume)  (ppm = C R T/(P M) 1e6)
  C = 1e-07 kg/m^3
  M = 0.046006 kg/mol
  T = 298.15 K
  P = 101325 Pa
  assumes: ideal gas
```

What the worked example means: This calculation determines the volume mixing ratio of a gaseous pollutant from its mass concentration using the ideal gas law. Given a mass concentration of 100 ug/m^3, a molar mass of 46.006 g/mol, an air temperature of 298.15 K, and an air pressure of 101.325 kPa, the resulting concentration is expressed as 0.0531787 parts per million or 53.1787 parts per billion. This conversion allows engineers to compare emission limits defined in mass units with atmospheric measurements typically reported in volumetric ratios.

Gas concentration: ppm (by volume) to mass concentration, `enveng_ppm_to_mass_concentration`

The mass concentration of a gaseous pollutant from its volume mixing ratio in ppm, its molar mass and the air temperature and pressure (ideal gas).

$$C = \mathrm{ppm} \times 10^{-6}\,\frac{PM}{RT}$$

symbol		meaning	SI unit
`ppm`	in	volume mixing ratio in parts per million	,
`M`	in	molar mass of the pollutant	kg/mol
`T`	in	air temperature	K
`P`	in	air pressure	Pa
`C`	out	mass concentration	kg/m^3
`C_ugm3`	out	in micrograms per cubic metre	,
`C_mgm3`	out	in milligrams per cubic metre	,

Applies when: ideal gas.

```
$ environmental-engineering solve enveng_ppm_to_mass_concentration ppm=0.14 "M=64.066 g/mol"
"T=298.15 K" "P=101.325 kPa"
C = 3.666091151e-07 kg/m^3
C_ugm3 = 366.6091151
C_mgm3 = 0.3666091151
  by: Gas concentration: ppm (by volume) to mass concentration  (C = ppm 1e-6 P M/(R T))
  ppm = 0.14
  M = 0.064066 kg/mol
  T = 298.15 K
  P = 101325 Pa
  assumes: ideal gas
```

What the worked example means: This calculation converts a volume mixing ratio of 0.14 into a mass concentration using the ideal gas law. Given the pollutant's molar mass of 64.066 g/mol, an air temperature of 298.15 K, and a pressure of 101.325 kPa, the resulting mass concentration is 3.66609e-07 kg/m^3. This value represents the actual weight of the pollutant present in each cubic metre of air, expressed as 366.609 or 0.366609.

Gaussian plume concentration at a receptor (ground reflection), `enveng_gaussian_plume_concentration`

The steady concentration downwind of a continuous point source at crosswind distance y and height z, given the dispersion coefficients at the receptor's distance and the effective stack height, with full reflection at the ground.

$$C = \frac{Q}{2\pi u \sigma_y \sigma_z} e^{-\frac{y^2}{2\sigma_y^2}} \left[e^{-\frac{(z-H)^2}{2\sigma_z^2}} + e^{-\frac{(z+H)^2}{2\sigma_z^2}} \right]$$

symbol		meaning	SI unit
`Q`	in	pollutant emission rate	kg/s
`u`	in	mean wind speed at the stack height	m/s
`sigma_y`	in	horizontal dispersion coefficient at the receptor distance	m
`sigma_z`	in	vertical dispersion coefficient at the receptor distance	m
`H`	in	effective stack height (stack height plus plume rise)	m
`y`	in	crosswind distance from the plume centreline	m
`z`	in	receptor height above the ground	m
`C`	out	concentration at the receptor	kg/m^3
`C_ugm3`	out	concentration in micrograms per cubic metre	,

Applies when: Q, u, sigma_y, sigma_z > 0; H, z >= 0; steady state, flat terrain.

```
$ environmental-engineering solve enveng_gaussian_plume_concentration "Q=100 g/s" "u=4 m/s"
"sigma_y=60 m" "sigma_z=30 m" "H=50 m" "y=20 m" "z=0 m"
C = 1.042805659e-06 kg/m^3
C_ugm3 = 1042.805659
  by: Gaussian plume concentration at a receptor (ground reflection)  (C = Q/(2 pi u sy sz) exp(-
y^2/2sy^2) [exp(-(z-H)^2/2sz^2) + exp(-(z+H)^2/2sz^2)])
  Q = 0.1 kg/s
  u = 4 m/s
  sigma_y = 60 m
  sigma_z = 30 m
  H = 50 m
  y = 20 m
  z = 0 m
  assumes: Q, u, sigma_y, sigma_z > 0; H, z >= 0; steady state, flat terrain
```

What the worked example means: This calculation determines the steady-state pollutant concentration downwind of a continuous point source. It uses the emission rate, wind speed, dispersion coefficients, effective stack height, and receptor position to account for plume spread and ground reflection. The resulting concentration is 1.04281e-06 kg/m^3 kilograms per cubic metre, equivalent to 1042.81 micrograms per cubic metre.

Gaussian plume concentration from the stability class, `enveng_plume_concentration_stability`

The concentration at a receptor (x, y, z) downwind of an elevated point source, with the dispersion coefficients taken from Briggs' formulas for the stability class and terrain.

$$C = \frac{Q}{2\pi u \sigma_y(x)\sigma_z(x)} e^{-\frac{y^2}{2\sigma_y^2}} \left[e^{-\frac{(z-H)^2}{2\sigma_z^2}} + e^{-\frac{(z+H)^2}{2\sigma_z^2}} \right]$$

symbol		meaning	SI unit
`Q`	in	pollutant emission rate	kg/s
`u`	in	mean wind speed at the stack height	m/s
`H`	in	effective stack height	m
`x`	in	downwind distance	m
`y`	in	crosswind distance from the centreline	m
`z`	in	receptor height	m
`cls`	in	Pasquill stability class A-F	,
`terrain`	in	rural or urban dispersion coefficients	,
`C`	out	concentration at the receptor	kg/m^3
`C_ugm3`	out	concentration in micrograms per cubic metre	,
`sigma_y`	out	horizontal dispersion coefficient at x	m
`sigma_z`	out	vertical dispersion coefficient at x	m

Applies when: 100 m <= x <= 10 km; Q, u > 0; H, z >= 0.

```
$ environmental-engineering solve enveng_plume_concentration_stability "Q=200 g/s" "u=5 m/s" "H=80
m" "x=2000 m" "y=0 m" "z=0 m" cls=c terrain=rural
C = 3.935687085e-07 kg/m^3
C_ugm3 = 393.5687085
sigma_y = 200.8316044 m
sigma_z = 135.2246808 m
  by: Gaussian plume concentration from the stability class  (Briggs sigma_y(x), sigma_z(x) for the
class, then the reflected Gaussian plume)
  Q = 0.2 kg/s
  u = 5 m/s
  H = 80 m
  x = 2000 m
  y = 0 m
  z = 0 m
  cls = c
  terrain = rural
  assumes: 100 m <= x <= 10 km; Q, u > 0; H, z >= 0
```

What the worked example means: This calculation determines the pollutant concentration at a specific receptor location downwind of an elevated point source. It uses Briggs' formulas to derive the horizontal and vertical dispersion coefficients based on the stability class and terrain, resulting in values of 200.832 m and 135.225 m. These coefficients are then applied to the Gaussian plume equation along with the emission rate, wind speed, and geometric parameters to yield a final concentration of 3.93569e-07 kg/m^3. This value represents the mass of pollutant per unit volume of air at the specified coordinates.

Gaussian plume trapped below an inversion lid (multiple reflections), `enveng_plume_mixing_lid`

The concentration of a plume reflected both at the ground and at the base of an elevated inversion (mixing height), by the image-source series, with the fully mixed limit for comparison.

$$C = \frac{Q e^{-y^2/2\sigma_y^2}}{2\pi u \sigma_y \sigma_z} \sum_{n=-\infty}^{\infty} \left[e^{-\frac{(z-H+2nL)^2}{2\sigma_z^2}} + e^{-\frac{(z+H+2nL)^2}{2\sigma_z^2}} \right]$$

symbol		meaning	SI unit
`Q`	in	emission rate	kg/s
`u`	in	mean wind speed	m/s
`sigma_y`	in	horizontal dispersion coefficient	m
`sigma_z`	in	vertical dispersion coefficient	m
`H`	in	effective stack height	m
`Lm`	in	mixing height (inversion base)	m
`y`	in	crosswind distance	m
`z`	in	receptor height	m
`C`	out	concentration with ground and lid reflections	kg/m^3
`C_ugm3`	out	in micrograms per cubic metre	,
`C_mixed`	out	uniformly mixed limit Q/(sqrt(2 pi) u sy Lm) e^(-y^2/2sy^2)	kg/m^3

Applies when: H, z <= Lm; sigma_z <= 10 Lm.

```
$ environmental-engineering solve enveng_plume_mixing_lid "Q=100 g/s" "u=4 m/s" "sigma_y=900 m"
"sigma_z=600 m" "H=80 m" "Lm=500 m" "y=0 m" "z=0 m"
C = 2.219531498e-08 kg/m^3
C_ugm3 = 22.19531498
C_mixed = 2.216346002e-08 kg/m^3
  by: Gaussian plume trapped below an inversion lid (multiple reflections)  (image sources at z =
+-H + 2 n Lm summed until the terms vanish)
  Q = 0.1 kg/s
  u = 4 m/s
  sigma_y = 900 m
  sigma_z = 600 m
  H = 80 m
  Lm = 500 m
  y = 0 m
  z = 0 m
  assumes: H, z <= Lm; sigma_z <= 10 Lm
```

In the worked example, Q = 100 g/s, u = 4 m/s, sigma_y = 900 m, sigma_z = 600 m, H = 80 m, Lm = 500 m, y = 0 m, z = 0 m go through the equation above and give C = 2.219531498e-08 kg/m^3, C_ugm3 = 22.19531498, C_mixed = 2.216346002e-08 kg/m^3. It applies only when H, z <= Lm; sigma_z <= 10 Lm: outside that it says what is wrong instead of returning a number.

Gravity settling chamber collection efficiency, `enveng_settling_chamber_efficiency`

The Stokes settling velocity of a particle in a gas and the collection efficiency of a horizontal-flow settling chamber with N trays (laminar plug-flow model).

$$\eta = \frac{v_t L W N}{Q}, \quad v_t = \frac{g(\rho_p - \rho_g) d_p^2}{18\mu}$$

symbol		meaning	SI unit
`dp`	in	particle diameter	m
`rho_p`	in	particle density	kg/m^3
`rho_g`	in	gas density	kg/m^3
`mu`	in	gas viscosity	Pa*s
`L`	in	chamber length	m
`W`	in	chamber width	m
`Q`	in	gas flow rate	m^3/s
`N`	in	number of trays (1 for a single chamber)	,
`vt`	out	Stokes terminal settling velocity	m/s
`eta`	out	collection efficiency (fraction, at most 1)	,
`Re`	out	particle Reynolds number	,

Applies when: Stokes regime Re < 1; laminar plug flow.

```
$ environmental-engineering solve enveng_settling_chamber_efficiency "dp=50 um" "rho_p=2000 kg/m^3"
"rho_g=1.2 kg/m^3" "mu=1.8e-05 Pa*s" "L=5 m" "W=2 m" "Q=10 m^3/s" N=1
vt = 0.151246389 m/s
eta = 0.151246389
Re = 0.5041546301
  by: Gravity settling chamber collection efficiency  (vt = g (rho_p - rho_g) dp^2/(18 mu); eta =
min(1, vt L W N/Q))
  dp = 5e-05 m
  rho_p = 2000 kg/m^3
  rho_g = 1.2 kg/m^3
  mu = 1.8e-05 Pa*s
  L = 5 m
  W = 2 m
  Q = 10 m^3/s
  assumes: Stokes regime Re < 1; laminar plug flow
```

What the worked example means: This calculation determines the particle's terminal settling velocity using Stokes law, which yields 0.151246 m/s, and then computes the fraction of particles captured by a horizontal-flow settling chamber with multiple trays. The resulting collection efficiency is 0.151246, representing the proportion of incoming particulate matter that successfully settles out before exiting the system.

Ground-level centreline concentration of a plume, `enveng_ground_centerline_concentration`

The ground-level concentration directly below the plume axis (y = 0, z = 0) from the emission rate, wind speed, dispersion coefficients and effective stack height (H = 0 for a ground-level source).

$$C(x,0,0) = \frac{Q}{\pi u \sigma_y \sigma_z} \exp\left(-\frac{H^2}{2\sigma_z^2}\right)$$

symbol		meaning	SI unit
`Q`	in	pollutant emission rate	kg/s
`u`	in	mean wind speed	m/s
`sigma_y`	in	horizontal dispersion coefficient	m
`sigma_z`	in	vertical dispersion coefficient	m
`H`	in	effective stack height (0 for a ground-level source)	m
`C`	out	ground-level centreline concentration	kg/m^3
`C_ugm3`	out	concentration in micrograms per cubic metre	,

Applies when: Q, u, sigma_y, sigma_z > 0; H >= 0.

```
$ environmental-engineering solve enveng_ground_centerline_concentration "Q=150 g/s" "u=5 m/s"
"sigma_y=80 m" "sigma_z=40 m" "H=60 m"
C = 9.688133431e-07 kg/m^3
C_ugm3 = 968.8133431
  by: Ground-level centreline concentration of a plume  (C = Q/(pi u sy sz) exp(-H^2/(2 sz^2)))
  Q = 0.15 kg/s
  u = 5 m/s
  sigma_y = 80 m
  sigma_z = 40 m
  H = 60 m
  assumes: Q, u, sigma_y, sigma_z > 0; H >= 0
```

What the worked example means: This calculation determines the pollutant concentration at ground level directly below the plume axis using the emission rate, wind speed, horizontal and vertical dispersion coefficients, and effective stack height. The resulting ground-level centerline concentration is 9.68813e-07 kg/m^3, which converts to 968.813 in micrograms per cubic meter. This value represents the exposure at the specific downwind location defined by the input parameters.

Holland plume rise, `enveng_holland_plume_rise`

Plume rise by Holland's formula (momentum term plus a buoyancy term with the pressure in millibars) and the effective stack height.

$$\Delta h = \frac{v_s d}{u}\left(1.5 + 2.68\times10^{-3}\, p\, d\, \frac{T_s - T_a}{T_s}\right)$$

symbol		meaning	SI unit
`vs`	in	stack gas exit velocity	m/s
`d`	in	stack inside diameter	m
`u`	in	wind speed at the stack top	m/s
`p`	in	atmospheric pressure	Pa
`Ts`	in	stack gas temperature	K
`Ta`	in	ambient air temperature	K
`hs`	in	physical stack height	m
`dh`	out	plume rise	m
`H`	out	effective stack height	m

Applies when: Ts > Ta.

```
$ environmental-engineering solve enveng_holland_plume_rise "vs=10 m/s" "d=2 m" "u=4 m/s"
"p=101.325 kPa" "Ts=400 K" "Ta=290 K" "hs=50 m"
dh = 14.9676525 m
H = 64.9676525 m
  by: Holland plume rise  (dh = vs d/u (1.5 + 2.68e-3 p[mbar] d (Ts - Ta)/Ts))
  vs = 10 m/s
  d = 2 m
  u = 4 m/s
  p = 101325 Pa
  Ts = 400 K
  Ta = 290 K
  hs = 50 m
  assumes: Ts > Ta
```

What the worked example means: This calculation determines how far the smoke plume rises above the physical stack using Holland's formula, which combines momentum from the exit velocity and buoyancy driven by temperature differences. The computed plume rise of 14.9677 m represents the vertical distance the hot gases travel upward due to their initial speed and heat compared to the surrounding air. Adding this rise to the physical stack height yields an effective stack height of 64.9677 m, which is the virtual elevation used for predicting downwind pollutant dispersion.

Maximum ground-level concentration (constant sigma_y/sigma_z), `enveng_max_ground_concentration_ratio`

The largest ground-level centreline concentration of an elevated source when sigma_y/sigma_z is taken constant along the plume, and the vertical spread at which it occurs (sigma_z = H/sqrt 2).

$$C_{max} = \frac{2Q}{\pi e\, uH^2}\frac{\sigma_z}{\sigma_y}, \quad \sigma_z = \frac{H}{\sqrt{2}}$$

symbol		meaning	SI unit
`Q`	in	emission rate	kg/s
`u`	in	mean wind speed	m/s
`H`	in	effective stack height	m
`k`	in	ratio sigma_y/sigma_z (constant along the plume)	,
`C_max`	out	maximum ground-level concentration	kg/m^3
`C_max_ugm3`	out	maximum concentration in micrograms per cubic metre	,
`sigma_z_max`	out	vertical dispersion coefficient at the maximum	m

Applies when: Q, u, H, k > 0; sigma_y/sigma_z constant along the plume.

```
$ environmental-engineering solve enveng_max_ground_concentration_ratio "Q=100 g/s" "u=5 m/s"
"H=100 m" k=2
C_max = 2.341993261e-07 kg/m^3
C_max_ugm3 = 234.1993261
sigma_z_max = 70.71067812 m
  by: Maximum ground-level concentration (constant sigma_y/sigma_z)  (maximise C = Q/(pi u k sz^2)
exp(-H^2/2sz^2) over sz: sz = H/sqrt2, Cmax = 2Q/(pi e u H^2 k))
  Q = 0.1 kg/s
  u = 5 m/s
  H = 100 m
  k = 2
  assumes: Q, u, H, k > 0; sigma_y/sigma_z constant along the plume
```

What the worked example means: This calculation determines the highest concentration at ground level for an elevated source, assuming the ratio of horizontal to vertical dispersion remains constant. By optimizing the Gaussian plume equation with respect to the vertical dispersion coefficient, the peak occurs when the vertical spread equals the effective stack height divided by the square root of two. For the given emission rate, wind speed, and stack height, the resulting maximum concentration is 2.34199e-07 kg/m^3, which corresponds to 234.199 in micrograms per cubic metre. This value represents the worst-case exposure scenario along the centerline of the plume under these specific atmospheric conditions.

Maximum ground-level concentration and its distance (Briggs coefficients), `enveng_max_ground_concentration_briggs`

The distance of the largest ground-level centreline concentration of an elevated source and that concentration, found exactly on Briggs' dispersion curves for the stability class (no constant-ratio shortcut).

$$\frac{d\ln C}{dx} = -\frac{\sigma_y'}{\sigma_y} + \frac{\sigma_z'}{\sigma_z}\left(\frac{H^2}{\sigma_z^2} - 1\right) = 0$$

symbol		meaning	SI unit
`Q`	in	emission rate	kg/s
`u`	in	mean wind speed	m/s
`H`	in	effective stack height	m
`cls`	in	Pasquill stability class A-F	,
`terrain`	in	rural or urban dispersion coefficients	,
`x_max`	out	downwind distance of the maximum	m
`C_max`	out	maximum ground-level concentration	kg/m^3
`C_max_ugm3`	out	maximum concentration in micrograms per cubic metre	,
`sigma_y`	out	sigma_y at the maximum	m
`sigma_z`	out	sigma_z at the maximum	m

Applies when: the maximum lies between 100 m and 10 km.

```
$ environmental-engineering solve enveng_max_ground_concentration_briggs "Q=100 g/s" "u=5 m/s"
"H=50 m" cls=c terrain=rural
x_max = 459.3930757 m
C_max = 1.333568186e-06 kg/m^3
C_max_ugm3 = 1333.568186
sigma_y = 49.41102781 m
sigma_z = 35.17120532 m
  by: Maximum ground-level concentration and its distance (Briggs coefficients)  (root of d ln C/dx
= -sy'/sy + (sz'/sz)(H^2/sz^2 - 1) by a log-spaced scan and bisection)
  Q = 0.1 kg/s
  u = 5 m/s
  H = 50 m
  cls = c
  terrain = rural
  assumes: the maximum lies between 100 m and 10 km
```

What the worked example means: This calculation determines the downwind location and magnitude of the highest pollutant concentration at ground level for an elevated source. By analyzing Briggs' dispersion coefficients, it finds where the rate of change in concentration equals zero. The result shows that with an effective stack height of 50 m and stability class c, the peak concentration reaches 1333.57 micrograms per cubic metre at 459.393 m metres downwind. This precise method avoids simplified assumptions, ensuring accuracy for regulatory or safety assessments.

Pasquill-Turner atmospheric stability class, `enveng_stability_class`

The Pasquill stability class (A very unstable to F stable) from the surface wind speed and the daytime insolation or night-time cloud cover.

$$\text{class} = T(u,\ \text{insolation or cloud cover})$$

symbol		meaning	SI unit
`u`	in	surface wind speed at 10 m	m/s
`condition`	in	daytime insolation (strong, moderate, slight), overcast (day or night), night_cloudy (at least 4/8 low cloud) or night_clear (at most 3/8 cloud)	,
`stability`	out	Pasquill stability class (A-F; A-B etc. for intermediate cases)	,

Applies when: u > 0; no class is defined at night with u below 2 m/s.

```
$ environmental-engineering solve enveng_stability_class "u=2.5 m/s" condition=strong
stability = A-B
  by: Pasquill-Turner atmospheric stability class  (Turner's table: wind-speed rows < 2, 2-3, 3-5,
5-6, > 6 m/s against insolation or cloud-cover columns; heavy overcast is D)
  u = 2.5 m/s
  condition = strong
  assumes: u > 0; no class is defined at night with u below 2 m/s
```

What the worked example means: This calculation determines the atmospheric stability class, represented as A-B, by applying Turner's classification method. The result is derived from the surface wind speed of 2.5 m/s and the specified sky condition or insolation level strong. This class indicates how rapidly pollutants disperse vertically in the atmosphere, with values ranging from very unstable to stable.

Stack plume: effective height, dispersion and ground-level concentration,
`enveng_stack_plume_ground_concentration`

The whole chain for a buoyant stack in neutral or unstable air: Briggs plume rise to the effective height, Briggs dispersion coefficients at the receptor distance, then the ground-level centreline concentration.

$$C = \frac{Q}{\pi u \sigma_y \sigma_z} \exp\left(-\frac{(h_s + \Delta h)^2}{2\sigma_z^2}\right)$$

symbol		meaning	SI unit
`Q`	in	emission rate	kg/s
`u`	in	wind speed at the stack top	m/s
`vs`	in	stack gas exit velocity	m/s
`d`	in	stack inside diameter at the exit	m
`Ts`	in	stack gas temperature	K
`Ta`	in	ambient air temperature	K
`hs`	in	physical stack height	m
`x`	in	downwind distance of the receptor	m
`cls`	in	Pasquill stability class A-D	,
`terrain`	in	rural or urban dispersion coefficients	,
`H`	out	effective stack height	m
`sigma_y`	out	sigma_y at x	m
`sigma_z`	out	sigma_z at x	m
`C`	out	ground-level centreline concentration at x	kg/m^3
`C_ugm3`	out	in micrograms per cubic metre	,

Applies when: Ts > Ta; class A-D; 100 m <= x <= 10 km.

```
$ environmental-engineering solve enveng_stack_plume_ground_concentration "Q=100 g/s" "u=6 m/s"
"vs=10 m/s" "d=1.5 m" "Ts=400 K" "Ta=290 K" "hs=50 m" "x=3000 m" cls=c terrain=rural
H = 77.44719963 m
sigma_y = 289.4291464 m
sigma_z = 189.7366596 m
C = 8.888445322e-08 kg/m^3
C_ugm3 = 88.88445322
  by: Stack plume: effective height, dispersion and ground-level concentration  (Briggs final rise
(2/3 law) -> H; Briggs sigma_y, sigma_z at x; C = Q/(pi u sy sz) exp(-H^2/2sz^2))
  Q = 0.1 kg/s
  u = 6 m/s
  vs = 10 m/s
  d = 1.5 m
  Ts = 400 K
  Ta = 290 K
  hs = 50 m
  x = 3000 m
  cls = c
  terrain = rural
  assumes: Ts > Ta; class A-D; 100 m <= x <= 10 km
```

What the worked example means: This calculation determines the pollutant concentration at a receptor downwind of a stack. It first computes the effective stack height, which results in 77.4472 m, by adding the plume rise to the physical stack height. Then, it evaluates the horizontal and vertical dispersion coefficients at the specified distance, yielding 289.429 m for crosswind spread and 189.737 m for vertical spread. Finally, these values are used to find the ground-level centerline concentration, calculated as 8.88845e-08 kg/m^3 or 88.8845. The result represents the mass of pollutant per unit volume of air at the specific location.

Sulfur dioxide emission from fuel sulfur, `enveng_so2_emission`

The SO2 emission rate from a fuel burning rate and its sulfur mass fraction (all sulfur to SO2), before and after a control device.

$$E = \dot{m}_{fuel}\, S\, \frac{M_{SO_2}}{M_S}(1-\eta)$$

symbol		meaning	SI unit
`m_fuel`	in	fuel burning rate	kg/s
`S`	in	sulfur mass fraction of the fuel (fraction or %)	,
`eta`	in	SO2 control (removal) efficiency (fraction or %; 0 if uncontrolled)	,
`E`	out	controlled SO2 emission rate	kg/s
`E_uncontrolled`	out	uncontrolled SO2 emission rate	kg/s
`E_kg_per_day`	out	controlled emission in kg per day	,

Applies when: all fuel sulfur oxidised to SO2.

```
$ environmental-engineering solve enveng_so2_emission "m_fuel=36 t/h" S=0.02 eta=0.9
E = 0.03995870887 kg/s
E_uncontrolled = 0.3995870887 kg/s
E_kg_per_day = 3452.432447
  by: Sulfur dioxide emission from fuel sulfur  (E = m_fuel S (M_SO2/M_S)(1 - eta))
  m_fuel = 10 kg/s
  S = 0.02
  eta = 0.9
  assumes: all fuel sulfur oxidised to SO2
```

What the worked example means: This calculation determines the mass flow rate of sulfur dioxide emitted into the atmosphere. It starts with the uncontrolled emission potential, which depends directly on how much fuel is burned and how much sulfur that fuel contains. The result assumes all sulfur converts to sulfur dioxide. A control efficiency factor then reduces this amount to produce the final controlled emission rate of 0.0399587 kg/s. If no control device is present, the efficiency is zero, and the output equals the uncontrolled rate.

Wind speed at height (power law), `enveng_wind_power_law`

The wind speed at another height from a measured speed with the power-law profile u2 = u1 (z2/z1)^p (p from the stability class and terrain, e.g. 0.15 rural neutral).

$$u_2 = u_1 \left(\frac{z_2}{z_1} \right)^p$$

symbol		meaning	SI unit
`u1`	in	measured wind speed	m/s
`z1`	in	measurement height	m
`z2`	in	height of interest (e.g. the stack top)	m
`p`	in	power-law exponent (0 < p < 1)	,
`u2`	out	wind speed at z2	m/s

Applies when: 0 < p < 1.

```
$ environmental-engineering solve enveng_wind_power_law "u1=4 m/s" "z1=10 m" "z2=100 m" p=0.15
u2 = 5.650150178 m/s
  by: Wind speed at height (power law)  (u2 = u1 (z2/z1)^p)
  u1 = 4 m/s
  z1 = 10 m
  z2 = 100 m
  p = 0.15
  assumes: 0 < p < 1
```

What the worked example means: This calculation determines the wind speed at a specific height using the power law profile. It takes a known wind speed measurement, 4 m/s, taken at height 10 m, and adjusts it to the height of interest, 100 m, using an exponent 0.15 that reflects terrain and atmospheric stability. The resulting wind speed at the new height is 5.65015 m/s. This method assumes a neutral or stable boundary layer where wind speed changes predictably with altitude according to the chosen exponent.

Gas transfer (5)

Dissolved concentration in equilibrium with a gas (Henry's law), `enveng_henry_law_equilibrium`

The equilibrium molar (and, with the molar mass, mass) concentration of a gas dissolved in water from its partial pressure and the Henry's volatility constant.

$$C = \frac{p}{H}$$

symbol		meaning	SI unit
`p`	in	partial pressure of the gas	Pa
`H`	in	Henry's volatility constant	Pa*m^3/mol
`M`	in	molar mass (for the mass concentration) (optional)	kg/mol
`C`	out	dissolved molar concentration	mol/m^3
`C_mass`	out	dissolved mass concentration	kg/m^3
`C_mgL`	out	in mg/L	,

Applies when: dilute solution, equilibrium.

```
$ environmental-engineering solve enveng_henry_law_equilibrium "p=0.21 atm" "H=0.79 atm*m^3/mol"
"M=31.9988 g/mol"
C = 0.2658227848 mol/m^3
C_mass = 0.008506010127 kg/m^3
C_mgL = 8.506010127
  by: Dissolved concentration in equilibrium with a gas (Henry's law)  (C = p/H)
  p = 21278.25 Pa
  H = 80046.75 Pa*m^3/mol
  M = 0.0319988 kg/mol
  assumes: dilute solution, equilibrium
```

What the worked example means: This calculation determines the equilibrium concentration of a gas in water using Henry's law. By dividing the partial pressure of the gas, which is 0.21 atm, by the Henry volatility constant, which is 0.79 atm*m^3/mol, this gives the molar concentration 0.265823 mol/m^3. To express this as a mass concentration, the molar value is multiplied by the molar mass 31.9988 g/mol, resulting in 0.00850601 kg/m^3. This represents how much of the gas dissolves into the liquid phase under these specific conditions.

Henry's law constant conversion between forms, `enveng_henry_constant_conversion`

A Henry's law constant converted between its common forms: volatility (Pa m^3/mol, atm m^3/mol), dimensionless gas/liquid ratio at temperature T, mole-fraction form (atm) and solubility forms (mol/(m^3 Pa), mol/(L atm)).

$$H_{cc} = \frac{H_{pc}}{RT}, \quad H_{px} = H_{pc}\, c_w, \quad H_{cp} = \frac{1}{H_{pc}}$$

symbol		meaning	SI unit
`H`	in	the Henry's constant value in the stated form	,
`form`	in	form of H: pa_m3_per_mol, atm_m3_per_mol, dimensionless (Cg/Cl), atm (p = H x), mol_per_m3_pa or m_per_atm (mol/(L atm))	,
`T`	in	temperature (for the dimensionless form)	K
`H_pa_m3_per_mol`	out	volatility constant, Pa m^3/mol	,
`H_atm_m3_per_mol`	out	volatility constant, atm m^3/mol	,
`H_dimensionless`	out	dimensionless gas/liquid ratio at T	,
`H_atm`	out	mole-fraction form, atm	,
`H_mol_per_m3_pa`	out	solubility constant, mol/(m^3 Pa)	,
`H_m_per_atm`	out	solubility constant, mol/(L atm)	,

Applies when: dilute aqueous solution (water 55344.59 mol/m^3).

```
$ environmental-engineering solve enveng_henry_constant_conversion H=0.0055 form=atm_m3_per_mol
"T=298.15 K"
H_pa_m3_per_mol = 557.2875
H_atm_m3_per_mol = 0.0055
H_dimensionless = 0.2248072449
H_atm = 304.395245
H_mol_per_m3_pa = 0.001794405939
H_m_per_atm = 0.1818181818
  by: Henry's law constant conversion between forms  (all forms through the volatility constant
Hpc: Hcc = Hpc/(R T), Hpx = Hpc rho_w, Hcp = 1/Hpc)
  H = 0.0055
  T = 298.15 K
  form = atm_m3_per_mol
  assumes: dilute aqueous solution (water 55344.59 mol/m^3)
```

What the worked example means: This calculation converts the input Henry's law constant 0.0055 into all standard forms. The primary volatility constant is determined as 557.288, which allows derivation of the dimensionless gas-to-liquid concentration ratio 0.224807 at temperature 298.15 K. Additionally, the mole-fraction form 304.395 and solubility constants 0.00179441 and 0.181818 are computed. These values describe how the chemical partitions between air and water under dilute aqueous conditions.

Overall liquid-phase transfer coefficient and flux (two-film theory), `enveng_two_film_transfer`

The overall liquid-side mass-transfer coefficient from the liquid- and gas-film coefficients and the dimensionless Henry's constant, the share of resistance in the liquid film, and the flux from water to air (negative when the gas dissolves).

$$\frac{1}{K_L} = \frac{1}{k_l} + \frac{1}{H k_g}, \quad N = K_L \left(C - \frac{C_g}{H} \right)$$

symbol		meaning	SI unit
`kl`	in	liquid-film coefficient	m/s
`kg`	in	gas-film coefficient	m/s

symbol		meaning	SI unit
`H`	in	dimensionless Henry's constant (Cg/Cl)	,
`C`	in	bulk liquid concentration	kg/m^3
`Cg`	in	bulk gas concentration	kg/m^3
`KL`	out	overall liquid-phase coefficient	m/s
`flux`	out	flux from liquid to gas	kg/(m^2*s)
`liquid_resistance_fraction`	out	fraction of the resistance in the liquid film	,

Applies when: linear equilibrium.

```
$ environmental-engineering solve enveng_two_film_transfer "kl=2e-05 m/s" "kg=0.005 m/s" H=0.2 "C=1
mg/L" "Cg=0 ug/m^3"
KL = 1.960784314e-05 m/s
flux = 1.960784314e-08 kg/(m^2*s)
liquid_resistance_fraction = 0.9803921569
  by: Overall liquid-phase transfer coefficient and flux (two-film theory)  (1/KL = 1/kl + 1/(H
kg); flux = KL (C - Cg/H))
  kl = 2e-05 m/s
  kg = 0.005 m/s
  H = 0.2
  C = 0.001 kg/m^3
  Cg = 0 kg/m^3
  assumes: linear equilibrium
```

What the worked example means: This calculation determines the overall liquid-phase mass-transfer coefficient, denoted as KL, by combining the individual liquid-film coefficient kl and gas-film coefficient kg with the dimensionless Henry's constant H. The resulting coefficient KL equals 1.96078e-05 m/s. Using this value, the net flux from the liquid to the gas phase is computed as 1.96078e-08 kg/(m^2*s), which represents the rate of mass transfer per unit area. Additionally, the analysis reveals that the liquid film accounts for 0.980392 of the total resistance to mass transfer, indicating how much of the barrier to diffusion occurs on the water side versus the air side.

Packed-tower air stripping: stripping factor, transfer units and height, `enveng_air_stripping_tower`

The stripping factor, number of transfer units, packed height and minimum air-to-water ratio of a countercurrent packed tower stripping a volatile compound with clean air.

$$NTU = \frac{R}{R-1}\ln\left[\frac{(C_{in}/C_{out})(R-1)+1}{R}\right], \quad Z = HTU \cdot NTU$$

symbol		meaning	SI unit
`Qw`	in	water flow	m^3/s
`Qa`	in	air flow	m^3/s
`H`	in	dimensionless Henry's constant (Cg/Cl)	,
`Cin`	in	influent concentration	kg/m^3
`Cout`	in	required effluent concentration	kg/m^3
`HTU`	in	height of a transfer unit	m

symbol		meaning	SI unit
`R`	out	stripping factor H Qa/Qw	,
`NTU`	out	number of transfer units	,
`Z`	out	packed height HTU NTU	m
`air_to_water_min`	out	minimum air-to-water ratio (Cin - Cout)/(H Cin)	,

Applies when: Qa/Qw above the minimum; clean inlet air; dilute, linear equilibrium.

```
$ environmental-engineering solve enveng_air_stripping_tower "Qw=0.05 m^3/s" "Qa=1.5 m^3/s" H=0.2
"Cin=200 ug/L" "Cout=5 ug/L" "HTU=1 m"
R = 6
NTU = 4.213854527
Z = 4.213854527 m
air_to_water_min = 4.875
  by: Packed-tower air stripping: stripping factor, transfer units and height  (R = H Qa/Qw; NTU =
R/(R - 1) ln[((Cin/Cout)(R - 1) + 1)/R] (Cin/Cout - 1 when R = 1); Z = HTU NTU)
  Qw = 0.05 m^3/s
  Qa = 1.5 m^3/s
  H = 0.2
  Cin = 0.0002 kg/m^3
  Cout = 5e-06 kg/m^3
  HTU = 1 m
  assumes: Qa/Qw above the minimum; clean inlet air; dilute, linear equilibrium
```

What the worked example means: This calculation determines the required packed tower height, 4.21385 m, based on the stripping factor, 6, and the number of transfer units, 4.21385. The stripping factor compares the air-to-water ratio against equilibrium constraints, while the number of transfer units reflects the difficulty of removing the contaminant from influent concentration 200 ug/L to effluent concentration 5 ug/L. Multiplying the height of a transfer unit, 1 m, by the number of transfer units yields the total physical height needed for effective treatment.

Temperature dependence of Henry's constant (van 't Hoff), `enveng_henry_temperature_dependence`

The Henry's solubility constant at a temperature T from its value at a reference temperature and the van 't Hoff coefficient B = -d ln Hcp / d(1/T) (the form tabulated in solubility compilations).

$$H^{cp}(T) = H^{cp}(T_{ref}) \exp\left[B\left(\frac{1}{T} - \frac{1}{T_{ref}}\right)\right]$$

symbol		meaning	SI unit
`Hcp`	in	Henry's solubility constant at Tref	mol/(m^3*Pa)
`B`	in	temperature coefficient d ln Hcp/d(1/T), in K	,
`T`	in	temperature of interest	K
`Tref`	in	reference temperature (usually 298.15 K)	K
`Hcp_T`	out	solubility constant at T	mol/(m^3*Pa)
`Hpc_T`	out	volatility constant 1/Hcp at T	Pa*m^3/mol

Applies when: constant enthalpy of solution over the range.

```
$ environmental-engineering solve enveng_henry_temperature_dependence "Hcp=1.3e-05 mol/(m^3*Pa)"
B=1500 "T=283.15 K" "Tref=298.15 K"
Hcp_T = 1.697039196e-05 mol/(m^3*Pa)
Hpc_T = 58926.15813 Pa*m^3/mol
  by: Temperature dependence of Henry's constant (van 't Hoff)  (Hcp(T) = Hcp(Tref) exp(B (1/T -
1/Tref)))
  Hcp = 1.3e-05 mol/(m^3*Pa)
  B = 1500
  T = 283.15 K
  Tref = 298.15 K
  assumes: constant enthalpy of solution over the range
```

What the worked example means: This calculation determines the temperature-dependent Henry's law constant using the van 't Hoff equation. Starting from the reference solubility constant 1.3e-05 mol/(m^3*Pa) at 298.15 K, the model applies the exponential factor derived from the coefficient 1500 and the difference in inverse temperatures between 283.15 K and 298.15 K. The resulting solubility constant 1.69704e-05 mol/(m^3*Pa) indicates how readily the substance dissolves in water at 283.15 K, while its reciprocal, the volatility constant 58926.2 Pa*m^3/mol, reflects the tendency of the substance to partition into the air phase.

Noise (7)

Adding sound levels in decibels, `enveng_decibel_addition`

The combined sound pressure level of several incoherent sources, added on an energy basis.

$$L = 10 \log_{10} \sum_i 10^{L_i/10}$$

symbol		meaning	SI unit
`L`	in	sound levels in dB	,
`L_total`	out	combined level, dB	,

Applies when: incoherent sources.

```
$ environmental-engineering solve enveng_decibel_addition "L=[85, 85]"
L_total = 88.01029996
  by: Adding sound levels in decibels  (L = 10 log10(sum 10^(Li/10)))
  assumes: incoherent sources
```

What the worked example means: This calculation determines the total sound pressure level from multiple incoherent sources by converting each individual decibel value into its linear energy equivalent, summing those energies, and then converting the total back to a logarithmic decibel scale. The result, 88.0103 dB, represents the perceived loudness when all sources operate simultaneously, which is higher than any single source but follows logarithmic addition rules rather than simple arithmetic summation.

Day-night (Ldn) and day-evening-night (Lden) sound levels, `enveng_day_night_level`

The day-night average level (10 dB night penalty, 22:00-07:00) or the day-evening-night level (5 dB evening 19:00-23:00, 10 dB night 23:00-07:00) from 24 hourly equivalent levels.

$$L_{dn} = 10 \log_{10} \frac{1}{24} \left(\sum_{day} 10^{L_h/10} + \sum_{night} 10^{(L_h+10)/10} \right)$$

symbol		meaning	SI unit
`L`	in	24 hourly Leq values in dB, the first for 00:00-01:00	,
`metric`	in	ldn or lden	,
`L`	out	Ldn or Lden, dB	,

Applies when: exactly 24 hourly levels.

```
$ environmental-engineering solve enveng_day_night_level "L=[50, 50, 50, 50, 50, 50, 50, 65, 65,
65, 65, 65, 65, 65, 65, 65, 65, 65, 65, 60, 60, 60, 55, 55]" metric=ldn
L = 63.54363682
  by: Day-night (Ldn) and day-evening-night (Lden) sound levels  (L = 10 log10((1/24) sum 10^((L_h
+ penalty_h)/10)))
  metric = ldn
  assumes: exactly 24 hourly levels
```

What the worked example means: This calculation determines the day-night or day-evening-night sound level using the provided twenty-four hourly equivalent levels. The method applies specific penalties to evening and night hours before averaging the energy values logarithmically. The resulting 63.5436 indicates the overall noise exposure adjusted for these time-of-day sensitivities, offering a single metric that reflects human annoyance potential better than a simple average.

Equivalent continuous sound level Leq, `enveng_equivalent_sound_level`

The equivalent continuous sound level of a period made of intervals at different levels (energy average weighted by duration).

$$L_{eq} = 10 \log_{10} \frac{\sum_i t_i 10^{L_i/10}}{\sum_i t_i}$$

symbol		meaning	SI unit
`L`	in	levels of the intervals in dB	,
`t`	in	durations of the intervals (any one unit)	,
`Leq`	out	equivalent continuous level, dB	,

Applies when: one duration per level.

```
$ environmental-engineering solve enveng_equivalent_sound_level "L=[70, 85, 60]" "t=[4, 1, 3]"
Leq = 76.52279911
  by: Equivalent continuous sound level Leq  (Leq = 10 log10(sum t_i 10^(L_i/10)/sum t_i))
  assumes: one duration per level
```

What the worked example means: This calculation determines the equivalent continuous sound level, which represents a single steady noise level containing the same acoustic energy as the varying noise environment over the measurement period. The result, 76.5228 dB, is derived by weighting each interval's sound pressure

level, given as [70, 85, 60] dB, by its corresponding duration, provided as [4, 1, 3]. This method effectively averages the logarithmic decibel values on an energy basis rather than a simple arithmetic mean, reflecting how human hearing perceives cumulative noise exposure.

Occupational noise dose and 8-hour TWA (OSHA, 5 dB exchange), `enveng_occupational_noise_dose`

The daily noise dose (per cent of the permissible exposure) and the 8-hour time-weighted average from levels and exposure times, with the 90 dBA criterion, 5 dB exchange rate and 80 dBA threshold.

$$D = 100 \sum_i \frac{C_i}{T_i},\ T_i = \frac{8}{2^{(L_i - 90)/5}},\ TWA = 16.61 \log_{10} \frac{D}{100} + 90$$

symbol		meaning	SI unit
`L`	in	A-weighted levels in dBA	,
`hours`	in	exposure time at each level in hours	,
`dose_percent`	out	noise dose, per cent	,
`TWA`	out	8-hour time-weighted average, dBA	,

Applies when: levels below 80 dBA excluded.

```
$ environmental-engineering solve enveng_occupational_noise_dose "L=[90, 95, 85]" "hours=[4, 2, 2]"
dose_percent = 112.5
TWA = 90.8496434
  by: Occupational noise dose and 8-hour TWA (OSHA, 5 dB exchange)  (T = 8/2^((L - 90)/5); D = 100
sum C/T; TWA = 16.61 log10(D/100) + 90)
  assumes: levels below 80 dBA excluded
```

In the worked example, L = [90, 95, 85], hours = [4, 2, 2] go through the equation above and give dose_percent = 112.5, TWA = 90.8496434. It applies only when levels below 80 dBA excluded: outside that it says what is wrong instead of returning a number.

Sound level at another distance (point or line source), `enveng_noise_distance_attenuation`

The sound level at a second distance from a point source (6 dB per doubling) or a line source such as a busy road (3 dB per doubling), free field.

$$L_2 = L_1 - 20 \log_{10} \frac{r_2}{r_1}\ \text{(point)}$$

symbol		meaning	SI unit
`L1`	in	level at distance r1, dB	,
`r1`	in	first distance	m
`r2`	in	second distance	m
`source`	in	point or line source	,
`L2`	out	level at distance r2, dB	,

Applies when: free field, no absorption.

```
$ environmental-engineering solve enveng_noise_distance_attenuation L1=90 "r1=10 m" "r2=80 m"
source=point
L2 = 71.93820026
  by: Sound level at another distance (point or line source)  (L2 = L1 - 20 log10(r2/r1) (point),
L1 - 10 log10(r2/r1) (line))
  L1 = 90
  r1 = 10 m
  r2 = 80 m
  source = point
  assumes: free field, no absorption
```

What the worked example means: This calculation determines the sound pressure level at a specific distance from a noise source, assuming free-field conditions with no atmospheric absorption. Using the provided initial level of 90 measured at 10 m, and the target distance of 80 m, the model applies geometric divergence rules for either a point or line source as indicated by point. The resulting level at the new location is 71.9382. This output represents the expected acoustic intensity after accounting for the change in distance, illustrating how sound energy spreads out as it travels away from the origin.

Sound pressure level from sound power level, `enveng_sound_power_to_pressure`

The sound pressure level at a distance from a source of given sound power level and directivity factor (1 free field, 2 on a hard floor, 4 at a wall-floor edge, 8 in a corner).

$$L_p = L_W + 10\log_{10}\frac{Q}{4\pi r^2}$$

symbol		meaning	SI unit
`Lw`	in	sound power level, dB re 1 pW	,
`r`	in	distance from the source	m
`Qd`	in	directivity factor (1, 2, 4 or 8)	,
`Lp`	out	sound pressure level, dB	,

Applies when: far field, no absorption; rho c taken as 400 rayl (Lp = LI).

```
$ environmental-engineering solve enveng_sound_power_to_pressure Lw=110 "r=20 m" Qd=2
Lp = 75.9976014
  by: Sound pressure level from sound power level  (Lp = Lw + 10 log10(Q/(4 pi r^2)))
  Lw = 110
  r = 20 m
  Qd = 2
  assumes: far field, no absorption; rho c taken as 400 rayl (Lp = LI)
```

What the worked example means: This calculation determines the sound pressure level, denoted as Lp, based on the source's sound power level Lw, the directivity factor Qd, and the distance r from the source. The result, 75.9976, represents the acoustic intensity perceived at that specific location. This value accounts for how the sound energy spreads out in space and whether the environment reflects sound, such as near a hard floor or wall, which affects the overall loudness experienced by a listener.

Source level after removing background noise, `enveng_background_noise_correction`

The sound level of a source alone from the total measured level and the background level (energy subtraction).

$$L_s = 10 \log_{10}\left(10^{L_t/10} - 10^{L_b/10}\right)$$

symbol		meaning	SI unit
`Lt`	in	total measured level, dB	,
`Lb`	in	background level, dB	,
`L_source`	out	level of the source alone, dB	,

Applies when: Lt > Lb.

```
$ environmental-engineering solve enveng_background_noise_correction Lt=85 Lb=80
L_source = 83.34911461
  by: Source level after removing background noise  (Ls = 10 log10(10^(Lt/10) - 10^(Lb/10)))
  Lt = 85
  Lb = 80
  assumes: Lt > Lb
```

What the worked example means: This calculation determines the sound pressure level of a specific source in isolation. It uses the total measured level, 85, and the background level, 80. Because decibels are logarithmic units representing power ratios, simple subtraction of the numbers does not work. Instead, the method converts both levels back to linear energy values, subtracts the background energy from the total energy, and then converts the remaining energy back into a decibel scale. The resulting value, 83.3491, represents how loud the source would be if the background noise were completely absent.

Solid waste (5)

Heating value of waste from its elemental composition (modified Dulong), `enveng_dulong_heating_value`

The higher heating value of a waste or fuel from its dry mass fractions of carbon, hydrogen, oxygen, sulfur and nitrogen by the modified Dulong formula.

$$HHV = 337C + 1419\left(H - \frac{O}{8}\right) + 93S + 23N \;\; [\mathrm{kJ/kg},\ \%]$$

symbol		meaning	SI unit
`C`	in	carbon mass fraction (fraction or %)	,
`H`	in	hydrogen mass fraction	,
`O`	in	oxygen mass fraction	,
`S`	in	sulfur mass fraction	,
`N`	in	nitrogen mass fraction	,
`HHV`	out	higher heating value	J/kg
`HHV_kJ_per_kg`	out	in kJ/kg	,
`HHV_MJ_per_kg`	out	in MJ/kg	,

Applies when: fractions on the same (dry) basis, sum at most 1.

```
$ environmental-engineering solve enveng_dulong_heating_value C=0.48 H=0.064 O=0.376 S=0.004
N=0.008
HHV = 18643900 J/kg
HHV_kJ_per_kg = 18643.9
HHV_MJ_per_kg = 18.6439
  by: Heating value of waste from its elemental composition (modified Dulong)  (HHV (kJ/kg) = 337 C
+ 1419 (H - O/8) + 93 S + 23 N, mass per cent)
  C = 0.48
  H = 0.064
  O = 0.376
  S = 0.004
  N = 0.008
  assumes: fractions on the same (dry) basis, sum at most 1
```

What the worked example means: This calculation determines the higher heating value of a waste sample using the modified Dulong formula. It uses the dry mass fractions of carbon, hydrogen, oxygen, sulfur, and nitrogen to estimate the energy content. The resulting higher heating value is 18643.9, which indicates the total heat released per unit mass when the fuel is completely combusted under standard conditions.

Landfill life with daily cover and waste growth, `enveng_landfill_life`

The landfill volume used in the first year (waste at its in-place density plus cover soil) and the life of a landfill of given capacity when the waste grows at a constant yearly rate.

$$n = \frac{\ln\left(1 + \frac{Cg}{V_0}\right)}{\ln(1+g)}, \quad V_0 = \frac{M(1+c)}{\rho}$$

symbol		meaning	SI unit
`capacity`	in	available landfill volume	m^3
`M`	in	waste delivered in the first year	kg/s
`rho`	in	in-place (compacted) waste density	kg/m^3
`cover`	in	cover soil volume per volume of waste (e.g. 0.25)	,
`g`	in	yearly growth of the waste quantity (fraction or %; 0 for none)	,
`V_first_year`	out	volume used in the first year, m^3	,
`life_years`	out	landfill life, years	,

Applies when: growth compounded yearly, life read continuously.

```
$ environmental-engineering solve enveng_landfill_life "capacity=2000000 m^3" "M=50000 t/yr"
"rho=600 kg/m^3" cover=0.25 g=0
V_first_year = 104166.6667
life_years = 19.2
  by: Landfill life with daily cover and waste growth  (V0 = M (1 + cover)/rho per year; capacity =
V0 ((1 + g)^n - 1)/g, so n = ln(1 + capacity g/V0)/ln(1 + g))
  capacity = 2000000 m^3
  M = 1.584404391 kg/s
  rho = 600 kg/m^3
  cover = 0.25
  g = 0
  assumes: growth compounded yearly, life read continuously
```

What the worked example means: This calculation determines the operational lifespan of a landfill by first establishing the volume consumed in the initial year. The first-year volume, denoted as 104167, is derived from the waste delivery rate 50000 t/yr, adjusted for cover soil 0.25, and divided by the compacted density 600 kg/m^3. Using this base volume and the annual growth factor 0, the model computes how many years 19.2 it will take to fill the available capacity 2e+06 m^3. This result indicates when the site will reach its physical limit under current operating assumptions.

Landfill methane generation (first-order decay, constant acceptance), `enveng_landfill_gas_generation`

The methane generation rate and the cumulative methane of a landfill receiving waste at a constant rate for its operating life, each deposit decaying at first order (LandGEM-type model in continuous form), and the landfill gas flow at 50 % methane.

$$Q(t) = \int_0^{\min(t,t_c)} k L_0 M\, e^{-k(t-\tau)} d\tau = M L_0 \left(e^{-k(t-\min(t,t_c))} - e^{-kt} \right)$$

symbol		meaning	SI unit
`M`	in	waste acceptance rate	kg/s
`L0`	in	methane generation potential	m^3/kg
`k`	in	methane generation rate constant	1/s
`tc`	in	operating (filling) period	s
`t`	in	time since opening	s
`Q_CH4`	out	methane generation rate at t	m^3/s
`Q_CH4_m3_per_year`	out	in m^3 per year	,
`V_CH4`	out	cumulative methane generated up to t	m^3
`Q_LFG`	out	landfill gas rate at 50 % methane	m^3/s

Applies when: constant acceptance from opening to tc; first-order decay of every deposit.

```
$ environmental-engineering solve enveng_landfill_gas_generation "M=100000 t/yr" "L0=100 m^3/t"
"k=0.05 1/yr" "tc=20 yr" "t=25 yr"
Q_CH4 = 0.1559991844 m^3/s
Q_CH4_m3_per_year = 4922959.862
V_CH4 = 101540802.8 m^3
Q_LFG = 0.3119983688 m^3/s
  by: Landfill methane generation (first-order decay, constant acceptance)  (Q(t) = M L0 (e^(-k (t
- min(t, tc))) - e^(-k t)); cumulative volume by integrating Q)
  M = 3.168808781 kg/s
  L0 = 0.1 m^3/kg
  k = 1.584404391e-09 1/s
  tc = 631152000 s
  t = 788940000 s
  assumes: constant acceptance from opening to tc; first-order decay of every deposit
```

What the worked example means: This calculation determines the current methane generation rate for a landfill that has received waste at a constant acceptance rate of 100000 t/yr since its opening. Using a first-order decay model with a rate constant of 0.05 1/yr and a methane generation potential of 100 m^3/t, the system yields an instantaneous methane flow of 0.155999 m^3/s. This rate translates to 4.92296e+06 annually. The total amount of methane produced from the start of operations until the current time of 25 yr is calculated as 1.01541e+08 m^3. Based on these figures, the total landfill gas flow, assuming fifty percent methane content, is estimated at 0.311998 m^3/s.

Moisture content of mixed solid waste, `enveng_waste_moisture_content`

The moisture content (wet and dry basis) and the dry mass of a waste mixture from the masses of its components and their moisture fractions.

$$M_{wet} = \frac{\sum m_i w_i}{\sum m_i}$$

symbol		meaning	SI unit
`m`	in	wet masses of the components (any one unit)	,
`w`	in	moisture fractions of the components, wet basis	,
`moisture_wet`	out	moisture content, wet basis	,
`dry_mass`	out	dry mass, in the unit of m	,
`moisture_dry`	out	moisture content, dry basis	,

Applies when: moisture fractions below 1.

```
$ environmental-engineering solve enveng_waste_moisture_content "m=[40, 25, 15, 20]" "w=[0.7, 0.06,
0.02, 0.2]"
moisture_wet = 0.338
dry_mass = 66.2
moisture_dry = 0.5105740181
  by: Moisture content of mixed solid waste  (water = sum m_i w_i; M_wet = water/sum m; M_dry =
water/(sum m - water))
  assumes: moisture fractions below 1
```

What the worked example means: This calculation determines the overall moisture content of a mixed solid waste stream on both wet and dry bases, as well as its total dry mass. It sums the water mass contributed by each component based on their individual wet masses [40, 25, 15, 20] and moisture fractions [0.7, 0.06, 0.02, 0.2], then divides this total water by the sum of all wet masses to find the wet basis result 0.338. The dry mass 66.2 is derived by subtracting the total water from the total wet mass, which allows for the calculation of the dry basis moisture content 0.510574. These values are essential for assessing the handling, storage, and processing requirements of the waste mixture.

Municipal solid waste generation and collection trucks, `enveng_solid_waste_generation`

The daily and yearly mass of municipal solid waste of a population, its compacted volume and the number of truck loads per day.

$$\dot{m} = P\,r, \quad n = \left\lceil \frac{\dot{m}}{\rho V_t} \right\rceil$$

symbol		meaning	SI unit
`pop`	in	population served	,
`rate`	in	generation rate in kg per person per day	,
`rho`	in	compacted density in the truck	kg/m^3
`Vt`	in	truck body volume	m^3
`m`	out	waste generation	kg/s
`m_kg_per_day`	out	in kg/d	,
`m_t_per_year`	out	in t per 365-day year	,
`V_m3_per_day`	out	compacted volume per day, m^3	,
`trucks_per_day`	out	truck loads per day (rounded up)	,

Applies when: full truck loads at the stated density.

```
$ environmental-engineering solve enveng_solid_waste_generation pop=50000 rate=1.5 "rho=400 kg/m^3"
"Vt=15 m^3"
m = 0.8680555556 kg/s
m_kg_per_day = 75000
m_t_per_year = 27375
V_m3_per_day = 187.5
trucks_per_day = 13
  by: Municipal solid waste generation and collection trucks  (m = P r; V = m/rho; trucks =
ceil(V/Vt))
  rate = 1.5
  rho = 400 kg/m^3
  Vt = 15 m^3
  assumes: full truck loads at the stated density
```

What the worked example means: This calculation determines the municipal solid waste generation rate based on population and per capita production. The total daily mass of waste is computed as 75000. This mass is converted into a compacted volume of 187.5 cubic meters using the specified density. Finally, the number of collection trucks needed to transport this volume in full loads is determined to be 13.

Wastewater (18)

Activated sludge (complete mix) effluent substrate and biomass (Lawrence-McCarty), `enveng_activated_sludge_cstr_design`

The effluent soluble substrate, the mixed-liquor biomass and the observed yield of a complete-mix activated-sludge reactor with recycle, from the kinetic coefficients, the SRT and HRT and the influent substrate.

$$S = \frac{K_s(1 + k_d\theta_c)}{\theta_c(Yk - k_d) - 1}, \quad X = \frac{\theta_c Y(S_0 - S)}{\theta(1 + k_d\theta_c)}$$

symbol		meaning	SI unit
`Y`	in	true yield coefficient, kg VSS per kg BOD	,
`k`	in	maximum specific substrate utilisation rate	1/s
`Ks`	in	half-saturation constant	kg/m^3
`kd`	in	endogenous decay coefficient	1/s
`SRT`	in	solids retention time	s
`HRT`	in	hydraulic retention time	s
`S0`	in	influent substrate (BOD)	kg/m^3
`S`	out	effluent soluble substrate	kg/m^3
`S_mgL`	out	in mg/L	,
`X`	out	biomass concentration in the reactor	kg/m^3
`X_mgL`	out	in mg/L	,
`Y_obs`	out	observed yield Y/(1 + kd SRT)	,

Applies when: steady state, complete mix; SRT above the washout limit; S < S0.

```
$ environmental-engineering solve enveng_activated_sludge_cstr_design Y=0.5 "k=5 1/day" "Ks=60
mg/L" "kd=0.06 1/day" "SRT=10 day" "HRT=6 h" "S0=250 mg/L"
S = 0.004102564103 kg/m^3
S_mgL = 4.102564103
X = 3.073717949 kg/m^3
X_mgL = 3073.717949
Y_obs = 0.3125
  by: Activated sludge (complete mix) effluent substrate and biomass (Lawrence-McCarty)  (S = Ks (1
+ kd SRT)/(SRT (Y k - kd) - 1); X = (SRT/HRT) Y (S0 - S)/(1 + kd SRT))
  Y = 0.5
  k = 5.787037037e-05 1/s
  Ks = 0.06 kg/m^3
  kd = 6.944444444e-07 1/s
  SRT = 864000 s
  HRT = 21600 s
  S0 = 0.25 kg/m^3
  assumes: steady state, complete mix; SRT above the washout limit; S < S0
```

What the worked example means: This calculation determines the steady-state performance of a complete-mix activated-sludge reactor. Using the kinetic coefficients, solids retention time, hydraulic retention time, and influent substrate, it computes the effluent soluble substrate at 0.00410256 kg/m^3 and the mixed-liquor

biomass at 3.07372 kg/m^3. The result indicates how effectively the system removes organic matter and maintains microbial mass under the specified operational conditions.

Dissolved oxygen during aeration and the transfer rate, `enveng_aeration_do_curve`

The dissolved oxygen after an aeration time from the starting DO, the saturation DO and KLa, and the oxygen transfer rate KLa (Cs - C) at that moment.

$$C = C_s - (C_s - C_0)e^{-K_L a\, t}$$

symbol		meaning	SI unit
`Cs`	in	saturation DO	kg/m^3
`C0`	in	starting DO	kg/m^3
`KLa`	in	volumetric transfer coefficient	1/s
`t`	in	aeration time	s
`C`	out	DO at t	kg/m^3
`C_mgL`	out	in mg/L	,
`OTR`	out	oxygen transfer rate at t	kg/(m^3*s)
`OTR_mg_per_L_h`	out	transfer rate in mg/(L h)	,

Applies when: C0 <= Cs; no oxygen uptake.

```
$ environmental-engineering solve enveng_aeration_do_curve "Cs=9.1 mg/L" "C0=1 mg/L" "KLa=10 1/h"
"t=10 min"
C = 0.007570107617 kg/m^3
C_mgL = 7.570107617
OTR = 4.249701064e-06 kg/(m^3*s)
OTR_mg_per_L_h = 15.29892383
  by: Dissolved oxygen during aeration and the transfer rate  (dC/dt = KLa (Cs - C), C = Cs - (Cs -
C0) e^(-KLa t))
  Cs = 0.0091 kg/m^3
  C0 = 0.001 kg/m^3
  KLa = 0.002777777778 1/s
  t = 600 s
  assumes: C0 <= Cs; no oxygen uptake
```

What the worked example means: This calculation determines the dissolved oxygen concentration at time t using the first-order kinetic model. Starting from an initial concentration of 1 mg/L, the system approaches the saturation limit of 9.1 mg/L with a volumetric transfer coefficient of 10 1/h. The resulting concentration is 0.00757011 kg/m^3, which converts to 7.57011 for practical reporting. Additionally, the instantaneous oxygen transfer rate at this moment is calculated as 4.2497e-06 kg/(m^3*s), equivalent to 15.2989. This output indicates how quickly oxygen is being transferred into the water at that specific point in time.

Field (actual) oxygen transfer rate of an aeration system, `enveng_field_oxygen_transfer`

The actual oxygen transfer rate in the process from the standard (clean water, 20 degC, zero DO) rate, corrected by alpha, beta, the temperature coefficient, the site saturation and the operating DO.

$$AOTR = SOTR \, \alpha \, \theta^{T-20} \, \frac{\beta C_{s,T} F - C_L}{C_{s,20}}$$

symbol		meaning	SI unit
`SOTR`	in	standard oxygen transfer rate	kg/s
`alpha`	in	alpha factor (process/clean water KLa)	,
`beta`	in	beta factor (process/clean water saturation)	,
`theta`	in	temperature coefficient (1.024)	,
`CsT`	in	clean-water saturation DO at the process temperature	kg/m^3
`Cs20`	in	clean-water saturation DO at 20 degC	kg/m^3
`CL`	in	operating DO	kg/m^3
`T`	in	process temperature	K
`Fp`	in	pressure (elevation) correction of saturation (optional)	,
`AOTR`	out	actual oxygen transfer rate	kg/s
`AOTR_kg_per_h`	out	in kg O2/h	,
`ratio`	out	AOTR/SOTR	,

Applies when: beta CsT Fp > CL.

```
$ environmental-engineering solve enveng_field_oxygen_transfer "SOTR=100 kg/h" alpha=0.6 beta=0.95
theta=1.024 "CsT=8.26 mg/L" "Cs20=9.09 mg/L" "CL=2 mg/L" "T=25 degC"
AOTR = 0.01207029108 kg/s
AOTR_kg_per_h = 43.45304789
ratio = 0.4345304789
  by: Field (actual) oxygen transfer rate of an aeration system  (AOTR = SOTR alpha theta^(T - 20)
(beta CsT Fp - CL)/Cs20)
  SOTR = 0.02777777778 kg/s
  alpha = 0.6
  beta = 0.95
  theta = 1.024
  CsT = 0.00826 kg/m^3
  Cs20 = 0.00909 kg/m^3
  CL = 0.002 kg/m^3
  T = 298.15 K
  assumes: beta CsT Fp > CL
```

What the worked example means: This calculation determines the field or actual oxygen transfer rate by adjusting the standard oxygen transfer rate for site-specific conditions. The result, 0.0120703 kg/s, represents the effective mass of oxygen transferred per second under current operating parameters. This value is derived from the standard rate 100 kg/h, modified by the process factors alpha and beta, the temperature coefficient theta raised to the power of the difference between the process temperature T and twenty degrees Celsius, and the ratio of the corrected saturation concentration minus the operating dissolved oxygen level to the standard saturation concentration at twenty degrees Celsius. The hourly equivalent is given as 43.453.

Food-to-microorganism ratio (F/M), `enveng_food_to_microorganism_ratio`

The food-to-microorganism ratio of an aeration tank from the flow, influent BOD, tank volume and mixed-liquor volatile suspended solids.

$$\frac{F}{M} = \frac{QS_0}{VX}$$

symbol		meaning	SI unit
`Q`	in	influent flow	m^3/s
`S0`	in	influent BOD (or COD)	kg/m^3
`V`	in	aeration tank volume	m^3
`X`	in	mixed liquor volatile suspended solids (MLVSS)	kg/m^3
`FM`	out	F/M ratio	1/s
`FM_per_day`	out	F/M in kg BOD/(kg MLVSS d)	,

Applies when: Q, S0, V, X > 0.

```
$ environmental-engineering solve enveng_food_to_microorganism_ratio "Q=10000 m^3/day" "S0=200
mg/L" "V=3000 m^3" "X=2500 mg/L"
FM = 3.086419753e-06 1/s
FM_per_day = 0.2666666667
  by: Food-to-microorganism ratio (F/M)  (F/M = Q S0/(V X))
  Q = 0.1157407407 m^3/s
  S0 = 0.2 kg/m^3
  V = 3000 m^3
  X = 2.5 kg/m^3
  assumes: Q, S0, V, X > 0
```

What the worked example means: This calculation determines the Food-to-Microorganism ratio for an aeration tank. It uses the influent flow 10000 m^3/day, influent biochemical oxygen demand 200 mg/L, tank volume 3000 m^3, and mixed liquor volatile suspended solids 2500 mg/L. The resulting ratio of 3.08642e-06 1/s indicates the balance between available organic matter and active biomass, which is critical for controlling treatment efficiency and sludge characteristics.

Hydraulic retention time and volumetric organic loading, `enveng_hrt_organic_loading`

The hydraulic retention time of a reactor and its volumetric organic (BOD) loading rate from the flow, influent BOD and volume.

$$\theta = \frac{V}{Q}, \quad L_v = \frac{QS_0}{V}$$

symbol		meaning	SI unit
`Q`	in	influent flow	m^3/s
`S0`	in	influent BOD	kg/m^3
`V`	in	reactor volume	m^3
`HRT`	out	hydraulic retention time	s
`HRT_h`	out	HRT in hours	,

symbol		meaning	SI unit
`OLR`	out	volumetric organic loading rate	kg/(m^3*s)
`OLR_kg_per_m3_day`	out	loading in kg BOD/(m^3 d)	,

Applies when: Q, S0, V > 0.

```
$ environmental-engineering solve enveng_hrt_organic_loading "Q=10000 m^3/day" "S0=200 mg/L"
"V=3000 m^3"
HRT = 25920 s
HRT_h = 7.2
OLR = 7.716049383e-06 kg/(m^3*s)
OLR_kg_per_m3_day = 0.6666666667
  by: Hydraulic retention time and volumetric organic loading  (HRT = V/Q; OLR = Q S0/V)
  Q = 0.1157407407 m^3/s
  S0 = 0.2 kg/m^3
  V = 3000 m^3
  assumes: Q, S0, V > 0
```

What the worked example means: This calculation determines the hydraulic retention time and volumetric organic loading rate for a reactor. Using the influent flow of 10000 m^3/day, influent biochemical oxygen demand of 200 mg/L, and reactor volume of 3000 m^3, the system yields a hydraulic retention time of 25920 s and a loading rate of 7.71605e-06 kg/(m^3*s). The hydraulic retention time indicates how long water remains in the tank, while the loading rate shows the mass of organic matter applied per unit volume of the reactor.

KLa fitted to a reaeration test, `enveng_kla_regression`

The volumetric oxygen-transfer coefficient KLa from a series of dissolved-oxygen readings during a reaeration test, by linear regression of ln(Cs - C) against time.

$$\ln(C_s - C) = \ln(C_s - C_0) - K_L a\, t$$

symbol		meaning	SI unit
`t`	in	times in minutes	,
`C`	in	DO readings in mg/L (same order)	,
`Cs`	in	saturation DO	kg/m^3
`KLa_per_min`	out	KLa in 1/min	,
`KLa`	out	KLa	1/s
`KLa_per_h`	out	KLa in 1/h	,
`r2`	out	coefficient of determination	,

Applies when: every reading below Cs; at least three distinct times.

```
$ environmental-engineering solve enveng_kla_regression "t=[2, 4, 6, 8, 10, 12]" "C=[2.5, 4.1, 5.4,
6.3, 7, 7.6]" "Cs=9.1 mg/L"
KLa_per_min = 0.1469891116
KLa = 0.002449818526 1/s
KLa_per_h = 8.819346694
r2 = 0.9991806961
  by: KLa fitted to a reaeration test  (least squares of ln(Cs - C) = ln(Cs - C0) - KLa t)
  Cs = 0.0091 kg/m^3
  assumes: every reading below Cs; at least three distinct times
```

What the worked example means: This calculation determines the volumetric oxygen-transfer coefficient KLa by performing a least-squares linear regression on the natural logarithm of the dissolved oxygen deficit against time. Using the saturation concentration 9.1 mg/L and the measured readings [2.5, 4.1, 5.4, 6.3, 7, 7.6] at times [2, 4, 6, 8, 10, 12], the method isolates the exponential decay rate. The resulting coefficient 0.00244982 1/s represents the speed at which oxygen transfers into the water, while the correlation statistic 0.999181 indicates how well the first-order model fits the observed reaeration behavior.

Methane production from COD removed (anaerobic digestion), `enveng_anaerobic_methane_yield`

The methane gas flow from an anaerobic process from the COD removed less the COD converted to biomass (1.42 kg COD per kg VSS), at a stated temperature and pressure (64 g COD per mole of methane).

$$Q_{CH_4} = \frac{\mathrm{COD} - 1.42 P_x}{64\ \mathrm{g/mol}} \frac{RT}{P}$$

symbol		meaning	SI unit
`COD`	in	COD removed	kg/s
`Px`	in	biomass (VSS) produced	kg/s
`T`	in	gas temperature	K
`P`	in	gas pressure	Pa
`Q_CH4`	out	methane flow at T and P	m^3/s
`Q_CH4_m3_per_day`	out	in m^3/d at T and P	,
`Q_CH4_stp_m3_per_day`	out	in m^3/d at 0 degC and 1 atm	,

Applies when: ideal gas; COD balance.

```
$ environmental-engineering solve enveng_anaerobic_methane_yield "COD=5000 kg/day" "Px=300 kg/day"
"T=308.15 K" "P=101.325 kPa"
Q_CH4 = 0.02091695562 m^3/s
Q_CH4_m3_per_day = 1807.224965
Q_CH4_stp_m3_per_day = 1601.958459
  by: Methane production from COD removed (anaerobic digestion)  (n = (COD - 1.42 Px)/(64 g/mol); Q
= n R T/P)
  COD = 0.05787037037 kg/s
  Px = 0.003472222222 kg/s
  T = 308.15 K
  P = 101325 Pa
  assumes: ideal gas; COD balance
```

What the worked example means: This calculation determines the volumetric flow of methane gas produced from anaerobic digestion. It starts with the total chemical oxygen demand removed, which is 5000 kg/day, and subtracts the portion converted into new biomass cells, represented by 300 kg/day. The remaining mass is divided by sixty-four grams per mole to find the number of moles of methane generated. This molar quantity is then multiplied by the ideal gas constant, the absolute temperature of 308.15 K, and divided by the pressure of 101.325 kPa to yield the final gas volume flow of 0.020917 m^3/s.

Minimum (washout) solids retention time, `enveng_minimum_srt`

The washout SRT of a complete-mix biological reactor: below it the organisms are lost faster than they grow on the influent substrate.

$$\frac{1}{\theta_{c,min}} = \frac{Yk S_0}{K_s + S_0} - k_d$$

symbol		meaning	SI unit
`Y`	in	true yield coefficient, kg VSS per kg BOD	,
`k`	in	maximum specific substrate utilisation rate	1/s
`Ks`	in	half-saturation constant	kg/m^3
`kd`	in	endogenous decay coefficient	1/s
`S0`	in	influent substrate	kg/m^3
`SRT_min`	out	minimum SRT	s
`SRT_min_days`	out	minimum SRT in days	,

Applies when: Y k S0/(Ks + S0) > kd.

```
$ environmental-engineering solve enveng_minimum_srt Y=0.5 "k=5 1/day" "Ks=60 mg/L" "kd=0.06 1/day"
"S0=250 mg/L"
SRT_min = 44168.86544 s
SRT_min_days = 0.5112137203
  by: Minimum (washout) solids retention time  (1/SRT_min = Y k S0/(Ks + S0) - kd)
  Y = 0.5
  k = 5.787037037e-05 1/s
  Ks = 0.06 kg/m^3
  kd = 6.944444444e-07 1/s
  S0 = 0.25 kg/m^3
  assumes: Y k S0/(Ks + S0) > kd
```

What the worked example means: This calculation determines the minimum solids retention time, or washout SRT, for a complete-mix biological reactor. It uses the true yield coefficient (0.5), maximum specific substrate utilisation rate (5 1/day), half-saturation constant (60 mg/L), endogenous decay coefficient (0.06 1/day), and influent substrate concentration (250 mg/L). The result indicates that if the actual solids retention time drops below 44168.9 s, microorganisms will be washed out of the system faster than they can reproduce, leading to treatment failure.

Monod specific growth rate, `enveng_monod_growth_rate`

The specific growth rate of microorganisms at a substrate concentration by the Monod equation, and the net rate when the endogenous decay coefficient is given.

$$\mu = \frac{\mu_{max} S}{K_s + S}$$

symbol		meaning	SI unit
`mu_max`	in	maximum specific growth rate	1/s
`Ks`	in	half-saturation constant	kg/m^3
`S`	in	substrate concentration	kg/m^3
`kd`	in	endogenous decay coefficient (optional)	1/s
`mu`	out	specific growth rate	1/s
`mu_per_day`	out	in 1/d	,
`mu_net`	out	net specific growth rate mu - kd	1/s
`mu_net_per_day`	out	net rate in 1/d	,

Applies when: Monod kinetics.

```
$ environmental-engineering solve enveng_monod_growth_rate "mu_max=3 1/day" "Ks=60 mg/L" "S=10
mg/L"
mu = 4.96031746e-06 1/s
mu_per_day = 0.4285714286
  by: Monod specific growth rate  (mu = mu_max S/(Ks + S); mu_net = mu - kd)
  mu_max = 3.472222222e-05 1/s
  Ks = 0.06 kg/m^3
  S = 0.01 kg/m^3
  assumes: Monod kinetics
```

In the worked example, mu_max = 3 1/day, Ks = 60 mg/L, S = 10 mg/L go through the equation above and give mu = 4.96031746e-06 1/s, mu_per_day = 0.4285714286. It applies only when Monod kinetics: outside that it says what is wrong instead of returning a number.

Overall oxygen transfer coefficient KLa from two DO readings, `enveng_kla_two_point`

The volumetric mass-transfer coefficient KLa from two dissolved-oxygen readings during reaeration toward a known saturation concentration.

$$K_L a = \frac{\ln \frac{C_s - C_1}{C_s - C_2}}{t_2 - t_1}$$

symbol		meaning	SI unit
`Cs`	in	saturation DO	kg/m^3
`C1`	in	DO at the first time	kg/m^3
`C2`	in	DO at the second time	kg/m^3
`t1`	in	first time	s
`t2`	in	second time	s
`KLa`	out	KLa	1/s
`KLa_per_h`	out	KLa in 1/h	,

Applies when: C1 < C2 < Cs; t2 > t1.

```
$ environmental-engineering solve enveng_kla_two_point "Cs=9.1 mg/L" "C1=2 mg/L" "C2=6 mg/L" "t1=2
min" "t2=10 min"
KLa = 0.001726443068 1/s
KLa_per_h = 6.215195044
  by: Overall oxygen transfer coefficient KLa from two DO readings  (KLa = ln((Cs - C1)/(Cs -
C2))/(t2 - t1))
  Cs = 0.0091 kg/m^3
  C1 = 0.002 kg/m^3
  C2 = 0.006 kg/m^3
  t1 = 120 s
  t2 = 600 s
  assumes: C1 < C2 < Cs; t2 > t1
```

What the worked example means: This calculation determines the volumetric mass-transfer coefficient, KLa, based on two dissolved oxygen readings taken during a reaeration process. Using the saturation concentration of 9.1 mg/L, the initial reading of 2 mg/L at time 2 min, and the subsequent reading of 6 mg/L at time 10 min, the model computes the rate of oxygen uptake. The resulting coefficient of 0.00172644 1/s indicates how quickly the water approaches equilibrium with the atmosphere under these specific conditions.

Oxygen requirement of an activated-sludge process, `enveng_aeration_oxygen_requirement`

The carbonaceous oxygen requirement: ultimate BOD removed (BOD5 removed divided by the BOD5/BODu ratio) less 1.42 times the biomass wasted.

$$\dot{m}_{O_2} = \frac{Q(S_0 - S)}{f} - 1.42 P_x$$

symbol		meaning	SI unit
`Q`	in	flow	m^3/s
`S0`	in	influent BOD5	kg/m^3
`S`	in	effluent soluble BOD5	kg/m^3
`f`	in	BOD5/BODu ratio (e.g. 0.68)	,
`Px`	in	biomass wasted (VSS)	kg/s
`O2`	out	oxygen required	kg/s
`O2_kg_per_day`	out	in kg O2/d	,

Applies when: carbonaceous demand only (no nitrification).

```
$ environmental-engineering solve enveng_aeration_oxygen_requirement "Q=10000 m^3/day" "S0=250
mg/L" "S=5 mg/L" f=0.68 "Px=800 kg/day"
O2 = 0.02855255991 kg/s
O2_kg_per_day = 2466.941176
  by: Oxygen requirement of an activated-sludge process  (O2 = Q (S0 - S)/f - 1.42 Px)
  Q = 0.1157407407 m^3/s
  S0 = 0.25 kg/m^3
  S = 0.005 kg/m^3
  f = 0.68
  Px = 0.009259259259 kg/s
  assumes: carbonaceous demand only (no nitrification)
```

What the worked example means: This calculation determines the oxygen needed for the activated-sludge process by subtracting the oxygen equivalent of wasted biomass from the ultimate biochemical oxygen demand removed. Using a flow of 10000 m^3/day, influent BOD5 of 250 mg/L, and effluent soluble BOD5 of 5 mg/L, divided by the ratio 0.68, and subtracting 1.42 times the biomass wasted of 800 kg/day, the result is an oxygen requirement of 0.0285526 kg/s. This value represents the daily load as 2466.94, assuming only carbonaceous demand is considered.

Return activated sludge ratio, `enveng_return_sludge_ratio`

The return sludge ratio and flow needed to hold the mixed-liquor concentration, from a solids balance around the aeration tank (influent solids neglected).

$$R = \frac{Q_r}{Q} = \frac{X}{X_r - X}$$

symbol		meaning	SI unit
`X`	in	mixed liquor suspended solids	kg/m^3
`Xr`	in	return sludge concentration	kg/m^3
`Q`	in	influent flow	m^3/s
`R`	out	return ratio Qr/Q	,
`Qr`	out	return sludge flow	m^3/s

Applies when: Xr > X; influent solids negligible.

```
$ environmental-engineering solve enveng_return_sludge_ratio "X=3000 mg/L" "Xr=10000 mg/L" "Q=10000
m^3/day"
R = 0.4285714286
Qr = 0.0496031746 m^3/s
  by: Return activated sludge ratio  ((Q + Qr) X = Qr Xr, so R = X/(Xr - X))
  X = 3 kg/m^3
  Xr = 10 kg/m^3
  Q = 0.1157407407 m^3/s
  assumes: Xr > X; influent solids negligible
```

What the worked example means: This calculation determines the return activated sludge ratio and the corresponding return sludge flow rate needed to maintain the desired mixed liquor suspended solids concentration in the aeration tank. Using a solids balance around the tank where influent solids are neglected, the ratio is derived from the relationship between the mixed liquor concentration and the return sludge

concentration. The resulting ratio of 0.428571 indicates how much return flow is needed relative to the influent flow, while the absolute return flow of 0.0496032 m^3/s represents the volumetric rate at which concentrated sludge must be pumped back into the system.

Sludge volume after thickening or dewatering, `enveng_sludge_thickening`

The sludge volume after thickening or dewatering from one solids fraction to another (same specific gravity), and the fractional volume reduction.

$$V_2 = V_1 \frac{P_1}{P_2}$$

symbol		meaning	SI unit
`V1`	in	sludge volume rate before	m^3/s
`P1`	in	solids fraction before (fraction or %)	,
`P2`	in	solids fraction after (fraction or %)	,
`V2`	out	sludge volume rate after	m^3/s
`reduction`	out	fractional volume reduction	,

Applies when: P2 > P1; same specific gravity.

```
$ environmental-engineering solve enveng_sludge_thickening "V1=100 m^3/day" P1=0.01 P2=0.05
V2 = 0.0002314814815 m^3/s
reduction = 0.8
  by: Sludge volume after thickening or dewatering  (V2 = V1 P1/P2)
  V1 = 0.001157407407 m^3/s
  P1 = 0.01
  P2 = 0.05
  assumes: P2 > P1; same specific gravity
```

What the worked example means: This calculation determines the new sludge volume rate after thickening or dewatering. By applying the solids balance principle, the initial volume rate of 100 m^3/day is adjusted for the change in solids fraction from 0.01 to 0.05. The resulting volume rate is 0.000231481 m^3/s, which indicates how much space the sludge occupies after processing. Additionally, the fractional volume reduction of 0.8 quantifies the efficiency of the process in shrinking the liquid waste stream.

Sludge volume index (SVI), `enveng_sludge_volume_index`

The sludge volume index from the 30-minute settled volume and the mixed-liquor suspended solids, with the customary estimate of the return sludge concentration (10^6/SVI mg/L).

$$SVI = \frac{V_{30}}{MLSS}$$

symbol		meaning	SI unit
`V30`	in	settled sludge volume after 30 minutes, mL/L	,
`MLSS`	in	mixed liquor suspended solids	kg/m^3
`SVI`	out	sludge volume index, mL/g	,

symbol		meaning	SI unit
`Xr_estimate`	out	estimated maximum return sludge concentration	kg/m^3
`Xr_estimate_mgL`	out	estimate in mg/L	,

Applies when: V30 <= 1000 mL/L.

```
$ environmental-engineering solve enveng_sludge_volume_index V30=300 "MLSS=2500 mg/L"
SVI = 120
Xr_estimate = 8.333333333 kg/m^3
Xr_estimate_mgL = 8333.333333
  by: Sludge volume index (SVI)  (SVI = V30 (mL/L)/MLSS (g/L))
  V30 = 300
  MLSS = 2.5 kg/m^3
  assumes: V30 <= 1000 mL/L
```

What the worked example means: This calculation determines the sludge volume index by dividing the thirty minute settled volume, given as 300, by the mixed liquor suspended solids concentration, provided as 2500 mg/L. The resulting value of 120 represents the volume in milliliters occupied by one gram of dried sludge after settling. This metric helps operators assess how well the biological floc settles and compacts within the clarifier, which is essential for maintaining proper return activated sludge concentrations.

Solids retention time (mean cell residence time), `enveng_solids_retention_time`

The solids retention time (sludge age) of an activated-sludge system from the biomass in the tank and the biomass leaving in the waste sludge and the effluent.

$$\theta_c = \frac{VX}{Q_w X_w + Q_e X_e}$$

symbol		meaning	SI unit
`V`	in	aeration tank volume	m^3
`X`	in	MLVSS in the tank	kg/m^3
`Qw`	in	waste sludge flow	m^3/s
`Xw`	in	VSS in the waste sludge	kg/m^3
`Qe`	in	effluent flow	m^3/s
`Xe`	in	VSS in the effluent	kg/m^3
`SRT`	out	solids retention time	s
`SRT_days`	out	SRT in days	,

Applies when: steady state.

```
$ environmental-engineering solve enveng_solids_retention_time "V=3000 m^3" "X=2500 mg/L" "Qw=100
m^3/day" "Xw=10000 mg/L" "Qe=9900 m^3/day" "Xe=15 mg/L"
SRT = 564214.1924 s
SRT_days = 6.530256857
  by: Solids retention time (mean cell residence time)  (SRT = V X/(Qw Xw + Qe Xe))
  V = 3000 m^3
  X = 2.5 kg/m^3
  Qw = 0.001157407407 m^3/s
  Xw = 10 kg/m^3
  Qe = 0.1145833333 m^3/s
  Xe = 0.015 kg/m^3
  assumes: steady state
```

What the worked example means: This calculation determines the mean cell residence time, or sludge age, for an activated-sludge system. It uses the aeration tank volume of 3000 m^3 and the mixed liquor volatile suspended solids concentration of 2500 mg/L to find the total biomass in the reactor. This value is divided by the sum of biomass leaving via waste sludge flow 100 m^3/day at concentration 10000 mg/L and effluent flow 9900 m^3/day at concentration 15 mg/L. The resulting solids retention time of 564214 s indicates how long microorganisms remain in the system on average, which governs biological treatment efficiency and sludge production rates.

Trickling filter BOD removal efficiency (NRC equation), `enveng_nrc_trickling_filter`

The BOD removal efficiency of a single-stage stone-media trickling filter (with its settling tank) by the NRC equation, from the BOD load, the filter volume and the recirculation ratio.

$$E = \frac{100}{1 + 0.4432\sqrt{W/(VF)}}, \quad F = \frac{1+R}{(1+R/10)^2}$$

symbol		meaning	SI unit
`W`	in	BOD load to the filter (excluding recycle)	kg/s
`V`	in	filter media volume	m^3
`R`	in	recirculation ratio Qr/Q	,
`F`	out	recirculation factor (1 + R)/(1 + R/10)^2	,
`E`	out	BOD removal efficiency (fraction)	,
`E_percent`	out	efficiency in per cent	,

Applies when: first-stage stone filter at 20 degC; W in kg/d and V in m^3 inside the formula constant.

```
$ environmental-engineering solve enveng_nrc_trickling_filter "W=800 kg/day" "V=1000 m^3" R=2
F = 2.083333333
E = 0.7845346289
E_percent = 78.45346289
  by: Trickling filter BOD removal efficiency (NRC equation)  (F = (1 + R)/(1 + R/10)^2; E = 1/(1 +
0.4432 sqrt(W/(V F))))
  W = 0.009259259259 kg/s
  V = 1000 m^3
  R = 2
  assumes: first-stage stone filter at 20 degC; W in kg/d and V in m^3 inside the formula constant
```

What the worked example means: This calculation determines the BOD removal efficiency for a single-stage stone-media trickling filter using the National Research Council equation. It uses the BOD load of 800 kg/day, the filter media volume of 1000 m^3, and the recirculation ratio of 2 to compute a recirculation factor of 2.08333. The resulting efficiency is 0.784535 as a fraction, or 78.4535 when expressed as a percentage, indicating how effectively the system removes organic matter under these specific operating conditions.

Volume of wet sludge from dry solids, `enveng_sludge_volume`

The volume (flow) of wet sludge from the dry-solids mass rate, the solids fraction and the specific gravity of the sludge (water 1000 kg/m^3).

$$V = \frac{M_s}{\rho_w S_{sl} P_s}$$

symbol		meaning	SI unit
`Ms`	in	dry solids mass rate	kg/s
`Ps`	in	solids fraction of the wet sludge (fraction or %)	,
`Ssl`	in	specific gravity of the wet sludge	,
`V`	out	wet sludge volume rate	m^3/s
`V_m3_per_day`	out	in m^3/d	,

Applies when: 0 < Ps <= 1.

```
$ environmental-engineering solve enveng_sludge_volume "Ms=1000 kg/day" Ps=0.04 Ssl=1.02
V = 0.0002836782861 m^3/s
V_m3_per_day = 24.50980392
  by: Volume of wet sludge from dry solids  (V = Ms/(rho_w Ssl Ps))
  Ms = 0.01157407407 kg/s
  Ps = 0.04
  Ssl = 1.02
  assumes: 0 < Ps <= 1
```

What the worked example means: This calculation determines the volumetric flow rate of wet sludge based on the mass rate of dry solids, the fraction of solids in the mixture, and the specific gravity of the sludge. The result, 0.000283678 m^3/s, represents the volume of wet sludge produced each second. This value is also expressed as 24.5098 cubic meters per day for operational planning. The calculation assumes that the density of water is exactly one thousand kilograms per cubic meter and that the specific gravity provided accurately reflects the bulk density of the wet sludge relative to water.

Waste biomass production (observed yield), `enveng_sludge_production`

The observed yield and the daily mass of biological solids produced (to be wasted) from the kinetic yield, decay coefficient, SRT, flow and substrate removed.

$$P_x = \frac{Y}{1 + k_d \theta_c} Q(S_0 - S)$$

symbol		meaning	SI unit
`Y`	in	true yield, kg VSS per kg BOD	,
`kd`	in	endogenous decay coefficient	1/s
`SRT`	in	solids retention time	s
`Q`	in	flow	m^3/s
`S0`	in	influent substrate	kg/m^3
`S`	in	effluent substrate	kg/m^3
`Y_obs`	out	observed yield	,
`Px`	out	biomass production	kg/s
`Px_kg_per_day`	out	in kg VSS/d	,

Applies when: S < S0.

```
$ environmental-engineering solve enveng_sludge_production Y=0.5 "kd=0.06 1/day" "SRT=10 day"
"Q=10000 m^3/day" "S0=250 mg/L" "S=5 mg/L"
Y_obs = 0.3125
Px = 0.008861400463 kg/s
Px_kg_per_day = 765.625
  by: Waste biomass production (observed yield)  (Y_obs = Y/(1 + kd SRT); Px = Y_obs Q (S0 - S))
  Y = 0.5
  kd = 6.944444444e-07 1/s
  SRT = 864000 s
  Q = 0.1157407407 m^3/s
  S0 = 0.25 kg/m^3
  S = 0.005 kg/m^3
  assumes: S < S0
```

What the worked example means: This calculation determines the daily mass of biological solids produced and the observed yield based on kinetic parameters. The observed yield, calculated as 0.3125, reflects the true yield adjusted for endogenous decay over the solids retention time. Using this yield with the flow rate and substrate removal, the model computes the total biomass production at 0.0088614 kg/s. This value represents the mass of volatile suspended solids generated per second, which converts to 765.625 when expressed on a daily basis. Understanding these outputs helps engineers size waste sludge handling systems accurately.

Water quality (17)

BOD exerted after a time (first-order), `enveng_bod_exerted`

The BOD exerted after time t and the oxygen demand remaining, from the ultimate BOD and the first-order rate constant.

$$BOD_t = L_0\left(1 - e^{-kt}\right)$$

symbol		meaning	SI unit
`L0`	in	ultimate (carbonaceous) BOD	kg/m^3
`k`	in	BOD rate constant (base e)	1/s
`t`	in	incubation or travel time	s

symbol		meaning	SI unit
`BOD_t`	out	BOD exerted after t	kg/m^3
`L_t`	out	BOD remaining after t	kg/m^3
`BOD_t_mgL`	out	BOD exerted in mg/L	,

Applies when: first-order kinetics.

```
$ environmental-engineering solve enveng_bod_exerted "L0=250 mg/L" "k=0.23 1/day" "t=5 day"
BOD_t = 0.1708408077 kg/m^3
L_t = 0.07915919234 kg/m^3
BOD_t_mgL = 170.8408077
  by: BOD exerted after a time (first-order)  (BOD_t = L0 (1 - e^(-k t)), L_t = L0 e^(-k t))
  L0 = 0.25 kg/m^3
  k = 2.662037037e-06 1/s
  t = 432000 s
  assumes: first-order kinetics
```

What the worked example means: This calculation determines the biochemical oxygen demand exerted over a specific period and the amount remaining, based on first-order kinetics. Using an ultimate BOD of 250 mg/L and a rate constant of 0.23 1/day for a duration of 5 day, the model computes that 0.170841 kg/m^3 has been consumed. Consequently, the residual oxygen demand is 0.0791592 kg/m^3. This result indicates how much organic matter has been oxidized by microorganisms during the incubation or travel time.

BOD from a dilution test (with optional seed correction), `enveng_bod_dilution_test`

The BOD of a sample from the dissolved oxygen of the diluted sample before and after incubation and the sample fraction, with the seed correction when the dilution water is seeded.

$$BOD = \frac{(D_1 - D_2) - (B_1 - B_2)f}{P}$$

symbol		meaning	SI unit
`D1`	in	DO of the diluted sample immediately after preparation	kg/m^3
`D2`	in	DO of the diluted sample after incubation	kg/m^3
`P`	in	decimal fraction of sample in the bottle (sample volume / bottle volume)	,
`B1`	in	DO of the seed control before incubation (optional)	kg/m^3
`B2`	in	DO of the seed control after incubation (optional)	kg/m^3
`f`	in	ratio of seed in the sample bottle to seed in the control (optional)	,
`BOD`	out	BOD of the sample	kg/m^3
`BOD_mgL`	out	BOD in mg/L	,

Applies when: D1 > D2; B1, B2 and f given together or not at all.

```
$ environmental-engineering solve enveng_bod_dilution_test "D1=8.5 mg/L" "D2=4 mg/L" P=0.05
BOD = 0.09 kg/m^3
BOD_mgL = 90
  by: BOD from a dilution test (with optional seed correction)  (BOD = ((D1 - D2) - (B1 - B2) f)/P
(unseeded: BOD = (D1 - D2)/P))
  D1 = 0.0085 kg/m^3
  D2 = 0.004 kg/m^3
  P = 0.05
  assumes: D1 > D2; B1, B2 and f given together or not at all
```

What the worked example means: This calculation determines the Biochemical Oxygen Demand of a water sample using dilution data. It subtracts the oxygen depletion of the seed control from the depletion observed in the diluted sample, then divides by the fraction of the sample present. The result, expressed as 0.09 kg/m^3, represents the amount of oxygen consumed by microorganisms to decompose organic matter in the sample over the incubation period.

BOD rate constant and ultimate BOD fitted to BOD data, `enveng_bod_rate_fit`

The first-order rate constant k and ultimate BOD L0 that best fit a series of BOD measurements (nonlinear least squares of BOD = L0 (1 - e^(-k t))).

$$\min_{k,L_0} \sum_i \left[y_i - L_0 \left(1 - e^{-k t_i}\right) \right]^2$$

symbol		meaning	SI unit
`t`	in	incubation times in days	,
`y`	in	measured BOD values in mg/L (same order)	,
`k`	out	fitted rate constant	1/s
`k_per_day`	out	fitted rate constant in 1/d	,
`L0`	out	fitted ultimate BOD	kg/m^3
`L0_mgL`	out	fitted ultimate BOD in mg/L	,
`rss`	out	residual sum of squares in (mg/L)^2	,

Applies when: at least three distinct positive times; a single rate constant between 0.001 and 20 per day fits.

```
$ environmental-engineering solve enveng_bod_rate_fit "t=[1, 2, 3, 5, 7, 10]" "y=[41, 74, 98, 132,
152, 168]"
k = 3.002440202e-06 1/s
k_per_day = 0.2594108335
L0 = 0.1815717527 kg/m^3
L0_mgL = 181.5717527
rss = 0.5327137697
  by: BOD rate constant and ultimate BOD fitted to BOD data  (for each k the best L0 is sum(y
f)/sum(f^2) with f = 1 - e^(-k t); k is the root of the stationarity condition sum((y - L0 f) t
e^(-k t)) = 0 (scan and bisection))
  assumes: at least three distinct positive times; a single rate constant between 0.001 and 20 per
day fits
```

What the worked example means: This calculation determines the best-fit parameters for the first-order biochemical oxygen demand model using nonlinear least squares. By minimizing the squared differences between measured values and the theoretical curve, it finds a single rate constant of 0.259411 per day and an ultimate BOD concentration of 181.572 mg/L that most accurately describe the decomposition process observed over time.

Concentration after mixing a discharge with a river, `enveng_mixing_two_streams`

The fully mixed concentration (BOD, DO, a pollutant) and flow just below a wastewater outfall from the flows and concentrations of the discharge and the river.

$$C = \frac{Q_w C_w + Q_r C_r}{Q_w + Q_r}$$

symbol		meaning	SI unit
`Qw`	in	wastewater (discharge) flow	m^3/s
`Cw`	in	concentration in the wastewater	kg/m^3
`Qr`	in	river flow upstream	m^3/s
`Cr`	in	concentration in the river upstream	kg/m^3
`C`	out	mixed concentration	kg/m^3
`C_mgL`	out	in mg/L	,
`Q`	out	combined flow	m^3/s

Applies when: complete mixing; conservative over the mixing zone.

```
$ environmental-engineering solve enveng_mixing_two_streams "Qw=0.5 m^3/s" "Cw=200 mg/L" "Qr=5
m^3/s" "Cr=2 mg/L"
C = 0.02 kg/m^3
C_mgL = 20
Q = 5.5 m^3/s
  by: Concentration after mixing a discharge with a river  (C = (Qw Cw + Qr Cr)/(Qw + Qr))
  Qw = 0.5 m^3/s
  Cw = 0.2 kg/m^3
  Qr = 5 m^3/s
  Cr = 0.002 kg/m^3
  assumes: complete mixing; conservative over the mixing zone
```

What the worked example means: This calculation determines the fully mixed concentration downstream of a wastewater outfall by combining the discharge and river flows. Using the wastewater flow of 0.5 m^3/s at concentration 200 mg/L and the upstream river flow of 5 m^3/s at concentration 2 mg/L, the resulting mixture has a concentration of 0.02 kg/m^3 and a total flow of 5.5 m^3/s. This value represents the immediate impact on water quality assuming complete mixing occurs.

Concentration in a well-mixed lake over time, `enveng_lake_transient`

The concentration in a completely mixed lake a time t after a change in load, from the initial concentration, the load, outflow, volume and first-order decay.

$$C(t) = C_{ss} + (C_0 - C_{ss})e^{-(Q/V+k)t}$$

symbol		meaning	SI unit
`W`	in	pollutant load after the change	kg/s
`Q`	in	outflow rate	m^3/s
`k`	in	first-order decay constant	1/s
`V`	in	lake volume	m^3
`C0`	in	concentration at t = 0	kg/m^3
`t`	in	elapsed time	s
`C`	out	concentration at t	kg/m^3
`C_mgL`	out	in mg/L	,
`C_ss`	out	new steady state	kg/m^3

Applies when: completely mixed; constant flow, volume and load.

```
$ environmental-engineering solve enveng_lake_transient "W=100 kg/day" "Q=10 m^3/s" "k=0.2 1/day"
"V=10000000 m^3" "C0=0 mg/L" "t=5 day"
C = 2.657713748e-05 kg/m^3
C_mgL = 0.02657713748
C_ss = 3.491620112e-05 kg/m^3
  by: Concentration in a well-mixed lake over time  (V dC/dt = W - Q C - k C V, so C = Css + (C0 -
Css) e^(-(Q/V + k) t))
  W = 0.001157407407 kg/s
  Q = 10 m^3/s
  k = 2.314814815e-06 1/s
  V = 10000000 m^3
  C0 = 0 kg/m^3
  t = 432000 s
  assumes: completely mixed; constant flow, volume and load
```

What the worked example means: This calculation determines the pollutant concentration in a completely mixed lake after a change in load. It uses the initial concentration 0 mg/L, the new load 100 kg/day, outflow rate 10 m^3/s, decay constant 0.2 1/day, and volume 1e+07 m^3. The resulting concentration at elapsed time 5 day is 2.65771e-05 kg/m^3, which corresponds to 0.0265771. The long-term equilibrium value, or new steady state, is calculated as 3.49162e-05 kg/m^3.

Critical (minimum) dissolved oxygen of the oxygen sag, `enveng_streeter_phelps_critical_point`

The critical time at which the oxygen deficit of a river is largest, the critical deficit and the minimum dissolved oxygen (Streeter-Phelps).

$$t_c = \frac{1}{k_a - k_d}\ln\left[\frac{k_a}{k_d}\left(1 - \frac{D_0(k_a - k_d)}{k_d L_0}\right)\right], \quad D_c = \frac{k_d}{k_a}L_0 e^{-k_d t_c}$$

symbol		meaning	SI unit
`kd`	in	deoxygenation rate constant	1/s
`ka`	in	reaeration rate constant	1/s

symbol		meaning	SI unit
`L0`	in	ultimate BOD of the mixed river water at the outfall	kg/m^3
`D0`	in	oxygen deficit at the outfall (DOsat - DO)	kg/m^3
`DOsat`	in	saturation dissolved oxygen	kg/m^3
`t_c`	out	critical travel time	s
`t_c_days`	out	critical time in days	,
`D_c`	out	critical (largest) deficit	kg/m^3
`DO_min`	out	minimum dissolved oxygen	kg/m^3
`DO_min_mgL`	out	minimum dissolved oxygen in mg/L	,

Applies when: the critical deficit stays below saturation; if the deficit falls from the outfall on, t_c = 0 and D_c = D0.

```
$ environmental-engineering solve enveng_streeter_phelps_critical_point "kd=0.23 1/day" "ka=0.46
1/day" "L0=10 mg/L" "D0=1 mg/L" "DOsat=9.1 mg/L"
t_c = 220803.3385 s
t_c_days = 2.555594195
D_c = 0.002777777778 kg/m^3
DO_min = 0.006322222222 kg/m^3
DO_min_mgL = 6.322222222
  by: Critical (minimum) dissolved oxygen of the oxygen sag  (t_c = ln[(ka/kd)(1 - D0 (ka - kd)/(kd
L0))]/(ka - kd); D_c = (kd/ka) L0 e^(-kd t_c))
  kd = 2.662037037e-06 1/s
  ka = 5.324074074e-06 1/s
  L0 = 0.01 kg/m^3
  D0 = 0.001 kg/m^3
  DOsat = 0.0091 kg/m^3
  assumes: the critical deficit stays below saturation; if the deficit falls from the outfall on,
t_c = 0 and D_c = D0
```

What the worked example means: This calculation determines the worst-case water quality conditions downstream of an outfall using the Streeter-Phelps model. It computes the critical travel time 2.55559 when the oxygen deficit reaches its maximum value of 0.00277778 kg/m^3. Consequently, the dissolved oxygen level drops to its lowest point, recorded here as 6.32222. This result helps engineers assess whether the river can recover from the pollution load or if further treatment is needed.

Dissolved oxygen at a distance downstream (Streeter-Phelps), `enveng_oxygen_sag_distance`

The oxygen deficit and dissolved oxygen at a distance downstream of an outfall from the river velocity (travel time x/v) and the Streeter-Phelps sag.

$$D(x) = \frac{k_d L_0}{k_a - k_d}\left(e^{-k_d x/v} - e^{-k_a x/v}\right) + D_0 e^{-k_a x/v}$$

symbol		meaning	SI unit
`kd`	in	deoxygenation rate constant	1/s
`ka`	in	reaeration rate constant	1/s
`L0`	in	ultimate BOD of the mixed river water at the outfall	kg/m^3

symbol		meaning	SI unit
`D0`	in	oxygen deficit at the outfall (DOsat - DO)	kg/m^3
`x`	in	distance downstream	m
`v`	in	mean river velocity	m/s
`DOsat`	in	saturation dissolved oxygen	kg/m^3
`D`	out	oxygen deficit at x	kg/m^3
`DO`	out	dissolved oxygen at x	kg/m^3
`D_mgL`	out	deficit in mg/L	,
`DO_mgL`	out	dissolved oxygen in mg/L	,
`t`	out	travel time	s

Applies when: plug flow at constant velocity; deficit stays below saturation.

```
$ environmental-engineering solve enveng_oxygen_sag_distance "kd=0.23 1/day" "ka=0.46 1/day" "L0=10
mg/L" "D0=1 mg/L" "x=30 km" "v=0.3 m/s" "DOsat=9.1 mg/L"
D = 0.002378123211 kg/m^3
DO = 0.006721876789 kg/m^3
D_mgL = 2.378123211
DO_mgL = 6.721876789
t = 100000 s
  by: Dissolved oxygen at a distance downstream (Streeter-Phelps)  (t = x/v, then the Streeter-
Phelps deficit)
  kd = 2.662037037e-06 1/s
  ka = 5.324074074e-06 1/s
  L0 = 0.01 kg/m^3
  D0 = 0.001 kg/m^3
  x = 30000 m
  v = 0.3 m/s
  DOsat = 0.0091 kg/m^3
  assumes: plug flow at constant velocity; deficit stays below saturation
```

What the worked example means: The model calculates the oxygen deficit at a specific distance downstream using the Streeter-Phelps equation. It considers the travel time derived from river velocity and distance, along with deoxygenation and reaeration rates. The resulting deficit is 2.37812, which corresponds to a dissolved oxygen concentration of 6.72188. This value indicates how much oxygen has been consumed by biological activity relative to the saturation level at that point in the river.

Dissolved oxygen saturation concentration (Benson-Krause), `enveng_do_saturation`

The saturation concentration of dissolved oxygen in water in equilibrium with moist air at 1 atm, from the temperature and salinity (Benson and Krause equation as adopted in Standard Methods).

$$\ln C_s = -139.34411 + \frac{1.575701 \times 10^5}{T} - \frac{6.642308 \times 10^7}{T^2} + \frac{1.2438 \times 10^{10}}{T^3} - \frac{8.621949 \times 10^{11}}{T^4} - S($$

symbol		meaning	SI unit
`T`	in	water temperature	K

symbol		meaning	SI unit
`S`	in	salinity in g/kg (0 for fresh water)	,
`DOsat`	out	saturation dissolved oxygen	kg/m^3
`DOsat_mgL`	out	in mg/L	,

Applies when: 0-40 degC; 0-40 g/kg salinity; 1 atm moist air.

```
$ environmental-engineering solve enveng_do_saturation "T=20 degC" S=0
DOsat = 0.009092426043 kg/m^3
DOsat_mgL = 9.092426043
  by: Dissolved oxygen saturation concentration (Benson-Krause)  (ln C = -139.34411 + 1.575701e5/T
- 6.642308e7/T^2 + 1.2438e10/T^3 - 8.621949e11/T^4 - S(1.7674e-2 - 10.754/T + 2140.7/T^2))
  T = 293.15 K
  S = 0
  assumes: 0-40 degC; 0-40 g/kg salinity; 1 atm moist air
```

What the worked example means: This calculation determines the maximum amount of oxygen that water can hold when in equilibrium with moist air at one atmosphere. It uses the Benson-Krause equation, which depends on the absolute temperature and salinity of the water. For the given conditions, the resulting saturation level is 0.00909243 kg/m^3, which corresponds to 9.09243. This value represents the upper limit for dissolved oxygen availability in this specific aquatic environment.

First-order decay of a pollutant downstream (plug flow), `enveng_river_first_order_decay`

The concentration of a decaying pollutant (BOD, coliforms, a chemical) a distance downstream in a river in plug flow, and the travel time.

$$C = C_0\, e^{-kx/u}$$

symbol		meaning	SI unit
`C0`	in	concentration at the start (after mixing)	kg/m^3
`k`	in	first-order decay constant	1/s
`x`	in	distance downstream	m
`u`	in	mean velocity	m/s
`C`	out	concentration at x	kg/m^3
`C_mgL`	out	in mg/L	,
`t`	out	travel time x/u	s
`fraction_remaining`	out	C/C0	,

Applies when: plug flow; first-order decay.

```
$ environmental-engineering solve enveng_river_first_order_decay "C0=20 mg/L" "k=0.3 1/day" "x=40
km" "u=0.25 m/s"
C = 0.01147506841 kg/m^3
C_mgL = 11.47506841
t = 160000 s
fraction_remaining = 0.5737534207
  by: First-order decay of a pollutant downstream (plug flow)  (C = C0 e^(-k x/u))
  C0 = 0.02 kg/m^3
  k = 3.472222222e-06 1/s
  x = 40000 m
  u = 0.25 m/s
  assumes: plug flow; first-order decay
```

What the worked example means: This calculation determines the pollutant concentration at a specific distance downstream using first-order decay kinetics under plug flow conditions. Starting from an initial mixed concentration of 20 mg/L, the substance decays as it travels 40 km meters at a mean velocity of 0.25 m/s. The resulting concentration is 0.0114751 kg/m^3, equivalent to 11.4751 in milligrams per liter. The fraction of the original pollutant remaining after this journey is 0.573753, and the time required to cover the distance is 160000 s. This model helps estimate how much of a biodegradable or chemically reactive pollutant persists in a river segment.

Flow-weighted mixing of several streams, `enveng_mixing_several_streams`

The flow-weighted concentration (or temperature) of several streams combined, and the total flow; flows in any one unit, concentrations in any one unit.

$$C = \frac{\sum_i Q_i C_i}{\sum_i Q_i}$$

symbol		meaning	SI unit
`Q`	in	flows of the streams (any one unit, e.g. m^3/s)	,
`C`	in	concentrations of the streams (any one unit, e.g. mg/L)	,
`C_mix`	out	mixed concentration, in the unit of C	,
`Q_total`	out	total flow, in the unit of Q	,

Applies when: complete mixing; conservative substance.

```
$ environmental-engineering solve enveng_mixing_several_streams "Q=[2, 0.5, 1]" "C=[3, 120, 40]"
C_mix = 30.28571429
Q_total = 3.5
  by: Flow-weighted mixing of several streams  (C = sum(Q_i C_i)/sum(Q_i))
  assumes: complete mixing; conservative substance
```

What the worked example means: This calculation determines the final concentration of a mixture by weighting each input stream's concentration by its respective flow rate. The numerator sums the product of every individual flow and concentration, while the denominator sums all flows to find the total volume moving through the system. The result, 30.2857, represents the uniform concentration achieved when these streams combine completely, assuming no chemical reactions or losses occur during the mixing process.

Pollutant mass load of a flow, `enveng_pollutant_load`

The mass load (rate) carried by a flow at a concentration, in kg/s, kg per day and tonnes per year.

$$W = Q\,C$$

symbol		meaning	SI unit
`Q`	in	flow rate	m^3/s
`C`	in	concentration	kg/m^3
`W`	out	mass load	kg/s
`W_kg_per_day`	out	load in kg per day	,
`W_t_per_year`	out	load in tonnes per (365.25-day) year	,

Applies when: Q > 0.

```
$ environmental-engineering solve enveng_pollutant_load "Q=0.5 m^3/s" "C=30 mg/L"
W = 0.015 kg/s
W_kg_per_day = 1296
W_t_per_year = 473.364
  by: Pollutant mass load of a flow  (W = Q C)
  Q = 0.5 m^3/s
  C = 0.03 kg/m^3
  assumes: Q > 0
```

What the worked example means: This calculation determines the pollutant mass load carried by a flow. By multiplying the flow rate 0.5 m^3/s by the concentration 30 mg/L, this gives the instantaneous load of 0.015 kg/s. This result is then converted into daily units of 1296 and annual units of 473.364 to provide practical measures for environmental management and reporting.

Steady-state concentration in a well-mixed lake (first-order decay), `enveng_lake_steady_state`

The steady concentration of a pollutant in a lake treated as a completely mixed reactor with inflow load, outflow and first-order decay, and the hydraulic residence time.

$$C = \frac{W}{Q + kV}$$

symbol		meaning	SI unit
`W`	in	total pollutant input (load)	kg/s
`Q`	in	outflow rate	m^3/s
`k`	in	first-order decay constant (0 if conservative)	1/s
`V`	in	lake volume	m^3
`C`	out	steady-state concentration	kg/m^3
`C_mgL`	out	in mg/L	,
`tau`	out	hydraulic residence time V/Q	s

Applies when: completely mixed; steady state.

```
$ environmental-engineering solve enveng_lake_steady_state "W=100 kg/day" "Q=10 m^3/s" "k=0.2
1/day" "V=10000000 m^3"
C = 3.491620112e-05 kg/m^3
C_mgL = 0.03491620112
tau = 1000000 s
  by: Steady-state concentration in a well-mixed lake (first-order decay)  (0 = W - Q C - k C V, C
= W/(Q + k V))
  W = 0.001157407407 kg/s
  Q = 10 m^3/s
  k = 2.314814815e-06 1/s
  V = 10000000 m^3
  assumes: completely mixed; steady state
```

What the worked example means: This calculation determines the equilibrium pollutant level in a lake modeled as a completely mixed reactor. By balancing the input load 100 kg/day against losses via outflow 10 m^3/s and first-order decay 0.2 1/day within volume 1e+07 m^3, the model computes the steady-state concentration 3.49162e-05 kg/m^3. The result, also expressed as 0.0349162, represents the long-term average quality of the water body under these conditions. Additionally, the hydraulic residence time 1e+06 s is calculated to indicate how long water remains in the system on average.

Stream reaeration coefficient (O'Connor-Dobbins, Churchill, Owens-Gibbs), `enveng_reaeration_coefficient`

The reaeration rate constant of a stream at 20 degC from its mean velocity and depth by a chosen empirical formula.

$$k_a = \frac{3.93\,u^{0.5}}{H^{1.5}} \ \text{(O'Connor-Dobbins)}$$

symbol		meaning	SI unit
`method`	in	o_connor_dobbins, churchill or owens_gibbs	,
`u`	in	mean stream velocity	m/s
`H`	in	mean depth	m
`ka`	out	reaeration rate constant at 20 degC	1/s
`ka_per_day`	out	in 1/d	,

Applies when: u in m/s and H in m inside the formula constants.

```
$ environmental-engineering solve enveng_reaeration_coefficient method=o_connor_dobbins "u=0.3 m/s"
"H=2 m"
ka = 8.808347541e-06 1/s
ka_per_day = 0.7610412275
  by: Stream reaeration coefficient (O'Connor-Dobbins, Churchill, Owens-Gibbs)  (ka = 3.93
u^0.5/H^1.5 (O'Connor-Dobbins), 5.026 u/H^1.67 (Churchill), 5.32 u^0.67/H^1.85 (Owens-Gibbs), per
day)
  u = 0.3 m/s
  H = 2 m
  method = o_connor_dobbins
  assumes: u in m/s and H in m inside the formula constants
```

What the worked example means: This calculation determines the stream reaeration coefficient at twenty degrees Celsius using the selected empirical method. It uses the mean stream velocity of 0.3 m/s and the mean depth of 2 m. The resulting rate constant is 8.80835e-06 1/s, which represents how quickly oxygen transfers from the atmosphere into the water column. This value is also expressed as 0.761041 in daily units for standard modeling applications.

Streeter-Phelps oxygen deficit and dissolved oxygen at a travel time, `enveng_streeter_phelps_deficit`

The dissolved-oxygen deficit and the dissolved oxygen of a river at a travel time downstream of a BOD discharge (Streeter-Phelps oxygen sag).

$$D = \frac{k_d L_0}{k_a - k_d}\left(e^{-k_d t} - e^{-k_a t}\right) + D_0 e^{-k_a t}$$

symbol		meaning	SI unit
`kd`	in	deoxygenation rate constant	1/s
`ka`	in	reaeration rate constant	1/s
`L0`	in	ultimate BOD of the mixed river water at the outfall	kg/m^3
`D0`	in	oxygen deficit at the outfall (DOsat - DO)	kg/m^3
`t`	in	travel time from the outfall	s
`DOsat`	in	saturation dissolved oxygen	kg/m^3
`D`	out	oxygen deficit at t	kg/m^3
`DO`	out	dissolved oxygen at t	kg/m^3
`D_mgL`	out	deficit in mg/L	,
`DO_mgL`	out	dissolved oxygen in mg/L	,

Applies when: first-order deoxygenation and reaeration; plug flow; deficit stays below saturation.

```
$ environmental-engineering solve enveng_streeter_phelps_deficit "kd=0.23 1/day" "ka=0.46 1/day"
"L0=10 mg/L" "D0=1 mg/L" "t=2 day" "DOsat=9.1 mg/L"
D = 0.002726165085 kg/m^3
DO = 0.006373834915 kg/m^3
D_mgL = 2.726165085
DO_mgL = 6.373834915
  by: Streeter-Phelps oxygen deficit and dissolved oxygen at a travel time  (D = kd L0/(ka - kd)
(e^(-kd t) - e^(-ka t)) + D0 e^(-ka t); for ka = kd, D = (kd L0 t + D0) e^(-kd t))
  kd = 2.662037037e-06 1/s
  ka = 5.324074074e-06 1/s
  L0 = 0.01 kg/m^3
  D0 = 0.001 kg/m^3
  t = 172800 s
  DOsat = 0.0091 kg/m^3
  assumes: first-order deoxygenation and reaeration; plug flow; deficit stays below saturation
```

What the worked example means: This calculation determines the oxygen deficit and dissolved oxygen levels in a river at a specific travel time downstream of a discharge. Using the Streeter-Phelps model, which balances deoxygenation from biochemical demand against reaeration from the atmosphere, the system computes that the deficit reaches 0.00272617 kg/m^3 while the actual dissolved oxygen stands at 0.00637383 kg/m^3. These values indicate how much oxygen has been consumed relative to saturation and what remains available for aquatic life.

Temperature correction of a rate constant (theta model), `enveng_rate_constant_temperature`

A first-order rate constant (BOD, reaeration, decay) at temperature T from its 20 degC value and the temperature coefficient theta.

$$k_T = k_{20}\,\theta^{\,T-20}$$

symbol		meaning	SI unit
`k20`	in	rate constant at 20 degC	1/s
`theta`	in	temperature coefficient (1.047 BOD, 1.024 reaeration)	,
`T`	in	water temperature	K
`kT`	out	rate constant at T	1/s
`kT_per_day`	out	rate constant in 1/d	,

Applies when: 0.9 < theta < 1.2; -5 degC <= T <= 60 degC.

```
$ environmental-engineering solve enveng_rate_constant_temperature "k20=0.23 1/day" theta=1.047
"T=25 degC"
kT = 3.349249506e-06 1/s
kT_per_day = 0.2893751573
  by: Temperature correction of a rate constant (theta model)  (kT = k20 theta^(T - 20))
  k20 = 2.662037037e-06 1/s
  theta = 1.047
  T = 298.15 K
  assumes: 0.9 < theta < 1.2; -5 degC <= T <= 60 degC
```

What the worked example means: This calculation adjusts a first-order rate constant from its standard reference value at twenty degrees Celsius to the actual water temperature using the theta model. By applying the temperature coefficient theta, the method accounts for how biological and chemical reaction speeds change with thermal conditions. The result shows that at the current temperature, the effective rate constant is 3.34925e-06 1/s per second, equivalent to 0.289375 per day, allowing for accurate modeling of processes like biochemical oxygen demand decay or reaeration.

Theoretical oxygen demand of an organic compound, `enveng_theoretical_oxygen_demand`

The theoretical oxygen demand (g O2 per g compound) of a compound CaHbOcNd oxidised to CO2 and water, with its nitrogen released as ammonia or, with nitrification, oxidised to nitrate.

$$\mathrm{ThOD} = \frac{\left(a + \frac{b}{4} - \frac{c}{2} - \frac{3d}{4}\right) M_{O_2}}{M}$$

symbol		meaning	SI unit
`formula`	in	molecular formula with C, H, O, N only (e.g. C6H12O6)	,
`nitrification`	in	include the oxygen to nitrify ammonia (yes) or not (no)	,
`thod`	out	theoretical oxygen demand, g O2 per g compound	,
`o2_per_mol`	out	mol O2 per mol compound	,
`molar_mass`	out	molar mass, g/mol	,

Applies when: elements C, H, O, N only; b >= 3d.

```
$ environmental-engineering solve enveng_theoretical_oxygen_demand formula=C6H12O6 nitrification=no
thod = 1.065703767
o2_per_mol = 6
molar_mass = 180.15588
  by: Theoretical oxygen demand of an organic compound  (CaHbOcNd + (a + b/4 - c/2 - 3d/4) O2 -> a
CO2 + (b - 3d)/2 H2O + d NH3; nitrification adds 2d O2)
  formula = C6H12O6
  nitrification = no
  assumes: elements C, H, O, N only; b >= 3d
```

What the worked example means: This calculation determines the theoretical oxygen demand, expressed as grams of oxygen per gram of compound, for the molecular formula C6H12O6. The process assumes complete oxidation of carbon to carbon dioxide and hydrogen to water, with nitrogen released as ammonia unless nitrification is enabled. The result, 1.0657, indicates the maximum oxygen required if all organic matter were biologically or chemically oxidized under these specific conditions, based on a molar mass of 180.156 and an oxygen consumption of 6 moles per mole of compound.

Ultimate BOD from a BOD test, `enveng_ultimate_bod`

The ultimate carbonaceous BOD from a BOD measured after t days (e.g. BOD5) and the rate constant.

$$L_0 = \frac{BOD_t}{1 - e^{-kt}}$$

symbol		meaning	SI unit
`BOD_t`	in	BOD measured after time t (e.g. BOD5)	kg/m^3
`k`	in	BOD rate constant (base e)	1/s
`t`	in	incubation time	s
`L0`	out	ultimate BOD	kg/m^3
`L0_mgL`	out	ultimate BOD in mg/L	,

Applies when: first-order kinetics.

```
$ environmental-engineering solve enveng_ultimate_bod "BOD_t=200 mg/L" "k=0.23 1/day" "t=5 day"
L0 = 0.2926701219 kg/m^3
L0_mgL = 292.6701219
  by: Ultimate BOD from a BOD test  (L0 = BOD_t/(1 - e^(-k t)))
  BOD_t = 0.2 kg/m^3
  k = 2.662037037e-06 1/s
  t = 432000 s
  assumes: first-order kinetics
```

In the worked example, BOD_t = 200 mg/L, k = 0.23 1/day, t = 5 day go through the equation above and give L0 = 0.2926701219 kg/m^3, L0_mgL = 292.6701219. It applies only when first-order kinetics: outside that it says what is wrong instead of returning a number.

Water treatment (26)

Activated carbon dose from the Freundlich isotherm, `enveng_freundlich_carbon_dose`

The equilibrium adsorbent loading from the Freundlich isotherm q = K Ce^(1/n) (q in mg/g, Ce in mg/L) and the batch carbon dose that lowers C0 to Ce.

$$q_e = K C_e^{1/n}, \quad \frac{m}{V} = \frac{C_0 - C_e}{q_e}$$

symbol		meaning	SI unit
`C0`	in	initial concentration	kg/m^3
`Ce`	in	target equilibrium concentration	kg/m^3
`K`	in	Freundlich capacity factor, (mg/g)(L/mg)^(1/n)	,
`n`	in	Freundlich exponent n (isotherm exponent 1/n)	,
`qe`	out	equilibrium loading, mg/g	,
`dose`	out	adsorbent dose	kg/m^3
`dose_mgL`	out	dose in mg/L	,

Applies when: Ce < C0; batch equilibrium.

```
$ environmental-engineering solve enveng_freundlich_carbon_dose "C0=10 mg/L" "Ce=1 mg/L" K=50 n=2
qe = 50
dose = 0.18 kg/m^3
dose_mgL = 180
  by: Activated carbon dose from the Freundlich isotherm  (qe = K Ce^(1/n); dose = (C0 - Ce)/qe)
  C0 = 0.01 kg/m^3
  Ce = 0.001 kg/m^3
  K = 50
  n = 2
  assumes: Ce < C0; batch equilibrium
```

What the worked example means: This calculation determines the amount of activated carbon needed to reduce a contaminant concentration from an initial value of 10 mg/L to a target equilibrium value of 1 mg/L. First, the Freundlich isotherm equation uses the capacity factor 50 and exponent 2 to find the equilibrium loading 50, which represents how much contaminant each gram of carbon can hold. Then, the mass balance equation divides the difference between the initial and final concentrations by this loading to yield the necessary dose 0.18 kg/m^3. This result indicates the practical quantity of adsorbent required for batch treatment under these specific conditions.

Adsorbent dose from the Langmuir isotherm, `enveng_langmuir_carbon_dose`

The equilibrium loading from the Langmuir isotherm q = qmax b Ce/(1 + b Ce) (q in mg/g, Ce in mg/L) and the batch adsorbent dose that lowers C0 to Ce.

$$q_e = \frac{q_{max} b C_e}{1 + b C_e}, \qquad \frac{m}{V} = \frac{C_0 - C_e}{q_e}$$

symbol		meaning	SI unit
`C0`	in	initial concentration	kg/m^3
`Ce`	in	target equilibrium concentration	kg/m^3
`qmax`	in	Langmuir monolayer capacity, mg/g	,
`b`	in	Langmuir constant, L/mg	,
`qe`	out	equilibrium loading, mg/g	,
`dose`	out	adsorbent dose	kg/m^3
`dose_mgL`	out	dose in mg/L	,

Applies when: Ce < C0.

```
$ environmental-engineering solve enveng_langmuir_carbon_dose "C0=10 mg/L" "Ce=1 mg/L" qmax=150
b=0.8
qe = 66.66666667
dose = 0.135 kg/m^3
dose_mgL = 135
  by: Adsorbent dose from the Langmuir isotherm  (qe = qmax b Ce/(1 + b Ce); dose = (C0 - Ce)/qe)
  C0 = 0.01 kg/m^3
  Ce = 0.001 kg/m^3
  qmax = 150
  b = 0.8
  assumes: Ce < C0
```

What the worked example means: This calculation determines the mass of adsorbent per unit volume of solution required to reduce the initial concentration from 10 mg/L to the target equilibrium concentration of 1 mg/L. It first computes the amount of contaminant held per gram of adsorbent at equilibrium, which is 66.6667, using the Langmuir isotherm parameters for monolayer capacity 150 and affinity constant 0.8. The resulting dose is 0.135 kg/m^3, or equivalently 135, indicating how much solid material must be added to achieve the desired water quality.

Chlorine dose and feed rate, `enveng_chlorine_dose_feed`

The chlorine dose (demand plus residual), the chlorine feed rate for a flow and the feed of a product with a stated available-chlorine fraction (e.g. 65 % calcium hypochlorite).

$$\dot{m} = Q\,(\text{demand} + \text{residual}), \quad \dot{m}_{product} = \frac{\dot{m}}{p}$$

symbol		meaning	SI unit
`Q`	in	flow treated	m^3/s
`demand`	in	chlorine demand	kg/m^3
`residual`	in	required free chlorine residual	kg/m^3
`purity`	in	available chlorine fraction of the product (1 for chlorine gas; fraction or %)	,
`dose`	out	chlorine dose	kg/m^3
`dose_mgL`	out	dose in mg/L	,
`feed`	out	chlorine feed rate	kg/s
`feed_kg_per_day`	out	chlorine feed in kg/d	,
`product_kg_per_day`	out	product feed in kg/d	,

Applies when: 0 < purity <= 1.

```
$ environmental-engineering solve enveng_chlorine_dose_feed "Q=20000 m^3/day" "demand=2.5 mg/L"
"residual=0.5 mg/L" purity=1
dose = 0.003 kg/m^3
dose_mgL = 3
feed = 0.0006944444444 kg/s
feed_kg_per_day = 60
product_kg_per_day = 60
  by: Chlorine dose and feed rate  (dose = demand + residual; feed = Q dose; product = feed/purity)
  Q = 0.2314814815 m^3/s
  demand = 0.0025 kg/m^3
  residual = 0.0005 kg/m^3
  purity = 1
  assumes: 0 < purity <= 1
```

What the worked example means: This calculation determines the total chlorine dose by adding the chlorine demand to the required free chlorine residual. The computed dose of 0.003 kg/m^3 is then multiplied by the flow treated to find the pure chlorine feed rate, which equals 0.000694444 kg/s. Finally, the feed rate for the specific chemical product is derived by dividing the pure chlorine feed by the available chlorine fraction of the product, yielding 60. This ensures the correct amount of commercial-grade chlorine is dosed to achieve the desired residual.

Clean-bed head loss through a granular filter (Ergun / Carman-Kozeny), `enveng_filter_clean_bed_headloss`

The head loss through a clean granular filter bed from the grain size, sphericity, porosity, depth and filtration rate (Ergun equation, the Carman-Kozeny form with friction factor 150/Re + 1.75).

$$\frac{h}{L} = \frac{150\mu(1-\varepsilon)^2 v}{\rho g \varepsilon^3 (\psi d)^2} + \frac{1.75(1-\varepsilon)v^2}{g\varepsilon^3 \psi d}$$

symbol		meaning	SI unit
`d`	in	grain diameter	m
`eps`	in	bed porosity (fraction)	,
`psi`	in	grain sphericity (fraction, 1 for spheres)	,
`L`	in	bed depth	m
`v`	in	filtration (approach) velocity	m/s
`rho`	in	water density	kg/m^3
`mu`	in	water viscosity	Pa*s
`dP`	out	pressure drop	Pa
`h`	out	head loss	m
`Re`	out	bed Reynolds number rho v psi d/(mu (1 - eps))	,

Applies when: 0 < eps < 1; 0 < psi <= 1; clean bed.

```
$ environmental-engineering solve enveng_filter_clean_bed_headloss "d=0.5 mm" eps=0.4 psi=0.85
"L=0.7 m" "v=8 m/h" "rho=998.2 kg/m^3" "mu=0.001002 Pa*s"
dP = 7414.170928 Pa
h = 0.7573983471 m
Re = 1.568104532
  by: Clean-bed head loss through a granular filter (Ergun / Carman-Kozeny)  (dP/L = 150 mu (1-
eps)^2 v/(eps^3 (psi d)^2) + 1.75 rho (1-eps) v^2/(eps^3 psi d); h = dP/(rho g))
  d = 0.0005 m
  eps = 0.4
  psi = 0.85
  L = 0.7 m
  v = 0.002222222222 m/s
  rho = 998.2 kg/m^3
  mu = 0.001002 Pa*s
  assumes: 0 < eps < 1; 0 < psi <= 1; clean bed
```

What the worked example means: This calculation determines the head loss through a clean granular filter bed using the Ergun equation, which combines viscous and inertial resistance terms. The result depends on the grain diameter 0.5 mm, sphericity 0.85, porosity 0.4, filtration velocity 8 m/h, and water properties density 998.2 kg/m^3 and viscosity 0.001002 Pa*s. For the given inputs, the total head loss is 0.757398 m meters, corresponding to a pressure drop of 7414.17 Pa Pascals over the bed depth of 0.7 m meters. This value represents the energy required to push water through the empty pore spaces of the filter media before any solids are captured.

Disinfection by the Chick-Watson law, `enveng_chick_watson`

The survival fraction and log inactivation of organisms exposed to a disinfectant concentration C for time t under ln(N/N0) = -k C^n t (k in (L/mg)^n per minute, C in mg/L, t in minutes inside the law).

$$\ln \frac{N}{N_0} = -k C^n t$$

symbol		meaning	SI unit
`k`	in	Chick-Watson coefficient in (L/mg)^n per minute	,
`n`	in	coefficient of dilution (1 for most disinfectants)	,
`C`	in	disinfectant concentration	kg/m^3
`t`	in	contact time	s
`survival`	out	N/N0	,
`log_inactivation`	out	log10 inactivation	,

Applies when: constant concentration; 0.3 <= n <= 3.

```
$ environmental-engineering solve enveng_chick_watson k=0.1 n=1 "C=1 mg/L" "t=30 min"
survival = 0.04978706837
log_inactivation = 1.302883446
  by: Disinfection by the Chick-Watson law  (ln(N/N0) = -k C^n t with C in mg/L and t in minutes)
  k = 0.1
  n = 1
  C = 0.001 kg/m^3
  t = 1800 s
  assumes: constant concentration; 0.3 <= n <= 3
```

What the worked example means: This calculation determines the effectiveness of a disinfectant using the Chick-Watson law. Given a coefficient of dilution 1, a rate constant 0.1, a concentration 1 mg/L, and a contact time 30 min, the model computes the resulting survival fraction 0.0497871 and the corresponding log inactivation 1.30288. These values indicate how many organisms remain alive relative to the initial population after exposure.

Disinfection CT value of a contact basin, `enveng_disinfection_ct`

The effective contact time t10 of a basin (baffling factor times the theoretical detention time) and the CT value of a disinfectant residual.

$$CT = C\,t_{10} = C\,BF\,\frac{V}{Q}$$

symbol		meaning	SI unit
`C`	in	disinfectant residual at the outlet	kg/m^3
`V`	in	basin volume	m^3
`Q`	in	peak flow	m^3/s
`BF`	in	baffling factor t10/T (0.1 unbaffled to 1 plug flow)	,
`t10`	out	effective contact time	s

symbol		meaning	SI unit
`CT`	out	CT value	kg*s/m^3
`CT_mg_min_L`	out	CT in mg min/L	,

Applies when: 0 < BF <= 1.

```
$ environmental-engineering solve enveng_disinfection_ct "C=1 mg/L" "V=1000 m^3" "Q=20000 m^3/day"
BF=0.5
t10 = 2160 s
CT = 2.16 kg*s/m^3
CT_mg_min_L = 36
  by: Disinfection CT value of a contact basin  (t10 = BF V/Q; CT = C t10)
  C = 0.001 kg/m^3
  V = 1000 m^3
  Q = 0.2314814815 m^3/s
  BF = 0.5
  assumes: 0 < BF <= 1
```

What the worked example means: This calculation determines the disinfection efficacy potential of a contact basin by first finding the effective contact time, t10. This is done by multiplying the baffling factor, 0.5, which accounts for flow short-circuiting, by the theoretical detention time derived from the basin volume, 1000 m^3, divided by the peak flow rate, 20000 m^3/day. The result, 2160 s, represents the actual time water spends in contact with the disinfectant. The CT value, 2.16 kg*s/m^3, is then computed by multiplying this effective contact time by the residual disinfectant concentration at the outlet, 1 mg/L. A higher CT value indicates greater disinfection power.

Filter bed expansion during backwash, `enveng_backwash_bed_expansion`

The expanded porosity, expanded depth and percentage expansion of a filter bed fluidised by backwash, from the backwash rate and the grains' settling velocity (expanded porosity (vb/vs)^0.22).

$$\varepsilon_e = \left(\frac{v_b}{v_s}\right)^{0.22}, \quad L_e = \frac{L(1-\varepsilon)}{1-\varepsilon_e}$$

symbol		meaning	SI unit
`L`	in	unexpanded bed depth	m
`eps`	in	unexpanded porosity (fraction)	,
`vb`	in	backwash rate	m/s
`vs`	in	settling velocity of the grains	m/s
`eps_e`	out	expanded porosity	,
`Le`	out	expanded bed depth	m
`expansion`	out	fractional expansion Le/L - 1	,

Applies when: the bed is fluidised: eps < (vb/vs)^0.22 < 1.

```
$ environmental-engineering solve enveng_backwash_bed_expansion "L=0.7 m" eps=0.42 "vb=50 m/h"
"vs=300 m/h"
eps_e = 0.6742279077
Le = 1.246270045 m
expansion = 0.780385778
  by: Filter bed expansion during backwash  (eps_e = (vb/vs)^0.22; Le = L (1 - eps)/(1 - eps_e))
  L = 0.7 m
  eps = 0.42
  vb = 0.01388888889 m/s
  vs = 0.08333333333 m/s
  assumes: the bed is fluidised: eps < (vb/vs)^0.22 < 1
```

What the worked example means: This calculation determines the state of a filter bed during backwashing. Using the unexpanded bed depth of 0.7 m and porosity of 0.42, along with a backwash rate of 50 m/h and grain settling velocity of 300 m/h, it computes the expanded porosity as 0.674228 and the new bed depth as 1.24627 m. The resulting fractional expansion is 0.780386, indicating how much the bed has lifted and loosened to facilitate cleaning.

Filtration (hydraulic loading) rate with one filter out of service, `enveng_filtration_rate`

The filtration rate of a bank of identical filters, with all in service and with one out of service (for backwashing).

$$v = \frac{Q}{NA}, \quad v' = \frac{Q}{(N-1)A}$$

symbol		meaning	SI unit
`Q`	in	plant flow	m^3/s
`A`	in	area of one filter	m^2
`N`	in	number of filters	,
`v`	out	filtration rate with all filters	m/s
`v_m_per_h`	out	in m/h	,
`v_one_out`	out	rate with one filter out of service	m/s
`v_one_out_m_per_h`	out	in m/h	,

Applies when: N >= 2 identical filters.

```
$ environmental-engineering solve enveng_filtration_rate "Q=40000 m^3/day" "A=50 m^2" N=6
v = 0.001543209877 m/s
v_m_per_h = 5.555555556
v_one_out = 0.001851851852 m/s
v_one_out_m_per_h = 6.666666667
  by: Filtration (hydraulic loading) rate with one filter out of service  (v = Q/(N A); v' = Q/((N
- 1) A))
  Q = 0.462962963 m^3/s
  A = 50 m^2
  assumes: N >= 2 identical filters
```

What the worked example means: This calculation determines the hydraulic loading rate for a bank of identical filters. Using the total plant flow 40000 m^3/day and the area of each individual filter 50 m^2, this

gives the rate when all 6 units are operating, resulting in 0.00154321 m/s. The rate is then recalculated with one unit offline for backwashing, which increases the load on the remaining active filters to 0.00185185 m/s. These values indicate how much water passes through each square meter of filter media per second.

Fraction of discrete particles removed in an ideal settling basin, `enveng_ideal_basin_removal`

The overflow rate of an ideal (Camp) settling basin and the fraction of particles of one settling velocity it removes (all if vs >= v0, otherwise vs/v0).

$$R = \min\left(1, \frac{v_s}{v_0}\right)$$

symbol		meaning	SI unit
`vs`	in	settling velocity of the particles	m/s
`Q`	in	flow	m^3/s
`A`	in	basin surface area	m^2
`v0`	out	overflow rate Q/A	m/s
`R`	out	fraction removed	,

Applies when: ideal basin, discrete (type I) settling.

```
$ environmental-engineering solve enveng_ideal_basin_removal "vs=0.5 m/h" "Q=10000 m^3/day" "A=400
m^2"
v0 = 0.0002893518519 m/s
R = 0.48
  by: Fraction of discrete particles removed in an ideal settling basin  (v0 = Q/A; R = min(1,
vs/v0))
  vs = 0.0001388888889 m/s
  Q = 0.1157407407 m^3/s
  A = 400 m^2
  assumes: ideal basin, discrete (type I) settling
```

What the worked example means: This calculation determines the removal efficiency for discrete particles in an ideal sedimentation tank. First, the overflow rate is computed by dividing the flow rate 10000 m^3/day by the surface area 400 m^2, resulting in 0.000289352 m/s. Then, the fraction removed 0.48 is found by comparing this overflow rate to the particle settling velocity 0.5 m/h. If the settling velocity exceeds the overflow rate, all particles are captured; otherwise, only a portion equal to their relative speeds is removed.

Fraction of free chlorine as hypochlorous acid (pH), `enveng_hypochlorous_acid_fraction`

The fractions of free chlorine present as HOCl and as OCl- at a pH, from the acid dissociation constant (given, or from the temperature by Morris' correlation).

$$\alpha_{HOCl} = \frac{1}{1 + 10^{\,pH - pK_a}}$$

symbol		meaning	SI unit
`pH`	in	pH of the water	,

symbol		meaning	SI unit
`pKa`	in	pKa of HOCl (7.54 at 25 degC) (optional)	,
`T`	in	water temperature (to compute pKa instead) (optional)	K
`alpha_HOCl`	out	fraction as HOCl	,
`alpha_OCl`	out	fraction as OCl-	,
`pKa`	out	pKa used	,

Applies when: either pKa or T; 0-35 degC for the correlation.

```
$ environmental-engineering solve enveng_hypochlorous_acid_fraction pH=7 pKa=7.54
alpha_HOCl = 0.7761545753
alpha_OCl = 0.2238454247
pKa = 7.54
  by: Fraction of free chlorine as hypochlorous acid (pH)  (alpha_HOCl = 1/(1 + 10^(pH - pKa)); pKa
= 3000/T - 10.0686 + 0.0253 T (Morris))
  pH = 7
  pKa = 7.54
  assumes: either pKa or T; 0-35 degC for the correlation
```

What the worked example means: This calculation determines how free chlorine distributes between its two forms in water. Using the provided pH and temperature or pKa values, it computes that 0.776155 of the total free chlorine exists as hypochlorous acid, while 0.223845 exists as hypochlorite ion. The effective acidity constant used for this split was 7.54. Hypochlorous acid is generally the more potent disinfectant, so knowing this fraction helps assess treatment efficiency under current conditions.

Freundlich isotherm constants fitted to adsorption data, `enveng_freundlich_fit`

The Freundlich constants K and 1/n fitted by linear regression of log q against log Ce, with the coefficient of determination.

$$\log q_e = \log K + \frac{1}{n} \log C_e$$

symbol		meaning	SI unit
`Ce`	in	equilibrium concentrations in mg/L	,
`qe`	in	equilibrium loadings in mg/g (same order)	,
`K`	out	Freundlich K, (mg/g)(L/mg)^(1/n)	,
`inv_n`	out	isotherm exponent 1/n	,
`n`	out	Freundlich n	,
`r2`	out	coefficient of determination of the log-log fit	,

Applies when: at least three positive points.

```
$ environmental-engineering solve enveng_freundlich_fit "Ce=[0.5, 1, 2, 5, 10]" "qe=[28, 40, 55,
86, 120]"
K = 39.47623429
inv_n = 0.483576413
n = 2.067925509
r2 = 0.9998093398
  by: Freundlich isotherm constants fitted to adsorption data  (least squares of log10 q = log10 K
+ (1/n) log10 Ce)
  assumes: at least three positive points
```

What the worked example means: This calculation determines the parameters for the Freundlich adsorption isotherm by performing a linear least-squares regression on the logarithmic form of the equation. The input data consists of equilibrium concentrations Ce and corresponding loadings qe. The resulting intercept yields the capacity factor K, which is 39.4762, while the slope provides the intensity factor 1/n, calculated as 0.483576. The goodness of fit for this log-log relationship is indicated by the coefficient of determination, r2, which equals 0.999809. These constants allow prediction of how much contaminant will adhere to the solid phase at various liquid concentrations.

Hydraulic detention time, `enveng_detention_time`

The hydraulic detention (residence) time of a tank or basin from its volume and the flow.

$$\theta = \frac{V}{Q}$$

symbol		meaning	SI unit
`V`	in	tank volume	m^3
`Q`	in	flow rate	m^3/s
`theta`	out	detention time V/Q	s
`theta_h`	out	detention time in hours	,

Applies when: V, Q > 0.

```
$ environmental-engineering solve enveng_detention_time "V=1000 m^3" "Q=12000 m^3/day"
theta = 7200 s
theta_h = 2
  by: Hydraulic detention time  (theta = V/Q)
  V = 1000 m^3
  Q = 0.1388888889 m^3/s
  assumes: V, Q > 0
```

What the worked example means: This calculation determines the average time water remains in a tank or basin. It uses the total volume of the container, given as 1000 m^3, and the flow rate entering the system, given as 12000 m^3/day. The result, 7200 s, represents how long a parcel of water stays inside before exiting. This metric helps engineers understand contact time for treatment processes like sedimentation or disinfection.

Langmuir isotherm constants fitted to adsorption data, `enveng_langmuir_fit`

The Langmuir capacity qmax and constant b fitted by linear regression of Ce/q against Ce (linearised Langmuir form), with the coefficient of determination.

$$\frac{C_e}{q_e} = \frac{1}{q_{max} b} + \frac{C_e}{q_{max}}$$

symbol		meaning	SI unit
`Ce`	in	equilibrium concentrations in mg/L	,
`qe`	in	equilibrium loadings in mg/g (same order)	,
`qmax`	out	monolayer capacity, mg/g	,
`b`	out	Langmuir constant, L/mg	,
`r2`	out	coefficient of determination of the linearised fit	,

Applies when: positive slope and intercept of Ce/q against Ce.

```
$ environmental-engineering solve enveng_langmuir_fit "Ce=[0.5, 1, 2, 5, 10]" "qe=[40, 66, 97, 133,
152]"
qmax = 177.9004838
b = 0.5896757373
r2 = 0.9999728233
  by: Langmuir isotherm constants fitted to adsorption data  (least squares of Ce/q = 1/(qmax b) +
Ce/qmax)
  assumes: positive slope and intercept of Ce/q against Ce
```

What the worked example means: This calculation determines the Langmuir adsorption parameters by performing linear regression on the transformed data. The equilibrium concentration divided by the equilibrium loading is plotted against the equilibrium concentration. From this linear relationship, the slope yields the reciprocal of the maximum capacity, while the intercept provides the ratio of one to the product of the maximum capacity and the affinity constant. The resulting monolayer capacity of 177.9 represents the theoretical limit of adsorbate uptake per mass of adsorbent when all surface sites are occupied. The Langmuir constant of 0.589676 indicates the affinity between the adsorbate and the adsorbent surface. The coefficient of determination of 0.999973 quantifies how well the linearized model fits the experimental observations.

Log inactivation from the CT ratio, `enveng_ct_log_inactivation`

The CT achieved, the ratio to the CT required for 3-log (99.9 %) inactivation from the regulatory tables, and the log inactivation credited (3 times the ratio).

$$\text{log inactivation} = 3\,\frac{Ct_{10}}{CT_{99.9}}$$

symbol		meaning	SI unit
`C`	in	disinfectant residual	kg/m^3
`t10`	in	effective contact time	s
`CT999`	in	CT required for 3-log inactivation (from the tables)	kg*s/m^3
`CT`	out	CT achieved	kg*s/m^3
`ratio`	out	CT achieved / CT for 3-log	,

symbol		meaning	SI unit
`log_inactivation`	out	log inactivation credited	,

Applies when: first-order (Chick-Watson) inactivation with n = 1.

```
$ environmental-engineering solve enveng_ct_log_inactivation "C=1.2 mg/L" "t10=40 min" "CT999=104
mg*min/L"
CT = 2.88 kg*s/m^3
ratio = 0.4615384615
log_inactivation = 1.384615385
  by: Log inactivation from the CT ratio  (log inactivation = 3 CT/CT_99.9)
  C = 0.0012 kg/m^3
  t10 = 2400 s
  CT999 = 6.24 kg*s/m^3
  assumes: first-order (Chick-Watson) inactivation with n = 1
```

What the worked example means: This calculation determines the disinfection effectiveness by comparing the achieved contact time concentration product to the regulatory requirement for three-log removal. The achieved CT value, calculated as the product of the disinfectant residual and effective contact time, is 2.88 kg*s/m^3 kg*s/m^3. This is divided by the required CT for ninety-nine point nine percent inactivation, which is 104 mg*min/L mg*min/L, yielding a ratio of 0.461538. Multiplying this ratio by three gives the final credited log inactivation of 1.38462. A higher ratio indicates greater microbial reduction relative to the standard benchmark.

Log removal and percentage removal, `enveng_log_removal`

The log10 removal (log reduction value) and the percentage removal from the counts or concentrations before and after treatment.

$$LR = \log_{10} \frac{N_0}{N}$$

symbol		meaning	SI unit
`N0`	in	count or concentration before treatment	,
`N`	in	count or concentration after treatment (same unit)	,
`log_removal`	out	log10 removal	,
`percent_removal`	out	percentage removed	,

Applies when: 0 < N < N0.

```
$ environmental-engineering solve enveng_log_removal N0=1000000 N=100
log_removal = 4
percent_removal = 99.99
  by: Log removal and percentage removal  (LR = log10(N0/N); percent = (1 - N/N0) 100)
  N0 = 1000000
  N = 100
  assumes: 0 < N < N0
```

What the worked example means: This calculation determines the effectiveness of the treatment by comparing the initial concentration or count before treatment, represented as N0, with the final value after

treatment, denoted as N. The log removal is computed using the base ten logarithm of the ratio of these two values, while the percentage removal reflects the proportion of contaminants eliminated relative to the starting amount. For the input values provided, the resulting log removal is 4 and the percentage removal is 99.99, indicating the scale of reduction achieved.

Mean velocity gradient G (rapid mixing and flocculation), `enveng_velocity_gradient`

The root-mean-square velocity gradient G of a mixing or flocculation tank from the power dissipated, the viscosity and the volume, and the Camp number G t when the detention time is given.

$$G = \sqrt{\frac{P}{\mu V}}$$

symbol		meaning	SI unit
`P`	in	power dissipated in the water	W
`mu`	in	water viscosity	Pa*s
`V`	in	tank volume	m^3
`t`	in	detention time (for G t) (optional)	s
`G`	out	mean velocity gradient	1/s
`Gt`	out	Camp number G t (dimensionless)	,

Applies when: P, mu, V > 0.

```
$ environmental-engineering solve enveng_velocity_gradient "P=2000 W" "mu=0.001002 Pa*s" "V=50 m^3"
G = 199.8002995 1/s
  by: Mean velocity gradient G (rapid mixing and flocculation)  (G = sqrt(P/(mu V)); Camp number G
t)
  P = 2000 W
  mu = 0.001002 Pa*s
  V = 50 m^3
  assumes: P, mu, V > 0
```

In the worked example, P = 2000 W, mu = 0.001002 Pa*s, V = 50 m^3 go through the equation above and give G = 199.8002995 1/s. It applies only when P, mu, V > 0: outside that it says what is wrong instead of returning a number.

Membrane recovery, rejection, flux and concentrate, `enveng_membrane_mass_balance`

The water recovery, solute rejection, permeate flux (also in L/(m^2 h)) and the concentrate flow and concentration of a membrane unit from the feed and permeate flows and concentrations and the membrane area.

$$r = \frac{Q_p}{Q_f},\ R = 1 - \frac{C_p}{C_f},\ C_c = \frac{Q_f C_f - Q_p C_p}{Q_f - Q_p}$$

symbol		meaning	SI unit
`Qf`	in	feed flow	m^3/s

symbol		meaning	SI unit
`Qp`	in	permeate flow	m^3/s
`Cf`	in	feed concentration	kg/m^3
`Cp`	in	permeate concentration	kg/m^3
`A`	in	membrane area	m^2
`recovery`	out	Qp/Qf	,
`rejection`	out	1 - Cp/Cf	,
`J`	out	permeate flux	m/s
`J_LMH`	out	flux in L/(m^2 h)	,
`Qc`	out	concentrate flow	m^3/s
`Cc`	out	concentrate concentration	kg/m^3
`Cc_mgL`	out	concentrate concentration in mg/L	,

Applies when: Qp < Qf; Cp < Cf; steady state.

```
$ environmental-engineering solve enveng_membrane_mass_balance "Qf=1000 m^3/day" "Qp=750 m^3/day"
"Cf=2000 mg/L" "Cp=50 mg/L" "A=1500 m^2"
recovery = 0.75
rejection = 0.975
J = 5.787037037e-06 m/s
J_LMH = 20.83333333
Qc = 0.002893518519 m^3/s
Cc = 7.85 kg/m^3
Cc_mgL = 7850
  by: Membrane recovery, rejection, flux and concentrate  (r = Qp/Qf; R = 1 - Cp/Cf; J = Qp/A; Qc =
Qf - Qp; Cc = (Qf Cf - Qp Cp)/Qc)
  Qf = 0.01157407407 m^3/s
  Qp = 0.008680555556 m^3/s
  Cf = 2 kg/m^3
  Cp = 0.05 kg/m^3
  A = 1500 m^2
  assumes: Qp < Qf; Cp < Cf; steady state
```

What the worked example means: This calculation determines the performance metrics of a membrane separation process based on feed and permeate flow rates, concentrations, and membrane area. The water recovery is found to be 0.75, indicating the fraction of feed converted to permeate. Solute rejection is 0.975, reflecting the membrane's ability to retain contaminants. The permeate flux is 20.8333 liters per square meter per hour, while the concentrate stream has a flow rate of 0.00289352 m^3/s and a concentration of 7850. These values characterize the efficiency and operating point of the system under steady-state conditions.

Microbial inactivation by Chick's law (first order), `enveng_chick_law`

The surviving organisms, survival fraction, log removal and percentage removal after a contact time under first-order (Chick's law) inactivation or die-off.

$$\frac{N}{N_0} = e^{-kt}$$

symbol		meaning	SI unit
`N0`	in	initial organism concentration (count per volume, e.g. per 100 mL)	,
`k`	in	inactivation (die-off) rate constant	1/s
`t`	in	contact time	s
`N`	out	surviving organisms, same unit as N0	,
`survival`	out	N/N0	,
`log_removal`	out	log10 removal	,
`percent_removal`	out	percentage removed	,

Applies when: first-order kinetics.

```
$ environmental-engineering solve enveng_chick_law N0=1000000 "k=0.2 1/min" "t=30 min"
N = 2478.752177
survival = 0.002478752177
log_removal = 2.605766891
percent_removal = 99.75212478
  by: Microbial inactivation by Chick's law (first order)  (N = N0 e^(-k t); log removal = k t/ln
10)
  N0 = 1000000
  k = 0.003333333333 1/s
  t = 1800 s
  assumes: first-order kinetics
```

What the worked example means: This calculation applies Chick's law to determine microbial inactivation under first-order kinetics. Given an initial organism count of 1e+06, a die-off rate constant of 0.2 1/min, and a contact time of 30 min, the model computes the final population as 2478.75. The survival fraction is 0.00247875, which corresponds to a log removal value of 2.60577 and a percentage removal of 99.7521. These results indicate how effectively the disinfection process reduces the microbial load during the specified exposure period.

Osmotic pressure of a dilute solution (van 't Hoff), `enveng_osmotic_pressure`

The osmotic pressure of a dilute salt solution from its mass concentration, molar mass, van 't Hoff factor and temperature.

$$\pi = i \frac{C}{M} RT$$

symbol		meaning	SI unit
`C`	in	solute mass concentration	kg/m^3
`M`	in	solute molar mass	kg/mol
`i`	in	van 't Hoff factor (ions per formula unit, 2 for NaCl)	,
`T`	in	temperature	K
`pi`	out	osmotic pressure	Pa
`pi_bar`	out	osmotic pressure in bar	,

Applies when: dilute (ideal) solution.

```
$ environmental-engineering solve enveng_osmotic_pressure "C=35 g/L" "M=58.44 g/mol" i=2 "T=298.15
K"
pi = 2969318.824 Pa
pi_bar = 29.69318824
  by: Osmotic pressure of a dilute solution (van 't Hoff)  (pi = i (C/M) R T)
  C = 35 kg/m^3
  M = 0.05844 kg/mol
  i = 2
  T = 298.15 K
  assumes: dilute (ideal) solution
```

What the worked example means: This calculation determines the osmotic pressure of a dilute salt solution using the van 't Hoff equation. It combines the solute mass concentration, molar mass, temperature, and the van 't Hoff factor to estimate the pressure required to stop solvent flow across a semipermeable membrane. The resulting osmotic pressure is 2.96932e+06 Pa, equivalent to 29.6932 bar.

Power needed for a target velocity gradient, `enveng_mixing_power`

The power that must be dissipated in a tank to give a target mean velocity gradient G.

$$P = G^2 \mu V$$

symbol		meaning	SI unit
`G`	in	target velocity gradient	1/s
`mu`	in	water viscosity	Pa*s
`V`	in	tank volume	m^3
`P`	out	power required	W

Applies when: G, mu, V > 0.

```
$ environmental-engineering solve enveng_mixing_power "G=700 1/s" "mu=0.001002 Pa*s" "V=10 m^3"
P = 4909.8 W
  by: Power needed for a target velocity gradient  (P = G^2 mu V)
  G = 700 1/s
  mu = 0.001002 Pa*s
  V = 10 m^3
  assumes: G, mu, V > 0
```

What the worked example means: This calculation determines the power that must be dissipated within a tank to achieve a specific mean velocity gradient. By using the formula involving the square of the gradient, the fluid viscosity, and the total volume, for a gradient of 700 1/s and a volume of 10 m^3, with water viscosity at 0.001002 Pa*s, the necessary power output is 4909.8 W. This value represents the energy input needed to maintain the desired mixing intensity throughout the specified liquid volume.

Sedimentation basin sizing from overflow rate and detention time, `enveng_sedimentation_basin_sizing`

The surface area, volume, side-water depth and (circular) diameter of a settling basin from the design flow, the design overflow rate and the detention time.

$$A = \frac{Q}{v_0},\ V = Q\theta,\ h = v_0\theta$$

symbol		meaning	SI unit
`Q`	in	design flow	m^3/s
`v0`	in	design overflow rate (surface loading)	m/s
`theta`	in	design detention time	s
`A`	out	surface area Q/v0	m^2
`V`	out	volume Q theta	m^3
`depth`	out	depth V/A = v0 theta	m
`D`	out	diameter of one circular basin	m

Applies when: one basin.

```
$ environmental-engineering solve enveng_sedimentation_basin_sizing "Q=15000 m^3/day" "v0=40 m/day"
"theta=2 h"
A = 375 m^2
V = 1250 m^3
depth = 3.333333333 m
D = 21.85096861 m
  by: Sedimentation basin sizing from overflow rate and detention time  (A = Q/v0; V = Q theta;
depth = V/A; D = sqrt(4A/pi))
  Q = 0.1736111111 m^3/s
  v0 = 0.000462962963 m/s
  theta = 7200 s
  assumes: one basin
```

What the worked example means: This calculation determines the physical dimensions of a single sedimentation basin based on the design flow, overflow rate, and detention time. The required surface area is found by dividing the flow rate by the overflow rate, yielding 375 m^2. The total volume needed is the product of the flow rate and the detention time, giving 1250 m^3. Consequently, the side water depth is derived from the ratio of volume to area, which equals 3.33333 m. For a circular tank, this area corresponds to a diameter of 21.851 m. These values ensure that particles have sufficient time and space to settle out of the water before it exits the basin.

Stokes settling velocity of a discrete particle, `enveng_stokes_settling_velocity`

The terminal settling velocity of a small spherical particle in water by Stokes' law, with the particle Reynolds number that confirms laminar settling.

$$v_s = \frac{g(\rho_p - \rho_w)d^2}{18\mu}$$

symbol		meaning	SI unit
`d`	in	particle diameter	m
`rho_p`	in	particle density	kg/m^3
`rho_w`	in	water density	kg/m^3

symbol		meaning	SI unit
`mu`	in	water viscosity	Pa*s
`vs`	out	settling velocity	m/s
`Re`	out	particle Reynolds number	,
`vs_m_per_h`	out	in m/h	,

Applies when: Re <= 1; rho_p > rho_w.

```
$ environmental-engineering solve enveng_stokes_settling_velocity "d=0.05 mm" "rho_p=2650 kg/m^3"
"rho_w=998.2 kg/m^3" "mu=0.001002 Pa*s"
vs = 0.002245318318 m/s
Re = 0.1118401569
vs_m_per_h = 8.083145943
  by: Stokes settling velocity of a discrete particle  (vs = g (rho_p - rho_w) d^2/(18 mu))
  d = 5e-05 m
  rho_p = 2650 kg/m^3
  rho_w = 998.2 kg/m^3
  mu = 0.001002 Pa*s
  assumes: Re <= 1; rho_p > rho_w
```

What the worked example means: This calculation determines the terminal settling velocity of a discrete spherical particle in water using Stokes' law. Given a particle diameter of 0.05 mm, a particle density of 2650 kg/m^3, and water properties including a density of 998.2 kg/m^3 and viscosity of 0.001002 Pa*s, the resulting settling velocity is 0.00224532 m/s m/s. The calculated particle Reynolds number is 0.11184, which verifies that the flow around the particle remains laminar, satisfying the condition for the validity of this method.

Surface overflow rate of a circular clarifier, `enveng_overflow_rate_circular`

The surface area and the surface overflow rate (surface loading) of a circular settling tank from the flow and the tank diameter.

$$v_0 = \frac{Q}{\pi D^2/4}$$

symbol		meaning	SI unit
`Q`	in	flow rate	m^3/s
`D`	in	tank diameter	m
`A`	out	surface area	m^2
`v0`	out	overflow rate Q/A	m/s
`v0_m_per_day`	out	overflow rate in m^3/(m^2 d)	,

Applies when: Q, D > 0.

```
$ environmental-engineering solve enveng_overflow_rate_circular "Q=10000 m^3/day" "D=20 m"
A = 314.1592654 m^2
v0 = 0.0003684142201 m/s
v0_m_per_day = 31.83098862
  by: Surface overflow rate of a circular clarifier  (A = pi D^2/4; v0 = Q/A)
  Q = 0.1157407407 m^3/s
  D = 20 m
  assumes: Q, D > 0
```

What the worked example means: This calculation determines the physical dimensions and loading characteristics of a circular clarifier. Using the provided flow rate 10000 m^3/day and tank diameter 20 m, the surface area 314.159 m^2 is computed first. This area is then used to find the surface overflow rate 0.000368414 m/s, which represents the velocity at which water rises through the tank. A lower overflow rate generally indicates better settling conditions for suspended solids.

Terminal settling velocity in any flow regime (drag coefficient iteration), `enveng_terminal_settling_velocity`

The terminal settling velocity of a sphere in a fluid for laminar, transitional or turbulent settling, solving the force balance with the drag law Cd = 24/Re + 3/sqrt(Re) + 0.34.

$$v_t = \sqrt{\frac{4gd(\rho_p - \rho_f)}{3C_D\rho_f}}, \quad C_D = \frac{24}{Re} + \frac{3}{\sqrt{Re}} + 0.34$$

symbol		meaning	SI unit
`d`	in	particle diameter	m
`rho_p`	in	particle density	kg/m^3
`rho_f`	in	fluid density	kg/m^3
`mu`	in	fluid viscosity	Pa*s
`vt`	out	terminal settling velocity	m/s
`Re`	out	particle Reynolds number	,
`Cd`	out	drag coefficient	,

Applies when: Re <= 2e5; rho_p > rho_f.

```
$ environmental-engineering solve enveng_terminal_settling_velocity "d=0.5 mm" "rho_p=2650 kg/m^3"
"rho_f=998.2 kg/m^3" "mu=0.001002 Pa*s"
vt = 0.09058056284 m/s
Re = 45.11852187
Cd = 1.318558136
  by: Terminal settling velocity in any flow regime (drag coefficient iteration)  (vt^2 Cd(Re) =
(4/3) g d (rho_p - rho_f)/rho_f with Cd = 24/Re + 3/sqrt(Re) + 0.34, solved by bisection below the
Stokes velocity)
  d = 0.0005 m
  rho_p = 2650 kg/m^3
  rho_f = 998.2 kg/m^3
  mu = 0.001002 Pa*s
  assumes: Re <= 2e5; rho_p > rho_f
```

What the worked example means: This calculation determines the steady speed at which a particle falls through a fluid, balancing gravitational pull against drag and buoyancy. Using the particle diameter 0.5 mm, densities 2650 kg/m^3 and 998.2 kg/m^3, and viscosity 0.001002 Pa*s, the algorithm iterates to find the velocity where forces equalize. The resulting terminal velocity is 0.0905806 m/s, corresponding to a Reynolds number of 45.1185 and a drag coefficient of 1.31856. This approach works for laminar, transitional, or turbulent regimes up to a Reynolds number of 200000.

Water hardness as CaCO3, `enveng_water_hardness`

Calcium, magnesium and total hardness expressed as mg/L of CaCO3 from the calcium and magnesium concentrations, with the usual classification (soft to very hard).

$$TH = Ca\,\frac{50.04}{20.04} + Mg\,\frac{50.04}{12.15}$$

symbol		meaning	SI unit
`Ca`	in	calcium concentration (as Ca)	kg/m^3
`Mg`	in	magnesium concentration (as Mg)	kg/m^3
`total_hardness`	out	total hardness, mg/L as CaCO3	,
`calcium_hardness`	out	calcium hardness, mg/L as CaCO3	,
`magnesium_hardness`	out	magnesium hardness, mg/L as CaCO3	,
`classification`	out	soft (< 60), moderately hard (60-120), hard (120-180), very hard (>= 180)	,

Applies when: only Ca and Mg contribute.

```
$ environmental-engineering solve enveng_water_hardness "Ca=60 mg/L" "Mg=15 mg/L"
total_hardness = 211.6074929
calcium_hardness = 149.8381656
magnesium_hardness = 61.7693273
classification = very hard
  by: Water hardness as CaCO3  (hardness = C (EW_CaCO3/EW_ion), EW_CaCO3 = 50.04, EW_Ca = 20.04,
EW_Mg = 12.15)
  Ca = 0.06 kg/m^3
  Mg = 0.015 kg/m^3
  assumes: only Ca and Mg contribute
```

What the worked example means: This calculation determines water hardness by converting the measured concentrations of calcium and magnesium into an equivalent mass of calcium carbonate. The calcium hardness is found to be 149.838, while the magnesium hardness is 61.7693, resulting in a total hardness value of 211.607. Based on these values, the water sample is classified as very hard, indicating its suitability for various uses and potential scaling issues.

Weir loading rate of a circular clarifier, `enveng_weir_loading_rate`

The weir length and weir loading rate of a circular clarifier with a peripheral weir.

$$WL = \frac{Q}{\pi D}$$

symbol		meaning	SI unit
`Q`	in	flow rate	m^3/s
`D`	in	weir (tank) diameter	m
`weir_length`	out	weir length pi D	m
`WL`	out	weir loading rate Q/(pi D)	m^2/s
`WL_m3_per_m_day`	out	weir loading in m^3/(m d)	,

Applies when: peripheral weir.

```
$ environmental-engineering solve enveng_weir_loading_rate "Q=10000 m^3/day" "D=20 m"
weir_length = 62.83185307 m
WL = 0.001842071101 m^2/s
WL_m3_per_m_day = 159.1549431
  by: Weir loading rate of a circular clarifier  (WL = Q/(pi D))
  Q = 0.1157407407 m^3/s
  D = 20 m
  assumes: peripheral weir
```

What the worked example means: This calculation determines the weir loading rate for a circular clarifier with a peripheral weir. It uses the flow rate 10000 m^3/day and the tank diameter 20 m to find the total weir length, which is 62.8319 m. The resulting loading rate is 0.00184207 m^2/s, representing the volume of water passing over each meter of weir per second.

Questions and reports: support@ai999x.com. AI999X, The Future Is Self-Improving.