power-electronics: the Power Electronics program, user guide

power-electronics-ai999x 1.1.0, Rust build: command line, desktop app and browser. **Creator / engineer:** Ibnul Jaif Farabi · **Company:** AI999X · support@ai999x.com

Power Electronics covers DC-DC converters in continuous and discontinuous conduction (buck, boost, buck-boost, Cuk, SEPIC, flyback, forward, bridge), rectifiers and phase control, inverters and PWM, motor drives, device losses, snubbers, thermal and magnetic design and resonant converters. This guide is about `power-electronics`, the model as a self-contained program for Windows and Linux: 79 capabilities in 13 topics, answered on your own computer with no network, no Python and nothing else to install. The same compiled model runs in the AI999X desktop app and in the browser on the model's page (https://www.ai999x.com/models/power-electronics-ai999x/); the Python package (`pip install power-electronics-ai999x`) has its own guide. Every command output printed here is what the program printed.

Contents

- 1. Get it: desktop app, command line, browser, Python
- 2. Quick start
- 3. Writing inputs
- 4. Outcomes and exit codes
- 5. Scripts and agents: batch and JSON
- 6. Figures
- 7. In a web page or Node.js: WebAssembly
- 8. Every capability

1. Get it

Version 1.5.0 of the AI999X desktop app and of the command-line bundle. Checksums for every file: https://downloads.ai999x.com/desktop/1.5.0/SHA256SUMS; the newest version is always under https://downloads.ai999x.com/desktop/latest/. Full instructions: https://www.ai999x.com/desktop-cli/

what	system	download
Desktop app: Power Electronics	Windows x86-64	https://downloads.ai999x.com/desktop/1.5.0/ai999x-power-electronics-1.5.0-windows-x86_64.zip
Desktop app: Power Electronics	Linux x86-64	https://downloads.ai999x.com/desktop/1.5.0/ai999x-power-electronics-1.5.0-linux-x86_64.tar.gz
Desktop app: all models	Windows x86-64	https://downloads.ai999x.com/desktop/1.5.0/ai999x-1.5.0-windows-x86_64.zip
Desktop app: all models	Linux x86-64	https://downloads.ai999x.com/desktop/1.5.0/ai999x-1.5.0-linux-x86_64.tar.gz
Command line	Windows x86-64	https://downloads.ai999x.com/desktop/1.5.0/ai999x-cli-1.5.0-windows-x86_64.zip
Command line	Linux x86-64	https://downloads.ai999x.com/desktop/1.5.0/ai999x-cli-1.5.0-linux-x86_64.tar.gz

Desktop app

Power Electronics in its own app: search, questions in words, input forms, live figures and explanations. Windows: Download ai999x-power-electronics-1.5.0-windows-x86_64.zip, right-click it → Extract All, then open the folder and start ai999x-power-electronics.exe. If Windows SmartScreen asks, choose More info → Run anyway. Linux:

```
curl -LO https://downloads.ai999x.com/desktop/1.5.0/ai999x-power-electronics-1.5.0-linux-
x86_64.tar.gz
curl -LO https://downloads.ai999x.com/desktop/1.5.0/SHA256SUMS
sha256sum -c --ignore-missing SHA256SUMS
tar xzf ai999x-power-electronics-1.5.0-linux-x86_64.tar.gz
./ai999x-power-electronics-1.5.0-linux-x86_64/ai999x-power-electronics
```

It opens on this model: type a question or pick a capability, fill in the form and press Compute. The AI999X desktop app with every model works the same way (choose the model first). Windows: Download ai999x-1.5.0-windows-x86_64.zip, right-click it → Extract All, then open the folder and start ai999x.exe. If Windows SmartScreen asks, choose More info → Run anyway. Linux:

```
curl -LO https://downloads.ai999x.com/desktop/1.5.0/ai999x-1.5.0-linux-x86_64.tar.gz
curl -LO https://downloads.ai999x.com/desktop/1.5.0/SHA256SUMS
sha256sum -c --ignore-missing SHA256SUMS
tar xzf ai999x-1.5.0-linux-x86_64.tar.gz
./ai999x-1.5.0-linux-x86_64/ai999x
```

Command line, Linux

The bundle holds one program per model; `power-electronics` is this one. The checksum line should print OK.

```
curl -LO https://downloads.ai999x.com/desktop/1.5.0/ai999x-cli-1.5.0-linux-x86_64.tar.gz
curl -LO https://downloads.ai999x.com/desktop/1.5.0/SHA256SUMS
sha256sum -c --ignore-missing SHA256SUMS
mkdir -p ~/.local/share && tar xzf ai999x-cli-1.5.0-linux-x86_64.tar.gz -C ~/.local/share
echo 'export PATH="$HOME/.local/share/ai999x-cli-1.5.0-linux-x86_64:$PATH"' >> ~/.bashrc && source
~/.bashrc
power-electronics --version
```

Command line, Windows (PowerShell)

The fourth line should print True.

```
$F = "ai999x-cli-1.5.0-windows-x86_64.zip"
Invoke-WebRequest "https://downloads.ai999x.com/desktop/1.5.0/$F" -OutFile $F
Invoke-WebRequest "https://downloads.ai999x.com/desktop/1.5.0/SHA256SUMS" -OutFile SHA256SUMS
(Get-FileHash $F -Algorithm SHA256).Hash.ToLower() -eq ((Select-String -SimpleMatch $F
SHA256SUMS).Line -split ' ')[0]
Expand-Archive $F -DestinationPath "$env:LOCALAPPDATA\AI999X" -Force
$D = "$env:LOCALAPPDATA\AI999X\ai999x-cli-1.5.0-windows-x86_64"; $env:Path += ";$D"
[Environment]::SetEnvironmentVariable("Path", [Environment]::GetEnvironmentVariable("Path", "User")
+ ";$D", "User")
power-electronics --version
```

In your browser

Open https://www.ai999x.com/models/power-electronics-ai999x/, choose a capability and press Compute in your browser: the same program runs on your device as WebAssembly; nothing is sent anywhere.

Python

```
pip install power-electronics-ai999x
```

2. Quick start

2.1 Check the install

Prints the model, its version and that this is the Rust build.

```
$ power-electronics --version
power-electronics-ai999x 1.5.0 (Rust build, ax-engine 1.5.0)
```

2.2 Ask in words

Write the question as you would say it: the program reads the quantities and their units, picks the capability and answers.

```
$ power-electronics ask "Buck converter in CCM: Vin = 24 V, Vout = 5 V, L = 22 uH, fs = 200 kHz, Io
= 3 A"
Read as: Buck converter in continuous conduction
D = 0.2083333333
dIL = 0.8996212121 A
IL_max = 3.449810606 A
IL_min = 2.550189394 A
ripple_ratio = 0.2998737374
Iin = 0.625 A
  by: Buck converter in continuous conduction  (D = Vout/Vin; dIL = (Vin - Vout) D/(L fs); IL = Io;
IL_max,min = Io +- dIL/2; Iin = D Io)
  Io = 3 A
  L = 2.2e-05 H
  Vin = 24 V
  Vout = 5 V
  fs = 200000 Hz
  assumes: 0 < Vout < Vin; continuous conduction (IL_min > 0)
```

2.3 Find a capability

Search the capabilities by what you want to know; the first column is the id to pass to info and solve.

```
$ power-electronics search "buck converter in continuous conduction"
pe_buck_ccm                          Buck converter in continuous conduction  (DC-DC converters /
buck)
pe_buck_boost_ccm                    Buck-boost converter in continuous conduction  (DC-DC
converters / buck-boost)
pe_boost_ccm                         Boost converter in continuous conduction  (DC-DC converters /
boost)
pe_cuk_ccm                           Cuk converter in continuous conduction  (DC-DC converters /
Cuk)
pe_flyback_ccm                       Flyback converter in continuous conduction  (isolated
converters / flyback)
pe_sepic_ccm                         SEPIC converter in continuous conduction  (DC-DC converters /
SEPIC)
pe_buck_dcm                          Buck converter in discontinuous conduction  (DC-DC converters
/ discontinuous conduction)
pe_buck_boost_dcm                    Buck-boost converter in discontinuous conduction  (DC-DC
converters / discontinuous conduction)
… 12 more
```

2.4 List the capabilities

Every capability the program answers: its id (what you pass to solve) and its name.

```
$ power-electronics list
pe_ac_voltage_controller               Single-phase AC voltage controller (resistive load)
pe_bldc_six_step                       BLDC motor with six-step (120 degree) drive
pe_boost_ccm                           Boost converter in continuous conduction
pe_boost_dcm                           Boost converter in discontinuous conduction
pe_boost_nonideal_gain                 Boost converter with inductor resistance: gain and
efficiency
pe_boost_output_ripple                 Boost converter output voltage ripple
pe_boost_pfc                           Boost power-factor-correction stage
pe_bootstrap_capacitor                 Bootstrap capacitor for a high-side gate driver
… 71 more
```

2.5 What a capability needs

The equation or method, every input and output with its SI unit. Read this before solve: it tells you the input names.

```
$ power-electronics info pe_buck_ccm
Buck converter in continuous conduction
  D = Vout/Vin; dIL = (Vin - Vout) D/(L fs); IL = Io; IL_max,min = Io +- dIL/2; Iin = D Io
  in   Vin      input voltage [V]
  in   Vout     output voltage [V]
  in   L        inductance [H]
  in   fs       switching frequency [Hz]
  in   Io       load (output) current [A]
  out  D        duty cycle [1]
  out  dIL      peak-to-peak inductor ripple [A]
  out  IL_max   peak inductor current [A]
  out  IL_min   valley inductor current [A]
  out  ripple_ratio ripple ratio dIL/Io [1]
  out  Iin      average input current [A]
```

2.6 Solve

Inputs as name=value, each with any unit of the right kind. The answer lists every output, the method used, each input converted to SI, and the conditions the answer assumes.

```
$ power-electronics solve pe_buck_ccm "Vin=24 V" "Vout=5 V" "L=22 uH" "fs=200 kHz" "Io=3 A"
D = 0.2083333333
dIL = 0.8996212121 A
IL_max = 3.449810606 A
IL_min = 2.550189394 A
ripple_ratio = 0.2998737374
Iin = 0.625 A
  by: Buck converter in continuous conduction  (D = Vout/Vin; dIL = (Vin - Vout) D/(L fs); IL = Io;
IL_max,min = Io +- dIL/2; Iin = D Io)
  Vin = 24 V
  Vout = 5 V
  L = 2.2e-05 H
  fs = 200000 Hz
  Io = 3 A
  assumes: 0 < Vout < Vin; continuous conduction (IL_min > 0)
```

2.7 Machine-readable answer

--json prints the same answer as one line of JSON (values in SI): for scripts and other programs.

```
$ power-electronics solve pe_buck_ccm "Vin=24 V" "Vout=5 V" "L=22 uH" "fs=200 kHz" "Io=3 A" --json
{"outcome":"SOLVED","message":"","value":0.899621212121,"unit":"A","solved_for":"dIL","si":
[["Vin",24.0],["Vout",5.0],["L",0.000022],["fs",200000.0],["Io",3.0]],"values":
[["D",0.208333333333,""],["dIL",0.899621212121,"A"],["IL_max",3.44981060606,"A"],
["IL_min",2.55018939394,"A"],["ripple_ratio",0.299873737374,""],
["Iin",0.625,"A"]],"target":"dIL","phrase":"duty cycle","assumptions":["0 < Vout < Vin","continuous
conduction (IL_min > 0)"],"name":"Buck converter in continuous conduction","equation":"D =
Vout/Vin; dIL = (Vin - Vout) D/(L fs); IL = Io; IL_max,min = Io +- dIL/2; Iin = D Io"}
```

2.8 When an input is missing

No number is guessed: the answer names what is missing, shows a complete call, and the program exits with status 1.

```
$ power-electronics solve pe_buck_ccm "Vin=24 V" "Vout=5 V" "L=22 uH" "fs=200 kHz"
NEEDS_INPUT: pe_buck_ccm needs Io (load (output) current). Example: solve('pe_buck_ccm', Vin='24
V', Vout='5 V', L='2.2e-05 H', fs='200000 Hz', Io='3 A').
```

2.9 Many questions at once

One JSON request per line in, one JSON answer per line out, in order: for scripts, notebooks and agents (the program starts once). In PowerShell: Get-Content cases.jsonl | power-electronics batch

`cases.jsonl`:

```
{"key": "pe_buck_ccm", "inputs": {"Vin": "24 V", "Vout": "5 V", "L": "22 uH", "fs": "200 kHz",
"Io": "3 A"}}
{"key": "pe_three_phase_controlled_rectifier", "inputs": {"VLL": "415 V", "alpha": "45 deg", "Id":
"50 A"}}
```

```
$ power-electronics batch < cases.jsonl
{"outcome":"SOLVED","message":"","value":0.899621212121,"unit":"A","solved_for":"dIL","si":
[["Vin",24.0],["Vout",5.0],["L",0.000022],["fs",200000.0],["Io",3.0]],"values":
[["D",0.208333333333,""],["dIL",0.899621212121,"A"],["IL_max",3.44981060606,"A"],
["IL_min",2.55018939394,"A"],["ripple_ratio",0.299873737374,""],
["Iin",0.625,"A"]],"target":"dIL","phrase":"duty cycle","assumptions":["0 < Vout < Vin","continuous
conduction (IL_min > 0)"],"name":"Buck converter in continuous conduction","equation":"D =
Vout/Vin; dIL = (Vin - Vout) D/(L fs); IL = Io; IL_max,min = Io +- dIL/2; Iin = D Io"}
{"outcome":"SOLVED","message":"","value":396.295808299,"unit":"V","solved_for":"Vdc","si":
[["VLL",415.0],["alpha",0.7853981633974483],["Id",50.0]],"values":[["Vdc",396.295808299,"V"],
["Vrms",415.0,"V"],["P",19814.7904149,"W"],["I_thy_avg",16.6666666667,"A"],
["I_thy_rms",28.8675134595,"A"],["Is_rms",40.8248290464,"A"],
["mode","rectifying",""]],"target":"Vdc","phrase":"average output voltage","assumptions":["0 <=
alpha < 180 degrees","continuous constant current, no source inductance"],"name":"Three-phase fully
controlled thyristor bridge","equation":"Vdc = 3 sqrt(2) VLL cos(alpha)/pi; Vrms = Vm sqrt(1/2 + 3
sqrt(3) cos(2 alpha)/(4 pi)); I_thy = Id/3 (avg), Id/sqrt(3) (rms)"}
```

3. Writing inputs

Inputs are written `name=value`, one per argument; `power-electronics info <capability>` lists the names. Quote an argument that holds a space or brackets (bash, zsh and PowerShell all accept double quotes). The answer always states each input as it was read, converted to SI, so a misread unit is visible at once.

kind	example	how it is read
a number with a unit	`"R=0.128 nm"`	any unit of the same kind; converted to SI
a number in SI	`R=1.28e-10`	no unit means the SI unit shown by info
a choice	`structure=FCC`	one of the values info lists
a list or vector	`"v=[1, 2, 3]" or "v=1, 2, 3"`	brackets keep it a list
a matrix	`"A=[[1, 2], [3, 4]]"`	one list per row
true / false	`inclusive=true`	for yes/no options

An equation can be solved for any of its quantities: give the others and add `--target <symbol>`. Without `--target`, the program solves for the quantity the capability is named after.

4. Outcomes and exit codes

The program never guesses a number: when it cannot answer, it says why and exits with status 1, so a script can tell an answer from a refusal without reading the text.

outcome	meaning	exit status
SOLVED	the answer: every output with its unit, the method, the inputs in SI, the conditions assumed	0
NEEDS_INPUT	an input is missing; the message names it and shows a complete call	1
INVALID_INPUT	a value or unit of the wrong kind, an unknown input name, or a value outside the conditions	1

outcome	meaning	exit status
AMBIGUOUS	the inputs allow two different answers; say which one is meant	1
OUT_OF_SCOPE	the model has no capability for this, or the result would not be meaningful	1
(usage)	a command the program does not know: it prints its usage	2

5. Scripts and agents: batch and JSON

`power-electronics solve ... --json` prints one answer as one line of JSON. `power-electronics batch` reads one request per line on standard input and writes one JSON answer per line, in order, starting the program once for any number of requests. A request is `{"key": "<capability>", "inputs": {"name": "value", ...}, "target": null}`. In PowerShell, pipe the file in: `Get-Content cases.jsonl | power-electronics batch`. `power-electronics catalog` prints every capability with its inputs as JSON, to build forms or tool definitions.

answer field	meaning
outcome	one of the outcomes above
message	why there is no answer (empty when SOLVED)
value, unit	the main result in SI units
values	every output: [symbol, value, unit] (procedures)
target	the quantity solved for
si	each numeric input converted to SI: [symbol, value]
assumptions	the conditions the answer relies on
name, equation	the capability and its equation or method

```
import json, subprocess

reqs = [{"key": "<capability>", "inputs": {"name": "value"}}]
out = subprocess.run(["power-electronics", "batch"], input="\n".join(map(json.dumps, reqs)),
                     capture_output=True, text=True, check=True).stdout
answers = [json.loads(line) for line in out.splitlines()]
```

6. Figures

`power-electronics figures <capability> name=value ... --out DIR` draws the live figures for those inputs and writes each as an SVG file into DIR (an existing folder); without `--out` the SVG text comes back as JSON. The desktop app and the model page draw the same figures as soon as you press Compute.

7. In a web page or Node.js: WebAssembly

The same model is a WebAssembly module, `power_electronics_ai999x.wasm` (https://www.ai999x.com/compute/rust/power_electronics_ai999x.wasm), with a small loader, `ax-wasm.js` (https://www.ai999x.com/compute/rust/ax-wasm.js). It runs in a browser, a Web Worker or Node.js, with no server.

```
<script src="ax-wasm.js"></script>
<script>
  AXWasm.load("power_electronics_ai999x.wasm").then(function (m) {
    var a = m.solve({key: "<capability>", inputs: {name: "value"}});
    console.log(a.outcome, a.values || a.value);
    console.log(m.catalog().capabilities.length + " capabilities");
  });
</script>
```

8. Every capability

By topic. For each: what it does, what it needs and gives, when it applies, and a command with what the program printed for it. `power-electronics info <id>` shows the same inputs and outputs in the terminal.

Control (2)

Control-to-output transfer function of a DC-DC converter, `pe_converter_small_signal`

The control-to-output (duty-to-voltage) transfer function features of an ideal buck, boost or buck-boost converter in continuous conduction: dc gain, double-pole frequency, quality factor and right-half-plane zero.

$$G_{vd}(s) = G_{d0}\frac{1 - s/\omega_z}{1 + s/(Q\omega_0) + (s/\omega_0)^2}, \quad \omega_{z,boost} = \frac{D'^2 R}{L}$$

symbol		meaning	SI unit
`topology`	in	buck, boost or buck-boost	,
`Vin`	in	input voltage	V
`D`	in	duty cycle (a fraction or %)	,
`L`	in	inductance	H
`C`	in	output capacitance	F
`R`	in	load resistance	ohm
`Gvd0`	out	dc gain of vo/d (volts per unit duty)	V
`f0`	out	double-pole (corner) frequency	Hz
`Q`	out	quality factor of the double pole	,
`f_rhpz`	out	right-half-plane zero frequency	Hz
`rhp_zero`	out	whether a right-half-plane zero is present	,

Applies when: ideal converter in continuous conduction, no ESR.

```
$ power-electronics solve pe_converter_small_signal topology=boost "Vin=12 V" D=0.5 "L=50 uH"
"C=100 uF" "R=10 ohm"
Gvd0 = 48 V
f0 = 1125.395395 Hz
Q = 7.071067812
f_rhpz = 7957.747155 Hz
rhp_zero = present
  by: Control-to-output transfer function of a DC-DC converter  (buck: Gvd0 = Vin, w0 = 1/sqrt(LC),
Q = R sqrt(C/L); boost: Gvd0 = Vin/D'^2, w0 = D'/sqrt(LC), Q = D' R sqrt(C/L), wz = D'^2 R/L; buck-
boost: wz = D'^2 R/(D L))
  Vin = 12 V
  D = 0.5
  L = 5e-05 H
  C = 0.0001 F
  R = 10 ohm
  topology = boost
  assumes: ideal converter in continuous conduction, no ESR
```

What the worked example means: This calculation determines the dynamic response characteristics of an ideal DC-DC converter operating in continuous conduction mode. Using the input voltage 12 V, duty cycle 0.5, inductance 50 uH, capacitance 100 uF, and load resistance 10 ohm, it computes the small-signal transfer function parameters. The result includes the DC gain 48 V, which represents the steady-state change in output voltage per unit change in duty cycle. The double-pole frequency 1125.4 Hz indicates where the magnitude begins to roll off at forty decibels per decade, while the quality factor 7.07107 describes the sharpness of the resonance peak near this frequency. If applicable, the right-half-plane zero frequency 7957.75 Hz is also calculated, marking a critical point for stability analysis.

Peak current mode: subharmonic stability and slope compensation, `pe_peak_current_mode_slope`

The inductor current slopes, the period-to-period perturbation factor, the stability verdict and the smallest and the deadbeat compensation ramp slopes of a peak-current-mode buck converter.

$$\alpha = -\frac{m_2 - m_a}{m_1 + m_a}, \quad |\alpha| < 1 \Leftarrow m_a > \frac{m_2 - m_1}{2}$$

symbol		meaning	SI unit
`Vin`	in	input voltage	V
`Vout`	in	output voltage	V
`L`	in	inductance	H
`fs`	in	switching frequency	Hz
`ma`	in	compensation ramp slope referred to the inductor current	A/s
`D`	out	duty cycle	,
`m1`	out	rising inductor current slope	A/s
`m2`	out	falling inductor current slope (magnitude)	A/s
`alpha`	out	perturbation factor per switching period	,
`stable`	out	stable or unstable	,
`ma_min`	out	smallest ramp slope for stability at this duty cycle	A/s
`ma_deadbeat`	out	deadbeat compensation ramp slope	A/s

Applies when: 0 < Vout < Vin; continuous conduction.

```
$ power-electronics solve pe_peak_current_mode_slope "Vin=12 V" "Vout=8 V" "L=10 uH" "fs=300 kHz"
"ma=0.3 A/us"
D = 0.6666666667
m1 = 400000 A/s
m2 = 800000 A/s
alpha = -0.7142857143
stable = stable
ma_min = 200000 A/s
ma_deadbeat = 800000 A/s
  by: Peak current mode: subharmonic stability and slope compensation  (m1 = (Vin - Vo)/L, m2 =
Vo/L; alpha = -(m2 - ma)/(m1 + ma); stable when |alpha| < 1; ma,min = (m2 - m1)/2)
  Vin = 12 V
  Vout = 8 V
  L = 1e-05 H
  fs = 300000 Hz
  ma = 300000 A/s
  assumes: 0 < Vout < Vin; continuous conduction
```

What the worked example means: This calculation determines the stability of a peak-current-mode buck converter by analyzing the inductor current slopes. The rising slope 400000 A/s and falling slope 800000 A/s are derived from the input voltage, output voltage, and inductance. These values feed into the perturbation factor formula to yield -0.714286. If the magnitude of this factor is less than one, the loop is stable; otherwise, subharmonic oscillations occur. The minimum compensation ramp required for stability at this operating point is 200000 A/s, while the deadbeat slope that eliminates ringing entirely is 800000 A/s.

DC-DC converters (15)

Boost converter in continuous conduction, `pe_boost_ccm`

The duty cycle, average inductor (input) current, inductor ripple, peak and valley currents and switch voltage stress of an ideal boost (step-up) converter in continuous conduction.

$$D = 1 - \frac{V_{in}}{V_o}, \quad I_L = \frac{I_o}{1 - D}, \quad \Delta i_L = \frac{V_{in} D}{L f_s}$$

symbol		meaning	SI unit
`Vin`	in	input voltage	V
`Vout`	in	output voltage	V
`L`	in	inductance	H
`fs`	in	switching frequency	Hz
`Io`	in	load (output) current	A
`D`	out	duty cycle	,
`IL`	out	average inductor current (input current)	A
`dIL`	out	peak-to-peak inductor ripple	A
`IL_max`	out	peak inductor current	A
`IL_min`	out	valley inductor current	A

symbol		meaning	SI unit
`V_switch`	out	switch and diode voltage stress	V

Applies when: Vout > Vin > 0; continuous conduction (IL_min > 0).

```
$ power-electronics solve pe_boost_ccm "Vin=12 V" "Vout=48 V" "L=100 uH" "fs=100 kHz" "Io=1 A"
D = 0.75
IL = 4 A
dIL = 0.9 A
IL_max = 4.45 A
IL_min = 3.55 A
V_switch = 48 V
  by: Boost converter in continuous conduction  (D = 1 - Vin/Vout; IL = Io/(1 - D); dIL = Vin D/(L
fs))
  Vin = 12 V
  Vout = 48 V
  L = 0.0001 H
  fs = 100000 Hz
  Io = 1 A
  assumes: Vout > Vin > 0; continuous conduction (IL_min > 0)
```

What the worked example means: This calculation determines the operating parameters for an ideal boost converter in continuous conduction mode. The duty cycle, computed as 0.75, dictates the voltage conversion ratio based on the input and output voltages. From this, the average inductor current, which equals the input current, is found to be 4 A. The peak-to-peak inductor ripple current is calculated as 0.9 A, derived from the input voltage, duty cycle, inductance, and switching frequency. These values define the steady-state behavior of the converter.

Boost converter in discontinuous conduction, `pe_boost_dcm`

The conversion ratio, output voltage, diode conduction interval D2, peak inductor current and load current of an ideal boost converter in discontinuous conduction.

$$M = \frac{1 + \sqrt{1 + 4D^2/K}}{2}, \quad D_2 = \frac{D}{M - 1}$$

symbol		meaning	SI unit
`Vin`	in	input voltage	V
`L`	in	inductance	H
`fs`	in	switching frequency	Hz
`R`	in	load resistance	ohm
`D`	in	duty cycle (a fraction or %)	,
`K`	out	dimensionless conduction parameter K	,
`M`	out	conversion ratio Vout/Vin	,
`Vout`	out	output voltage	V
`D2`	out	diode conduction interval as a fraction of the period	,
`I_pk`	out	peak inductor current	A

symbol		meaning	SI unit
`Io`	out	load current	A

Applies when: K < D (1 - D)^2 (discontinuous conduction).

```
$ power-electronics solve pe_boost_dcm "Vin=12 V" "L=10 uH" "fs=100 kHz" "R=100 ohm" D=0.4
K = 0.02
M = 3.372281323
Vout = 40.46737588 V
D2 = 0.1686140662
I_pk = 4.8 A
Io = 0.4046737588 A
  by: Boost converter in discontinuous conduction  (M = (1 + sqrt(1 + 4 D^2/K))/2; D2 = D/(M - 1);
I_pk = Vin D Ts/L)
  Vin = 12 V
  L = 1e-05 H
  fs = 100000 Hz
  R = 100 ohm
  D = 0.4
  assumes: K < D (1 - D)^2 (discontinuous conduction)
```

In the worked example, Vin = 12 V, L = 10 uH, fs = 100 kHz, R = 100 ohm, D = 0.4 go through the equation above and give K = 0.02, M = 3.372281323, Vout = 40.46737588 V, D2 = 0.1686140662. It applies only when K < D (1 - D)^2 (discontinuous conduction): outside that it says what is wrong instead of returning a number.

Boost converter output voltage ripple, `pe_boost_output_ripple`

The peak-to-peak output voltage ripple of a boost converter: the capacitor alone supplies the load current during the switch on-time (ideal capacitor, no ESR).

$$\Delta v_o = \frac{I_o D}{C f_s}$$

symbol		meaning	SI unit
`Vin`	in	input voltage	V
`Vout`	in	output voltage	V
`Io`	in	load current	A
`C`	in	output capacitance	F
`fs`	in	switching frequency	Hz
`D`	out	duty cycle	,
`dVo`	out	peak-to-peak output ripple	V
`dVo_pct`	out	ripple in percent of Vout	,

Applies when: Vout > Vin > 0; continuous conduction, ideal capacitor.

```
$ power-electronics solve pe_boost_output_ripple "Vin=12 V" "Vout=48 V" "Io=1 A" "C=47 uF" "fs=100
kHz"
D = 0.75
dVo = 0.1595744681 V
dVo_pct = 0.3324468085
  by: Boost converter output voltage ripple  (D = 1 - Vin/Vout; dVo = Io D/(C fs))
  Vin = 12 V
  Vout = 48 V
  Io = 1 A
  C = 4.7e-05 F
  fs = 100000 Hz
  assumes: Vout > Vin > 0; continuous conduction, ideal capacitor
```

What the worked example means: This calculation determines the peak-to-peak output voltage ripple for a boost converter operating in continuous conduction mode with an ideal capacitor. The duty cycle is first derived from the input and output voltages, resulting in a value of 0.75. This duty cycle, along with the load current, capacitance, and switching frequency, is used to compute the ripple voltage, which yields 0.159574 V. This result indicates the magnitude of voltage fluctuation caused by the capacitor supplying the load current during the switch on-time.

Buck converter in continuous conduction, `pe_buck_ccm`

The duty cycle, inductor ripple, peak and valley inductor currents, ripple ratio and average input current of an ideal buck (step-down) converter in continuous conduction.

$$D = \frac{V_o}{V_{in}}, \quad \Delta i_L = \frac{(V_{in} - V_o)D}{L f_s}, \quad I_{L,\max/\min} = I_o \pm \frac{\Delta i_L}{2}$$

symbol		meaning	SI unit
`Vin`	in	input voltage	V
`Vout`	in	output voltage	V
`L`	in	inductance	H
`fs`	in	switching frequency	Hz
`Io`	in	load (output) current	A
`D`	out	duty cycle	,
`dIL`	out	peak-to-peak inductor ripple	A
`IL_max`	out	peak inductor current	A
`IL_min`	out	valley inductor current	A
`ripple_ratio`	out	ripple ratio dIL/Io	,
`Iin`	out	average input current	A

Applies when: 0 < Vout < Vin; continuous conduction (IL_min > 0).

```
$ power-electronics solve pe_buck_ccm "Vin=24 V" "Vout=5 V" "L=22 uH" "fs=200 kHz" "Io=3 A"
D = 0.2083333333
dIL = 0.8996212121 A
IL_max = 3.449810606 A
IL_min = 2.550189394 A
ripple_ratio = 0.2998737374
Iin = 0.625 A
  by: Buck converter in continuous conduction  (D = Vout/Vin; dIL = (Vin - Vout) D/(L fs); IL = Io;
IL_max,min = Io +- dIL/2; Iin = D Io)
  Vin = 24 V
  Vout = 5 V
  L = 2.2e-05 H
  fs = 200000 Hz
  Io = 3 A
  assumes: 0 < Vout < Vin; continuous conduction (IL_min > 0)
```

What the worked example means: This calculation determines the operating point of an ideal step-down converter in continuous conduction mode. The duty cycle is derived from the ratio of output to input voltage, resulting in 0.208333. The peak-to-peak inductor ripple current is calculated as 0.899621 A, which leads to maximum and minimum inductor currents of 3.44981 A and 2.55019 A respectively. Finally, the average input current drawn from the source is found to be 0.625 A. These values describe how the converter steps down the voltage while managing current flow through the inductor.

Buck converter in discontinuous conduction, `pe_buck_dcm`

The conversion ratio, output voltage, second-interval duty D2 (diode conduction), peak inductor current and load current of an ideal buck converter in discontinuous conduction.

$$M = \frac{2}{1+\sqrt{1+4K/D^2}}, \quad K = \frac{2L}{RT_s}$$

symbol		meaning	SI unit
`Vin`	in	input voltage	V
`L`	in	inductance	H
`fs`	in	switching frequency	Hz
`R`	in	load resistance	ohm
`D`	in	duty cycle (a fraction or %)	,
`K`	out	dimensionless conduction parameter K	,
`M`	out	conversion ratio Vout/Vin	,
`Vout`	out	output voltage	V
`D2`	out	diode conduction interval as a fraction of the period	,
`I_pk`	out	peak inductor current	A
`Io`	out	load current	A

Applies when: K < 1 - D (discontinuous conduction).

```
$ power-electronics solve pe_buck_dcm "Vin=24 V" "L=10 uH" "fs=100 kHz" "R=20 ohm" D=0.3
K = 0.1
M = 0.6
Vout = 14.4 V
D2 = 0.2
I_pk = 2.88 A
Io = 0.72 A
  by: Buck converter in discontinuous conduction  (K = 2L/(R Ts); M = 2/(1 + sqrt(1 + 4K/D^2)); D2
= D (1 - M)/M; I_pk = (Vin - Vo) D Ts/L)
  Vin = 24 V
  L = 1e-05 H
  fs = 100000 Hz
  R = 20 ohm
  D = 0.3
  assumes: K < 1 - D (discontinuous conduction)
```

In the worked example, Vin = 24 V, L = 10 uH, fs = 100 kHz, R = 20 ohm, D = 0.3 go through the equation above and give K = 0.1, M = 0.6, Vout = 14.4 V, D2 = 0.2. It applies only when K < 1 - D (discontinuous conduction): outside that it says what is wrong instead of returning a number.

Buck converter inductor and capacitor design, `pe_buck_lc_design`

The inductance that gives a chosen ripple ratio and the output capacitance that limits the output ripple to a chosen value in a buck converter (continuous conduction, ideal capacitor).

$$L = \frac{(V_{in} - V_o)D}{rI_o f_s}, \quad C = \frac{rI_o}{8 f_s \Delta v_o}$$

symbol		meaning	SI unit
`Vin`	in	input voltage	V
`Vout`	in	output voltage	V
`Io`	in	load current	A
`fs`	in	switching frequency	Hz
`r`	in	ripple ratio dIL/Io (a fraction or %)	,
`dV`	in	allowed peak-to-peak output ripple	V
`D`	out	duty cycle	,
`L`	out	required inductance	H
`C`	out	required output capacitance	F
`IL_max`	out	peak inductor current	A
`dIL`	out	inductor ripple	A

Applies when: 0 < Vout < Vin; 0 < r < 2.

```
$ power-electronics solve pe_buck_lc_design "Vin=12 V" "Vout=3.3 V" "Io=5 A" "fs=500 kHz" r=0.3
"dV=0.01 V"
D = 0.275
L = 3.19e-06 H
C = 3.75e-05 F
IL_max = 5.75 A
dIL = 1.5 A
  by: Buck converter inductor and capacitor design  (L = (Vin - Vo) D/(r Io fs); C = r Io/(8 fs
dV))
  Vin = 12 V
  Vout = 3.3 V
  Io = 5 A
  fs = 500000 Hz
  r = 0.3
  dV = 0.01 V
  assumes: 0 < Vout < Vin; 0 < r < 2
```

In the worked example, Vin = 12 V, Vout = 3.3 V, Io = 5 A, fs = 500 kHz, r = 0.3, dV = 0.01 V go through the equation above and give D = 0.275, L = 3.19e-06 H, C = 3.75e-05 F, IL_max = 5.75 A. It applies only when 0 < Vout < Vin; 0 < r < 2: outside that it says what is wrong instead of returning a number.

Buck converter output voltage ripple, `pe_buck_output_ripple`

The peak-to-peak output voltage ripple of a buck converter in continuous conduction, with the inductor ripple current flowing entirely into the output capacitor (no ESR).

$$\Delta v_o = \frac{\Delta i_L}{8 C f_s} = \frac{(1-D) V_o}{8 L C f_s^2}$$

symbol		meaning	SI unit
`Vin`	in	input voltage	V
`Vout`	in	output voltage	V
`L`	in	inductance	H
`C`	in	output capacitance	F
`fs`	in	switching frequency	Hz
`D`	out	duty cycle	,
`dIL`	out	inductor ripple	A
`dVo`	out	peak-to-peak output ripple	V
`dVo_pct`	out	output ripple in percent of Vout	,

Applies when: 0 < Vout < Vin; continuous conduction; ripple current into C, ideal capacitor.

```
$ power-electronics solve pe_buck_output_ripple "Vin=24 V" "Vout=5 V" "L=22 uH" "C=100 uF" "fs=200
kHz"
D = 0.2083333333
dIL = 0.8996212121 A
dVo = 0.005622632576 V
dVo_pct = 0.1124526515
  by: Buck converter output voltage ripple  (dIL = (Vin - Vout) D/(L fs); dVo = dIL/(8 C fs) = (1 -
D) Vout/(8 L C fs^2))
  Vin = 24 V
  Vout = 5 V
  L = 2.2e-05 H
  C = 0.0001 F
  fs = 200000 Hz
  assumes: 0 < Vout < Vin; continuous conduction; ripple current into C, ideal capacitor
```

What the worked example means: This calculation determines the peak-to-peak output voltage ripple for a buck converter operating in continuous conduction mode. It uses the input voltage, output voltage, inductance, capacitance, and switching frequency to first find the inductor current ripple, then derives the voltage ripple assuming an ideal capacitor with no equivalent series resistance. The resulting output ripple is 0.00562263 V, representing 0.112453 percent of the nominal output voltage.

Buck converter switch, diode, inductor and input-capacitor currents, `pe_buck_component_currents`

The average and RMS currents of the switch and the diode, the RMS inductor current, the peak current and the RMS input-capacitor current of a buck converter in continuous conduction (trapezoidal waveforms with ripple).

$$I_{sw,rms} = \sqrt{D\left(I_o^2 + \frac{\Delta i_L^2}{12}\right)}, \quad I_{C_{in},rms} = \sqrt{I_{sw,rms}^2 - (DI_o)^2}$$

symbol		meaning	SI unit
`Vin`	in	input voltage	V
`Vout`	in	output voltage	V
`Io`	in	load current	A
`L`	in	inductance	H
`fs`	in	switching frequency	Hz
`D`	out	duty cycle	,
`I_sw_avg`	out	average switch current	A
`I_sw_rms`	out	RMS switch current	A
`I_d_avg`	out	average diode current	A
`I_d_rms`	out	RMS diode current	A
`I_L_rms`	out	RMS inductor current	A
`I_pk`	out	peak switch and inductor current	A
`I_cin_rms`	out	RMS input-capacitor ripple current	A

Applies when: 0 < Vout < Vin; continuous conduction.

```
$ power-electronics solve pe_buck_component_currents "Vin=24 V" "Vout=5 V" "Io=3 A" "L=22 uH"
"fs=200 kHz"
D = 0.2083333333
I_sw_avg = 0.625 A
I_sw_rms = 1.374427395 A
I_d_avg = 2.375 A
I_d_rms = 2.679252233 A
I_L_rms = 3.011219553 A
I_pk = 3.449810606 A
I_cin_rms = 1.224101983 A
  by: Buck converter switch, diode, inductor and input-capacitor currents  (I_sw,rms = sqrt(D (Io^2
+ dI^2/12)); I_d,rms = sqrt((1 - D)(Io^2 + dI^2/12)); I_cin,rms = sqrt(I_sw,rms^2 - (D Io)^2))
  Vin = 24 V
  Vout = 5 V
  Io = 3 A
  L = 2.2e-05 H
  fs = 200000 Hz
  assumes: 0 < Vout < Vin; continuous conduction
```

What the worked example means: This calculation determines the root mean square currents for the main components of a buck converter operating in continuous conduction mode. Using the duty cycle derived from the input voltage 24 V and output voltage 5 V, along with the load current 3 A, this gives the stress on the switch, diode, and input capacitor. The results show an average switch current of 0.625 A, an RMS switch current of 1.37443 A, and a peak current of 3.44981 A. These values are critical for selecting components that can handle thermal dissipation and electrical stress without failure.

Buck-boost converter in continuous conduction, `pe_buck_boost_ccm`

The duty cycle, average inductor current, ripple, peak and valley currents and switch voltage stress of an ideal inverting buck-boost converter in continuous conduction (output voltage as a magnitude).

$$D = \frac{|V_o|}{V_{in} + |V_o|}, \quad I_L = \frac{I_o}{1 - D}, \quad \Delta i_L = \frac{V_{in} D}{L f_s}$$

symbol		meaning	SI unit
`Vin`	in	input voltage	V
`Vout`	in	output voltage magnitude (the output is inverted)	V
`L`	in	inductance	H
`fs`	in	switching frequency	Hz
`Io`	in	load (output) current	A
`D`	out	duty cycle	,
`IL`	out	average inductor current	A
`dIL`	out	peak-to-peak inductor ripple	A
`IL_max`	out	peak inductor current	A
`IL_min`	out	valley inductor current	A
`V_switch`	out	switch voltage stress Vin + Vout	V

Applies when: Vin, Vout > 0; continuous conduction (IL_min > 0).

```
$ power-electronics solve pe_buck_boost_ccm "Vin=12 V" "Vout=15 V" "L=47 uH" "fs=100 kHz" "Io=1 A"
D = 0.5555555556
IL = 2.25 A
dIL = 1.418439716 A
IL_max = 2.959219858 A
IL_min = 1.540780142 A
V_switch = 27 V
  by: Buck-boost converter in continuous conduction  (D = Vout/(Vin + Vout); IL = Io/(1 - D); dIL = Vin D/(L fs))
  Vin = 12 V
  Vout = 15 V
  L = 4.7e-05 H
  fs = 100000 Hz
  Io = 1 A
  assumes: Vin, Vout > 0; continuous conduction (IL_min > 0)
```

What the worked example means: This calculation determines the operating point for an ideal inverting buck-boost converter assuming continuous conduction. The duty cycle, calculated as 0.555556, sets the switch timing to maintain the desired output magnitude. From this, the average inductor current is found to be 2.25 A A, which reflects the load demand adjusted by the conversion ratio. The peak-to-peak current ripple is 1.41844 A A, defining the fluctuation around the average value. These results help identify the peak current stress at 2.95922 A A and the valley current at 1.54078 A A, ensuring the converter remains in continuous mode.

Buck-boost converter in discontinuous conduction, `pe_buck_boost_dcm`

The conversion ratio (magnitude), output voltage, diode conduction interval, peak inductor current and load current of an ideal inverting buck-boost converter in discontinuous conduction.

$$M = \frac{D}{\sqrt{K}}, \quad D_2 = \sqrt{K}$$

symbol		meaning	SI unit
`Vin`	in	input voltage	V
`L`	in	inductance	H
`fs`	in	switching frequency	Hz
`R`	in	load resistance	ohm
`D`	in	duty cycle (a fraction or %)	,
`K`	out	dimensionless conduction parameter K	,
`M`	out	conversion ratio |Vout|/Vin	,
`Vout`	out	output voltage magnitude	V
`D2`	out	diode conduction interval (= sqrt K)	,
`I_pk`	out	peak inductor current	A
`Io`	out	load current	A

Applies when: K < (1 - D)^2 (discontinuous conduction).

```
$ power-electronics solve pe_buck_boost_dcm "Vin=12 V" "L=10 uH" "fs=100 kHz" "R=50 ohm" D=0.4
K = 0.04
M = 2
Vout = 24 V
D2 = 0.2
I_pk = 4.8 A
Io = 0.48 A
  by: Buck-boost converter in discontinuous conduction  (M = D/sqrt(K); D2 = sqrt(K); I_pk = Vin D
Ts/L)
  Vin = 12 V
  L = 1e-05 H
  fs = 100000 Hz
  R = 50 ohm
  D = 0.4
  assumes: K < (1 - D)^2 (discontinuous conduction)
```

In the worked example, Vin = 12 V, L = 10 uH, fs = 100 kHz, R = 50 ohm, D = 0.4 go through the equation above and give K = 0.04, M = 2, Vout = 24 V, D2 = 0.2. It applies only when K < (1 - D)^2 (discontinuous conduction): outside that it says what is wrong instead of returning a number.

Critical inductance at the CCM/DCM boundary, `pe_critical_inductance`

The smallest inductance that keeps a buck, boost or buck-boost converter in continuous conduction at a load resistance (the inductor current just reaches zero at the end of each period).

$$L_{c,buck} = \frac{(1-D)R}{2f_s},\ L_{c,boost} = \frac{D(1-D)^2R}{2f_s},\ L_{c,buck\text{-}boost} = \frac{(1-D)^2R}{2f_s}$$

symbol		meaning	SI unit
`topology`	in	buck, boost or buck-boost	,
`Vin`	in	input voltage	V
`Vout`	in	output voltage (magnitude)	V
`fs`	in	switching frequency	Hz
`R`	in	load resistance	ohm
`D`	out	duty cycle	,
`L_crit`	out	critical (boundary) inductance	H
`Io`	out	load current	A

Applies when: ideal converter at the boundary of continuous conduction.

```
$ power-electronics solve pe_critical_inductance topology=buck "Vin=24 V" "Vout=12 V" "fs=100 kHz"
"R=10 ohm"
D = 0.5
L_crit = 2.5e-05 H
Io = 1.2 A
  by: Critical inductance at the CCM/DCM boundary  (buck Lc = (1 - D) R/(2 fs); boost Lc = D (1 -
D)^2 R/(2 fs); buck-boost Lc = (1 - D)^2 R/(2 fs))
  Vin = 24 V
  Vout = 12 V
  fs = 100000 Hz
  R = 10 ohm
  topology = buck
  assumes: ideal converter at the boundary of continuous conduction
```

What the worked example means: This calculation determines the minimum inductor value needed to ensure the converter operates in continuous conduction mode rather than discontinuous mode. The result depends on the chosen topology, switching frequency, load resistance, and duty cycle. For a buck converter, the formula is Lc equals one minus D times R divided by two fs; for a boost, it is D times one minus D squared times R divided by two fs; and for a buck-boost, it is one minus D squared times R divided by two fs. If the actual inductance is lower than the computed 2.5e-05 H, the current will fall to zero during part of the switching period, increasing ripple and potentially causing instability.

Cuk converter in continuous conduction, `pe_cuk_ccm`

The duty cycle, inductor currents and ripples, coupling-capacitor voltage and its ripple of an ideal Cuk converter (inverted output, given as a magnitude) in continuous conduction.

$$D = \frac{V_o}{V_{in} + V_o},\ V_{C1} = V_{in} + V_o,\ \Delta i_{L1} = \frac{V_{in} D}{L_1 f_s},\ \Delta v_{C1} = \frac{I_o D}{C_1 f_s}$$

symbol		meaning	SI unit
`Vin`	in	input voltage	V
`Vout`	in	output voltage magnitude	V
`L1`	in	input inductance	H
`L2`	in	output inductance	H
`C1`	in	coupling (energy-transfer) capacitance	F
`fs`	in	switching frequency	Hz
`Io`	in	load current	A
`D`	out	duty cycle	,
`IL1`	out	average input inductor current	A
`IL2`	out	average output inductor current	A
`VC1`	out	average coupling-capacitor voltage Vin + Vout	V
`dIL1`	out	input inductor ripple	A
`dIL2`	out	output inductor ripple	A
`dVC1`	out	coupling-capacitor ripple	V

Applies when: continuous conduction in both inductors.

```
$ power-electronics solve pe_cuk_ccm "Vin=12 V" "Vout=15 V" "L1=100 uH" "L2=100 uH" "C1=10 uF"
"fs=100 kHz" "Io=1 A"
D = 0.5555555556
IL1 = 1.25 A
IL2 = 1 A
VC1 = 27 V
dIL1 = 0.6666666667 A
dIL2 = 0.6666666667 A
dVC1 = 0.5555555556 V
  by: Cuk converter in continuous conduction  (D = Vo/(Vin + Vo); IL1 = Io Vo/Vin; VC1 = Vin + Vo;
dIL1 = Vin D/(L1 fs); dIL2 = Vo (1 - D)/(L2 fs); dVC1 = Io D/(C1 fs))
  Vin = 12 V
  Vout = 15 V
  L1 = 0.0001 H
  L2 = 0.0001 H
  C1 = 1e-05 F
  fs = 100000 Hz
  Io = 1 A
  assumes: continuous conduction in both inductors
```

What the worked example means: This calculation determines the operating parameters for an ideal Cuk converter in continuous conduction mode. Based on the input voltage of 12 V and output magnitude of 15 V, the required duty cycle is found to be 0.555556. The average current through the input inductor is 1.25 A, while the output inductor carries 1 A. The coupling capacitor sustains a steady-state voltage of 27 V. Additionally, the current ripple across the input inductor is 0.666667 A, the output inductor ripple is 0.666667 A, and the voltage ripple on the coupling capacitor is 0.555556 V.

Ideal DC-DC conversion ratio from the duty cycle, `pe_conversion_ratio`

The ideal continuous-conduction voltage conversion ratio M = Vout/Vin and output voltage of a buck, boost, buck-boost, Cuk or SEPIC converter at a duty cycle, with the output polarity.

$$M_{buck} = D, \quad M_{boost} = \frac{1}{1-D}, \quad M_{buck\text{-}boost,\,Cuk,\,SEPIC} = \frac{D}{1-D}$$

symbol		meaning	SI unit
`topology`	in	converter topology: buck, boost, buck-boost, Cuk or SEPIC	,
`Vin`	in	input voltage	V
`D`	in	duty cycle (a fraction or %)	,
`M`	out	conversion ratio Vout/Vin (magnitude)	,
`Vout`	out	output voltage magnitude	V
`polarity`	out	output polarity relative to the input (same or inverted)	,

Applies when: 0 < D < 1; ideal, continuous conduction.

```
$ power-electronics solve pe_conversion_ratio topology=boost "Vin=12 V" D=0.6
M = 2.5
Vout = 30 V
polarity = same
  by: Ideal DC-DC conversion ratio from the duty cycle  (buck M = D; boost M = 1/(1 - D); buck-
boost, Cuk, SEPIC M = D/(1 - D))
  Vin = 12 V
  D = 0.6
  topology = boost
  assumes: 0 < D < 1; ideal, continuous conduction
```

What the worked example means: This calculation determines the ideal continuous-conduction voltage conversion ratio and resulting output voltage for a specified power electronics topology. By applying the appropriate formula based on whether the circuit is a buck, boost, or inverting type, this gives the magnitude of the output relative to the input. The result shows that with an input of 12 V and a duty cycle of 0.6, the system produces an output of 30 V, which corresponds to a conversion ratio of 2.5. The polarity is indicated as same, reflecting how the switch timing shapes the energy transfer from source to load.

Interleaved multiphase buck: output current ripple cancellation, `pe_interleaved_buck_ripple`

The per-phase and total output current ripple of an N-phase interleaved buck converter (phases shifted by T/N, equal inductors), the cancellation factor and the ripple frequency N fs.

$$\frac{\Delta i_{tot}}{\Delta i_{ph}} = \frac{N\left(D - \frac{m}{N}\right)\left(\frac{m+1}{N} - D\right)}{D(1-D)},\ m = \lfloor ND \rfloor$$

symbol		meaning	SI unit
`N`	in	number of phases	,
`Vin`	in	input voltage	V
`Vout`	in	output voltage	V
`L`	in	inductance of each phase	H
`fs`	in	switching frequency of each phase	Hz
`D`	out	duty cycle	,
`dI_phase`	out	ripple of one phase	A
`dI_total`	out	ripple of the summed output current	A
`cancellation`	out	ratio of total to per-phase ripple	,
`f_ripple`	out	output ripple frequency N fs	Hz

Applies when: 2 <= N <= 12; 0 < Vout < Vin; continuous conduction in each phase.

```
$ power-electronics solve pe_interleaved_buck_ripple N=2 "Vin=12 V" "Vout=1.2 V" "L=0.47 uH"
"fs=500 kHz"
D = 0.1
dI_phase = 4.595744681 A
dI_total = 4.085106383 A
cancellation = 0.8888888889
f_ripple = 1000000 Hz
  by: Interleaved multiphase buck: output current ripple cancellation  (m = floor(N D);
dI_total/dI_phase = N (D - m/N)((m + 1)/N - D)/(D (1 - D)); zero when N D is a whole number)
  Vin = 12 V
  Vout = 1.2 V
  L = 4.7e-07 H
  fs = 500000 Hz
  assumes: 2 <= N <= 12; 0 < Vout < Vin; continuous conduction in each phase
```

What the worked example means: This calculation determines the current ripple for an interleaved multiphase buck converter. The duty cycle is derived from the input and output voltages as 0.1. The individual phase ripple depends on inductance and switching frequency, resulting in 4.59574 A A. By summing the phases with their respective time shifts, the total output ripple is calculated to be 4.08511 A A. The cancellation factor indicates how effectively the interleaving reduces ripple compared to a single phase. The effective ripple frequency at the output is 1e+06 Hz Hz.

SEPIC converter in continuous conduction, `pe_sepic_ccm`

The duty cycle, inductor currents and ripples, coupling-capacitor voltage and ripple and switch voltage stress of an ideal SEPIC (non-inverting buck-boost) converter in continuous conduction.

$$D = \frac{V_o}{V_{in} + V_o},\ V_{C1} = V_{in},\ \Delta i_{L1,2} = \frac{V_{in} D}{L_{1,2} f_s},\ \Delta v_{C1} = \frac{I_o D}{C_1 f_s}$$

symbol		meaning	SI unit
`Vin`	in	input voltage	V
`Vout`	in	output voltage	V
`L1`	in	input inductance	H
`L2`	in	second inductance	H
`C1`	in	coupling capacitance	F
`fs`	in	switching frequency	Hz
`Io`	in	load current	A
`D`	out	duty cycle	,
`IL1`	out	average input inductor current	A
`IL2`	out	average second inductor current	A
`VC1`	out	average coupling-capacitor voltage (= Vin)	V
`dIL1`	out	input inductor ripple	A
`dIL2`	out	second inductor ripple	A
`dVC1`	out	coupling-capacitor ripple	V
`V_switch`	out	switch voltage stress Vin + Vout	V

Applies when: continuous conduction in both inductors.

```
$ power-electronics solve pe_sepic_ccm "Vin=9 V" "Vout=12 V" "L1=47 uH" "L2=47 uH" "C1=10 uF"
"fs=200 kHz" "Io=1 A"
D = 0.5714285714
IL1 = 1.333333333 A
IL2 = 1 A
VC1 = 9 V
dIL1 = 0.547112462 A
dIL2 = 0.547112462 A
dVC1 = 0.2857142857 V
V_switch = 21 V
  by: SEPIC converter in continuous conduction  (D = Vo/(Vin + Vo); IL1 = Io Vo/Vin; IL2 = Io; VC1
= Vin; dIL1 = Vin D/(L1 fs); dIL2 = Vin D/(L2 fs); dVC1 = Io D/(C1 fs))
  Vin = 9 V
  Vout = 12 V
  L1 = 4.7e-05 H
  L2 = 4.7e-05 H
  C1 = 1e-05 F
  fs = 200000 Hz
  Io = 1 A
  assumes: continuous conduction in both inductors
```

What the worked example means: This calculation determines the operating parameters for an ideal single-ended primary-inductor converter assuming continuous conduction mode. The duty cycle, derived from the input and output voltages, is 0.571429. The average current through the input inductor is 1.33333 A, while the second inductor carries an average current of 1 A. The coupling capacitor maintains a steady voltage equal to the input, here 9 V. Current ripples are calculated as 0.547112 A for the first inductor and 0.547112 A for the second, while the capacitor voltage ripple is 0.285714 V. Finally, the switch must withstand a voltage stress of 21 V.

Devices (9)

Bootstrap capacitor for a high-side gate driver, `pe_bootstrap_capacitor`

The charge drawn from a bootstrap capacitor during the longest high-side on-time and the smallest capacitance that keeps its droop within a limit, with the usual tenfold design margin.

$$C_{boot} \geq \frac{Q_g + I_{lk} D_{max} / f_s}{\Delta V}$$

symbol		meaning	SI unit
`Qg`	in	high-side gate charge	C
`Ileak`	in	quiescent plus leakage current of the high side	A
`fs`	in	switching frequency	Hz
`Dmax`	in	maximum high-side duty cycle (a fraction or %)	,
`dV`	in	allowed bootstrap droop	V
`Q_total`	out	charge drawn per cycle	C
`C_min`	out	smallest bootstrap capacitance	F

symbol		meaning	SI unit
`C_recommended`	out	tenfold margin	F

Applies when: the capacitor recharges fully while the low side is on.

```
$ power-electronics solve pe_bootstrap_capacitor "Qg=60 nC" "Ileak=200 uA" "fs=100 kHz" Dmax=0.9
"dV=0.5 V"
Q_total = 6.18e-08 C
C_min = 1.236e-07 F
C_recommended = 1.236e-06 F
  by: Bootstrap capacitor for a high-side gate driver  (Q = Qg + I_leak Dmax/fs; C_min = Q/dV)
  Qg = 6e-08 C
  Ileak = 0.0002 A
  fs = 100000 Hz
  Dmax = 0.9
  dV = 0.5 V
  assumes: the capacitor recharges fully while the low side is on
```

What the worked example means: This calculation determines the minimum bootstrap capacitor size needed to supply charge during the high-side switch's on-time. The total charge drawn per cycle, 6.18e-08 C, combines the gate charge and leakage losses. Dividing this by the allowed voltage drop yields the theoretical minimum capacitance of 1.236e-07 F. To account for real-world variations and ensure reliability, a tenfold margin is applied, resulting in a recommended capacitance of 1.236e-06 F.

Current sharing between paralleled MOSFETs, `pe_parallel_mosfet_sharing`

The current and conduction loss of each of several paralleled MOSFETs (or any resistive devices) sharing a total current in proportion to their on-state conductances, the total loss and the worst-case current imbalance.

$$I_k = I\frac{1/R_k}{\sum_j 1/R_j}, \quad P_k = I_k^2 R_k$$

symbol		meaning	SI unit
`R`	in	on-resistance of each device in milliohms	,
`I`	in	total current	A
`currents`	out	current in each device, amperes	,
`losses`	out	conduction loss of each device, watts	,
`P_total`	out	total conduction loss	W
`imbalance`	out	largest current divided by the equal share	,

Applies when: static sharing (on-resistance only).

```
$ power-electronics solve pe_parallel_mosfet_sharing "R=[10, 12]" "I=40 A"
currents = [21.8181818182,18.1818181818]
losses = [4.76033057851,3.96694214876]
P_total = 8.727272727 W
imbalance = 1.090909091
  by: Current sharing between paralleled MOSFETs  (I_k = I (1/R_k)/sum(1/R_j); P_k = I_k^2 R_k)
  I = 40 A
  assumes: static sharing (on-resistance only)
```

What the worked example means: This calculation determines how the total current divides among several parallel devices based on their individual on-resistances. Each device carries a portion of the total current inversely proportional to its resistance, resulting in specific branch currents of [21.8182, 18.1818] A and conduction losses of [4.76033, 3.96694] W. The aggregate power dissipated by all devices is 8.72727 W W, while the imbalance metric of 1.09091 indicates how unevenly the load is shared compared to an ideal equal split.

Diode reverse-recovery charge and losses, `pe_diode_reverse_recovery`

The recovered charge, the two recovery intervals and the reverse-recovery energy dissipated in the diode and the extra turn-on energy in the switch (and the powers) for a triangular recovery current of peak Irm, time trr and softness S = tb/ta.

$$Q_{rr} = \tfrac{1}{2} I_{rm} t_{rr}, \quad E_D = \frac{V_r I_{rm} t_b}{6}, \quad E_{sw} = V_r I_{rm} \left(\frac{t_a}{2} + \frac{t_b}{3} \right)$$

symbol		meaning	SI unit
`Irm`	in	peak reverse-recovery current	A
`trr`	in	reverse-recovery time	s
`S`	in	softness factor tb/ta	,
`Vr`	in	reverse (bus) voltage	V
`fs`	in	switching frequency	Hz
`Qrr`	out	recovered charge	C
`ta`	out	current rise interval	s
`tb`	out	current decay interval	s
`E_diode`	out	recovery energy dissipated in the diode	J
`E_switch`	out	extra switch turn-on energy	J
`P_diode`	out	diode recovery loss	W
`P_switch`	out	switch loss caused by recovery	W
`P_total`	out	total recovery loss (= Vr Qrr fs)	W

Applies when: triangular recovery current; diode voltage rises linearly during tb.

```
$ power-electronics solve pe_diode_reverse_recovery "Irm=10 A" "trr=100 ns" S=1 "Vr=400 V" "fs=100
kHz"
Qrr = 5e-07 C
ta = 5e-08 s
tb = 5e-08 s
E_diode = 3.333333333e-05 J
E_switch = 0.0001666666667 J
P_diode = 3.333333333 W
P_switch = 16.66666667 W
P_total = 20 W
  by: Diode reverse-recovery charge and losses  (ta = trr/(1 + S), tb = S trr/(1 + S); Qrr = Irm
trr/2; E_D = Vr Irm tb/6; E_sw = Vr Irm (ta/2 + tb/3); together Vr Qrr)
  Irm = 10 A
  trr = 1e-07 s
  S = 1
  Vr = 400 V
  fs = 100000 Hz
  assumes: triangular recovery current; diode voltage rises linearly during tb
```

What the worked example means: This calculation determines the reverse-recovery characteristics of a diode based on its peak recovery current, total recovery time, softness factor, and the applied reverse voltage. The recovered charge, given as 5e-07 C, represents the total amount of stored minority carrier charge that must be removed before the diode can block voltage again. The recovery interval is split into two parts: the current rise interval 5e-08 s and the current decay interval 5e-08 s. Using these values, the energy dissipated within the diode during recovery is computed as 3.33333e-05 J, while the additional turn-on energy imposed on the switching device is found to be 0.000166667 J. These individual energy losses are then multiplied by the switching frequency to determine the average power loss in the diode (3.33333 W) and the switch (16.6667 W), providing a complete picture of the thermal impact of reverse recovery.

Gate-drive power and currents, `pe_gate_drive_power`

The gate-driver power, energy per switching cycle, average gate current and peak gate current of a MOSFET or IGBT from its total gate charge, drive voltage, switching frequency and total gate resistance.

$$P_G = Q_g V_{drv} f_s, \quad I_{G,pk} = \frac{V_{drv}}{R_g}$$

symbol		meaning	SI unit
`Qg`	in	total gate charge at the drive voltage	C
`Vdrv`	in	gate-drive voltage swing	V
`fs`	in	switching frequency	Hz
`Rg`	in	total gate resistance (driver, external and internal)	ohm
`P_drive`	out	gate-drive power Qg V fs	W
`Ig_avg`	out	average gate current Qg fs	A
`Ig_peak`	out	peak gate current V/Rg	A
`E_cycle`	out	energy per switching cycle Qg V	J

Applies when: the gate fully charges and discharges every cycle.

```
$ power-electronics solve pe_gate_drive_power "Qg=50 nC" "Vdrv=12 V" "fs=200 kHz" "Rg=5 ohm"
P_drive = 0.12 W
Ig_avg = 0.01 A
Ig_peak = 2.4 A
E_cycle = 6e-07 J
  by: Gate-drive power and currents  (P = Qg Vdrv fs; Ig,avg = Qg fs; Ig,peak = Vdrv/Rg)
  Qg = 5e-08 C
  Vdrv = 12 V
  fs = 200000 Hz
  Rg = 5 ohm
  assumes: the gate fully charges and discharges every cycle
```

What the worked example means: This calculation determines the power consumed by the gate driver, the average current it must supply, and the instantaneous peak current required to switch the device. Using the total gate charge 50 nC, the drive voltage swing 12 V, the switching frequency 200 kHz, and the total gate resistance 5 ohm, the energy per cycle is 6e-07 J joules. The resulting average gate current of 0.01 A amperes represents the steady-state load on the driver, while the peak current of 2.4 A amperes indicates the maximum transient demand during each transition.

Hard-switching loss of a power transistor, `pe_switching_loss`

The turn-on and turn-off energies and the switching and output-capacitance losses of a MOSFET or IGBT switching an inductive (clamped) load with linear voltage and current transitions.

$$P_{sw} = \tfrac{1}{2} V I \left(t_r + t_f\right) f_s, \quad P_{oss} = \tfrac{1}{2} C_{oss} V^2 f_s$$

symbol		meaning	SI unit
`V`	in	blocking (dc bus) voltage	V
`I`	in	switched current	A
`tr`	in	turn-on crossover time	s
`tf`	in	turn-off crossover time	s
`fs`	in	switching frequency	Hz
`Coss`	in	output capacitance	F
`E_on`	out	turn-on energy	J
`E_off`	out	turn-off energy	J
`P_sw`	out	switching loss	W
`P_oss`	out	output-capacitance loss	W
`P_total`	out	total switching-related loss	W

Applies when: clamped inductive load, linear transitions.

```
$ power-electronics solve pe_switching_loss "V=400 V" "I=10 A" "tr=30 ns" "tf=50 ns" "fs=100 kHz"
"Coss=100 pF"
E_on = 6e-05 J
E_off = 0.0001 J
P_sw = 16 W
P_oss = 0.8 W
P_total = 16.8 W
  by: Hard-switching loss of a power transistor  (E_on = V I tr/2; E_off = V I tf/2; P_sw = (E_on +
E_off) fs; P_oss = Coss V^2 fs/2)
  V = 400 V
  I = 10 A
  tr = 3e-08 s
  tf = 5e-08 s
  fs = 100000 Hz
  Coss = 1e-10 F
  assumes: clamped inductive load, linear transitions
```

In the worked example, V = 400 V, I = 10 A, tr = 30 ns, tf = 50 ns, fs = 100 kHz, Coss = 100 pF go through the equation above and give E_on = 6e-05 J, E_off = 0.0001 J, P_sw = 16 W, P_oss = 0.8 W. It applies only when clamped inductive load, linear transitions: outside that it says what is wrong instead of returning a number.

MOSFET conduction loss at junction temperature, `pe_mosfet_conduction_loss`

The on-resistance of a MOSFET at its junction temperature (linear temperature coefficient from the 25 degC value) and the conduction loss for an RMS drain current, with the loss at 25 degC for comparison.

$$R_{ds}(T_j) = R_{ds,25}\,(1 + \alpha(T_j - 25^\circ\mathrm{C})), \quad P = I_{rms}^2 R_{ds}(T_j)$$

symbol		meaning	SI unit
`Rds25`	in	on-resistance at room temperature	ohm
`alpha`	in	temperature coefficient of the on-resistance per kelvin	,
`Tj`	in	junction temperature	K
`Irms`	in	RMS drain current	A
`Rds_T`	out	on-resistance at Tj	ohm
`P`	out	conduction loss at the junction temperature	W
`P_25`	out	conduction loss at room temperature	W
`ratio`	out	ratio of hot to room-temperature on-resistance	,

Applies when: linear temperature model.

```
$ power-electronics solve pe_mosfet_conduction_loss "Rds25=0.01 ohm" alpha=0.007 "Tj=125 degC"
"Irms=20 A"
Rds_T = 0.017 ohm
P = 6.8 W
P_25 = 4 W
ratio = 1.7
  by: MOSFET conduction loss at junction temperature  (Rds(Tj) = Rds25 (1 + alpha (Tj - 25 degC));
P = Irms^2 Rds(Tj))
  Rds25 = 0.01 ohm
  alpha = 0.007
  Tj = 398.15 K
  Irms = 20 A
  assumes: linear temperature model
```

What the worked example means: This calculation determines the power dissipated as heat in a MOSFET due to its internal resistance when current flows through it. It starts with the known resistance at room temperature, 0.01 ohm, and adjusts it for the actual operating junction temperature, 125 degC, using a linear coefficient 0.007. The resulting hot resistance, 0.017 ohm, is then combined with the square of the RMS drain current, 20 A, to yield the total conduction loss of 6.8 W. For reference, the loss at standard room conditions is also provided as 4 W, allowing you to see how much the heating effect increases the power burden.

RC snubber from measured ringing frequencies, `pe_rc_snubber_ringing`

The parasitic capacitance and inductance of a ringing switch node found by measuring the ringing frequency with and without an added capacitor, the damping resistor (characteristic impedance), the snubber capacitor (k times the parasitic) and the snubber resistor loss.

$$C_p = \frac{C_{add}}{(f_0/f_1)^2 - 1}, \quad L_p = \frac{1}{(2\pi f_0)^2 C_p}, \quad R_s = \sqrt{L_p/C_p}$$

symbol		meaning	SI unit
`f0`	in	ringing frequency without the added capacitor	Hz
`f1`	in	ringing frequency with the added capacitor	Hz
`Cadd`	in	added test capacitance	F
`k`	in	snubber capacitance as a multiple of the parasitic capacitance	,
`V`	in	voltage the node swings to	V
`fs`	in	switching frequency	Hz
`Cp`	out	parasitic capacitance	F
`Lp`	out	parasitic inductance	H
`Rs`	out	snubber resistance sqrt(Lp/Cp)	ohm
`Cs`	out	snubber capacitance k Cp	F
`P_R`	out	snubber resistor loss	W

Applies when: f1 < f0.

```
$ power-electronics solve pe_rc_snubber_ringing "f0=50000 kHz" "f1=25000 kHz" "Cadd=300 pF" k=4
"V=48 V" "fs=500 kHz"
Cp = 1e-10 F
Lp = 1.013211836e-07 H
Rs = 31.83098862 ohm
Cs = 4e-10 F
P_R = 0.4608 W
  by: RC snubber from measured ringing frequencies  (Cp = Cadd/((f0/f1)^2 - 1); Lp = 1/((2 pi f0)^2
Cp); Rs = sqrt(Lp/Cp); Cs = k Cp; P = Cs V^2 fs)
  f0 = 50000000 Hz
  f1 = 25000000 Hz
  Cadd = 3e-10 F
  k = 4
  V = 48 V
  fs = 500000 Hz
  assumes: f1 < f0
```

In the worked example, f0 = 50000 kHz, f1 = 25000 kHz, Cadd = 300 pF, k = 4, V = 48 V, fs = 500 kHz go through the equation above and give Cp = 1e-10 F, Lp = 1.013211836e-07 H, Rs = 31.83098862 ohm, Cs = 4e-10 F. It applies only when f1 < f0: outside that it says what is wrong instead of returning a number.

RCD turn-off snubber design, `pe_turnoff_snubber`

The turn-off snubber capacitance that lets the switch voltage reach the bus voltage just as the current finishes falling, the switch turn-off energy with and without the snubber, and the snubber (resistor) loss per cycle and in watts.

$$C_s = \frac{I t_f}{2V}, \quad E_{sw} = \frac{I^2 t_f^2}{24 C_s} = \frac{V I t_f}{12}, \quad E_R = \tfrac{1}{2} C_s V^2$$

symbol		meaning	SI unit
`I`	in	switched (load) current	A
`V`	in	bus voltage	V
`tf`	in	current fall time	s
`fs`	in	switching frequency	Hz
`Cs`	out	snubber capacitance	F
`E_off_with`	out	switch turn-off energy with the snubber	J
`E_off_without`	out	switch turn-off energy without a snubber	J
`E_snubber`	out	energy dumped in the snubber resistor	J
`P_switch`	out	switch turn-off loss with the snubber	W
`P_snubber`	out	snubber resistor loss	W
`P_total`	out	switch plus snubber loss	W

Applies when: linear current fall; the snubber capacitor discharges fully during the on-time.

```
$ power-electronics solve pe_turnoff_snubber "I=10 A" "V=300 V" "tf=100 ns" "fs=50 kHz"
Cs = 1.666666667e-09 F
E_off_with = 2.5e-05 J
E_off_without = 0.00015 J
E_snubber = 7.5e-05 J
P_switch = 1.25 W
P_snubber = 3.75 W
P_total = 5 W
  by: RCD turn-off snubber design  (Cs = I tf/(2V); E_sw = I^2 tf^2/(24 Cs); E_R = Cs V^2/2)
  I = 10 A
  V = 300 V
  tf = 1e-07 s
  fs = 50000 Hz
  assumes: linear current fall; the snubber capacitor discharges fully during the on-time
```

What the worked example means: This calculation determines the required RCD turn-off snubber components based on the switched current, bus voltage, and fall time. The snubber capacitance is found to be 1.66667e-09 F, which ensures the switch voltage rises linearly to the bus level as current falls. Consequently, the switch turn-off energy with the snubber is 2.5e-05 J, while the energy dissipated in the resistor per cycle is 7.5e-05 J. At the given switching frequency, these translate to a switch power loss of 1.25 W and a snubber power loss of 3.75 W, resulting in a combined thermal load of 5 W.

Zero-voltage switching: resonant transition of a switch node, `pe_zvs_transition`

Whether an inductor current can swing a switch node's capacitance from 0 to the input voltage (zero-voltage switching), the minimum current needed, the energies, and the transition time (or the time to the voltage peak when it cannot), for a resonant LC transition.

$$v(t) = I_0 Z \sin \omega t, \quad Z = \sqrt{L/C}, \quad t_{zvs} = \frac{1}{\omega} \sin^{-1} \frac{V_{in}}{I_0 Z}$$

symbol		meaning	SI unit
`Vin`	in	voltage the node must swing	V
`Ceq`	in	total node capacitance	F
`L`	in	resonant (leakage) inductance	H
`I0`	in	inductor current at the start of the transition	A
`Z`	out	characteristic impedance sqrt(L/C)	ohm
`f_res`	out	resonant frequency	Hz
`I_min`	out	minimum current for ZVS Vin/Z	A
`E_L`	out	inductor energy	J
`E_C`	out	capacitor energy	J
`zvs`	out	achieved or not achieved	,
`t_transition`	out	time to reach Vin (or to the voltage peak when ZVS fails)	s
`v_reached`	out	highest node voltage reached (capped at Vin)	V

Applies when: lossless resonant transition starting at 0 V.

```
$ power-electronics solve pe_zvs_transition "Vin=400 V" "Ceq=400 pF" "L=20 uH" "I0=3 A"
Z = 223.6067977 ohm
f_res = 1779406.359 Hz
I_min = 1.788854382 A
E_L = 9e-05 J
E_C = 3.2e-05 J
zvs = achieved
t_transition = 5.714183564e-08 s
v_reached = 400 V
  by: Zero-voltage switching: resonant transition of a switch node  (v(t) = I0 Z sin(w t), Z =
sqrt(L/C); ZVS when I0 Z >= Vin; t = asin(Vin/(I0 Z))/w)
  Vin = 400 V
  Ceq = 4e-10 F
  L = 2e-05 H
  I0 = 3 A
  assumes: lossless resonant transition starting at 0 V
```

In the worked example, Vin = 400 V, Ceq = 400 pF, L = 20 uH, I0 = 3 A go through the equation above and give Z = 223.6067977 ohm, f_res = 1779406.359 Hz, I_min = 1.788854382 A, E_L = 9e-05 J. It applies only when lossless resonant transition starting at 0 V: outside that it says what is wrong instead of returning a number.

Front ends (2)

Boost power-factor-correction stage, `pe_boost_pfc`

The peak line current, duty cycle and inductor ripple at the line peak, the largest ripple over the line cycle, the inductor current at the line peak and the second-harmonic output voltage ripple of a continuous-conduction boost PFC stage with unity power factor.

$$\Delta i_L(v) = \frac{v\,(1 - v/V_o)}{L f_s}, \quad \Delta i_{L,max} = \frac{V_o}{4 L f_s}, \quad \Delta V_o = \frac{P_o}{2\pi f_{line} C V_o}$$

symbol		meaning	SI unit
`Vac`	in	RMS line voltage	V
`f_line`	in	line frequency	Hz
`Vo`	in	dc output voltage	V
`Po`	in	output power	W
`eff`	in	efficiency (a fraction or %)	,
`L`	in	boost inductance	H
`fs`	in	switching frequency	Hz
`C`	in	output (bulk) capacitance	F
`I_in_pk`	out	peak line current	A
`D_peak`	out	duty cycle at the line peak	,
`dI_peak`	out	inductor ripple at the line peak	A
`dI_max`	out	largest inductor ripple over the line cycle	A
`IL_at_peak`	out	peak inductor current at the line peak	A

symbol		meaning	SI unit
`dVo_pp`	out	peak-to-peak second-harmonic output ripple	V

Applies when: unity power factor, continuous conduction; Vo > sqrt(2) Vac; small output ripple.

```
$ power-electronics solve pe_boost_pfc "Vac=230 V" "f_line=50 Hz" "Vo=400 V" "Po=500 W" eff=0.95
"L=500 uH" "fs=65 kHz" "C=330 uF"
I_in_pk = 3.236186642 A
D_peak = 0.1868272016
dI_peak = 1.869819057 A
dI_max = 3.076923077 A
IL_at_peak = 4.17109617 A
dVo_pp = 12.05719266 V
  by: Boost power-factor-correction stage  (Ipk = 2 Po/(eff Vpk); dI(v) = v (1 - v/Vo)/(L fs),
largest at v = Vo/2; dVo = Po/(2 pi f_line C Vo))
  Vac = 230 V
  f_line = 50 Hz
  Vo = 400 V
  Po = 500 W
  eff = 0.95
  L = 0.0005 H
  fs = 65000 Hz
  C = 0.00033 F
  assumes: unity power factor, continuous conduction; Vo > sqrt(2) Vac; small output ripple
```

What the worked example means: This calculation determines key operating parameters for a boost power factor correction stage. It computes the peak line current as 3.23619 A, derived from output power, efficiency, and peak input voltage. The duty cycle at the line peak is found to be 0.186827, while the largest inductor current ripple over the line cycle is 3.07692 A. Additionally, the second-harmonic output voltage ripple is calculated as 12.0572 V, assuming continuous conduction mode and unity power factor.

Hold-up (bulk) capacitor, `pe_hold_up_capacitor`

The bulk capacitance that keeps a constant-power load running for a hold-up time while the capacitor voltage falls from V1 to the minimum operating voltage V2, with the energies involved.

$$C = \frac{2 P_o t_{hold}}{V_1^2 - V_2^2}$$

symbol		meaning	SI unit
`Po`	in	load power drawn from the capacitor	W
`t_hold`	in	hold-up time	s
`V1`	in	starting capacitor voltage	V
`V2`	in	minimum operating voltage	V
`C`	out	required capacitance	F
`E_used`	out	energy delivered Po t	J
`E_initial`	out	energy stored at the starting voltage	J
`E_remaining`	out	energy left at the minimum voltage	J

Applies when: constant-power load; V2 < V1.

```
$ power-electronics solve pe_hold_up_capacitor "Po=300 W" "t_hold=20 ms" "V1=390 V" "V2=300 V"
C = 0.000193236715 F
E_used = 6 J
E_initial = 14.69565217 J
E_remaining = 8.695652174 J
  by: Hold-up (bulk) capacitor  (C = 2 Po t_hold/(V1^2 - V2^2))
  Po = 300 W
  t_hold = 0.02 s
  V1 = 390 V
  V2 = 300 V
  assumes: constant-power load; V2 < V1
```

What the worked example means: This calculation determines the bulk capacitance needed to maintain a constant-power load during a power interruption. It uses the energy balance principle, equating the energy drawn from the capacitor to the difference between its initial and final stored energies. The result shows that a capacitance of 0.000193237 F allows the voltage to drop from 390 V to 300 V while delivering 6 J of energy over 20 ms. This ensures the system remains operational until backup power engages.

Inverters (7)

Inverter dead-time voltage error, `pe_dead_time_error`

The average voltage error per switching period caused by the dead time of an inverter leg, the peak of its fundamental (the error is a square wave in phase with the current) and that as a percentage of the wanted fundamental.

$$\Delta V = t_d f_s V_{dc}, \quad \Delta \hat{V}_1 = \frac{4}{\pi} t_d f_s V_{dc}$$

symbol		meaning	SI unit
`Vdc`	in	dc-link voltage	V
`td`	in	dead time	s
`fs`	in	switching frequency	Hz
`V1`	in	wanted fundamental peak voltage	V
`dV_avg`	out	average voltage error td fs Vdc	V
`dV1_peak`	out	peak fundamental of the error	V
`dV1_pct`	out	error in percent of the wanted fundamental	,

Applies when: td fs < 0.5; the current does not change sign within a switching period.

```
$ power-electronics solve pe_dead_time_error "Vdc=600 V" "td=2000 ns" "fs=10 kHz" "V1=250 V"
dV_avg = 12 V
dV1_peak = 15.27887454 V
dV1_pct = 6.111549815
  by: Inverter dead-time voltage error  (dV = td fs Vdc; its fundamental 4 dV/pi)
  Vdc = 600 V
  td = 2e-06 s
  fs = 10000 Hz
  V1 = 250 V
  assumes: td fs < 0.5; the current does not change sign within a switching period
```

What the worked example means: This calculation determines the average voltage distortion caused by inverter dead time. Using the DC-link voltage 600 V, dead time 2000 ns, and switching frequency 10 kHz, it computes the average error 12 V. The peak of the fundamental component of this error is found to be 15.2789 V. When compared to the intended fundamental voltage 250 V, this error constitutes 6.11155 of the target signal, quantifying the impact on waveform quality.

Quasi-square-wave (phase-shifted) full-bridge inverter, `pe_quasi_square_inverter`

The fundamental, the RMS value of an odd harmonic n, the RMS output and the THD of a full-bridge inverter with a zero-voltage interval alpha at each end of every half-cycle, and the alpha that eliminates harmonic n.

$$V_{n,rms} = \frac{4V_{dc}}{n\pi\sqrt{2}}\cos(n\alpha), \quad V_{rms} = V_{dc}\sqrt{1 - \frac{2\alpha}{\pi}}$$

symbol		meaning	SI unit
`Vdc`	in	dc input voltage	V
`alpha`	in	zero-voltage interval at each end of a half-cycle	rad
`n`	in	odd harmonic order	,
`V1_rms`	out	RMS fundamental	V
`Vn_rms`	out	RMS value of harmonic n	V
`Vrms`	out	RMS output voltage	V
`THD`	out	total harmonic distortion	,
`alpha_eliminate_n_deg`	out	zero interval in degrees that removes harmonic n	,

Applies when: 0 <= alpha < 90 degrees; n odd, 3..99.

```
$ power-electronics solve pe_quasi_square_inverter "Vdc=100 V" "alpha=30 deg" n=3
V1_rms = 77.96968012 V
Vn_rms = 0 V
Vrms = 81.64965809 V
THD = 0.3108419393
alpha_eliminate_n_deg = 30
  by: Quasi-square-wave (phase-shifted) full-bridge inverter  (Vn = 4 Vdc cos(n alpha)/(n pi sqrt
2); Vrms = Vdc sqrt(1 - 2 alpha/pi); harmonic n vanishes at alpha = 90/n degrees)
  Vdc = 100 V
  alpha = 0.5235987756 rad
  assumes: 0 <= alpha < 90 degrees; n odd, 3..99
```

What the worked example means: This calculation determines the voltage characteristics of a phase-shifted full-bridge inverter. Using a DC input of 100 V and a zero-voltage interval of 30 deg, it computes the root mean square value of the fundamental frequency, which is 77.9697 V, as well as the RMS magnitude for the specified odd harmonic order, resulting in 0 V. The overall RMS output voltage is calculated as 81.6497 V, while the total harmonic distortion is expressed as 0.310842. Additionally, the method identifies the specific zero interval angle required to eliminate the selected harmonic, yielding 30.

Sinusoidal PWM: fundamental output voltage, `pe_spwm_fundamental`

The fundamental output voltage of sinusoidal (sine-triangle) PWM in the linear range: the peak and RMS phase-leg voltage, the RMS line voltage of a three-phase inverter, the RMS output of a bipolar full bridge, and the carrier frequency.

$$\hat{V}_{1,leg} = m_a \frac{V_{dc}}{2}, \quad V_{LL1,rms} = \frac{\sqrt{3}}{2\sqrt{2}} m_a V_{dc}, \quad f_c = m_f f_1$$

symbol		meaning	SI unit
`Vdc`	in	dc-link voltage	V
`ma`	in	amplitude modulation index	,
`mf`	in	frequency modulation ratio (odd whole number)	,
`f1`	in	fundamental output frequency	Hz
`V1_leg_peak`	out	peak fundamental of a leg against the dc midpoint	V
`V1_leg_rms`	out	RMS fundamental of a leg	V
`V1_LL_rms`	out	RMS fundamental line voltage of a three-phase inverter	V
`V1_fullbridge_rms`	out	RMS fundamental of a bipolar full bridge	V
`f_carrier`	out	carrier (switching) frequency	Hz

Applies when: 0 < ma <= 1; mf odd, 15..201 (natural sampling).

```
$ power-electronics solve pe_spwm_fundamental "Vdc=600 V" ma=0.8 mf=21 "f1=50 Hz"
V1_leg_peak = 240 V
V1_leg_rms = 169.7056275 V
V1_LL_rms = 293.9387691 V
V1_fullbridge_rms = 339.411255 V
f_carrier = 1050 Hz
  by: Sinusoidal PWM: fundamental output voltage  (V1,leg = ma Vdc/2 (peak); V1,LL = sqrt(3) ma
Vdc/(2 sqrt 2); bipolar full bridge V1 = ma Vdc/sqrt 2; fc = mf f1)
  Vdc = 600 V
  ma = 0.8
  f1 = 50 Hz
  assumes: 0 < ma <= 1; mf odd, 15..201 (natural sampling)
```

What the worked example means: This calculation determines the sinusoidal pulse-width modulation outputs for a power inverter. Using the dc-link voltage of 600 V and an amplitude modulation index of 0.8, it computes the peak leg voltage as 240 V and the root mean square line voltage as 293.939 V. The resulting switching pattern operates at a carrier frequency of 1050 Hz, derived from the fundamental output frequency of 50 Hz and the frequency modulation ratio of 21. These values define the effective voltage delivered to the load within the linear operating range.

Space-vector modulation dwell times, `pe_space_vector_times`

The sector and the dwell times T1, T2 of the two adjacent active vectors and T0 of the zero vectors that synthesise a reference space vector (peak phase voltage Vref at angle theta) in one switching period of a two-level three-phase inverter.

$$T_1 = \frac{\sqrt{3} T_s V_{ref}}{V_{dc}} \sin\left(\tfrac{\pi}{3} - \theta'\right), \quad T_2 = \frac{\sqrt{3} T_s V_{ref}}{V_{dc}} \sin\theta', \quad T_0 = T_s - T_1 - T_2$$

symbol		meaning	SI unit
`Vref`	in	reference vector magnitude (peak phase voltage)	V
`theta`	in	reference vector angle	rad
`Vdc`	in	dc-link voltage	V
`fs`	in	switching (sampling) frequency	Hz
`sector`	out	sector number	,
`T1`	out	dwell time of the first active vector	s
`T2`	out	dwell time of the second active vector	s
`T0`	out	total zero-vector time	s
`m`	out	modulation index	,

Applies when: inside the hexagon (T1 + T2 <= Ts).

```
$ power-electronics solve pe_space_vector_times "Vref=200 V" "theta=25 deg" "Vdc=600 V" "fs=10 kHz"
sector = 1
T1 = 3.311545099e-05 s
T2 = 2.439987672e-05 s
T0 = 4.248467229e-05 s
m = 0.5773502692
  by: Space-vector modulation dwell times  (T1 = sqrt(3) Ts Vref/Vdc sin(60 deg - theta'), T2 =
sqrt(3) Ts Vref/Vdc sin(theta'), T0 = Ts - T1 - T2, theta' = angle within the sector)
  Vref = 200 V
  theta = 0.436332313 rad
  Vdc = 600 V
  fs = 10000 Hz
  assumes: inside the hexagon (T1 + T2 <= Ts)
```

What the worked example means: This calculation determines the specific time durations required to synthesize a reference voltage vector using space-vector modulation. The resulting dwell times for the first active vector, second active vector, and zero vectors are 3.31155e-05 s, 2.43999e-05 s, and 4.24847e-05 s respectively, within switching period derived from frequency 10 kHz. These values ensure the average output matches the desired magnitude 200 V and angle 25 deg relative to the DC link voltage 600 V.

Square-wave inverter output and harmonics, `pe_square_wave_inverter`

The RMS output voltage, the fundamental (RMS and peak), the RMS value of an odd harmonic n and the THD of a single-phase half-bridge or full-bridge inverter operated with square-wave (180 degree) switching.

$$V_{n,rms} = \frac{4A}{n\pi\sqrt{2}}, \quad THD = \sqrt{\frac{\pi^2}{8} - 1}$$

symbol		meaning	SI unit
`Vdc`	in	dc input voltage	V
`bridge`	in	half-bridge or full-bridge	,
`n`	in	odd harmonic order	,
`Vrms`	out	RMS output voltage	V
`V1_rms`	out	RMS fundamental	V
`V1_peak`	out	peak fundamental	V
`Vn_rms`	out	RMS value of harmonic n	V
`THD`	out	total harmonic distortion	,

Applies when: n odd, 3..99; ideal switching, no dead time.

```
$ power-electronics solve pe_square_wave_inverter "Vdc=100 V" bridge=full-bridge n=3
Vrms = 100 V
V1_rms = 90.03163162 V
V1_peak = 127.3239545 V
Vn_rms = 30.01054387 V
THD = 0.4834258476
  by: Square-wave inverter output and harmonics  (A = Vdc (full bridge) or Vdc/2 (half bridge); V1
= 4 A/(pi sqrt 2); Vn = V1/n; THD = sqrt(pi^2/8 - 1))
  Vdc = 100 V
  bridge = full-bridge
  assumes: n odd, 3..99; ideal switching, no dead time
```

What the worked example means: This calculation determines the output characteristics of a square-wave inverter. Given a DC input voltage of 100 V and a full-bridge topology, it computes the root mean square voltage, which equals 100 V. The fundamental component has an RMS value of 90.0316 V and a peak value of 127.324 V. For the selected odd harmonic order 3, the RMS magnitude is 30.0105 V. Finally, the total harmonic distortion, representing the ratio of all harmonics to the fundamental, is calculated as 0.483426. These values describe the ideal voltage waveform produced by switching at one hundred eighty degrees.

Square-wave inverter with an RL load: current, `pe_inverter_rl_load_current`

The steady-state peak current, RMS current, load power and average dc source current of a full-bridge square-wave inverter driving a series RL load (exact exponential current, not a harmonic approximation).

$$I_{max} = \frac{V_{dc}}{R}\,\frac{1 - e^{-T/2\tau}}{1 + e^{-T/2\tau}}, \quad \tau = \frac{L}{R}$$

symbol		meaning	SI unit
`Vdc`	in	dc input voltage	V
`f`	in	output frequency	Hz
`R`	in	load resistance	ohm

symbol		meaning	SI unit
`L`	in	load inductance	H
`I_max`	out	peak load current	A
`I_rms`	out	RMS load current	A
`P`	out	load power	W
`Is_avg`	out	average dc source current	A

Applies when: steady state, ideal switches with antiparallel diodes.

```
$ power-electronics solve pe_inverter_rl_load_current "Vdc=100 V" "f=60 Hz" "R=10 ohm" "L=25 mH"
I_max = 9.311096087 A
I_rms = 6.643299141 A
P = 441.3342348 W
Is_avg = 4.413342348 A
  by: Square-wave inverter with an RL load: current  (I_max = (Vdc/R)(1 - e^(-T/2tau))/(1 + e^(-
T/2tau)); i(t) = Vdc/R + (-I_max - Vdc/R) e^(-t/tau) over a half-cycle; P = I_rms^2 R)
  Vdc = 100 V
  f = 60 Hz
  R = 10 ohm
  L = 0.025 H
  assumes: steady state, ideal switches with antiparallel diodes
```

What the worked example means: This calculation determines the exact exponential current response of a series RL load driven by a full-bridge square-wave inverter. Using the dc input voltage 100 V, output frequency 60 Hz, resistance 10 ohm, and inductance 25 mH, it computes the steady-state peak current 9.3111 A, the RMS current 6.6433 A, the average dc source current 4.41334 A, and the total load power 441.334 W. These values represent the true waveform characteristics rather than a fundamental harmonic approximation.

Three-phase six-step (square-wave) inverter, `pe_six_step_inverter`

The RMS line and phase voltages, their fundamentals, the THD and the 5th and 7th harmonics of a three-phase voltage-source inverter in six-step (180 degree) operation.

$$V_{LL1} = \frac{\sqrt{6}}{\pi} V_{dc}, \quad V_{LL} = \sqrt{\frac{2}{3}} V_{dc}, \quad V_{LL,h} = \frac{V_{LL1}}{h}$$

symbol		meaning	SI unit
`Vdc`	in	dc-link voltage	V
`f`	in	output (fundamental) frequency	Hz
`VLL_rms`	out	RMS line-to-line voltage	V
`VLL1_rms`	out	RMS fundamental line voltage	V
`Vph_rms`	out	RMS phase voltage	V
`Vph1_rms`	out	RMS fundamental phase voltage	V
`THD`	out	THD of the line voltage	,
`VLL5_rms`	out	RMS fifth-harmonic line voltage	V
`VLL7_rms`	out	RMS seventh-harmonic line voltage	V

symbol		meaning	SI unit
`f5`	out	fifth-harmonic frequency	Hz
`f7`	out	seventh-harmonic frequency	Hz

Applies when: balanced star load, ideal switching.

```
$ power-electronics solve pe_six_step_inverter "Vdc=600 V" "f=50 Hz"
VLL_rms = 489.8979486 V
VLL1_rms = 467.8180807 V
Vph_rms = 282.8427125 V
Vph1_rms = 270.0948948 V
THD = 0.3108419393
VLL5_rms = 93.56361615 V
VLL7_rms = 66.83115439 V
f5 = 250 Hz
f7 = 350 Hz
  by: Three-phase six-step (square-wave) inverter  (V_LL = sqrt(2/3) Vdc; V_LL1 = sqrt(6) Vdc/pi =
0.78 Vdc; harmonics 6k +- 1 at V_LL1/h)
  Vdc = 600 V
  f = 50 Hz
  assumes: balanced star load, ideal switching
```

What the worked example means: This calculation determines the voltage characteristics of a three-phase six-step inverter. Given a DC link voltage of 600 V, the total RMS line-to-line voltage is computed as 489.898 V. The fundamental frequency component of this voltage, which represents the useful power transfer capability, has an RMS value of 467.818 V. The corresponding phase voltages are also derived, with the fundamental phase voltage being 270.095 V. These values assume ideal switching devices and a balanced star-connected load.

Isolated converters (4)

Flyback converter in continuous conduction, `pe_flyback_ccm`

The duty cycle, magnetizing current (primary-referred) and ripple, peak primary and secondary currents and the switch and diode voltage stresses of an ideal flyback converter in continuous conduction.

$$\frac{V_o}{V_{in}} = \frac{1}{n}\frac{D}{1-D}, \quad I_m = \frac{I_o}{n(1-D)}, \quad \Delta i_m = \frac{V_{in}D}{L_m f_s}$$

symbol		meaning	SI unit
`Vin`	in	input voltage	V
`Vout`	in	output voltage	V
`n`	in	turns ratio Np/Ns	,
`Lm`	in	magnetizing inductance (primary)	H
`fs`	in	switching frequency	Hz
`Io`	in	load current	A
`D`	out	duty cycle	,
`Im`	out	average magnetizing current referred to the primary	A

symbol		meaning	SI unit
`dIm`	out	magnetizing current ripple	A
`Ipk_primary`	out	peak primary (switch) current	A
`Ipk_secondary`	out	peak secondary (diode) current	A
`V_switch`	out	switch voltage stress Vin + n Vo	V
`V_diode`	out	diode reverse voltage Vo + Vin/n	V

Applies when: continuous conduction of the magnetizing current; no leakage inductance.

```
$ power-electronics solve pe_flyback_ccm "Vin=48 V" "Vout=12 V" n=2 "Lm=200 uH" "fs=100 kHz" "Io=2
A"
D = 0.3333333333
Im = 1.5 A
dIm = 0.8 A
Ipk_primary = 1.9 A
Ipk_secondary = 3.8 A
V_switch = 72 V
V_diode = 36 V
  by: Flyback converter in continuous conduction  (D = n Vo/(Vin + n Vo); Im = Io/(n (1 - D)); dIm
= Vin D/(Lm fs))
  Vin = 48 V
  Vout = 12 V
  n = 2
  Lm = 0.0002 H
  fs = 100000 Hz
  Io = 2 A
  assumes: continuous conduction of the magnetizing current; no leakage inductance
```

What the worked example means: This calculation determines key operating parameters for an ideal flyback converter in continuous conduction mode. Using the input voltage of 48 V and output voltage of 12 V with a turns ratio of 2, the duty cycle is found to be 0.333333. The average magnetizing current referred to the primary side is calculated as 1.5 A, while the ripple component is 0.8 A. Consequently, the peak primary current is 1.9 A and the peak secondary current is 3.8 A. These values define the stress on the switching device and diode, with voltage stresses of 72 V and 36 V respectively.

Flyback magnetizing inductance for discontinuous conduction, `pe_flyback_dcm_design`

The magnetizing inductance at which a flyback converter delivers a power at a duty cycle in discontinuous conduction (the primary current ramps from zero every period), with the peak, RMS and average primary currents.

$$L_m = \frac{(V_{in}D)^2}{2P_{in}f_s}, \quad I_{pk} = \frac{V_{in}D}{L_m f_s}, \quad I_{rms} = I_{pk}\sqrt{D/3}$$

symbol		meaning	SI unit
`Vin`	in	input voltage (the minimum, for design)	V
`Po`	in	output power	W
`eff`	in	efficiency (a fraction or %)	,
`fs`	in	switching frequency	Hz

symbol		meaning	SI unit
`D`	in	duty cycle at this input voltage (a fraction or %)	,
`Pin`	out	input power	W
`Lm`	out	magnetizing inductance	H
`I_pk`	out	peak primary current	A
`I_rms`	out	RMS primary current	A
`I_avg`	out	average input current	A
`E_cycle`	out	energy stored per cycle	J

Applies when: discontinuous conduction: the stored energy is fully released every period.

```
$ power-electronics solve pe_flyback_dcm_design "Vin=100 V" "Po=30 W" eff=0.85 "fs=100 kHz" D=0.45
Pin = 35.29411765 W
Lm = 0.000286875 H
I_pk = 1.568627451 A
I_rms = 0.6075267994 A
I_avg = 0.3529411765 A
E_cycle = 0.0003529411765 J
  by: Flyback magnetizing inductance for discontinuous conduction  (Pin = Po/eff = Lm Ipk^2 fs/2
with Ipk = Vin D/(Lm fs) -> Lm = (Vin D)^2/(2 Pin fs); I_rms = Ipk sqrt(D/3))
  Vin = 100 V
  Po = 30 W
  eff = 0.85
  fs = 100000 Hz
  D = 0.45
  assumes: discontinuous conduction: the stored energy is fully released every period
```

What the worked example means: This calculation determines the magnetizing inductance needed for a flyback converter to deliver the specified output power while operating in discontinuous conduction mode. Using the input voltage of 100 V, duty cycle of 0.45, switching frequency of 100 kHz, and accounting for efficiency of 0.85, the resulting magnetizing inductance is 0.000286875 H. This value ensures that the energy stored in the magnetic field during each switching period is fully released to the output before the next cycle begins, yielding a peak primary current of 1.56863 A and an RMS current of 0.607527 A.

Forward converter with reset winding, `pe_forward_ccm`

The duty cycle, the largest duty cycle the reset winding allows, the switch voltage stress and the output inductor ripple of a single-switch forward converter in continuous conduction.

$$V_o = \frac{V_{in} D}{n}, \quad D_{max} = \frac{1}{1 + N_r/N_p}, \quad V_{sw} = V_{in}\left(1 + \frac{N_p}{N_r}\right)$$

symbol		meaning	SI unit
`Vin`	in	input voltage	V
`Vout`	in	output voltage	V
`n`	in	turns ratio Np/Ns	,
`Nr`	in	reset-winding to primary turns ratio Nr/Np	,

symbol		meaning	SI unit
`L`	in	output inductance	H
`fs`	in	switching frequency	Hz
`Io`	in	load current	A
`D`	out	duty cycle	,
`D_max`	out	largest duty cycle that resets the core	,
`V_switch`	out	switch voltage stress	V
`dIL`	out	output inductor ripple	A
`IL_max`	out	peak output inductor current	A
`IL_min`	out	valley output inductor current	A

Applies when: D < D_max; continuous conduction of the output inductor.

```
$ power-electronics solve pe_forward_ccm "Vin=48 V" "Vout=5 V" n=3 Nr=1 "L=22 uH" "fs=200 kHz"
"Io=5 A"
D = 0.3125
D_max = 0.5
V_switch = 96 V
dIL = 0.78125 A
IL_max = 5.390625 A
IL_min = 4.609375 A
  by: Forward converter with reset winding  (D = n Vo/Vin; D_max = 1/(1 + Nr/Np); Vsw = Vin (1 +
Np/Nr); dIL = (Vin/n - Vo) D/(L fs))
  Vin = 48 V
  Vout = 5 V
  n = 3
  Nr = 1
  L = 2.2e-05 H
  fs = 200000 Hz
  Io = 5 A
  assumes: D < D_max; continuous conduction of the output inductor
```

In the worked example, Vin = 48 V, Vout = 5 V, n = 3, Nr = 1, L = 22 uH, fs = 200 kHz, Io = 5 A go through the equation above and give D = 0.3125, D_max = 0.5, V_switch = 96 V, dIL = 0.78125 A. It applies only when D < D_max; continuous conduction of the output inductor: outside that it says what is wrong instead of returning a number.

Push-pull, half-bridge and full-bridge converters, `pe_bridge_converter`

The duty cycle per switch, switch voltage stress, output ripple frequency and output inductor ripple of an ideal push-pull, half-bridge or full-bridge DC-DC converter with a centre-tapped (full-wave) rectifier, in continuous conduction.

$$V_o = \frac{2DV_{in}}{n}\ \text{(push-pull, full-bridge)}, \quad V_o = \frac{DV_{in}}{n}\ \text{(half-bridge)}$$

symbol		meaning	SI unit
`topology`	in	push-pull, half-bridge or full-bridge	,

symbol		meaning	SI unit
`Vin`	in	input voltage	V
`Vout`	in	output voltage	V
`n`	in	turns ratio Np/Ns (primary to each secondary half)	,
`L`	in	output inductance	H
`fs`	in	switching frequency	Hz
`Io`	in	load current	A
`D`	out	duty cycle of each switch	,
`V_switch`	out	switch voltage stress	V
`f_ripple`	out	output ripple frequency	Hz
`dIL`	out	output inductor ripple	A
`IL_min`	out	valley output inductor current	A

Applies when: D < 0.5; continuous conduction of the output inductor.

```
$ power-electronics solve pe_bridge_converter topology=full-bridge "Vin=400 V" "Vout=48 V" n=5
"L=50 uH" "fs=100 kHz" "Io=10 A"
D = 0.3
V_switch = 400 V
f_ripple = 200000 Hz
dIL = 1.92 A
IL_min = 9.04 A
  by: Push-pull, half-bridge and full-bridge converters  (Vo = 2 D Vin/n (push-pull, full-bridge),
Vo = D Vin/n (half-bridge); dIL = (Vsec - Vo) D/(L fs))
  Vin = 400 V
  Vout = 48 V
  n = 5
  L = 5e-05 H
  fs = 100000 Hz
  Io = 10 A
  topology = full-bridge
  assumes: D < 0.5; continuous conduction of the output inductor
```

What the worked example means: This calculation determines the operating point for an ideal full-bridge DC-DC converter. Based on the input voltage of 400 V and desired output of 48 V, the required duty cycle per switch is found to be 0.3. The resulting switch voltage stress is 400 V, while the output inductor ripple current is calculated as 1.92 A at a ripple frequency of 200000 Hz. These values assume continuous conduction mode and strictly limit the duty cycle below 0.5 to prevent shoot-through.

Losses (3)

Boost converter with inductor resistance: gain and efficiency, `pe_boost_nonideal_gain`

The conversion ratio, output voltage, efficiency and inductor current of a boost converter whose inductor has a series resistance, with the duty cycle of maximum gain and that maximum gain.

$$M = \frac{1}{1-D}\,\frac{1}{1+\frac{R_L}{(1-D)^2 R}}, \quad \eta = \frac{1}{1+\frac{R_L}{(1-D)^2 R}}$$

symbol		meaning	SI unit
`Vin`	in	input voltage	V
`D`	in	duty cycle (a fraction or %)	,
`R`	in	load resistance	ohm
`RL`	in	inductor series resistance	ohm
`M`	out	conversion ratio	,
`Vout`	out	output voltage	V
`efficiency`	out	efficiency	,
`IL`	out	average inductor current	A
`D_peak`	out	duty cycle of maximum gain	,
`M_max`	out	maximum gain	,

Applies when: 0 < RL < R; continuous conduction, ideal switches.

```
$ power-electronics solve pe_boost_nonideal_gain "Vin=12 V" D=0.75 "R=50 ohm" "RL=0.5 ohm"
M = 3.448275862
Vout = 41.37931034 V
efficiency = 0.8620689655
IL = 3.310344828 A
D_peak = 0.9
M_max = 5
  by: Boost converter with inductor resistance: gain and efficiency  (M = (1/(1 - D)) / (1 + RL/((1
- D)^2 R)); efficiency = 1/(1 + RL/((1 - D)^2 R)); D_peak = 1 - sqrt(RL/R); M_max = sqrt(R/RL)/2)
  Vin = 12 V
  D = 0.75
  R = 50 ohm
  RL = 0.5 ohm
  assumes: 0 < RL < R; continuous conduction, ideal switches
```

In the worked example, Vin = 12 V, D = 0.75, R = 50 ohm, RL = 0.5 ohm go through the equation above and give M = 3.448275862, Vout = 41.37931034 V, efficiency = 0.8620689655, IL = 3.310344828 A. It applies only when 0 < RL < R; continuous conduction, ideal switches: outside that it says what is wrong instead of returning a number.

Buck converter efficiency with conduction and switching losses, `pe_buck_with_losses`

The duty cycle needed and the losses of a buck converter with a switch on-resistance, inductor resistance, diode forward drop and hard switching: conduction, diode, inductor and switching losses and the efficiency (ripple neglected).

$$D = \frac{V_o + V_F + I_o R_L}{V_{in} - I_o R_{ds} + V_F}, \quad P_{sw} = \tfrac{1}{2} V_{in} I_o t_{sw} f_s, \quad \eta = \frac{P_o}{P_o + \sum P}$$

symbol		meaning	SI unit
`Vin`	in	input voltage	V
`Vout`	in	output voltage	V
`Io`	in	load current	A

symbol		meaning	SI unit
`fs`	in	switching frequency	Hz
`Rds`	in	switch on-resistance	ohm
`RL`	in	inductor resistance	ohm
`VF`	in	diode forward voltage	V
`tsw`	in	total switching (crossover) time per period, turn-on plus turn-off	s
`D`	out	duty cycle	,
`P_switch_cond`	out	switch conduction loss	W
`P_diode`	out	diode conduction loss	W
`P_inductor`	out	inductor copper loss	W
`P_switching`	out	switching loss	W
`P_loss`	out	total loss	W
`efficiency`	out	efficiency	,

Applies when: continuous conduction, ripple neglected; hard switching with linear crossover at Vin and Io.

```
$ power-electronics solve pe_buck_with_losses "Vin=24 V" "Vout=5 V" "Io=4 A" "fs=200 kHz" "Rds=0.02
ohm" "RL=0.01 ohm" "VF=0.5 V" "tsw=40 ns"
D = 0.2268632269
P_switch_cond = 0.0725962326 W
P_diode = 1.546273546 W
P_inductor = 0.16 W
P_switching = 0.384 W
P_loss = 2.162869779 W
efficiency = 0.9024102113
  by: Buck converter efficiency with conduction and switching losses  (D = (Vo + VF + Io RL)/(Vin -
Io Rds + VF); P_sw,cond = Io^2 Rds D; P_D = VF Io (1 - D); P_L = Io^2 RL; P_sw = Vin Io tsw fs/2)
  Vin = 24 V
  Vout = 5 V
  Io = 4 A
  fs = 200000 Hz
  Rds = 0.02 ohm
  RL = 0.01 ohm
  VF = 0.5 V
  tsw = 4e-08 s
  assumes: continuous conduction, ripple neglected; hard switching with linear crossover at Vin and
Io
```

What the worked example means: This calculation determines the operating point and power performance of a non-ideal buck converter. It computes the required duty cycle 0.226863 to maintain the output voltage 5 V given the input voltage 24 V and load current 4 A, accounting for parasitic resistances 0.02 ohm and 0.01 ohm and diode drop 0.5 V. The model then quantifies individual loss mechanisms, including switch conduction loss 0.0725962 W, diode conduction loss 1.54627 W, inductor copper loss 0.16 W, and switching loss 0.384 W, summing them to find the total loss 2.16287 W and final efficiency 0.90241.

IGBT and diode conduction losses in a sinusoidal PWM inverter, `pe_igbt_inverter_conduction_losses`

The conduction losses of one IGBT and one freewheeling diode (and of a whole leg) in a sinusoidal PWM inverter, from the peak phase current, modulation index, power-factor angle and the devices' threshold-

voltage plus slope-resistance models.

$$P_T = V_{ce0}\hat{I}\left(\frac{1}{2\pi} + \frac{M\cos\phi}{8}\right) + r_{ce}\hat{I}^2\left(\frac{1}{8} + \frac{M\cos\phi}{3\pi}\right)$$

symbol		meaning	SI unit
`Ip`	in	peak phase current	A
`M`	in	modulation index	,
`phi`	in	power-factor angle (current lagging positive)	rad
`Vce0`	in	IGBT threshold voltage	V
`rce`	in	IGBT slope resistance	ohm
`VF0`	in	diode threshold voltage	V
`rF`	in	diode slope resistance	ohm
`P_igbt`	out	conduction loss of one IGBT	W
`P_diode`	out	conduction loss of one diode	W
`P_switch_pair`	out	one IGBT plus one diode	W
`P_leg`	out	conduction loss of a leg (two of each)	W

Applies when: 0 < M <= 1, sinusoidal current, switching frequency far above the output frequency.

```
$ power-electronics solve pe_igbt_inverter_conduction_losses "Ip=100 A" M=0.9 "phi=30 deg"
"Vce0=0.9 V" "rce=0.01 ohm" "VF0=0.8 V" "rF=0.008 ohm"
P_igbt = 43.86238552 W
P_diode = 8.322220068 W
P_switch_pair = 52.18460559 W
P_leg = 104.3692112 W
  by: IGBT and diode conduction losses in a sinusoidal PWM inverter  (P_T = Vce0 Ip (1/(2pi) + M
cos(phi)/8) + rce Ip^2 (1/8 + M cos(phi)/(3pi)); P_D = VF0 Ip (1/(2pi) - M cos(phi)/8) + rF Ip^2
(1/8 - M cos(phi)/(3pi)))
  Ip = 100 A
  M = 0.9
  phi = 0.5235987756 rad
  Vce0 = 0.9 V
  rce = 0.01 ohm
  VF0 = 0.8 V
  rF = 0.008 ohm
  assumes: 0 < M <= 1, sinusoidal current, switching frequency far above the output frequency
```

What the worked example means: This calculation determines the conduction losses within an inverter leg using a linear approximation of the device voltage drops. The result, such as 104.369 W for the entire leg, depends on the peak phase current 100 A, modulation index 0.9, and power factor angle 30 deg. These values are combined with the threshold voltages 0.9 V and 0.8 V and slope resistances 0.01 ohm and 0.008 ohm to estimate how much energy is dissipated as heat during the time the devices conduct.

Magnetics (8)

Core loss by the Steinmetz equation, `pe_steinmetz_core_loss`

The core loss density and total core loss of a magnetic core under sinusoidal flux from the Steinmetz parameters k, alpha, beta (SI: f in Hz, B in T, loss density in W/m^3), the frequency, the peak flux density and the core volume.

$$P_v = k f^{\alpha} \hat{B}^{\beta}$$

symbol		meaning	SI unit
`k`	in	Steinmetz coefficient (SI units)	,
`alpha`	in	frequency exponent	,
`beta`	in	flux-density exponent	,
`f`	in	frequency	Hz
`Bpk`	in	peak flux density	T
`Vc`	in	core volume	m^3
`Pv`	out	core loss density	W/m^3
`Pv_mW_cm3`	out	core loss density in milliwatts per cubic centimetre	,
`P`	out	core loss	W

Applies when: sinusoidal flux, within the parameters' fitted range.

```
$ power-electronics solve pe_steinmetz_core_loss k=3.2 alpha=1.4 beta=2.5 "f=100 kHz" "Bpk=100 mT"
"Vc=5 cm^3"
Pv = 101192.8851 W/m^3
Pv_mW_cm3 = 101.1928851
P = 0.5059644256 W
  by: Core loss by the Steinmetz equation  (Pv = k f^alpha Bpk^beta; P = Pv Vc)
  k = 3.2
  alpha = 1.4
  beta = 2.5
  f = 100000 Hz
  Bpk = 0.1 T
  Vc = 5e-06 m^3
  assumes: sinusoidal flux, within the parameters' fitted range
```

What the worked example means: This calculation determines the volumetric core loss density using the Steinmetz equation with coefficient 3.2, frequency exponent 1.4, and flux density exponent 2.5. The result depends on the operating frequency 100 kHz and peak flux density 100 mT. Multiplying this density by the core volume 5 cm^3 yields the total core loss 0.505964 W. The derived loss density of 101193 W/m^3 indicates how much heat is generated per unit volume of magnetic material under these specific sinusoidal excitation conditions.

Core loss under triangular flux (iGSE), `pe_igse_triangular_core_loss`

The core loss of a magnetic component whose flux is triangular (a converter inductor or transformer with duty cycle D) by the improved generalized Steinmetz equation, from the sinusoidal Steinmetz parameters; also its ratio to the sinusoidal loss at the same peak flux.

$$P_v = k_i(\Delta B)^{\beta} f^{\alpha}\left(D^{1-\alpha} + (1-D)^{1-\alpha}\right),\ k_i = \frac{k}{(2\pi)^{\alpha-1}\int_0^{2\pi} |\cos\theta|^{\alpha} 2^{\beta-\alpha} d\theta}$$

symbol		meaning	SI unit
`k`	in	Steinmetz coefficient (SI units)	,
`alpha`	in	frequency exponent	,
`beta`	in	flux-density exponent	,
`f`	in	switching frequency	Hz
`dB`	in	peak-to-peak flux density swing	T
`D`	in	duty cycle of the rising flux (a fraction or %)	,
`Vc`	in	core volume	m^3
`ki`	out	iGSE coefficient	,
`Pv`	out	core loss density	W/m^3
`P`	out	core loss	W
`ratio_to_sine`	out	loss relative to a sinusoid of the same peak flux	,

Applies when: piecewise-linear flux, no relaxation effects.

```
$ power-electronics solve pe_igse_triangular_core_loss k=3.2 alpha=1.4 beta=2.5 "f=100 kHz" "dB=200
mT" D=0.5 "Vc=5 cm^3"
ki = 0.1998061472
Pv = 94324.78603 W/m^3
P = 0.4716239301 W
ratio_to_sine = 0.9321286364
  by: Core loss under triangular flux (iGSE)  (ki = k/((2 pi)^(alpha-1) int|cos|^alpha 2^(beta-
alpha)); Pv = ki dB^beta f^alpha (D^(1-alpha) + (1-D)^(1-alpha)))
  k = 3.2
  alpha = 1.4
  beta = 2.5
  f = 100000 Hz
  dB = 0.2 T
  D = 0.5
  Vc = 5e-06 m^3
  assumes: piecewise-linear flux, no relaxation effects
```

What the worked example means: This capability computes the volumetric core loss density using the improved generalized Steinmetz equation for triangular flux waveforms. It derives the iGSE coefficient from the standard sinusoidal Steinmetz parameters, then calculates the power dissipation per unit volume based on the duty cycle and switching frequency. The final total core loss is obtained by multiplying this density by the core volume, yielding a result of 0.471624 W watts.

Gapped-core inductor: turns and air gap, `pe_gapped_inductor_design`

The number of turns and the air-gap length of a gapped-core inductor that gives an inductance L with the peak flux density Bmax at the peak current (core reluctance and fringing neglected), the stored energy, the inductance factor AL and the gap volume.

$$N = \frac{L I_{pk}}{B_{max} A_c}, \quad l_g = \frac{\mu_0 N^2 A_c}{L}$$

symbol		meaning	SI unit
`L`	in	inductance	H
`Ipk`	in	peak current	A
`Bmax`	in	peak flux density allowed	T
`Ac`	in	core cross-section area	m^2
`N`	out	turns (before rounding)	,
`l_gap`	out	air-gap length	m
`E`	out	peak stored energy	J
`AL`	out	inductance per turn squared	H
`V_gap`	out	gap volume	m^3

Applies when: gap reluctance dominates; no fringing.

```
$ power-electronics solve pe_gapped_inductor_design "L=100 uH" "Ipk=10 A" "Bmax=300 mT" "Ac=1 cm^2"
N = 33.33333333
l_gap = 0.001396263401 m
E = 0.005 J
AL = 9e-08 H
V_gap = 1.396263401e-07 m^3
  by: Gapped-core inductor: turns and air gap  (N = L Ipk/(Bmax Ac); l_g = mu0 N^2 Ac/L; E = L
Ipk^2/2)
  L = 0.0001 H
  Ipk = 10 A
  Bmax = 0.3 T
  Ac = 0.0001 m^2
  assumes: gap reluctance dominates; no fringing
```

What the worked example means: This calculation determines the number of winding turns and the required air-gap length for a gapped-core inductor. It uses the desired inductance, peak current, maximum flux density, and core cross-section area to find that 33.3333 turns are needed with a gap of 0.00139626 m. The resulting stored energy is 0.005 J, which represents the magnetic field capacity at the specified operating point.

Inductor core area product, `pe_inductor_area_product`

The core area product Ap = Ac Wa an inductor needs to store its energy at the peak flux density Bmax with a current density J and window utilisation Ku (core selection by the area-product method).

$$A_p = A_c W_a = \frac{L\, I_{pk} I_{rms}}{B_{max} J K_u}$$

symbol		meaning	SI unit
`L`	in	inductance	H
`Ipk`	in	peak current	A

symbol		meaning	SI unit
`Irms`	in	RMS current	A
`Bmax`	in	peak flux density	T
`J`	in	winding current density	A/m^2
`Ku`	in	window utilisation factor (a fraction or %)	,
`Ap`	out	area product Ac Wa	m^4
`Ap_cm4`	out	area product in centimetres to the fourth	,

Applies when: 0 < Ku < 1.

```
$ power-electronics solve pe_inductor_area_product "L=100 uH" "Ipk=12 A" "Irms=10 A" "Bmax=300 mT"
"J=4 A/mm^2" Ku=0.4
Ap = 2.5e-08 m^4
Ap_cm4 = 2.5
  by: Inductor core area product  (Ap = L Ipk Irms/(Bmax J Ku))
  L = 0.0001 H
  Ipk = 12 A
  Irms = 10 A
  Bmax = 0.3 T
  J = 4000000 A/m^2
  Ku = 0.4
  assumes: 0 < Ku < 1
```

What the worked example means: This calculation determines the necessary core size for an inductor using the area-product method. By combining the inductance value 100 uH, peak current 12 A, and RMS current 10 A with the design limits of maximum flux density 300 mT, winding current density 4 A/mm^2, and window utilization factor 0.4, the tool computes the total area product. The resulting value 2.5e-08 m^4 represents the product of the core's cross-sectional area and its window area, which helps select a magnetic component capable of storing the required energy without saturating or overheating.

Skin effect in a round wire, `pe_skin_effect_round_wire`

The skin depth and the exact AC-to-DC resistance ratio (Bessel-function solution) of an isolated round conductor at a frequency, with its DC and AC resistance for a length.

$$\delta = \sqrt{\frac{\rho}{\pi f \mu_0}}, \quad \frac{R_{ac}}{R_{dc}} = \mathrm{Re}\left[\frac{kr}{2}\frac{J_0(kr)}{J_1(kr)}\right],\ k = \frac{1-j}{\delta}$$

symbol		meaning	SI unit
`d`	in	wire diameter	m
`f`	in	frequency	Hz
`rho`	in	conductor resistivity	ohm*m
`length`	in	conductor length	m
`delta`	out	skin depth	m
`d_over_delta`	out	diameter in skin depths	,
`Rdc`	out	DC resistance	ohm

symbol		meaning	SI unit
`Rac`	out	AC resistance	ohm
`ratio`	out	Rac/Rdc	,

Applies when: isolated straight wire (no proximity effect); radius at most 10 skin depths.

```
$ power-electronics solve pe_skin_effect_round_wire "d=1 mm" "f=100 kHz" "rho=1.72e-08 ohm*m"
"length=1 m"
delta = 0.000208729751 m
d_over_delta = 4.790883882
Rdc = 0.02189972017 ohm
Rac = 0.03178226064 ohm
ratio = 1.451263322
  by: Skin effect in a round wire  (delta = sqrt(rho/(pi f mu0)); Rac/Rdc = Re[(k r/2) J0(k r)/J1(k
r)], k = (1 - j)/delta)
  d = 0.001 m
  f = 100000 Hz
  rho = 1.72e-08 ohm*m
  length = 1 m
  assumes: isolated straight wire (no proximity effect); radius at most 10 skin depths
```

What the worked example means: This calculation determines the skin depth, which represents the effective penetration of current into the conductor, found to be 0.00020873 m. It also computes the DC resistance as 0.0218997 ohm and the AC resistance as 0.0317823 ohm, resulting in an increase factor or ratio of 1.45126. The diameter expressed in skin depths is 4.79088, indicating how significant the skin effect is for this specific wire geometry.

Transformer core area product, `pe_transformer_area_product`

The apparent power the windings handle and the core area product Ap = Ac Wa a two-winding transformer needs for an output power at an efficiency, flux density, frequency, current density and window utilisation (sine or square-wave excitation).

$$A_p = \frac{P_t}{K_f K_u B_m f J}, \quad P_t = P_o\left(1 + \frac{1}{\eta}\right)$$

symbol		meaning	SI unit
`Po`	in	output power	W
`eff`	in	efficiency (a fraction or %)	,
`waveform`	in	sine or square	,
`Bm`	in	peak flux density	T
`f`	in	frequency	Hz
`J`	in	current density	A/m^2
`Ku`	in	window utilisation (a fraction or %)	,
`Pt`	out	apparent power of both windings	W
`Ap`	out	area product	m^4
`Ap_cm4`	out	area product in centimetres to the fourth	,

Applies when: two windings at the same current density.

```
$ power-electronics solve pe_transformer_area_product "Po=250 W" eff=0.95 waveform=square "Bm=100
mT" "f=100 kHz" "J=4 A/mm^2" Ku=0.4
Pt = 513.1578947 W
Ap = 8.018092105e-09 m^4
Ap_cm4 = 0.8018092105
  by: Transformer core area product  (Pt = Po (1 + 1/eff); Ap = Pt/(Kf Ku Bm f J), Kf = 4.44 (sine)
or 4 (square))
  Po = 250 W
  eff = 0.95
  Bm = 0.1 T
  f = 100000 Hz
  J = 4000000 A/m^2
  Ku = 0.4
  waveform = square
  assumes: two windings at the same current density
```

What the worked example means: This calculation determines the transformer core area product needed for a two-winding design. First, the apparent power handled by the windings is found using the output power and efficiency, resulting in 513.158 W W. This value is then divided by the waveform factor, window utilisation, peak flux density, frequency, and current density to yield the area product of 8.01809e-09 m^4 m^4, which corresponds to 0.801809 when expressed in centimetres to the fourth power.

Transformer turns from Faraday's law, `pe_transformer_turns`

The primary and secondary turns of a transformer that keep the peak flux density at Bmax in a core of cross-section Ac (sine or square-wave excitation), the turns ratio and the volts per turn.

$$N_p = \frac{V}{K_f f B_{max} A_c}, \quad K_f = \sqrt{2}\pi\ (\text{sine}),\ 4\ (\text{square})$$

symbol		meaning	SI unit
`waveform`	in	sine or square	,
`V`	in	primary voltage (RMS for sine, amplitude for square)	V
`f`	in	frequency	Hz
`Bmax`	in	peak flux density	T
`Ac`	in	core cross-section area	m^2
`Vs`	in	secondary voltage (same measure as V)	V
`Np`	out	primary turns (before rounding up)	,
`Ns`	out	secondary turns (before rounding)	,
`n`	out	turns ratio Np/Ns	,
`volts_per_turn`	out	volts per turn	V

Applies when: the core does not saturate; no dc bias.

```
$ power-electronics solve pe_transformer_turns waveform=square "V=48 V" "f=100 kHz" "Bmax=150 mT"
"Ac=1.25 cm^2" "Vs=12 V"
Np = 6.4
Ns = 1.6
n = 4
volts_per_turn = 7.5 V
  by: Transformer turns from Faraday's law  (Np = V/(Kf f Bmax Ac), Kf = 4.44 (sine, RMS) or 4
(square))
  V = 48 V
  f = 100000 Hz
  Bmax = 0.15 T
  Ac = 0.000125 m^2
  Vs = 12 V
  waveform = square
  assumes: the core does not saturate; no dc bias
```

What the worked example means: This calculation determines the number of primary turns needed to limit the peak flux density in the core. Using the applied voltage, frequency, and core area, the model computes that 6.4 primary turns are required. The corresponding secondary turns are 1.6, resulting in a turns ratio of 4. Each turn carries 7.5 V volts under these conditions.

Winding AC resistance factor (Dowell), `pe_dowell_proximity_factor`

The ratio of AC to DC resistance of a winding of m layers of foil (or equivalent layer) thickness h at a frequency, including skin and proximity effects by Dowell's one-dimensional solution.

$$F_R = \Delta \left[\frac{\sinh 2\Delta + \sin 2\Delta}{\cosh 2\Delta - \cos 2\Delta} + \frac{2(m^2-1)}{3} \frac{\sinh \Delta - \sin \Delta}{\cosh \Delta + \cos \Delta} \right]$$

symbol		meaning	SI unit
`h`	in	layer (conductor) thickness	m
`f`	in	frequency	Hz
`rho`	in	conductor resistivity	ohm*m
`m`	in	number of layers	,
`delta`	out	skin depth	m
`Delta`	out	layer thickness in skin depths h/delta	,
`FR`	out	AC-to-DC resistance factor	,

Applies when: full-width layers (foil or porosity-corrected); sinusoidal current.

```
$ power-electronics solve pe_dowell_proximity_factor "h=0.2 mm" "f=100 kHz" "rho=1.72e-08 ohm*m"
m=4
delta = 0.000208729751 m
Delta = 0.9581767764
FR = 2.431126826
  by: Winding AC resistance factor (Dowell)  (F_R = D [ (sinh 2D + sin 2D)/(cosh 2D - cos 2D) + 2
(m^2 - 1)/3 (sinh D - sin D)/(cosh D + cos D) ], D = h/delta)
  h = 0.0002 m
  f = 100000 Hz
  rho = 1.72e-08 ohm*m
  assumes: full-width layers (foil or porosity-corrected); sinusoidal current
```

What the worked example means: This calculation determines the ratio of alternating current resistance to direct current resistance for a winding. It uses Dowell's one-dimensional model, which accounts for skin and proximity effects in layers of foil or equivalent conductors. The result depends on the number of layers 4, the conductor resistivity 1.72e-08 ohm*m, and the operating frequency 100 kHz. For the given inputs, the skin depth is 0.00020873 m, leading to a normalized layer thickness of 0.958177. The final AC resistance factor 2.43113 indicates how much higher the effective resistance is compared to the DC value under sinusoidal conditions.

Motor drives (9)

Armature current ripple of a chopper-fed DC motor, `pe_dc_motor_armature_ripple`

The maximum, minimum, peak-to-peak and average armature current of a DC motor fed by a step-down chopper, from the exact exponential (RL plus back-EMF) waveform in continuous conduction.

$$I_{max} = \frac{V_s}{R_a}\frac{1-e^{-DT/\tau}}{1-e^{-T/\tau}} - \frac{E_a}{R_a},\; I_{min} = \frac{V_s}{R_a}\frac{e^{DT/\tau}-1}{e^{T/\tau}-1} - \frac{E_a}{R_a}$$

symbol		meaning	SI unit
`Vs`	in	dc supply voltage	V
`D`	in	duty cycle (a fraction or %)	,
`fs`	in	chopping frequency	Hz
`Ra`	in	armature resistance	ohm
`La`	in	armature inductance	H
`Ea`	in	back EMF	V
`I_max`	out	maximum armature current	A
`I_min`	out	minimum armature current	A
`dI`	out	peak-to-peak ripple	A
`I_avg`	out	average armature current	A

Applies when: continuous conduction (I_min > 0); constant speed (constant back EMF) over a period.

```
$ power-electronics solve pe_dc_motor_armature_ripple "Vs=220 V" D=0.5 "fs=1 kHz" "Ra=1 ohm" "La=10
mH" "Ea=100 V"
I_max = 12.74942723 A
I_min = 7.250572773 A
dI = 5.498854453 A
I_avg = 10 A
  by: Armature current ripple of a chopper-fed DC motor  (I_max = (Vs/Ra)(1 - e^(-DT/tau))/(1 -
e^(-T/tau)) - Ea/Ra; I_min = (Vs/Ra)(e^(DT/tau) - 1)/(e^(T/tau) - 1) - Ea/Ra; I_avg = (D Vs -
Ea)/Ra)
  Vs = 220 V
  D = 0.5
  fs = 1000 Hz
  Ra = 1 ohm
  La = 0.01 H
  Ea = 100 V
  assumes: continuous conduction (I_min > 0); constant speed (constant back EMF) over a period
```

What the worked example means: This calculation determines the exact exponential waveform of the armature current for a DC motor fed by a step-down chopper. It computes the maximum value 12.7494 A and minimum value 7.25057 A based on the supply voltage, duty cycle, chopping frequency, resistance, inductance, and back EMF. The difference gives the peak-to-peak ripple 5.49885 A, while the steady-state average is 10 A, assuming continuous conduction.

BLDC motor with six-step (120 degree) drive, `pe_bldc_six_step`

The speed, torque, no-load speed, stall current, electrical frequency and commutation interval of a trapezoidal brushless DC motor driven six-step from a PWM-chopped dc bus (two phases conduct in series).

$$DV_{dc} = 2R_{ph}I + 2K_{e,ph}\omega, \quad T = 2K_{e,ph}I$$

symbol		meaning	SI unit
`Vdc`	in	dc bus voltage	V
`D`	in	PWM duty cycle (a fraction or %)	,
`Rph`	in	phase resistance	ohm
`Keph`	in	phase back-EMF constant (flat top)	V*s/rad
`I`	in	dc link (phase) current	A
`p`	in	pole pairs	,
`omega`	out	speed	rad/s
`rpm`	out	speed in rpm	,
`T`	out	torque	N*m
`omega_no_load`	out	no-load speed	rad/s
`I_stall`	out	stall current	A
`f_e`	out	electrical frequency	Hz
`t_commutation`	out	time between commutations	s

Applies when: ideal trapezoidal EMF and block currents; winding inductance and commutation neglected.

```
$ power-electronics solve pe_bldc_six_step "Vdc=48 V" D=0.8 "Rph=0.1 ohm" "Keph=0.05 V*s/rad" "I=10
A" p=4
omega = 364 rad/s
rpm = 3475.943957
T = 1 N*m
omega_no_load = 384 rad/s
I_stall = 192 A
f_e = 231.7295971 Hz
t_commutation = 0.0007192290874 s
  by: BLDC motor with six-step (120 degree) drive  (D Vdc = 2 Rph I + 2 Keph w; T = 2 Keph I; f_e =
p w/(2 pi))
  Vdc = 48 V
  D = 0.8
  Rph = 0.1 ohm
  Keph = 0.05 V*s/rad
  I = 10 A
  assumes: ideal trapezoidal EMF and block currents; winding inductance and commutation neglected
```

What the worked example means: The model calculates the operating point of a brushless DC motor driven in six-step mode. Using the applied duty cycle 0.8 and dc bus voltage 48 V, it determines that the phase current 10 A produces a torque of 1 N*m N*m. The resulting electrical frequency is 231.73 Hz Hz, corresponding to a mechanical speed of 364 rad/s rad/s or 3475.94 rpm. The time between commutations is found to be 0.000719229 s s.

Chopper-fed separately excited DC motor: speed and torque, `pe_dc_motor_chopper_drive`

The armature current, average armature voltage, back EMF, speed (rad/s and rpm), output power and armature efficiency of a separately excited DC motor fed by a step-down chopper at a duty cycle and carrying a load torque (continuous current, ripple neglected).

$$V_a = DV_s, \quad I_a = \frac{T_L}{K}, \quad \omega = \frac{V_a - I_a R_a}{K}$$

symbol		meaning	SI unit
`Vs`	in	dc supply voltage	V
`D`	in	chopper duty cycle (a fraction or %)	,
`Ra`	in	armature resistance	ohm
`K`	in	motor constant K = Ke = Kt	V*s/rad
`TL`	in	load torque	N*m
`Ia`	out	armature current TL/K	A
`Va`	out	average armature voltage D Vs	V
`Ea`	out	back EMF	V
`omega`	out	speed	rad/s
`rpm`	out	speed in rpm	,
`P_out`	out	developed (output) power	W
`efficiency`	out	armature efficiency Ea/Va	,

Applies when: continuous armature current; constant field.

```
$ power-electronics solve pe_dc_motor_chopper_drive "Vs=220 V" D=0.6 "Ra=0.5 ohm" "K=1.2 V*s/rad"
"TL=24 N*m"
Ia = 20 A
Va = 132 V
Ea = 122 V
omega = 101.6666667 rad/s
rpm = 970.8451529
P_out = 2440 W
efficiency = 0.9242424242
  by: Chopper-fed separately excited DC motor: speed and torque  (Va = D Vs; Ia = TL/K; Ea = Va -
Ia Ra; w = Ea/K)
  Vs = 220 V
  D = 0.6
  Ra = 0.5 ohm
  K = 1.2 V*s/rad
  TL = 24 N*m
  assumes: continuous armature current; constant field
```

What the worked example means: For a separately excited DC motor fed by a step-down chopper, the average armature voltage is determined by the duty cycle and supply voltage, resulting in 132 V V. The armature current required to support the load torque is calculated as 20 A A. This current causes a voltage drop across the armature resistance, leaving a back electromotive force of 122 V V. Consequently, the motor speed settles at 101.667 rad/s rad/s, which corresponds to 970.845 revolutions per minute. The developed output power is 2440 W W, and the armature efficiency is 0.924242.

Induction motor constant V/f speed control, `pe_induction_motor_vf`

The supply voltage, synchronous speed, rotor speed, slip and slip frequency of an induction motor under constant V/f control below base frequency, from its rated voltage, frequency and speed (linear torque-slip region, torque as a fraction of rated).

$$\frac{V}{f} = \text{const}, \quad n = \frac{120 f}{P} - (n_{s,r} - n_r)\frac{T}{T_r}$$

symbol		meaning	SI unit
`V_rated`	in	rated line voltage	V
`f_rated`	in	rated (base) frequency	Hz
`poles`	in	number of poles	,
`n_rated`	in	rated speed in rpm	,
`f`	in	operating frequency	Hz
`T_ratio`	in	load torque as a fraction of rated torque (or %)	,
`V`	out	supply voltage at f (constant V/f)	V
`ns`	out	synchronous speed in rpm	,
`n`	out	rotor speed in rpm	,
`slip`	out	slip	,
`f_slip`	out	slip (rotor) frequency	Hz

Applies when: f <= f_rated; linear torque-slip region (T_ratio <= 1.5); stator resistance drop neglected.

```
$ power-electronics solve pe_induction_motor_vf "V_rated=400 V" "f_rated=50 Hz" poles=4
n_rated=1450 "f=30 Hz" T_ratio=1
V = 240 V
ns = 900
n = 850
slip = 0.05555555556
f_slip = 1.666666667 Hz
  by: Induction motor constant V/f speed control  (V = V_rated f/f_rated; ns = 120 f/P; the slip
speed at constant V/f is proportional to torque: n = ns - (ns,rated - n_rated) T/T_rated)
  V_rated = 400 V
  f_rated = 50 Hz
  n_rated = 1450
  f = 30 Hz
  T_ratio = 1
  assumes: f <= f_rated; linear torque-slip region (T_ratio <= 1.5); stator resistance drop
neglected
```

What the worked example means: This calculation determines the operating parameters of an induction motor under constant voltage to frequency control. Given a rated voltage of 400 V and rated frequency of 50 Hz, the system applies a supply voltage of 240 V at the operating frequency of 30 Hz. The resulting synchronous speed is 900 rpm. With a load torque ratio of 1, the slip increases proportionally, reducing the actual rotor speed to 850 rpm. This yields a slip value of 0.0555556 and a slip frequency of 1.66667 Hz Hz.

Maximum torque per ampere (MTPA) of an interior PMSM, `pe_pmsm_mtpa`

The d- and q-axis currents, current advance angle and torque that give the most torque for a given current magnitude in a salient (interior) permanent-magnet synchronous motor, and the torque with id = 0 for comparison.

$$i_d = \frac{\psi_f - \sqrt{\psi_f^2 + 8(L_q - L_d)^2 I_s^2}}{4(L_q - L_d)}, \quad i_q = \sqrt{I_s^2 - i_d^2}$$

symbol		meaning	SI unit
`Ld`	in	d-axis inductance	H
`Lq`	in	q-axis inductance (Lq > Ld)	H
`psi_f`	in	magnet flux linkage	Wb
`p`	in	pole pairs	,
`Is`	in	current magnitude (peak)	A
`id`	out	d-axis current (negative)	A
`iq`	out	q-axis current	A
`beta_deg`	out	current advance angle from the q axis, degrees	,
`Te`	out	maximum torque at this current	N*m
`Te_id0`	out	torque with zero d-axis current	N*m

Applies when: Lq > Ld; magnetic saturation neglected.

```
$ power-electronics solve pe_pmsm_mtpa "Ld=0.4 mH" "Lq=1 mH" "psi_f=80 mWb" p=4 "Is=100 A"
id = -44.84026266 A
iq = 89.38316869 A
beta_deg = 26.64124423
Te = 57.33259411 N*m
Te_id0 = 48 N*m
  by: Maximum torque per ampere (MTPA) of an interior PMSM  (id = (psi_f - sqrt(psi_f^2 + 8 (Lq -
Ld)^2 Is^2)) / (4 (Lq - Ld)); iq = sqrt(Is^2 - id^2))
  Ld = 0.0004 H
  Lq = 0.001 H
  psi_f = 0.08 Wb
  Is = 100 A
  assumes: Lq > Ld; magnetic saturation neglected
```

What the worked example means: This calculation determines the optimal d- and q-axis currents for maximum torque per ampere in an interior permanent magnet synchronous motor. Given a stator current magnitude of 100 A, the algorithm computes the field-weakening or flux-weakening component as -44.8403 A and the torque-producing component as 89.3832 A. The resulting electromagnetic torque is 57.3326 N*m, which exceeds the torque produced with zero d-axis current (48 N*m) due to the contribution of reluctance torque from the magnetic saliency.

Phase-controlled rectifier DC motor drive, `pe_dc_drive_controlled_rectifier`

The armature voltage, back EMF, speed, torque and developed power of a separately excited DC motor fed by a single-phase or three-phase fully controlled thyristor bridge at a firing angle, with continuous armature current.

$$V_a = \frac{2\sqrt{2}V_s}{\pi}\cos\alpha\ (1\phi),\ \frac{3\sqrt{2}V_{LL}}{\pi}\cos\alpha\ (3\phi), \quad \omega = \frac{V_a - I_a R_a}{K}$$

symbol		meaning	SI unit
`converter`	in	single-phase or three-phase full converter	,
`Vs`	in	RMS supply voltage (line-to-line for three-phase)	V
`alpha`	in	firing angle	rad
`Ra`	in	armature resistance	ohm
`K`	in	motor constant	V*s/rad
`Ia`	in	armature current	A
`Va`	out	average armature voltage	V
`Ea`	out	back EMF	V
`omega`	out	speed	rad/s
`rpm`	out	speed in rpm	,
`T`	out	developed torque K Ia	N*m
`P`	out	developed power Ea Ia	W
`mode`	out	motoring or reverse	,

Applies when: continuous armature current.

```
$ power-electronics solve pe_dc_drive_controlled_rectifier converter=single-phase "Vs=230 V"
"alpha=45 deg" "Ra=1 ohm" "K=1 V*s/rad" "Ia=10 A"
Va = 146.4225476 V
Ea = 136.4225476 V
omega = 136.4225476 rad/s
rpm = 1302.739368
T = 10 N*m
P = 1364.225476 W
mode = motoring
  by: Phase-controlled rectifier DC motor drive  (Va = 2 sqrt(2) Vs cos(alpha)/pi (single-phase) or
3 sqrt(2) VLL cos(alpha)/pi (three-phase); Ea = Va - Ia Ra; w = Ea/K)
  Vs = 230 V
  alpha = 0.7853981634 rad
  Ra = 1 ohm
  K = 1 V*s/rad
  Ia = 10 A
  converter = single-phase
  assumes: continuous armature current
```

What the worked example means: This calculation determines the operating point of a separately excited DC motor fed by a phase-controlled rectifier. The average armature voltage, 146.423 V, is derived from the supply voltage 230 V and firing angle 45 deg. From this voltage, the back electromotive force is found to be 136.423 V after accounting for the armature resistance drop caused by current 10 A. Consequently, the motor runs at a speed of 136.423 rad/s radians per second, or 1302.74 revolutions per minute, while producing a developed torque of 10 N*m newton meters and mechanical power of 1364.23 W watts.

PMSM steady state in the dq frame: voltages and torque, `pe_pmsm_dq_model`

The electrical speed, d- and q-axis voltages, voltage magnitude, electromagnetic torque, mechanical, input and copper power and power factor of a permanent-magnet synchronous motor in steady state from its dq currents (amplitude-invariant Park transform).

$$v_d = R_s i_d - \omega_e L_q i_q,\; v_q = R_s i_q + \omega_e (L_d i_d + \psi_f),\; T_e = \tfrac{3}{2} p \left(\psi_f i_q + (L_d - L_q) i_d i_q\right)$$

symbol		meaning	SI unit
`Rs`	in	stator resistance per phase	ohm
`Ld`	in	d-axis inductance	H
`Lq`	in	q-axis inductance	H
`psi_f`	in	permanent-magnet flux linkage	Wb
`p`	in	pole pairs	,
`id`	in	d-axis current (negative for field weakening)	A
`iq`	in	q-axis current	A
`omega_m`	in	mechanical speed	rad/s
`omega_e`	out	electrical speed p w_m	rad/s
`vd`	out	d-axis voltage	V
`vq`	out	q-axis voltage	V
`V_peak`	out	peak phase voltage magnitude	V

symbol		meaning	SI unit
`Te`	out	electromagnetic torque	N*m
`P_mech`	out	mechanical power	W
`P_in`	out	electrical input power	W
`P_cu`	out	stator copper loss	W
`PF`	out	power factor	,

Applies when: steady state, sinusoidal machine, iron loss neglected; amplitude-invariant transform.

```
$ power-electronics solve pe_pmsm_dq_model "Rs=0.05 ohm" "Ld=0.4 mH" "Lq=1 mH" "psi_f=80 mWb" p=4
"id=-20 A" "iq=60 A" "omega_m=300 rad/s"
omega_e = 1200 rad/s
vd = -73 V
vq = 89.4 V
V_peak = 115.4181961 V
Te = 33.12 N*m
P_mech = 9936 W
P_in = 10236 W
P_cu = 300 W
PF = 0.9348345181
  by: PMSM steady state in the dq frame: voltages and torque  (vd = Rs id - omega_e Lq iq; vq = Rs
iq + omega_e (Ld id + psi_f); Te = 1.5 p (psi_f iq + (Ld - Lq) id iq); P_in = 1.5 (vd id + vq iq))
  Rs = 0.05 ohm
  Ld = 0.0004 H
  Lq = 0.001 H
  psi_f = 0.08 Wb
  id = -20 A
  iq = 60 A
  omega_m = 300 rad/s
  assumes: steady state, sinusoidal machine, iron loss neglected; amplitude-invariant transform
```

What the worked example means: This calculation determines the steady-state behavior of a permanent-magnet synchronous motor using its dq-axis currents. It computes the d-axis and q-axis voltages, which combine to give a peak phase voltage of 115.418 V. The electromagnetic torque is found to be 33.12 N*m, resulting in a mechanical power output of 9936 W. These values are derived from the stator resistance, inductances, flux linkage, pole pairs, and specified currents, assuming an amplitude-invariant Park transform and neglecting iron losses.

Regenerative braking of a DC motor with a chopper, `pe_regenerative_braking_chopper`

The back EMF, average armature voltage, armature current, braking torque, mechanical power absorbed, power returned to the supply and braking efficiency of a DC motor braked regeneratively by a step-up chopper.

$$I_a = \frac{K\omega - (1-D)V_s}{R_a}, \quad P_{regen} = (1-D)V_s I_a$$

symbol		meaning	SI unit
`Vs`	in	dc supply voltage	V
`D`	in	chopper duty cycle (a fraction or %)	,

symbol		meaning	SI unit
`Ra`	in	armature resistance	ohm
`K`	in	motor constant	V*s/rad
`omega`	in	motor speed	rad/s
`Ea`	out	back EMF K w	V
`Va`	out	average armature voltage	V
`Ia`	out	armature (braking) current	A
`T_brake`	out	braking torque	N*m
`P_mech`	out	mechanical power absorbed Ea Ia	W
`P_regen`	out	power returned to the supply	W
`efficiency`	out	braking efficiency P_regen/P_mech	,

Applies when: Ea > (1 - D) Vs; continuous armature current.

```
$ power-electronics solve pe_regenerative_braking_chopper "Vs=220 V" D=0.5 "Ra=0.5 ohm" "K=1
V*s/rad" "omega=150 rad/s"
Ea = 150 V
Va = 110 V
Ia = 80 A
T_brake = 80 N*m
P_mech = 12000 W
P_regen = 8800 W
efficiency = 0.7333333333
  by: Regenerative braking of a DC motor with a chopper  (Ea = K w; Va = (1 - D) Vs; Ia = (Ea -
Va)/Ra; P_regen = Va Ia)
  Vs = 220 V
  D = 0.5
  Ra = 0.5 ohm
  K = 1 V*s/rad
  omega = 150 rad/s
  assumes: Ea > (1 - D) Vs; continuous armature current
```

In the worked example, Vs = 220 V, D = 0.5, Ra = 0.5 ohm, K = 1 V*s/rad, omega = 150 rad/s go through the equation above and give Ea = 150 V, Va = 110 V, Ia = 80 A, T_brake = 80 N*m. It applies only when Ea > (1 - D) Vs; continuous armature current: outside that it says what is wrong instead of returning a number.

Surface PMSM field weakening: base speed, maximum speed and torque, `pe_pmsm_field_weakening`

The base speed, the maximum speed, and at a given speed the d- and q-axis currents, torque and power of a surface (non-salient) permanent-magnet motor at its current and voltage limits (field weakening above base speed; stator resistance neglected).

$$\omega_b = \frac{V_{max}}{p\sqrt{\psi_f^2 + (L_s I_{max})^2}},\ \omega_{max} = \frac{V_{max}}{p(\psi_f - L_s I_{max})},\ i_d = \frac{(V_{max}/p\omega)^2 - \psi_f^2 - L_s^2 I_{max}^2}{2\psi_f L_s}$$

symbol		meaning	SI unit
`Ls`	in	synchronous inductance (Ld = Lq)	H

symbol		meaning	SI unit
psi_f	in	magnet flux linkage	Wb
p	in	pole pairs	,
Imax	in	current limit (peak)	A
Vmax	in	voltage limit (peak phase)	V
omega	in	mechanical speed of interest	rad/s
omega_base	out	base speed (mechanical)	rad/s
omega_max	out	maximum speed (mechanical)	rad/s
rpm_base	out	base speed in rpm	,
id	out	d-axis current at omega	A
iq	out	q-axis current at omega	A
T	out	available torque at omega	N*m
P	out	available power at omega	W

Applies when: psi_f > Ls Imax (finite maximum speed); omega < omega_max; Rs = 0.

```
$ power-electronics solve pe_pmsm_field_weakening "Ls=1 mH" "psi_f=100 mWb" p=4 "Imax=60 A"
"Vmax=200 V" "omega=600 rad/s"
omega_base = 428.7464629 rad/s
omega_max = 1250 rad/s
rpm_base = 4094.227134
id = -33.27777778 A
iq = 49.92584006 A
T = 29.95550404 N*m
P = 17973.30242 W
  by: Surface PMSM field weakening: base speed, maximum speed and torque  (w_b = Vmax/(p
sqrt(psi_f^2 + (Ls Imax)^2)); w_max = Vmax/(p (psi_f - Ls Imax)); above w_b: id = ((Vmax/(p w))^2 -
psi_f^2 - Ls^2 Imax^2)/(2 psi_f Ls))
  Ls = 0.001 H
  psi_f = 0.1 Wb
  Imax = 60 A
  Vmax = 200 V
  omega = 600 rad/s
  assumes: psi_f > Ls Imax (finite maximum speed); omega < omega_max; Rs = 0
```

What the worked example means: This calculation determines the operating limits for a surface permanent magnet motor. The base speed, where voltage constraints begin to limit performance, is computed as 428.746 rad/s. The theoretical maximum speed under current and voltage limits is 1250 rad/s. At the input speed of 600 rad/s, the resulting d-axis current is -33.2778 A and q-axis current is 49.9258 A, producing an available torque of 29.9555 N*m and power of 17973.3 W.

Power quality (3)

Average and RMS of a rectangular pulse train, `pe_pulse_waveform_rms`

The average, RMS and AC-RMS values, form factor and ripple factor of a unipolar rectangular pulse train of amplitude A and duty cycle D (a PWM switch voltage or current).

$$V_{avg} = DA, \quad V_{rms} = \sqrt{D}\,A, \quad RF = \sqrt{\tfrac{1}{D} - 1}$$

symbol		meaning	SI unit
`A`	in	pulse amplitude (any unit)	,
`D`	in	duty cycle (a fraction or %)	,
`avg`	out	average value D A	,
`rms`	out	RMS value sqrt(D) A	,
`ac_rms`	out	RMS of the AC component	,
`form_factor`	out	form factor rms/avg	,
`ripple_factor`	out	ripple factor ac_rms/avg	,

Applies when: 0 < D < 1.

```
$ power-electronics solve pe_pulse_waveform_rms A=12 D=0.25
avg = 3
rms = 6
ac_rms = 5.196152423
form_factor = 2
ripple_factor = 1.732050808
  by: Average and RMS of a rectangular pulse train  (avg = D A; rms = sqrt(D) A; ac = A sqrt(D (1 -
D)); FF = 1/sqrt(D); RF = sqrt(1/D - 1))
  A = 12
  D = 0.25
  assumes: 0 < D < 1
```

What the worked example means: This calculation determines the average, root mean square, and alternating current component of a rectangular pulse train. Using an amplitude of 12 and a duty cycle of 0.25, the resulting average voltage or current is 3. The root mean square value, which represents the equivalent heating effect, is calculated as 6. Additionally, the form factor comparing these two values is 2, while the ripple factor indicating the magnitude of the fluctuating part relative to the average is 1.73205.

Power factor with harmonic distortion, `pe_power_factor_distortion`

The displacement power factor, distortion factor and true power factor of a load drawing a distorted current from a sinusoidal voltage, from the current THD and the displacement angle of its fundamental.

$$PF = \frac{\cos\phi_1}{\sqrt{1 + THD_i^2}}$$

symbol		meaning	SI unit
`THD`	in	current total harmonic distortion (a fraction or %)	,
`phi`	in	displacement angle of the fundamental current (lagging positive)	rad
`DPF`	out	displacement power factor cos(phi)	,
`distortion_factor`	out	distortion factor	,
`PF`	out	true power factor	,

Applies when: sinusoidal voltage; -90 <= phi <= 90 degrees.

```
$ power-electronics solve pe_power_factor_distortion THD=0.483 "phi=0 deg"
DPF = 1
distortion_factor = 0.900466522
PF = 0.900466522
  by: Power factor with harmonic distortion  (PF = cos(phi) / sqrt(1 + THD^2))
  THD = 0.483
  phi = 0 rad
  assumes: sinusoidal voltage; -90 <= phi <= 90 degrees
```

What the worked example means: This calculation determines the true power factor for a load connected to a sinusoidal voltage but drawing a distorted current. It combines the displacement power factor, which is 1, with the distortion factor derived from the current total harmonic distortion of 0.483. The resulting true power factor is 0.900467, reflecting how effectively the apparent power is converted into real work given both the phase shift and the waveform purity.

Total harmonic distortion from harmonic values, `pe_thd_from_harmonics`

The total harmonic distortion, RMS value and distortion factor of a waveform from the RMS value of its fundamental and of its harmonics 2, 3, 4, ... in order.

$$THD = \frac{\sqrt{\sum_{h\geq 2} V_h^2}}{V_1}, \quad V_{rms} = V_1\sqrt{1+THD^2}$$

symbol		meaning	SI unit
`V1`	in	RMS value of the fundamental (any unit, the same as the harmonics)	,
`Vh`	in	RMS values of the harmonics in order of harmonic number, starting with the second	,
`THD`	out	total harmonic distortion	,
`THD_pct`	out	THD in percent	,
`Vrms`	out	RMS value of the waveform	,
`distortion_factor`	out	distortion factor	,

Applies when: V1 > 0, harmonics >= 0.

```
$ power-electronics solve pe_thd_from_harmonics V1=230 "Vh=[0, 11.5, 0, 6.9, 0, 4.6]"
THD = 0.06164414003
THD_pct = 6.164414003
Vrms = 230.4365856
distortion_factor = 0.9981053979
  by: Total harmonic distortion from harmonic values  (THD = sqrt(sum Vh^2)/V1; Vrms = sqrt(V1^2 +
sum Vh^2); DF = V1/Vrms = 1/sqrt(1 + THD^2))
  V1 = 230
  assumes: V1 > 0, harmonics >= 0
```

What the worked example means: This calculation determines the total harmonic distortion, root mean square voltage, and distortion factor for a waveform. It uses the fundamental voltage 230 and the sequence of harmonic voltages [0, 11.5, 0, 6.9, 0, 4.6]. The resulting total harmonic distortion of 0.0616441 indicates how

much the waveform deviates from a pure sine wave, while the computed RMS voltage of 230.437 represents the effective heating value of the distorted signal.

Rectifiers (11)

Capacitor-input rectifier filter: exact ripple and peak diode current, `pe_capacitor_filter_exact`

The exact steady state of a half-wave or full-wave rectifier with a smoothing capacitor and resistive load: diode turn-off angle, recharge angle, peak-to-peak ripple, average output voltage, peak diode current and conduction angle (no small-ripple approximation).

$$\theta = \pi - \tan^{-1}(\omega RC),\ \sin\alpha = \sin\theta\, e^{-(P+\alpha-\theta)/\omega RC},\ I_{D,pk} = V_p\left(\omega C\cos\alpha + \frac{\sin\alpha}{R}\right)$$

symbol		meaning	SI unit
`circuit`	in	half-wave or full-wave	,
`Vp`	in	peak source voltage (after any diode drop)	V
`f`	in	line frequency	Hz
`R`	in	load resistance	ohm
`C`	in	filter capacitance	F
`theta_off_deg`	out	angle at which the diode turns off, degrees	,
`alpha_deg`	out	angle at which the diode turns on again, degrees	,
`dV`	out	peak-to-peak ripple	V
`V_avg`	out	average output voltage	V
`I_D_peak`	out	peak diode current	A
`conduction_deg`	out	diode conduction angle, degrees	,

Applies when: ideal diode and source, steady state.

```
$ power-electronics solve pe_capacitor_filter_exact circuit=half-wave "Vp=169.7 V" "f=0.06 kHz"
"R=500 ohm" "C=100 uF"
theta_off_deg = 93.03678865
alpha_deg = 48.23082389
dV = 43.13189012 V
V_avg = 148.1028626 V
I_D_peak = 4.514737529 A
conduction_deg = 44.80596476
  by: Capacitor-input rectifier filter: exact ripple and peak diode current  (theta = pi - atan(w R
C); sin(alpha) = sin(theta) exp(-(P + alpha - theta)/(w R C)) (bisection), P = 2 pi or pi; dV = Vp
(1 - sin alpha); I_D,peak = Vp (w C cos alpha + sin alpha/R))
  Vp = 169.7 V
  f = 60 Hz
  R = 500 ohm
  C = 0.0001 F
  circuit = half-wave
  assumes: ideal diode and source, steady state
```

In the worked example, circuit = half-wave, Vp = 169.7 V, f = 0.06 kHz, R = 500 ohm, C = 100 uF go through the equation above and give theta_off_deg = 93.03678865, alpha_deg = 48.23082389, dV = 43.13189012 V, V_avg = 148.1028626 V. It applies only when ideal diode and source, steady state: outside that it says what is wrong instead of returning a number.

Commutation overlap in a single-phase thyristor bridge, `pe_single_phase_overlap`

The overlap (commutation) angle and the reduced average output voltage of a single-phase fully controlled bridge with source inductance Ls and a constant dc current.

$$\cos(\alpha + u) = \cos\alpha - \frac{2\omega L_s I_d}{V_m}, \quad V_{dc} = \frac{2V_m}{\pi}\cos\alpha - \frac{2\omega L_s I_d}{\pi}$$

symbol		meaning	SI unit
`Vs`	in	RMS source voltage	V
`f`	in	line frequency	Hz
`Ls`	in	source (commutating) inductance	H
`Id`	in	constant dc current	A
`alpha`	in	firing angle	rad
`u_deg`	out	overlap angle in degrees	,
`Vdc`	out	average output voltage with overlap	V
`dV`	out	voltage lost to commutation	V

Applies when: commutation finishes within the half-cycle.

```
$ power-electronics solve pe_single_phase_overlap "Vs=230 V" "f=0.05 kHz" "Ls=2 mH" "Id=20 A"
"alpha=30 deg"
u_deg = 7.930416019
Vdc = 171.3302643 V
dV = 8 V
  by: Commutation overlap in a single-phase thyristor bridge  (cos(alpha + u) = cos(alpha) - 2 w Ls
Id/Vm; Vdc = 2 Vm cos(alpha)/pi - 2 w Ls Id/pi)
  Vs = 230 V
  f = 50 Hz
  Ls = 0.002 H
  Id = 20 A
  alpha = 0.5235987756 rad
  assumes: commutation finishes within the half-cycle
```

What the worked example means: This calculation determines the commutation overlap angle and the resulting average DC output voltage for a single-phase thyristor bridge with source inductance. Using the firing angle of 30 deg, the RMS source voltage of 230 V, and the DC current of 20 A, it computes that the overlap angle is 7.93042. Consequently, the average output voltage drops to 171.33 V, reflecting a voltage loss of 8 V caused by the finite time required for current transfer between thyristors.

Commutation overlap in a three-phase thyristor bridge, `pe_three_phase_overlap`

The overlap angle, the average output voltage and the voltage lost to commutation of a six-pulse thyristor (or diode, alpha = 0) bridge with source inductance Ls per phase and a constant dc current.

$$\cos(\alpha + u) = \cos\alpha - \frac{2\omega L_s I_d}{\sqrt{2}V_{LL}}, \quad V_{dc} = \frac{3\sqrt{2}V_{LL}}{\pi}\cos\alpha - \frac{3\omega L_s I_d}{\pi}$$

symbol		meaning	SI unit
`VLL`	in	RMS line-to-line voltage	V
`f`	in	line frequency	Hz
`Ls`	in	source inductance per phase	H
`Id`	in	constant dc current	A
`alpha`	in	firing angle	rad
`u_deg`	out	overlap angle in degrees	,
`Vdc`	out	average output voltage	V
`dV`	out	voltage lost to commutation	V

Applies when: commutation finishes before the next one starts.

```
$ power-electronics solve pe_three_phase_overlap "VLL=400 V" "f=0.05 kHz" "Ls=0.5 mH" "Id=100 A"
"alpha=30 deg"
u_deg = 5.856228511
Vdc = 452.8180807 V
dV = 15 V
  by: Commutation overlap in a three-phase thyristor bridge  (cos(alpha + u) = cos(alpha) - 2 w Ls
Id/(sqrt(2) VLL); Vdc = 3 sqrt(2) VLL cos(alpha)/pi - 3 w Ls Id/pi)
  VLL = 400 V
  f = 50 Hz
  Ls = 0.0005 H
  Id = 100 A
  alpha = 0.5235987756 rad
  assumes: commutation finishes before the next one starts
```

What the worked example means: This calculation determines the commutation overlap angle, average direct current output voltage, and voltage loss for a three-phase thyristor bridge. Using an input line-to-line voltage of 400 V, frequency of 0.05 kHz, source inductance of 0.5 mH, load current of 100 A, and firing angle of 30 deg, the model computes an overlap angle of 5.85623. The resulting average output voltage is 452.818 V, while the voltage lost due to commutation is 15 V. These values indicate how much the ideal rectified voltage is degraded by the time required to transfer current between phases.

Half-wave diode rectifier with an RL load, `pe_half_wave_rl_rectifier`

The extinction angle (where the load current returns to zero), the load impedance angle and magnitude, and the average output voltage and current of a half-wave diode rectifier feeding a series RL load.

$$\sin(\beta - \theta) + \sin\theta\, e^{-\beta/\omega\tau} = 0, \quad V_{avg} = \frac{V_m(1 - \cos\beta)}{2\pi}$$

symbol		meaning	SI unit
`Vs`	in	RMS source voltage	V
`f`	in	line frequency	Hz

symbol		meaning	SI unit
`R`	in	load resistance	ohm
`L`	in	load inductance	H
`beta_deg`	out	extinction angle in degrees	,
`theta_deg`	out	load impedance angle atan(wL/R) in degrees	,
`Z`	out	load impedance magnitude	ohm
`V_avg`	out	average output voltage	V
`I_avg`	out	average load current	A

Applies when: ideal diode, no freewheeling diode.

```
$ power-electronics solve pe_half_wave_rl_rectifier "Vs=120 V" "f=0.06 kHz" "R=100 ohm" "L=100 mH"
beta_deg = 200.6578643
theta_deg = 20.65599738
Z = 106.8701223 ohm
V_avg = 52.28236942 V
I_avg = 0.5228236942 A
  by: Half-wave diode rectifier with an RL load  (sin(beta - theta) + sin(theta) exp(-beta/(wL/R))
= 0 (bisection on pi < beta < 2 pi); Vavg = Vm (1 - cos beta)/(2 pi); Iavg = Vavg/R)
  Vs = 120 V
  f = 60 Hz
  R = 100 ohm
  L = 0.1 H
  assumes: ideal diode, no freewheeling diode
```

What the worked example means: This calculation determines the operating point of a half-wave diode rectifier with a series RL load. It solves for the extinction angle where the inductive load current returns to zero, yielding an extinction angle of 200.658 degrees and a load impedance angle of 20.656 degrees. Based on these angles, the average output voltage is calculated as 52.2824 V volts, resulting in an average load current of 0.522824 A amperes through a load impedance magnitude of 106.87 ohm ohms.

Rectifier line current: THD, displacement and power factor, `pe_rectifier_line_current_pf`

The RMS and fundamental line current, current THD, displacement power factor, power factor, real power and apparent power of a single-phase or three-phase (six-pulse) bridge rectifier with a constant dc current at a firing angle (0 for diodes).

$$PF = \frac{I_{s1}}{I_s}\cos\alpha, \quad \frac{I_{s1}}{I_s} = \frac{2\sqrt{2}}{\pi}\ (1\phi),\ \frac{3}{\pi}\ (3\phi)$$

symbol		meaning	SI unit
`circuit`	in	single-phase or three-phase bridge	,
`Id`	in	constant dc output current	A
`Vs`	in	RMS source voltage (line-to-line for three-phase)	V
`alpha`	in	firing angle	rad
`Is_rms`	out	RMS line current	A
`Is1_rms`	out	RMS fundamental line current	A

symbol		meaning	SI unit
`THD`	out	current THD	,
`DPF`	out	displacement power factor cos(alpha)	,
`PF`	out	power factor	,
`P`	out	real power	W
`S`	out	apparent power	VA

Applies when: constant (ripple-free) dc current, no commutation overlap.

```
$ power-electronics solve pe_rectifier_line_current_pf circuit=single-phase "Id=10 A" "Vs=230 V"
"alpha=0 deg"
Is_rms = 10 A
Is1_rms = 9.003163162 A
THD = 0.4834258476
DPF = 1
PF = 0.9003163162
P = 2070.727527 W
S = 2300 VA
  by: Rectifier line current: THD, displacement and power factor  (single-phase: Is = Id, Is1 = 2
sqrt(2) Id/pi (PF = 0.9 cos a); three-phase: Is = sqrt(2/3) Id, Is1 = sqrt(6) Id/pi (PF = 0.955 cos
a))
  Id = 10 A
  Vs = 230 V
  alpha = 0 rad
  circuit = single-phase
  assumes: constant (ripple-free) dc current, no commutation overlap
```

What the worked example means: This calculation determines the line current characteristics for a bridge rectifier operating with a constant dc output current. The RMS line current is found to be 10 A and the fundamental component is 9.00316 A. From these values, the total harmonic distortion is calculated as 0.483426. The overall power factor, which combines the phase shift and waveform distortion, results in 0.900316. This metric indicates how effectively the source voltage and current are aligned in delivering real power 2070.73 W relative to the apparent power 2300 VA.

Rectifier line-current harmonic spectrum, `pe_rectifier_line_harmonics`

The RMS value of harmonic h of the line current of a single-phase or six-pulse three-phase bridge with a constant dc current, its ratio to the fundamental (1/h for characteristic harmonics), and the THD of harmonics up to h.

$$I_h = \frac{I_1}{h}, \quad h = 6k \pm 1\ (3\phi),\ h\ \text{odd}\ (1\phi)$$

symbol		meaning	SI unit
`circuit`	in	single-phase or three-phase bridge	,
`Id`	in	constant dc output current	A
`h`	in	harmonic order	,
`Ih`	out	RMS current of harmonic h	A

symbol		meaning	SI unit
`Ih_over_I1`	out	ratio to the fundamental	,
`THD_to_h`	out	THD counting harmonics up to order h	,
`I1`	out	RMS fundamental current	A

Applies when: 1 <= h <= 49; constant dc current, no overlap.

```
$ power-electronics solve pe_rectifier_line_harmonics circuit=three-phase "Id=100 A" h=5
Ih = 15.59393602 A
Ih_over_I1 = 0.2
THD_to_h = 0.2
I1 = 77.96968012 A
  by: Rectifier line-current harmonic spectrum  (single-phase: odd h, Ih = 2 sqrt(2) Id/(h pi);
three-phase: h = 6k +- 1, Ih = sqrt(6) Id/(h pi); others 0)
  Id = 100 A
  circuit = three-phase
  assumes: 1 <= h <= 49; constant dc current, no overlap
```

What the worked example means: This calculation determines the root mean square value of the line current harmonic at order 5 for a rectifier bridge operating with a constant direct current of 100 A. The result, 15.5939 A, represents the magnitude of that specific harmonic component. The ratio of this harmonic to the fundamental current 77.9697 A is given by 0.2, indicating its relative strength compared to the primary frequency. Additionally, the total harmonic distortion accumulated from all characteristic harmonics up to order 5 is reported as 0.2, providing a measure of overall waveform purity.

Single-phase AC voltage controller (resistive load), `pe_ac_voltage_controller`

The RMS output voltage and current, load power, input power factor and the average and RMS thyristor currents of a single-phase AC voltage controller (antiparallel thyristors or a triac) with a resistive load at a firing angle.

$$V_o = V_s\sqrt{1 - \frac{\alpha}{\pi} + \frac{\sin 2\alpha}{2\pi}}, \quad PF = \frac{V_o}{V_s}$$

symbol		meaning	SI unit
`Vs`	in	RMS source voltage	V
`alpha`	in	firing angle	rad
`R`	in	load resistance	ohm
`Vo_rms`	out	RMS output voltage	V
`Io_rms`	out	RMS load current	A
`P`	out	load power	W
`PF`	out	input power factor	,
`I_scr_avg`	out	average thyristor current	A
`I_scr_rms`	out	RMS thyristor current	A

Applies when: 0 <= alpha < 180 degrees; resistive load.

```
$ power-electronics solve pe_ac_voltage_controller "Vs=230 V" "alpha=60 deg" "R=10 ohm"
Vo_rms = 206.2958829 V
Io_rms = 20.62958829 A
P = 4255.799131 W
PF = 0.8969386214
I_scr_avg = 7.765228227 A
I_scr_rms = 14.58732177 A
  by: Single-phase AC voltage controller (resistive load)  (Vo = Vs sqrt(1 - alpha/pi + sin(2
alpha)/(2 pi)); PF = Vo/Vs; I_SCR,avg = sqrt(2) Vs (1 + cos alpha)/(2 pi R))
  Vs = 230 V
  alpha = 1.047197551 rad
  R = 10 ohm
  assumes: 0 <= alpha < 180 degrees; resistive load
```

What the worked example means: This calculation determines the performance of a single-phase AC voltage controller with a resistive load. Given the source voltage 230 V, the firing angle 60 deg, and the resistance 10 ohm, it computes the RMS output voltage 206.296 V, the RMS load current 20.6296 A, the load power 4255.8 W, and the input power factor 0.896939. It also finds the average thyristor current 7.76523 A and the RMS thyristor current 14.5873 A. The results show how delaying the turn-on of the thyristors reduces the effective voltage delivered to the load, thereby controlling the power.

Single-phase phase-controlled thyristor rectifier, `pe_single_phase_controlled_rectifier`

The average, RMS and AC (ripple) output voltage of a single-phase thyristor rectifier at a firing angle: half-wave with a resistive load, fully controlled bridge with continuous load current, or semi-converter (half-controlled) with continuous current.

$$V_{dc,HW} = \frac{V_m(1+\cos\alpha)}{2\pi},\ V_{dc,FB} = \frac{2V_m\cos\alpha}{\pi},\ V_{dc,semi} = \frac{V_m(1+\cos\alpha)}{\pi}$$

symbol		meaning	SI unit
`circuit`	in	half-wave, full-bridge or semi-converter	,
`Vs`	in	RMS source voltage	V
`alpha`	in	firing angle (delay from the natural commutation point)	rad
`Vdc`	out	average output voltage	V
`Vrms`	out	RMS output voltage	V
`Vac_rms`	out	RMS of the AC component	V
`mode`	out	rectifying or inverting (negative average voltage)	,

Applies when: 0 <= alpha < 180 degrees; ideal thyristors, no source inductance.

```
$ power-electronics solve pe_single_phase_controlled_rectifier circuit=full-bridge "Vs=230 V"
"alpha=30 deg"
Vdc = 179.3302643 V
Vrms = 230 V
Vac_rms = 144.0161668 V
mode = rectifying
  by: Single-phase phase-controlled thyristor rectifier  (half-wave: Vdc = Vm (1 + cos a)/(2 pi);
full bridge: Vdc = 2 Vm cos a/pi; semi-converter: Vdc = Vm (1 + cos a)/pi)
  Vs = 230 V
  alpha = 0.5235987756 rad
  circuit = full-bridge
  assumes: 0 <= alpha < 180 degrees; ideal thyristors, no source inductance
```

What the worked example means: This calculation determines the direct current characteristics of a single-phase thyristor rectifier based on the chosen topology, which may be half-wave, full bridge, or semi-converter. Using an RMS source voltage of 230 V and a firing angle of 30 deg, the model computes the average output voltage as 179.33 V. It also provides the root mean square output voltage of 230 V and the alternating component magnitude of 144.016 V. The operating mode is identified as rectifying, indicating whether the device acts as a rectifier or inverter.

Three-phase diode bridge rectifier with resistive load, `pe_three_phase_diode_bridge`

The average and RMS output voltage, ripple and form factors, ripple frequency, diode peak inverse voltage, and the load, diode and line currents of a six-pulse three-phase diode bridge feeding a resistor.

$$V_{dc} = \frac{3\sqrt{2}\,V_{LL}}{\pi}, \quad V_{rms} = \sqrt{2}V_{LL}\sqrt{\tfrac{1}{2} + \tfrac{3\sqrt{3}}{4\pi}}$$

symbol		meaning	SI unit
`VLL`	in	RMS line-to-line source voltage	V
`f`	in	line frequency	Hz
`R`	in	load resistance	ohm
`Vdc`	out	average output voltage	V
`Vrms`	out	RMS output voltage	V
`ripple_factor`	out	ripple factor	,
`form_factor`	out	form factor	,
`f_ripple`	out	ripple frequency	Hz
`PIV`	out	diode peak inverse voltage	V
`Idc`	out	average load current	A
`I_diode_avg`	out	average diode current	A
`I_diode_rms`	out	RMS diode current	A
`Is_rms`	out	RMS line current	A

Applies when: ideal diodes, no source inductance, resistive load.

```
$ power-electronics solve pe_three_phase_diode_bridge "VLL=400 V" "f=0.05 kHz" "R=50 ohm"
Vdc = 540.1897897 V
Vrms = 540.6652707 V
ripple_factor = 0.04196661381
form_factor = 1.000880211
f_ripple = 300 Hz
PIV = 565.6854249 V
Idc = 10.80379579 A
I_diode_avg = 3.601265265 A
I_diode_rms = 6.243064791 A
Is_rms = 8.829026898 A
  by: Three-phase diode bridge rectifier with resistive load  (Vm = sqrt(2) VLL; Vdc = 3 Vm/pi;
Vrms = Vm sqrt(1/2 + 3 sqrt(3)/(4 pi)); diode avg = Idc/3)
  VLL = 400 V
  f = 50 Hz
  R = 50 ohm
  assumes: ideal diodes, no source inductance, resistive load
```

What the worked example means: This calculation determines the performance of a six-pulse three-phase diode bridge rectifier supplying a resistive load. Using an input line-to-line RMS voltage of 400 V and a load resistance of 50 ohm, the model computes the DC output voltage as 540.19 V and the RMS output voltage as 540.665 V. These values define the steady-state operating point, allowing for the derivation of current levels such as the average load current of 10.8038 A and the peak inverse voltage across each diode of 565.685 V. The results assume ideal switching components and neglect source inductance, providing a baseline for understanding converter behavior under resistive loading conditions.

Three-phase fully controlled thyristor bridge, `pe_three_phase_controlled_rectifier`

The average and RMS output voltage, the power, and the thyristor and line currents of a six-pulse fully controlled thyristor bridge with continuous (constant) load current at a firing angle, rectifying or inverting.

$$V_{dc} = \frac{3\sqrt{2}V_{LL}}{\pi}\cos\alpha, \quad I_{s,rms} = \sqrt{\tfrac{2}{3}}\, I_d$$

symbol		meaning	SI unit
`VLL`	in	RMS line-to-line source voltage	V
`alpha`	in	firing angle	rad
`Id`	in	constant dc output current	A
`Vdc`	out	average output voltage	V
`Vrms`	out	RMS output voltage	V
`P`	out	dc output power Vdc Id	W
`I_thy_avg`	out	average thyristor current	A
`I_thy_rms`	out	RMS thyristor current	A
`Is_rms`	out	RMS line current	A
`mode`	out	rectifying or inverting	,

Applies when: 0 <= alpha < 180 degrees; continuous constant current, no source inductance.

```
$ power-electronics solve pe_three_phase_controlled_rectifier "VLL=415 V" "alpha=45 deg" "Id=50 A"
Vdc = 396.2958083 V
Vrms = 415 V
P = 19814.79041 W
I_thy_avg = 16.66666667 A
I_thy_rms = 28.86751346 A
Is_rms = 40.82482905 A
mode = rectifying
  by: Three-phase fully controlled thyristor bridge  (Vdc = 3 sqrt(2) VLL cos(alpha)/pi; Vrms = Vm
sqrt(1/2 + 3 sqrt(3) cos(2 alpha)/(4 pi)); I_thy = Id/3 (avg), Id/sqrt(3) (rms))
  VLL = 415 V
  alpha = 0.7853981634 rad
  Id = 50 A
  assumes: 0 <= alpha < 180 degrees; continuous constant current, no source inductance
```

What the worked example means: This calculation determines the operating characteristics of a three-phase fully controlled thyristor bridge. Using the line-to-line RMS source voltage 415 V and the firing angle 45 deg, the model computes the average DC output voltage as 396.296 V and the root-mean-square output voltage as 415 V. With a constant load current of 50 A, the resulting DC power delivered to the load is 19814.8 W. The currents flowing through individual thyristors have an average value of 16.6667 A and a root-mean-square value of 28.8675 A, while the RMS line current on the AC side is 40.8248 A. The sign of the voltage indicates whether the circuit is operating in rectifying or inverting mode, which is reported as rectifying.

Three-phase half-wave (three-pulse) diode rectifier, `pe_three_phase_half_wave_rectifier`

The average and RMS output voltage, ripple and form factors, ripple frequency, diode peak inverse voltage and the load and diode currents of a three-pulse (star, half-wave) diode rectifier feeding a resistor.

$$V_{dc} = \frac{3\sqrt{3}\,V_m}{2\pi}, \quad V_{rms} = V_m\sqrt{\tfrac{1}{2} + \tfrac{3\sqrt{3}}{8\pi}}, \quad PIV = \sqrt{3}V_m$$

symbol		meaning	SI unit
`Vph`	in	RMS phase (line-to-neutral) voltage	V
`f`	in	line frequency	Hz
`R`	in	load resistance	ohm
`Vdc`	out	average output voltage	V
`Vrms`	out	RMS output voltage	V
`ripple_factor`	out	ripple factor	,
`form_factor`	out	form factor	,
`f_ripple`	out	ripple frequency	Hz
`PIV`	out	diode peak inverse voltage	V
`Idc`	out	average load current	A
`I_diode_avg`	out	average diode current	A
`I_diode_rms`	out	RMS diode current	A

Applies when: ideal diodes, resistive load.

```
$ power-electronics solve pe_three_phase_half_wave_rectifier "Vph=230 V" "f=0.05 kHz" "R=20 ohm"
Vdc = 268.9953964 V
Vrms = 273.4483021 V
ripple_factor = 0.1827065996
form_factor = 1.016553836
f_ripple = 150 Hz
PIV = 563.3826408 V
Idc = 13.44976982 A
I_diode_avg = 4.483256607 A
I_diode_rms = 7.893772542 A
  by: Three-phase half-wave (three-pulse) diode rectifier  (Vm = sqrt(2) Vph; Vdc = 3 sqrt(3) Vm/(2
pi); Vrms = Vm sqrt(1/2 + 3 sqrt(3)/(8 pi)); PIV = sqrt(3) Vm)
  Vph = 230 V
  f = 50 Hz
  R = 20 ohm
  assumes: ideal diodes, resistive load
```

What the worked example means: This calculation determines the performance of an ideal three-phase half-wave diode rectifier with a resistive load. Given the input phase voltage of 230 V at a frequency of 0.05 kHz hertz, the system computes the peak phase voltage to find the average DC output voltage of 268.995 V and the RMS output voltage of 273.448 V. These values define the form factor as 1.01655 and the ripple factor as 0.182707. The ripple frequency is found to be 150 Hz hertz, which is three times the input line frequency. Additionally, the peak inverse voltage stress on each diode is calculated as 563.383 V. The resulting average load current is 13.4498 A, while the average and RMS currents through each individual diode are 4.48326 A and 7.89377 A respectively.

Resonant converters (3)

Dual active bridge: power transfer and inductor current, `pe_dual_active_bridge_power`

The power transferred by a dual-active-bridge converter with single phase-shift modulation, the maximum transferable power, the inductor current at the switching instants of both bridges and its RMS value.

$$P = \frac{nV_1V_2\,\phi(\pi-\phi)}{2\pi^2 f_s L}, \quad P_{max} = \frac{nV_1V_2}{8 f_s L}$$

symbol		meaning	SI unit
`V1`	in	primary dc voltage	V
`V2`	in	secondary dc voltage	V
`n`	in	turns ratio Np/Ns	,
`L`	in	series (leakage) inductance referred to the primary	H
`fs`	in	switching frequency	Hz
`phi`	in	phase shift of the secondary bridge	rad
`P`	out	transferred power	W
`P_max`	out	maximum transferable power	W
`i0`	out	inductor current when the primary bridge switches	A
`i_phi`	out	inductor current when the secondary bridge switches	A

symbol		meaning	SI unit
`I_rms`	out	RMS inductor current	A

Applies when: square-wave bridges, single phase shift 0 < phi <= 90 degrees.

```
$ power-electronics solve pe_dual_active_bridge_power "V1=400 V" "V2=48 V" n=8 "L=50 uH" "fs=100
kHz" "phi=30 deg"
P = 2133.333333 W
P_max = 3840 W
i0 = -7.2 A
i_phi = 5.866666667 A
I_rms = 6.175699091 A
  by: Dual active bridge: power transfer and inductor current  (P = n V1 V2 phi (pi - phi)/(2 pi^2
fs L); i(0) = -(V1 pi + nV2 (2 phi - pi))/(2 w L); i(phi) = i(0) + (V1 + nV2) phi/(w L))
  V1 = 400 V
  V2 = 48 V
  n = 8
  L = 5e-05 H
  fs = 100000 Hz
  phi = 0.5235987756 rad
  assumes: square-wave bridges, single phase shift 0 < phi <= 90 degrees
```

What the worked example means: This calculation determines the power handling capability of a dual active bridge converter using single phase shift modulation. The result shows that the actual transferred power is 2133.33 W, which is below the theoretical maximum of 3840 W for this configuration. The magnetic component carries an inductor current that starts at -7.2 A when the primary switches and ends at 5.86667 A when the secondary switches, resulting in a root mean square value of 6.1757 A. These values define the electrical stress on the components and the efficiency of energy transfer between the two dc ports.

LLC resonant converter: tank gain (first harmonic), `pe_llc_resonant_gain`

The two resonant frequencies, the reflected AC load resistance, quality factor, inductance ratio and voltage gain of an LLC resonant tank at a switching frequency (first-harmonic approximation, full-wave rectified output).

$$M = \left| \frac{j\omega L_m \parallel R_{ac}}{j\omega L_r + \frac{1}{j\omega C_r} + j\omega L_m \parallel R_{ac}} \right|, \quad R_{ac} = \frac{8n^2 R}{\pi^2}$$

symbol		meaning	SI unit
`Lr`	in	series resonant inductance	H
`Cr`	in	resonant capacitance	F
`Lm`	in	magnetizing inductance	H
`n`	in	transformer turns ratio Np/Ns	,
`R`	in	dc load resistance	ohm
`f`	in	switching frequency	Hz
`fr1`	out	series resonant frequency	Hz
`fr2`	out	lower resonant frequency	Hz

symbol		meaning	SI unit
`Rac`	out	reflected AC load resistance	ohm
`Q`	out	quality factor sqrt(Lr/Cr)/Rac	,
`k`	out	inductance ratio Lm/Lr	,
`M`	out	tank voltage gain	,

Applies when: first-harmonic approximation.

```
$ power-electronics solve pe_llc_resonant_gain "Lr=60 uH" "Cr=27 nF" "Lm=300 uH" n=8 "R=2 ohm"
"f=100 kHz"
fr1 = 125043.9328 Hz
fr2 = 51048.9718 Hz
Rac = 103.752892 ohm
Q = 0.454353138
k = 5
M = 1.0981695
  by: LLC resonant converter: tank gain (first harmonic)  (Rac = 8 n^2 R/pi^2; M = |Zp/(Zs + Zp)|,
Zp = jwLm || Rac, Zs = jwLr + 1/(jwCr))
  Lr = 6e-05 H
  Cr = 2.7e-08 F
  Lm = 0.0003 H
  n = 8
  R = 2 ohm
  f = 100000 Hz
  assumes: first-harmonic approximation
```

In the worked example, Lr = 60 uH, Cr = 27 nF, Lm = 300 uH, n = 8, R = 2 ohm, f = 100 kHz go through the equation above and give fr1 = 125043.9328 Hz, fr2 = 51048.9718 Hz, Rac = 103.752892 ohm, Q = 0.454353138. It applies only when first-harmonic approximation: outside that it says what is wrong instead of returning a number.

Series resonant converter: tank gain (first harmonic), `pe_series_resonant_gain`

The resonant frequency, characteristic impedance, quality factor, normalised frequency and voltage gain of a series resonant tank driving an equivalent AC load resistance (first-harmonic approximation).

$$M = \frac{1}{\sqrt{1 + Q^2\left(f_n - \frac{1}{f_n}\right)^2}}, \quad Q = \frac{\sqrt{L_r/C_r}}{R}$$

symbol		meaning	SI unit
`Lr`	in	resonant inductance	H
`Cr`	in	resonant capacitance	F
`R`	in	equivalent AC load resistance	ohm
`f`	in	switching frequency	Hz
`fr`	out	resonant frequency	Hz
`Z0`	out	characteristic impedance sqrt(Lr/Cr)	ohm
`Q`	out	quality factor	,

symbol		meaning	SI unit
`fn`	out	normalised frequency f/fr	,
`M`	out	tank voltage gain	,

Applies when: first-harmonic approximation.

```
$ power-electronics solve pe_series_resonant_gain "Lr=100 uH" "Cr=25 nF" "R=30 ohm" "f=120 kHz"
fr = 100658.4242 Hz
Z0 = 63.2455532 ohm
Q = 2.108185107
fn = 1.192150592
M = 0.8019643432
  by: Series resonant converter: tank gain (first harmonic)  (fr = 1/(2 pi sqrt(Lr Cr)); Q =
sqrt(Lr/Cr)/R; M = 1/sqrt(1 + Q^2 (fn - 1/fn)^2))
  Lr = 0.0001 H
  Cr = 2.5e-08 F
  R = 30 ohm
  f = 120000 Hz
  assumes: first-harmonic approximation
```

What the worked example means: This calculation determines the voltage gain of a series resonant converter using the first-harmonic approximation. It starts by finding the resonant frequency fr as 100658 Hz and the characteristic impedance Z0 as 63.2456 ohm. The quality factor Q, which describes damping relative to the load resistance R of 30 ohm, is calculated as 2.10819. Comparing the switching frequency f of 120 kHz to the resonant frequency yields the normalised frequency fn of 1.19215. The resulting gain M of 0.801964 indicates how much the tank amplifies or attenuates the fundamental component of the input voltage.

Thermal (3)

Junction temperature under periodic power pulses, `pe_foster_periodic_pulses`

The peak, minimum and average junction temperature rise and the temperature ripple of a device described by a Foster network under a periodic rectangular power pulse train (exact periodic steady state, no single-pulse approximation).

$$\Delta T_{pk} = \sum_i P R_i \frac{1 - e^{-t_p/\tau_i}}{1 - e^{-T/\tau_i}}$$

symbol		meaning	SI unit
`R`	in	Foster thermal resistances in kelvin per watt	,
`tau`	in	Foster time constants in seconds	,
`P`	in	pulse power	W
`tp`	in	pulse duration	s
`T`	in	pulse period	s
`dT_peak`	out	peak temperature rise (end of each pulse)	K
`dT_min`	out	minimum temperature rise (start of each pulse)	K
`dT_avg`	out	average rise P Rth tp/T	K

symbol		meaning	SI unit
`ripple`	out	peak minus minimum	K

Applies when: periodic steady state; tp < T.

```
$ power-electronics solve pe_foster_periodic_pulses "R=[0.05, 0.1, 0.15]" "tau=[0.0001, 0.003,
0.05]" "P=500 W" "tp=2 ms" "T=10 ms"
dT_peak = 66.45250612 K
dT_min = 15.57762553 K
dT_avg = 30 K
ripple = 50.87488059 K
  by: Junction temperature under periodic power pulses  (per element: peak = P R (1 - e^(-
tp/tau))/(1 - e^(-T/tau)); minimum = peak e^(-(T - tp)/tau); summed over the network)
  P = 500 W
  tp = 0.002 s
  T = 0.01 s
  assumes: periodic steady state; tp < T
```

What the worked example means: This calculation determines the exact periodic steady-state thermal response of a device modeled by a Foster network. It computes the peak temperature rise at the end of each pulse, the minimum rise at the start, and the average rise based on duty cycle. For the given inputs, the peak rise reaches 66.4525 K and the minimum settles at 15.5776 K, resulting in a temperature swing of 50.8749 K. This method avoids single-pulse approximations by summing the exponential contributions of all thermal elements over the full period.

Several power devices on one heat sink, `pe_thermal_shared_heatsink`

The heat-sink temperature and every device's junction temperature when several devices, each with its own junction-to-case and case-to-sink resistance, share one heat sink to ambient.

$$T_s = T_a + R_{sa}\sum_k P_k, \quad T_{j,k} = T_s + P_k(R_{jc} + R_{cs})$$

symbol		meaning	SI unit
`P`	in	loss of each device in watts	,
`Rjc`	in	junction-to-case thermal resistance of each device	K/W
`Rcs`	in	case-to-sink (interface) resistance of each device	K/W
`Rsa`	in	sink-to-ambient resistance	K/W
`Ta`	in	ambient temperature	K
`P_total`	out	total loss	W
`Ts`	out	heat-sink temperature	K
`Tj`	out	junction temperature of each device, kelvin	,
`Tj_max`	out	hottest junction	K
`Tj_max_C`	out	hottest junction in degC	,

Applies when: steady state; the sink is isothermal.

```
$ power-electronics solve pe_thermal_shared_heatsink "P=[20, 20, 15]" "Rjc=0.8 K/W" "Rcs=0.2 K/W"
"Rsa=0.5 K/W" "Ta=40 degC"
P_total = 55 W
Ts = 340.65 K
Tj = [360.65,360.65,355.65]
Tj_max = 360.65 K
Tj_max_C = 87.5
  by: Several power devices on one heat sink  (Ts = Ta + Rsa sum(P); Tj,k = Ts + P_k (Rjc + Rcs))
  Rjc = 0.8 K/W
  Rcs = 0.2 K/W
  Rsa = 0.5 K/W
  Ta = 313.15 K
  assumes: steady state; the sink is isothermal
```

What the worked example means: This calculation determines the thermal state of multiple power devices sharing a single heat sink. First, the total power loss from all devices is summed to find the overall heat generation, which is 55 W. This total loss flows through the sink-to-ambient resistance, raising the heat sink temperature above ambient to 340.65 K. Each individual device then experiences additional heating based on its own dissipation and internal resistances. The resulting junction temperatures are calculated for each device, identifying the maximum value as 360.65 K, or 87.5 in Celsius.

Transient thermal impedance of a Foster network, `pe_foster_transient_thermal`

The transient thermal impedance Zth(tp) of a device described by a Foster RC network (datasheet R_i, tau_i pairs) and the junction temperature rise for a single power pulse of duration tp, with the steady-state values.

$$Z_{th}(t) = \sum_i R_i \left(1 - e^{-t/\tau_i}\right), \quad \Delta T_j = P\, Z_{th}(t_p)$$

symbol		meaning	SI unit
`R`	in	Foster thermal resistances in kelvin per watt	,
`tau`	in	Foster time constants in seconds	,
`P`	in	pulse power	W
`tp`	in	pulse duration	s
`Zth`	out	transient thermal impedance at tp	K/W
`dTj`	out	junction temperature rise at the end of the pulse	K
`Rth_total`	out	steady-state thermal resistance	K/W
`dTj_steady`	out	steady-state rise for continuous power	K

Applies when: linear network, starting from thermal equilibrium.

```
$ power-electronics solve pe_foster_transient_thermal "R=[0.05, 0.1, 0.15]" "tau=[0.0001, 0.003,
0.05]" "P=500 W" "tp=10 ms"
Zth = 0.1736229877 K/W
dTj = 86.81149385 K
Rth_total = 0.3 K/W
dTj_steady = 150 K
  by: Transient thermal impedance of a Foster network  (Zth(t) = sum R_i (1 - exp(-t/tau_i)); dTj =
P Zth(tp))
  P = 500 W
  tp = 0.01 s
  assumes: linear network, starting from thermal equilibrium
```

In the worked example, R = [0.05, 0.1, 0.15], tau = [0.0001, 0.003, 0.05], P = 500 W, tp = 10 ms go through the equation above and give Zth = 0.1736229877 K/W, dTj = 86.81149385 K, Rth_total = 0.3 K/W, dTj_steady = 150 K. It applies only when linear network, starting from thermal equilibrium: outside that it says what is wrong instead of returning a number.

Questions and reports: support@ai999x.com. AI999X, The Future Is Self-Improving.