SPI Driver

Task

Initialization API

Standard API

<device>_get_data

<device>_init

Initialize CS pin

Device Driver

Start Transaction

Finish Transaction

Hardware Initalization

Initialize SPI Interface:
SCK, MOSI, MISO,
Peripheral Clock, etc.
(ONCE)

SPI Interface