



Wattuino RC Roboter Controller - ATSAMW25 = SAMD21 + WINC1500

SPI: Input voltage 0V - 5V Output voltage 0V - 3.3V





I²C: Input and output voltage 0V - 5V

UART: Input voltage 0V - 5V Output voltage 0V - 3.3V Use **Serial1** to address

J1-J7: Input voltage 0V - 5V Output voltage 0V - 3.3V









LED BUILTIN-



M1-M4, S1: output only, 0V - VIN, max 1A per phase

1st bit 2nd bit

M4

M3



10 = forward

01 = reverse

00 = coast11 = brake

M2

M1

S1 max 2A

VIN: 7-14V, for small loads use 5V USB



GND

Use Serial to address USB serial

















