


SolarTrac4® API Guide



Access to SolarTrac4 API functions is by http call.

API Interface



Call Structure:

https://	Host IP Address	:7781	?	objtype=objtype	&objid=objid	&objprop=objprop	&cmd=command	&newval=command
----------	-----------------	-------	---	-----------------	--------------	------------------	--------------	-----------------

Parameters

objtypes	objprop	cmd	
=======	=======	=======	
building	status	read	
floor	pos	set	
zone	mode		
motor	Config		
sensor	value		

Response Format: Responses to http calls are in JSON format

Call Examples

To move a shade with id 17 to position 3: http://localhost:7781/?objtype=motor&objid=17&objprop=pos&cmd=set&newval=3
To move a zone with id 103 to position 1: http://localhost:7781/?objtype=zone&objid=17&objprop=pos&cmd=set&newval=3



command	object	objectid	obj property	value	response	comment
read	solartrac		version		version of each module	
read	building	nnn	objects		floor list	
read	global		status	night, clear, cloud	skytype, sunrise, sunset, solaz, solalt	
set	global		skytype	clear, cloud	message confirmation	force sky type
read	alerts		status		list of all open alerts/notifications	, .,,,,
read	scheduler		events		list all scheduled events	
read	floor	nnn	objects		zone list, sensor list, interface list	
read	zone	nnn	status		current position, current mode	
set	zone	nnn	position	0-31, auto	message confirmation	
set	zone	nnn	mode	maint_on/maint_off/inhin_on/inhib_off	message confirmation	
read	zone	nnn	objects		motor list	
read	zone	nnn	config		zone configuration settings	
set	zone	nnn	solpen			
set	zone	nnn	sleeptime			
read	motor	nnn	status		current position, current mode	
set	motor	nnn	position	0-31, auto	message confirmation	
set	motor	nnn	mode	maint on/maint off/inhin on/inhib off	message confirmation	
read	motor	nnn	config	maint_on/maint_on/mini_on/mini_on	zone configuration settings	
Teau	motor	111111	comig		Zone configuration settings	
read	sensor	nnn	status		current value	
set	sensor	nnn	value	0-65,000	message confirmation	virtual sensor



Zone Status Query

call

http://192.168.1.200:7781?objtype=zone&objid=2&objprop=status&cmd=read

```
response
{
   "message": {
    "objtype": "zone",
    "objid": "2",
    "cmd": "read",
    "objprop": "status",
    "timeposted": "2020-03-04 16:29:49"
},
   "data": {
    "name": "Zone 01-02 DC",
    "mode": "SUClear",
    "current position": "4"
}
}
```



Zone Position Query

call

http://192.168.1.200:7781?objtype=zone&objid=3&objprop=pos&cmd=read

```
response
{
    "message": {
        "objtype": "zone",
        "objid": "3",
        "cmd": "read",
        "objprop": "pos",
        "timeposted": "2020-03-04 17:11:40"
},
    "data": {
        "name": "Zone 01-03",
        "current position": "0"
}
```



Zone Mode Query

call

http://192.168.1.200:7781?objtype=zone&objid=3&objprop=mode&cmd=read

```
response
{
    "message": {
        "objtype": "zone",
        "objid": "3",
        "cmd": "read",
        "objprop": "mode",
        "timeposted": "2020-03-04 17:09:38"
},
    "data": {
        "name": "Zone 01-03",
        "current mode": "SUClear"
}
}
```



Zone Mode Override

call

http://192.168.1.200:7781?objtype=zone&objid=3&objprop=mode&cmd=set&newval=maint_on

```
response
{
    "message": {
        "objtype": "zone",
        "objid": "3",
        "cmd": "set",
        "objprop": "mode",
        "timeposted": "2020-03-04 17:13:08"
    },
    "data": {
        "current mode": "0",
        "set mode": "maint_on"
    }
}
```



Zone Position Override

call

http://192.168.1.200:7781?objtype=zone&objid=3&objprop=pos&cmd=set&newval=1

```
response
{
    "message": {
        "objtype": "zone",
        "objid": "3",
        "cmd": "set",
        "objprop": "pos",
        "timeposted": "2020-03-04 16:55:31"
},
    "data": {
        "name": "Zone 01-03",
        "current position": "0",
        "set position": "1"
}
}
```



Motor Status Query

call

http://192.168.1.200:7781?objtype=motor&objid=101&objprop=status&cmd=read

```
response
 "message": {
  "objtype": "motor",
  "objid": "101",
  "cmd": "read",
  "objprop": "status",
  "timeposted": "2020-03-04 16:39:09"
 "data": {},
 "data": [
   "name": "Zone 01-02 DC",
   "current mode": "UNKNOWN",
   "current position": "-1",
   "scheduled mode": "CLEAR",
   "scheduled position": "5"
```



Motor Position Override

call

http://192.168.1.200:7781?objtype=motor&objid=101&objprop=pos&cmd=set&newval=3

```
response
{
    "message": {
        "objtype": "motor",
        "objid": "101",
        "cmd": "set",
        "objprop": "pos",
        "timeposted": "2020-03-04 17:02:56"
},
    "data": {
        "name": "EV 0325",
        "current position": "-1",
        "set position": "3"
}
```



Sensor Status Query

call

http://192.168.1.200:7781?objtype=sensor&objid=1&objprop=status&cmd=read

```
response
 "message": {
  "objtype": "sensor",
  "objid": "1",
  "cmd": "read",
  "objprop": "status",
  "timeposted": "2020-03-04 17:24:44"
 "data": {
  "name": "Radiometer W Matrix"
  "location": "roof"
  "current value": "27621"
  "units": "LUX"
```