

Instructions for Installing Arduino IDE, mBot Library & Driver

- 1. The Arduino Integrated Development Environment (IDE) is the key software used for programming the mBot. To download it, go to https://www.arduino.cc/en/software. Scroll down to "Legacy IDE (1.8.X)", choose Arduino IDE 1.8.19. You can also download the latest version (2.x.x), just that the interface will be slightly different.
 - For Windows operating systems, you may choose "Windows Win 7 and newer".
 - For Mac OS X, you may choose "Mac OS X 10.10 or newer".



- 2. After downloading the Arduino IDE's installation file, install it into your computer.
- 3. Next, we will download mBot's library. Click on the following link:

 https://codeload.github.com/Makeblock-official/Makeblock-Libraries/zip/master
 (Take note of where you'd saved the file.
 There is no need to unzip this file.)
- 4. We will now add mBot's library into your Arduino IDE.
 - In the Arduino IDE, choose from the menu: "Sketch" -> "Include Library" -> "Add .ZIP Library", then select the .zip file you'd downloaded in Step 3.



- 5. Now, we need to install the USB driver for the mBot.
 - For Windows operating system, download the driver from http://www.wch-ic.com/downloads/CH341SER ZIP.html



- o Unzip the ".zip" file.
- To install the driver, run the "SETUP.EXE" file inside the newly created folder.
- For Mac OS X, download the driver from http://www.wch-ic.com/downloads/CH341SER MAC ZIP.html



- Unzip the ".zip" file.
- o Follow the instructions given in "ReadMe.pdf".