### 1 Pacemaker Cells

- Function as the natural "pacemakers" of the heart, initiating the electrical impulses that set the heart's rhythm.
- Gradual depolarization occurs until a threshold is reached, triggering the action potential.
- Located primarily in the sinoatrial (SA) node, with secondary pacemakers in the atrioventricular (AV) node and Purkinje system.

## 2 Contractile (Myocardial) Cells

- Responsible for the mechanical contraction of the heart.
- Generate forceful contractions upon electrical stimulation from the pacemaker cells.

# 3 The major types of Waves in a given ECG waveform,

- P-wave
- QRS complex
- T-wave

Between these three waves, there are transition segments like the P-R segment(between P and QRS complex), the S-T segment(between QRS and T).

# Parts of the ECG ORS Complex R wave S wave R Segment P Segment T

QT Interval

# 4 Significance of each part

**Baseline** 

PR Interval

### 4.1 P wave:

- 1. This part represents Atrial depolarisation, which leads to contraction of atria.
- 2. When atria contracts, P wave is observed.

### 4.2 PR segment:

- 1. This tell about the delay of AV(atrioventricular) node.
- 2. AV node is like a gatekeeper, which gives time to atria for dumping blood into Ventricules.

### 4.3 PR interval:

- 1. It extends from the beginning of the P wave till QRS complex.
- 2. Demonstrates time it takes for electrical signal to go form atria to AV node.
- 3. This can be used to determine whether patient has a heart block or not.

### 4.4 QRS complex:

- 1. It represents Ventricular Depolarization (leading to contraction of the ventricules).
- 2. Atrial repolarization also occurs here, but not visible.

### 4.5 ST segment:

- 1. Signifies completion of ventricular depolarization and the beginning of ventricular repolarization.
- 2. This is a flat line(isoelectric), which signifies the resting of the heart cells.

### 4.6 T wave:

- 1. Signifies the beginning of ventricular repolarization (Relaxation).
- 2. Caused by large size of the ventricules as they relax.

After T wave a flat line is observed due to ventricular repolarization and again it goes to new P wave and continues this Cycle again.

### 4.7 QT interval:

1. This represents the time taken for electrical signals to cause the ventricles to contract and then rest.

# 5 Coordination of Action Potentials and the Cardiac Cycle

The sequence of pacemaker and contractile cell action potentials coordinates the electrical and mechanical phases of the heart as follows:

- 1. Atrial Depolarization and Contraction: The SA node action potential propagates through atrial myocardium, causing atrial depolarization (P wave) and contraction, which contributes to ventricular filling.
- 2. **AV Nodal Delay:** The impulse is delayed at the AV node (PR interval), ensuring atrial contraction completes before ventricular activation.
- 3. Ventricular Depolarization and Isovolumetric Contraction: Rapid conduction through the His-Purkinje system leads to synchronized ventricular depolarization (QRS complex) and isovolumetric contraction, raising intraventricular pressure.
- 4. **Ventricular Ejection:** During the plateau phase of ventricular action potentials (ST segment), the semilunar valves open and blood is ejected into the aorta and pulmonary artery.

nderstanding ECG waves May 18, 2025
5. Ventricular Repolarization and Relaxation: Ventricular repolarization (T

wave) initiates relaxation; ventricular pressure falls, semilunar valves close, and the heart returns to diastole with passive filling.