PoolMate

Detailed user guide - how to do everything PoolMate can do: pool libraries, normalize a plate, dilute samples, and generate Eppendorf epMotion worklists. Everything runs locally in your browser.

Which tab do I use?

Tab	Use it to	Produces
Pool	Combine several libraries into one tube (Tube layout), or normalize each into its own well (Plate layout).	DNA.csv + Buffer.csv (+ worksheet, inputs)
Normalize	Dilute every library to one common concentration, plate to plate.	Normalization_DNA.csv + Normalization_Buffer.csv
Dilute	Dilute one sample or a list - on the bench (tubes) or plate to plate.	dilution list CSV, and dilution_DNA.csv + dilution_Buffer.csv

Each tab is self-contained: its own inputs, its own live graphic, and its own export. The graphic always shows **where each sample goes and how much**.

Pool - combine libraries

1. For each sample enter the **source well**, a **name**, and either **concentration reads (ng/µL) + size (bp)**, or a **direct nM** value. Replicate Qubit reads can be separated by commas, semicolons or spaces and are averaged.
2. Set the **Pool calculation mode**: target final concentration (nM) for Illumina-style pools, or total fmol for ONT-style loading. Then set the **Total final volume**.
3. Choose the **Layout**: **Tube** pools every sample into one tube; **Plate** puts each sample in its own well (normalization in place).
4. Optionally open **Optional extra pooling parameters** to set racks, buffer position, pool well, minimum transfer, rounding, dead volume and tip policy.
5. Click **Generate worklists** and download the files.

The three Pool actions

Button	What it does	Robot files?
Calculate molarities	Converts concentration + size to nM using the sample table only. No volumes.	No
Quick pool table	A manual pipetting table from total fmol or fmol per sample.	No
Generate worklists	The full epMotion export: transfer volumes, buffer, tips, CV check.	Yes

Normalize - one concentration across a plate

1. Choose the **concentration unit** (nM or ng/µL), the **target concentration**, and the **final volume per well**.
2. For each library enter its **input well**, a name, and its **concentration**.

3. Optionally set an **Output well** to place the library somewhere else on the output plate (for example A3 to D5). Leave it blank to keep the same well.
4. Check the live two-plate graphic, then click **Download Normalization worklists**.

Libraries too concentrated to reach the target in a single step are flagged - dilute those first (see below), then normalize.

Dilute - one sample or a list

1. Enter each sample's **stock concentration**. Target, final volume, minimum transfer, maximum well capacity and rounding all default to the shared values at the top and can be **overridden per row**.
2. Use **Tube view** for bench work (a virtual tube per sample, with a Done checklist) or **Plate view** for a plate-to-plate run.
3. In Plate view, set **In well** and **Out well** to control exactly where each sample is diluted.
4. **Download dilution list CSV** for a bench record, or **Download epMotion worklists** to run it on the robot.

Choosing output wells

Anywhere PoolMate writes to a plate - Pool in Plate layout, Normalize, and Dilute in Plate view - an **Out well** column decides where each sample lands. Leave it blank to keep the sample in its own well. The live graphic shows the move and the exported DNA/Buffer worklists follow it exactly.

Deck, racks and tips

Rack 1 = source plate. **Rack 2** = destination (the pool tube in Tube layout). Buffer is drawn from the reservoir at **position “1”** on the buffer rack, which normally matches the source rack. Tools: **TS_50** = 50 µL tips, **TS_300** = 300 µL tips.

Dilution and pooling cannot share one run

A pooling script executes one DNA transfer list plus one buffer transfer list. Pooling must draw from wells that have already been diluted **and mixed**, so dilution and pooling are always separate runs:

1. **Run 1 - dilute:** use Dilute (or Normalize) to export worklists, run them, then mix the wells.
2. **Run 2 - pool:** generate the pooling worklists drawing from those wells and run them.

Serial (multi-step) dilutions need one run per step for the same reason; PoolMate excludes them from a worklist export and flags them instead.

If a transfer would be below the minimum

Very concentrated libraries can require less than 1 µL, which is not reliably pipettable. Either pre-dilute the sample first (Dilute tab), pick a target/volume that keeps every transfer above the minimum, or set **Low-volume handling** to *pre-dilute hot samples* so PoolMate emits a Dilution.csv plan to run before the pool.

Saving work and file outputs

A plain page reload always starts blank. Use **Save run (JSON)** to keep a run and **Open run** to restore it; if a session was left unsaved a recovery banner offers to restore it. Saved runs include all

three tabs.

File	What it is
DNA.csv	Sample/stock transfer worklist for the robot.
Buffer.csv	Buffer/diluent transfer worklist. Load it after the DNA file.
Dilution.csv	Pre-dilution transfers, when low-volume handling produced a plan. Run it first.
*_pooling_worksheet.csv	Full calculation record including the post-rounding CV check.
*_inputs.csv / .txt	The run's settings and sample list; the CSV re-imports into PoolMate.
dilution_list.csv	Bench-readable dilution table (DNA + diluent per sample).

About the numbers

Molarity for dsDNA: **nM = conc(ng/µL) x 10^6 / (660 x size_bp)**. Pool transfers are calculated as equal fmol per sample, rounded to the selected increment, then audited for post-rounding deviation (CV%). In fmol mode the target nM is total fmol divided by final volume. Dilutions use **C1V1 = C2V2**.

Import, export and templates

Import instrument CSV/TXT reads a quantification file and fills the sample table (it recognises well, name, concentration, size and nM columns, plus an optional output well). **Blank CSV template** downloads a correctly-shaped starter file. **Export contents** saves what you typed as CSV or TXT.

Important: platform presets are vendor starting points. Confirm all volumes and loading concentrations against your own kit / instrument SOP before running the robot.