

#### Prof. Dr. Florian Künzner

#### **CA** 4 – Technical realisation


The lecture is based on the work and the documents of Prof. Dr. Theodor Tempelmeier

**Computer Science** 



### Goal

Goal



Computer Science

### Goal



#### **CA::Technical realisation**

- Development of integrated circuits
- Circuit families
- Programmable Logic Devices



## Logical functionality

### ...and it's technical realisation

**Computer Science** 



## Development of integrated circuits (ICs)





## Development of integrated circuits (ICs)

Description with "(HDL) hardware description language" (simulation)

$$y = a * b$$

**Computer Science** 




## Development of integrated circuits (ICs)

Description with "(HDL) hardware description language" (simulation)

$$y = a * b$$

Logic (CAD, simulation)



Computer Science




## Development of integrated circuits (ICs)


Description with "(HDL) hardware description language" (simulation)

$$y = a * b$$

Logic (CAD, simulation)



Technical – principle (CAD, simulation)



Computer Science




## Development of integrated circuits (ICs)


Description with "(HDL) hardware description language" (simulation)

$$y = a * b$$

Logic (CAD, simulation)



Technical – principle (CAD, simulation)



Technical – layout and layers on a chip (CAD, simulation)





### Circuit families

#### **Bipolar**

Transistor transistor logic (TTL) Emitter coupled logic (ECL)

- + fast
- high power dissipation (Verlustleistung)
- low integration density

#### Unipolar

Metal oxide semiconductor (MOS) Field effect transistor (FET)

- not that fast
- + low power dissipation
- + high integration density

Use in microprocessors and memory devices



## Circuit families

#### **Bipolar**

Transistor transistor logic (TTL) Emitter coupled logic (ECL)

- + fast
  - high power dissipation (Verlustleistung)
- low integration density

#### Unipolar

Metal oxide semiconductor (MOS) Field effect transistor (FET)

- not that fast
- + low power dissipation
- + high integration density

Use in microprocessors and memory devices

**Computer Science** 



## **Bipolar**

Transistor transistor logic (TTL) Emitter coupled logic (ECL)

- + fast
- high power dissipation (Verlustleistung)

# Technische Hochschule Rosenheim Technical University of Applied Sciences

### Circuit families

#### **Bipolar**

Transistor transistor logic (TTL) Emitter coupled logic (ECL)

- + fast
- high power dissipation (Verlustleistung)
- low integration density

#### Unipolar

Metal oxide semiconductor (MOS) Field effect transistor (FET)

- not that fast
- + low power dissipation
- + high integration density

Use in microprocessors and memory devices.



### Circuit families

#### **Bipolar**

Transistor transistor logic (TTL)
Emitter coupled logic (ECL)

- + fast
- high power dissipation (Verlustleistung)
- low integration density

#### Unipolar

Metal oxide semiconductor (MOS) Field effect transistor (FET)

- not that fast
- + low power dissipation
- + high integration density

Use in microprocessors and memory devices

Technical University of Applied Sciences

### Circuit families

#### **Bipolar**

Transistor transistor logic (TTL)
Emitter coupled logic (ECL)

- + fast
- high power dissipation (Verlustleistung)
- low integration density

#### Unipolar

Metal oxide semiconductor (MOS) Field effect transistor (FET)

- not that fast
- + low power dissipation
- high integration density

Use in microprocessors and memory devices

Computer Science





#### **Bipolar**

Transistor transistor logic (TTL)
Emitter coupled logic (ECL)

- + fast
- high power dissipation (Verlustleistung)
- low integration density

#### Unipolar

Metal oxide semiconductor (MOS) Field effect transistor (FET)

- not that fast
- + low power dissipation
- + high integration density

Use in microprocessors and memory devices.

### Circuit families

#### **Bipolar**

Transistor transistor logic (TTL)
Emitter coupled logic (ECL)

- + fast
- high power dissipation (Verlustleistung)
- low integration density

#### Unipolar

Metal oxide semiconductor (MOS) Field effect transistor (FET)

- not that fast
- + low power dissipation
- + high integration density

Use in microprocessors and memory devices

Technical University of Applied Sciences



### Circuit families

#### **Bipolar**

Transistor transistor logic (TTL)
Emitter coupled logic (ECL)

- + fast
- high power dissipation (Verlustleistung)
- low integration density

### Unipolar

Metal oxide semiconductor (MOS) Field effect transistor (FET)

- not that fast
- + low power dissipation
- + high integration density

Use in microprocessors and memory devices.

Computer Science



## Programmable logic devices

#### Types of IC's (integrated circuits):

- 1 Standard IC (the whole logic is predefined)
- 2 Full custom IC

Chip with customer logic (may be expensive and time consuming until production finished)

- 3 Gate arrays
  - Chip with a lot of logic elements (1. production step is the same for everyone)
  - Connection of the gates according to customer specifications (2. production step with mask according to customer specifications)
- Field programmable logic modules (PLA, FPLA, PAL, EPLD, EEPLD, GAL, ..., FPGA)
  - "On site" with PC and programming device or even in soldered in state "programmable" Programming means put user-specific logic into the IC.

#### **Terminology**

The ICs under the numbers 2 and 3 (sometimes also 4) are called ASICs.

Computer Science



## Programmable logic devices

#### Types of IC's (integrated circuits):

- Standard IC (the whole logic is predefined)
- 2 Full custom IC

Chip with customer logic (may be expensive and time consuming until production finished)

- Gate arrays
  - Chip with a lot of logic elements (1. production step is the same for everyone)
  - Connection of the gates according to customer specifications (2. production step with mask according to customer specifications)
- Field programmable logic modules (PLA, FPLA, PAL, EPLD, EEPLD, GAL, ..., FPGA)
  - "On site" with PC and programming device or even in soldered in state "programmable" Programming means put user-specific logic into the IC.

#### **Terminology**

The ICs under the numbers 2 and 3 (sometimes also 4) are called ASICs

Computer Science



## Programmable logic devices

#### Types of IC's (integrated circuits):

- Standard IC (the whole logic is predefined)
- 2 Full custom IC
  - Chip with customer logic (may be expensive and time consuming until production finished)
  - Gate arrays
    - Chip with a lot of logic elements (1. production step is the same for everyone)
    - Connection of the gates according to customer specifications (2. production step with mask according to customer specifications)
  - Field programmable logic modules (PLA, FPLA, PAL, EPLD, EEPLD, GAL, ..., FPGA)
    - "On site" with PC and programming device or even in soldered in state "programmable" Programming means put user-specific logic into the IC.

#### **Terminology**:

The ICs under the numbers 2 and 3 (sometimes also 4) are called ASICs.

**Computer Science** 



## Programmable logic devices

#### Types of IC's (integrated circuits):

- Standard IC (the whole logic is predefined)
- 2 Full custom IC
  Chip with customer logic (may be expensive and time consuming until production finished)
- Gate arrays
  - Chip with a lot of logic elements (1. production step is the same for everyone)
  - Connection of the gates according to customer specifications (2. production step with mask according to customer specifications)
- Field programmable logic modules (PLA, FPLA, PAL, EPLD, EEPLD, GAL, ..., FPGA)
  - "On site" with PC and programming device or even in soldered in state "programmable" Programming means put user-specific logic into the IC.

#### **Terminology**

The ICs under the numbers 2 and 3 (sometimes also 4) are called ASICs



## Programmable logic devices

#### Types of IC's (integrated circuits):

- Standard IC (the whole logic is predefined)
- Full custom IC Chip with customer logic (may be expensive and time consuming until production finished)
- 3 Gate arrays
  - Chip with a lot of logic elements (1. production step is the same for everyone)
  - Connection of the gates according to customer specifications (2. production step with mask according to customer specifications)
- 4 Field programmable logic modules (PLA, FPLA, PAL, EPLD, EEPLD, GAL, ..., FPGA)
  - "On site" with PC and programming device or even in soldered in state "programmable" -Programming means put user-specific logic into the IC.

Computer Science



## Programmable logic devices

#### Types of IC's (integrated circuits):

- 1 Standard IC (the whole logic is predefined)
- 2 Full custom IC Chip with customer logic (may be expensive and time consuming until production finished)
- Gate arrays
  - Chip with a lot of logic elements (1. production step is the same for everyone)
  - Connection of the gates according to customer specifications (2. production step with mask according to customer specifications)
- Field programmable logic modules (PLA, FPLA, PAL, EPLD, EEPLD, GAL, ..., FPGA)
  - "On site" with PC and programming device or even in soldered in state "programmable" Programming means put user-specific logic into the IC.

#### **Terminology:**

The ICs under the numbers 2 and 3 (sometimes also 4) are called ASICs.



## **Example: Field programmable logic** modules

Programmable array logic PAL

GAL Generic array logic



FPGA Field programmable gate array


[Image sources: wikipedia.org]

**Computer Science** 



## Example: GAL (generic array logic)

- Type: GAL16V8
- Company: Lattice
- Programmable AND array
- 20 year data retention



#### **CAMPUS** Rosenheim **Computer Science**

#### Technische Hochschule Rosenheim Technical University of Applied Sciences

## Questions?

All right?  $\Rightarrow$ 

Question?  $\Rightarrow$ 

and use chat


speak after I ask you to

**Computer Science** 




Example: GAL logic diagram (GAL16V8)

1 N P 4 T S



OUTPATO



**Computer Science** 



## Questions?

All right?  $\Rightarrow$ 



Question?  $\Rightarrow$ 



and use chat

speak after I ask you to

## Tango-PLD

#### A language to describe the logic.

- The Tango-PLD compiler automatically creates the contact pattern (JEDEC file, zeros and ones)
- JEDEC file (Joint Electron Device Engineering Council):
   File format between data preperation system and PLD programmer
- Tango-PLD is outdated, because it's too simple for modern FPGAs.

Computer Science



## Tango-PLD

#### A language to describe the logic.

- The Tango-PLD compiler automatically creates the contact pattern (JEDEC file, zeros and ones)
- JEDEC file (Joint Electron Device Engineering Council): File format between data preperation system and PLD programmer
- Tango-PLD is outdated, because it's too simple for modern FPGAs.

Computer Science



## Tango-PLD

#### A language to describe the logic.

- The Tango-PLD compiler automatically creates the contact pattern (JEDEC file, zeros and ones)
- JEDEC file (Joint Electron Device Engineering Council): File format between data preperation system and PLD programmer
- Tango-PLD is outdated, because it's too simple for modern FPGAs.



## Tango-PLD

#### Technische Hochschule Rosenheim Technical University of Applied Sciences

#### A language to describe the logic.

```
Logic(in AO, A1, A2, A3, B; out Q){
    Q = !A3 \& A2 \& !A1 \& A0 | B;
    putpart("g16v8", "Logic",
             -, AO, A1, A2, A3, B, -, -, -, GND,
             -,-,-,-,-,-,Q,VCC);
```

- The Tango-PLD compiler automatically creates the contact pattern (JEDEC file, zeros and ones)
- JEDEC file (Joint Electron Device Engineering Council): File format between data preperation system and PLD programmer
- Tango-PLD is outdated, because it's too simple for modern FPGAs.

Computer Science



## Hardware description languages

- ⇒ Programming of FPGAs!
  - A precise, formal description of an electronic circuit
  - Allows automated analysis and simulation of an electronic circuit
  - HDL! = Programming language (HDL explicitly consider the notion of time and is therefore more complex)
  - The syntax of VHDL is very similar to the programming language Ada.

## Hardware description languages

- **⇒** Programming of FPGAs!
  - A precise, formal description of an electronic circuit
  - Allows automated analysis and simulation of an electronic circuit
  - HDL! = Programming language (HDL explicitly consider the notion of time and is therefore more complex)
  - The syntax of VHDL is very similar to the programming language Ada.



## Hardware description languages

- ⇒ Programming of FPGAs!
  - A precise, formal description of an electronic circuit
  - Allows automated analysis and simulation of an electronic circuit
  - HDL! = Programming language (HDL explicitly consider the notion of time and is therefore more complex)
  - The syntax of VHDL is very similar to the programming language Ada.



## Hardware description languages

- ⇒ Programming of FPGAs!
  - A precise, formal description of an electronic circuit
  - Allows automated analysis and simulation of an electronic circuit
  - HDL ! = Programming language (HDL explicitly consider the notion of time and is therefore more complex)
  - The syntax of VHDL is very similar to the programming language Ada.

Computer Science



## Hardware description languages

- ⇒ Programming of FPGAs!
  - A precise, formal description of an electronic circuit
  - Allows automated analysis and simulation of an electronic circuit
  - HDL! = Programming language (HDL explicitly consider the notion of time and is therefore more complex)
  - The syntax of VHDL is very similar to the programming language Ada.

Computer Science



## Questions?

All right?  $\Rightarrow$ 

> <

Question?  $\Rightarrow$ 

\*

and use chat

speak after I ask you to

Computer Science

## **Summary and outlook**

#### **Summary**

- Development of integrated circuits
- Circuit families
- Programmable Logic Devices

#### Outlook

Processor architecture



Computer Science



#### Summary

- Development of integrated circuits
- Circuit families
- Programmable Logic Devices

#### Outlook

Processor architecture

