

Medianav - ULC Log generation

La prise de log est interdite pour les clients

Si vous avez des demandes de DEASMM dans ce sens il faut demander au client:

-> Passage dealer

-> Prise de LOG par le cotech et creation du ticket FIC pour le suivi

(Les opérations de ce type dans les systèmes onboard sont interdits pour le client et les seuls autorisés à le faire sont les opérateurs FIC)

En cas de besoin, DEASMM RTR (Roumanie) peut demander les logs en cas de problème du device onboard.
Il est tout à fait possible de demander les logs au L1 avant l'escalade

Voici la procédure à communiquer au L1 avant de redescendre le ticket

Note : La procédure peut être appliquée **par le client**. Faire attention au format de la clef USB (normalement **FAT32** et entre **8Gb et 32Gb** or **exFAT** de 64Gb max d'espace (pas plus !))

Template

Hello L1 Team

In order to continue the investigation, L3 team requires additional logs to be provided. Please find the process below, customer has to do it and return the requested folder(s)

- At the root of the USB Key, create a folder named ""logfiles_bavn"" (careful with the spelling)*
- Then proceed to connect the USB key to Head Unit*
- Wait for about 30+ seconds.*
- A message saying : ""Log to USB, Copying is completed"" is supposed to appear*
- Disconnect USB Key*
- When check on the computer Log files will be available in the ""logfiles_bavn"" directory*

*There should be few folders (bsd, core_dump, log_data, log_emmc...) and files available.
Ask the customer to ZIP them all and please revert back to us with the content.*

*Thanks & regards
L2 team*

*note: To restart the log generation process on the same USB key, All files must be deleted in the ""logfiles_bavn"" directory
note 2: USB Key must be formatted to FAT32 and between 8Gb and 32Gb of space or formatted to exFAT for a max size of 64Gb*

Article de référence pour le L1 : 000040582 // Article - L1 - Procedure – Media Nav – How to collect logs