Sheet: Processor Sheet: Coprocessor Sheet: Agnus Multi Adapter Sheet: Memory and Kickstart Sheet: Clocks and Gary Sheet: Video Sheet: Paula Sheet: Floppy and Parallel Sheet: BUS CONTROL Sheet: Serial Sheet: Zorro Expansion Sheet: ISA

File: Processor.sch File: coprocessor.sch File: paula.sch File: paula.sch File: paula.sch File: bus.sch File: serial.sch File: jeaula.sch File: j

## AGNUS CONFIG JUMPERS

Agnus	8372A	8375	8375
Commodore Part Number	ALL	390554-01 390554-02 318069-12 318069-13	318069-10 318069-11 390544-01 390544-02
Jumper			
JA1	3-2	1-2	1-2
JA2	3-2	1-2	1-2
JA3	3-2	1-2	1-2
JA4	3-2	1-2	1-2
JA5	3-2	OPEN	1-2
JA6	3-2	1-2	1-2
JA7	SHORT	OPEN	OPEN
JA8	3-2	1-2	1-2
JA9	3-2	1-2	1-2
JA10	3-2	1-2	1-2
JA11	3-2	1-2	1-2
JA12	3-2	1-2	1-2
JA13	3-2	1-2	1-2
JA14	3-2	1-2	1-2
J102	SHORT for NTSC OPEN for PAL	SHORT	SHORT

## OTHER JUMPERS

Jumper	Description	Detail		
J301	DF1 Presence	Place jumper when using two internal disk drives		
J900	Chip RAM DMA Slowdown	Place jumper (factory default)		
J9001	Reset	Attach EATX case reset switch		
J9002	Power LED	Attach EATX case power LED		
J9003	Case Fan	Attach 12V cooling fan		
J9004	HSYNC/COMPSYNC	Sends Composite Sync or HSYNC on video port		
J9100	Power Switch	Attach EATX case power switch		


## Amiga 2000 EATX Details


Sheet: / File: 2000ATX.sch


Title: Amiga 2000 EATX


 Size: A4
 Date: 2021-09-19
 Rev: 2.0


 KiCad E.D.A. kicad 5.1.6+dfsg1-1
 Id: 1/14




















When installing the optional real time clock, add all the components with the REAL TIME CLOCK except RTC62423. DO NOT install both clock ICs.

	BUSt	er				
		a 2000	EATX			
Sheet: /BUS CONTROL/ File: bus.sch						
	Title:					
	Size: B	Date: 2021-09-19			Rev:	
KiCad E.D.A. kicad 5.1.6+dfsg1-1					ld: 7/14	
		7		8		

