





FireBeetle Wi-Fi / Bluetooth ESP8266/ESP32 A0/IO36 A1/IO39 A2/IO34 A3/IO35 A4/IO15 PS1 IO9/D5 OR JMP (NF) IO10/D6 IO0 OR JMP (NF) IO13/D7 SCK/IO18 IO5/D8 MOSI/IO23 IO2/D9 MISO/IO19 IO6/CLK SDA/IO21 IO7/SD0 SCL/IO22 IO8/SD1 BCLK/IO14 IO11/CMD MCLK/IO12 GND DO/IO4 AREF DI/IO16 3V3 VCC LRCK/IO17 RST PS0, PS1 to remain floating If needed, solder R2, R3 SMT jumpers Mounting Holes Grounded Board powered by +5 VDC USB Input or +3.7 VDC Li-Po battery Charging via USB automatically handled

