OVERHEATING

Alarm E12 means that the motor is overheating. Stop the pump

Let the motor cool down for thirty minutes before you start the p

Call the service when the alarm returns within one hour after th