PTZ camera control commands in VISCA procotal

edited at Nov. 15th, 2013

Action	Command	Comments
TILT_UP	8x 01 06 01 00 ww 03 01 ff	ww: tilt speed=01-18
TILT_DOWN	8x 01 06 01 00 ww 03 02 ff	
TILT_OFF	8x 01 06 01 00 00 03 03 ff	
PAN_LEFT	8x 01 06 01 vv 00 01 03 ff	vv: pan speed=01-18
PAN_RIGHT	8x 01 06 01 vv 00 02 03 ff	
PAN_OFF	8x 01 06 01 00 00 03 03 ff	
ZOOM_IN(Tele)	8x 01 04 07 02 ff	standard mode
	8x 01 04 07 2n ff	Variable mode speed=1 (L) -7 (H)
ZOOM_OUT(Wide)	8x 01 04 07 03 ff	standard mode
	8x 01 04 07 3n ff	Variable mode speed=1 (L) -7 (H)
ZOOM_OFF	8x 01 04 07 00 ff	
FOCUS_NEAR	8x 01 04 08 03 ff	standard mode
	8x 01 04 08 <mark>3n</mark> ff	Variable mode speed=1 (L) -7 (H)
FOCUS_FAR	8x 01 04 08 02 ff	standard mode
	8x 01 04 08 2n ff	Variable mode speed=1 (L) -7 (H)
;FOCUS_FAR_OFF	8x 01 04 08 00 ff	