

This product is no longer manufactured

This product was replaced by [X-SAVE VTR 300/B L](#)



VR

[Find more details in our online catalogue](#)

Technical parameters

Unit

Frequency	50	Hz
Voltage (nominal)	230	V
Phases	1~	
Recommended fuse	10 A	
Enclosure class	IP24	
Speed regulation	Stepless	

Supply fan

Input power (P1), supply fan	114	W
------------------------------	-----	---

Supply air filter

Filter class, supply air	F7	
--------------------------	----	--

Return fan / Extract fan

Input power (P1), extract fan	114	W
-------------------------------	-----	---

Extract air filter

Filter class, extract air	G3	
---------------------------	----	--

Heater

Heater type	Electric
-------------	----------

Preheater / Reheater

Input power, reheater	1.67 kW
-----------------------	------------

Exchanger

Heat exchanger	Rotating
----------------	----------

Others

Fan control	CAV, air flow control
-------------	-----------------------

Installation type	Vertical
-------------------	----------


Supply side	Left
-------------	------

Dimensions and weights

Weight	56.4 kg
--------	------------

Dimension

Left hand
version



Right hand
version

Duct connection $\varnothing 160$ mm

*) Cooker hood $\varnothing 125$ mm

Supply air

Exhaust
air

Outdoor
air

Extract air



Accessories

- CE/CD-diverting plug 4pin (37367)
- F-T120 Timer frame (5137)
- JP Junction plug for cable (12428)
- LDC 160-900 Silencer (5193)
- T 120 Timer (5165)
- TG-K360 Duct sensor 0-60°C (4846)
- VBC 160-3 Water heating batt (9840)
- ZTR 15-0,6 valve 3-way (6573)
- ZTV 15-0,6 2-way valve (6571)
- CWK 160-3-2,5 Duct cooler,circ (30022)
- FK 160 Fast clamp (1610)
- LDC 160-600 Silencer (5192)
- RVAZ4 24A Actuator 0-10V (9862)
- TG-A130 Surface sensor 0-30°C (5159)
- VBC 160-2 Water heating batt (5458)
- ZTR 15-0,4 valve 3-way (9670)
- ZTV 15-0,4 2-way valve (9829)

Documents

- Modbus_for_residential_D24810_User_manual_EN (A007).pdf
- Quick_Guide 205821.pdf
- VR 400-700_DC, DCV, DCVB_205816_GB_WD_A002.pdf
- VR 400&700 DCV Installation Instructions 205818_10-03_.pdf
- VR 400&700 DCV Operation and Maintenance instructions 205820_11-04_.pdf