

1
V_Source
[IS]
Source Current
Source_Scope
V
I
Input Reactive Power
Input Active Power
1
V_DC_Link
[idc]
Dc Link Current
DC_Link
DC Link Power
Continuous
<Voltage (V)>
<Current (A)>
<SOC (%)>
SOC
Bat_Scope
Bat_Input_Power
[Vhf1]
1
I_hf1
-T-
1
I_hf2
[IS]
AC Sourse
A
B
[idc]
DCL
C2F1
Source Rectifier
P
N
HF Inverter
-T-
C1
1
2
C2
P
N
Vehicle Rectifier
R
Li-Ion Battery
m