### nooelec neSDR SMArT SDR Zidag Software Driver Installation

Completed — 4.9 MB https://support.nooelec.com/hc/en-us/articles/360005298053-NESDR-Installation-Guide


This driver is required to use RTL-SDR compatible SDR software on Windows operating systems.

<u>Click here to download the latest version of Zadig, used to install the SDR driver for your NESDR</u>. The driver is required to use RTL-SDR compatible SDR software on Windows operating systems.

1. Plug your NESDR into an available USB port

0 devices found.

2. Open the 'NESDR Driver Installer', Zadig, by clicking the link above



Zadig 2.2.689

#### **SOFTWARE AirSpy SDR# Studio**

IF\_Ave Ver 2.8 PlugIn for SDR# Studio Full Installation of SDR# & IF\_Ave 2.7

https://www.dropbox.com/scl/fi/2f67lyu6qgt2cp98rg9kp/SDR-2.ZIP?rlkey=y82yv6jzjyu7e92sap3x8ewm7&st=tcil7w3s&dl=0


The latest Rev of IF\_Ave allows
Saving and Recalling named Background Correction Files
replace the above with this newer \* DLL


#### IF\_Ave Version 2.8


https://www.dropbox.com/scl/fi/aitn8xtookwwxm6mvybkp/SDRSharp.Average.dll?rlkey=667f4a83958krn77ie28 62jxf&dl=0


# nooelec neSDR SMArT SDR **Zidag Software Driver Installation**




















## QUICK System Verification using Load/Open on nooelec SAWbirdH1 LNA Input

w/ RF Gain max @ 42 dB







AirSpy SDR# Kaminski IF\_avg Plugin > HLine3D **Rinearn Graphics** - RTL-SDR USB d Convert IF\_Avg -> .CSV Version: ja\_ap\_varMX8\_intLogo\_11jan25\_01 mcpySE\_D40\_25Oct24\_intlogo\_CSN\_mxb\_dBScaled.csv 001.420.405.000 8.14E-2 Offset Tuning
RTL AGC
Tuner AGC
RF Gain 36,4 dB Choose Dir 0.802 90 HLine 0.43 1,420 000 G 1,420 500 G 1,421 000 G 5.84E-2 -3.0E-2 1419.655 1420.404 1420.778 1421.1