CS395T: Introduction to Scientific and Technical Computing

topic: single-processor computer architecture

Instructors:

Dr. Karl W. Schulz, Research Associate, TACC Dr. Victor Eijkhout, Research Scientist, TACC



Outline

- Basic Anatomy of a Server/Desktop/Laptop/Cluster-node
 - Memory Hierarchy
 - Structure, Size, Speed, Line Size, Associativity
 - Latencies and Bandwidths
 - Intel vs. AMD platforms
 - Memory Architecture



Microarchitecture

- Memory hierarchies
- Commodity CPUs
 - theoretical performance
 - pipelining
 - superscaling
 - Performance




Memory Hierarchies

- Due primarily to cost, memory is divided into different levels:
 - Registers
 - Caches
 - Main Memory
- Memory is accessed through the hierarchy
 - registers where possible
 - ... then the caches
 - ... then main memory



Memory Relativity





Latency and Bandwidth

- The two most important terms related to performance for memory subsystems and for networks are:
 - Latency
 - How long does it take to retrieve a word of memory?
 - Units are generally nanoseconds or clock periods (CP).
 - Bandwith
 - What data rate can be sustained once the message is started?
 - Units are B/sec (MB/sec, GB/sec, etc.)



Registers

- Highest bandwidth, lowest latency memory that a modern processor can acces
 - built into the CPU
 - often a scarce resource
 - not RAM
- AMD x86-64 and Intel EM64T Registers





Registers

- Processors instructions operate on registers directly
 - have names like: eax, ebx, ecx, etc.
 - sample instruction:

```
addl %eax, %edx
```

 Separate instructions and registers for floating-point operations



Cache

- Between the CPU Registers and main memory
- L1 Cache: Data cache closest to registers (on die)
- L2 Cache: Secondary data cache, stores both data and instructions (on die)
 - Data from L2 has to go through L1 to registers
 - L2 is 10 to 100 times larger than L1
 - Some systems have a off-die L3 cache, ~10x larger than L2
- Cache line
 - The smallest unit of data transferred between main memory and the caches (or between levels of cache)
 - N sequentially-stored, multi-byte words (usually N=8 or 16).



Main Memory

- Cheapest form of RAM
- Also the slowest
 - lowest bandwidth
 - highest latency
- Unfortunately most of our data lives out here




Approximate Latencies and Bandwidths in a Memory Hierarchy

Registers	Latency	Bandwidth				
L1 Cache	~5 CP •	~2	W/CP			
L2 Cache	~15 CP ⁴	~1	W/CP			
Memory	~300 CP *	~0.2	5 W/CP			
Dist. Mem.	~10000 CP *	~0.0	1 W/CP			



Example: Pentium 4




Line size L1/L2 = 8W/16W




Memory Bandwidth and Size Diagram

Relative Memory Bandwidths




Relative Memory Sizes






IBM Power4 Chip Layout





Memory/Cache Related Terms





Why Caches?

- Since registers are expensive
- ... and main memory slow
- Caches provide a buffer between the two
- Access is transparent
 - either it's in a register or
 - it's in a memory location
 - processor/cache controller/MMU hides cache access from the programmer



Memory Access Example

```
#include <stdlib.h>
#include <stdio.h>
#define N 1234
int main()
 int i;
 int *buf=malloc(N*sizeof(int));
 buf[0]=1;
 for (i=1; i < N; ++i)
  buf[i]=i;
 printf("%d\n",buf[N-1]);
```

```
movl $1, (%eax)
movl $1, %edx

L2:
movl %edx, (%eax,%edx,4)
addl $1, %edx
cmpl $1234, %edx
jne .L2
```



Hits, Misses, Thrashing

Cache hit

- location referenced is found in the cache
- Cache miss
 - location referenced is not found in cache
 - triggers access to the next higher cache or memory
- Cache thrashing
 - a thrashed cache line (TCL) must be repeatedly recalled in the process of accessing its elements
 - caused when other cache lines, assigned to the same location, are simultaneous accessing data/instructions that replace the TCL with their content.



Design Considerations

- Data cache designed with two key concepts in mind
- Spatial Locality
 - when an element is referenced, its neighbors will be referenced, too
 - all items in the cache line are fetched together
 - work on consecutive data elements in the same cache line gives performance boost
- Temporal Locality
 - when an element is referenced, it will be referenced again soon
 - arrange code so that date in cache is reused as often as possible



Cache Line Size vs Access Mode

Access	Sequential data	Random data
Line-size		
Short	more fetches	Best—low
Line	(overhead)	"latency"
Long	BestFewer fetches,	Longer
Line	but higher probability	"latency",
	for cache trashing.	effectively
		smaller cache




Cache Mapping

- Because each memory subsystem is smaller than the next-closer level, data must be mapped
- Types of mapping
 - Direct
 - Set associative
 - Fully associative



Direct Mapped Caches

<u>Direct mapped cache:</u> A block from main memory can go in exactly one place in the cache. This is called direct mapped because there is direct mapping from any block address in memory to a single location in the cache.





Direct Mapped Caches


- If the cache size is N_c and it is divided into k
 lines, then each cache line is N_c/k in size
- If the main memory size is N_m , memory is then divided into $N_m/(N_c/k)$ blocks that are mapped into each of the k cache lines
- Means that each cache line is associated with particular regions of memory



Set Associative Caches

Set associative cache: The middle range of designs between direct mapped cache and fully associative cache is called set-associative cache. In a n-way set-associative cache a block from main memory can go into n (n at least 2) locations in the cache.

2-way set-associative cache






Set Associative Caches

- Direct-mapped caches are 1-way setassociative caches
- For a k-way set-associative cache, each memory region can be associated with k cache lines



Fully Associative Caches

Fully associative cache: A block from main memory can be placed in any location in the cache. This is called fully associative because a block in main memory may be associated with any entry in the cache.





Fully Associative Caches

- Ideal situation
- Any memory location can be associated with any cache line
- Cost prohibitive



Intel Woodcrest Caches

- L1
 - 32 KB
 - 8-way set associative
 - 64 byte line size
- L2
 - 4 MB
 - 8-way set associative
 - 64 byte line size



TLB

- Translation Look-aside Buffer
- Translates between logical space that each program has and actual memory addresses
- Memory organized in 'small pages', a few Kbyte in size
- Memory requests go through the TLB, normally very fast
- Pages that are not tracked through the TLB can be found through the 'page table': much slower
- => jumping between more pages than the TLB can track has a performance penalty.
- This illustrates the need for spatial locality.



Data reuse

- Performance is limited by data transfer rate
- High performance if data items are used multiple times
- Example: vector addition $x_i = x_i + y_i$: 1op, 3 mem accesses
- Example: inner product s=s+x_i*y_i: 2op, 2 mem access (s in register; also no writes)



Data reuse: matrix-vector product

- Matrix vector product: 2n² ops, n²+2n data
- However, only theoretical: in naïve implementation the source vector gets reloaded lots of times
- Loop exchange doesn't help: output gets written many times
- Solution: blocking (see below)

```
for (i) {
    s = 0;
    for (j)
        s = s+A<sub>ij</sub>*x<sub>j</sub>;
    y<sub>i</sub> = s;
}

for (j) {
    for (i)
        y<sub>i</sub> = y<sub>i</sub>+A<sub>ij</sub>*x<sub>j</sub>;
}
```



Data reuse: matrix-matrix product

- Matrix-matrix product: $2n^3$ ops, $2n^2$ data
- If it can be programmed right, this can overcome the bandwidth/cpu speed gap
- Again only theoretically: naïve implementation inefficient



Programming strategies: contiguous access


- Avoid strides: cache lines contain 4 (or so) words, might as well use them all
- Example: dot product, sequential access of the vectors
- Strided dot product:

```
sum=0.;
for (j=0; j < stride; ++j)
  for(i=j; i < n; i+=stride)
  sum += a[i]*b[i];</pre>
```

Not all elements on a cache line used.




Dot Product Performance





Programming strategies: blocked algorithms

- Long vectors are flushed from cache: break up in smaller blocks
- Reuse of input vector (limited)
- Use of cache lines in matrix





More on blocked algorithms

- This gets tricky fast
- Matrix-matrix multiply is triple loop; blocked is 6-deep loop
- Choice of blocking sizes is complicated
- Loop exchange to aim for L1 or L2 reuse (Atlas vs Goto approach)



Pipelining


Pipeline

A serial multistage functional unit. Each stage can work on different sets of independent operands simultaneously.

After execution in the final stage, first result is available.

Latency = # of stages * CP/stage

CP/stage is the same for each stage and usually 1.





Branch Prediction

- The "instruction pipeline" is all of the processing steps (also called segments) that an instruction must pass through to be "executed".
- Higher frequency machines have a larger number of segments.
- Branches are points in the instruction stream where the execution may jump to another location, instead of executing the next instruction.
- For repeated branch points (within loops), instead of waiting for the loop to branch route outcome, it is predicted.

Pentium III processor pipeline

1		2 3 4			5	6		7	7 8		9)	10					
Pentium 4 processor pipeline																			
1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20

Misprediction is more "expensive" on Pentium 4's.

