#### **MODULE PRACTICE**

## Control Unit (CU)

Some functions of the CU:

- Determine what/where the next instruction must go for processing
- Send clock signals to all hardware to force synchronous operations
- Send memory taskings if appropriate

The Control Unit (CU) on a CPU receives information from the software; then, it distributes and directs the data to the relevant hardware components.

## Complex Instruction Set Computers (CISC)

### CISC Instructions Attributes:

- Single instructions take more than one CPU cycle to complete
- Instruction length varies based on the instruction type
- Hardware must be designed to accept more complicated instructions

CISC (Complex Instruction Set Computer) is an ISA design practice that focuses on multi-step instructions and complex, power-consuming hardware. These designs primarily focus on hardware components and binary instruction complexity. Processing components are typically not interchangeable with RISC-designed systems.

## **Instruction Set Architectures**

Some things an ISA defines:

- How binary instructions are formatted
- What instructions are available to be processed on a specific hardware setup
- How computer memory, (volatile and non-volatile) is accessed

An Instruction Set Architecture (ISA) defines the communication rules between the hardware and software of the computer. The ISA is a design principle (conceptual) and not stored in a computer's memory.

## Reduced Instruction Set Computers (RISC)

#### General RISC Instructions Attributes:

- Single instructions take only one CPU cycle to complete
- Instruction lengths are fixed, regardless of the instruction type
- Reduced complexity of hardware leads to less power consumption at the expense of overall processing times.

RISC (Reduced Instruction Set Computer) is an ISA design practice of ISAs that focuses on simple, quickly executed instructions to improve efficiency and reduce power consumption. These designs primarily focus on simple hardware components and reducing binary instruction complexity. Processing components are typically not interchangeable with CISC-designed systems.

# Arithmetic and Logic Unit (ALU)

#### Some ALU functions:

- Addition & subtraction
- Determining equality
- AND/OR/XOR/NOR/NOT/NAND logic gates and more!

An Arithmetic Logic Unit (ALU) is a digital circuit used to perform arithmetic and logic operations. It is the fundamental building block of the CPU.

## **Computer Instructions**

Computer instructions are written in binary, also known as machine code. Computer hardware operates on a series of these binary instructions through pulsating power signals that signify either **OFF** or **ON** based on the binary digits **0** and **1** respectively.

# Registers

Functions of a register:

- Store temporary data for immediate processing by the ALU
- Hold "flag" information if an operation results in overflow or triggers other flags
- Hold the location of the next instruction to be processed by the CPU

A register is a volatile memory system that provides the CPU with rapid access to information it is immediately using.