

Arm® BSA ACS Bare-metal

Version 1.0

User Guide

Non-Confidential

Copyright $\ensuremath{\mathbb{Q}}$ 2023 Arm Limited (or its affiliates). All rights reserved.

Issue 01

107935_0100_01_en



Arm® BSA ACS Bare-metal

User Guide

Copyright © 2023 Arm Limited (or its affiliates). All rights reserved.

Release Information

Document history

Issue	Date	Confidentiality	Change
0100-01	28 March 2023	Non-Confidential	REL v1.0.4

Proprietary Notice

This document is protected by copyright and other related rights and the practice or implementation of the information contained in this document may be protected by one or more patents or pending patent applications. No part of this document may be reproduced in any form by any means without the express prior written permission of Arm. No license, express or implied, by estoppel or otherwise to any intellectual property rights is granted by this document unless specifically stated.

Your access to the information in this document is conditional upon your acceptance that you will not use or permit others to use the information for the purposes of determining whether implementations infringe any third party patents.

THIS DOCUMENT IS PROVIDED "AS IS". ARM PROVIDES NO REPRESENTATIONS AND NO WARRANTIES, EXPRESS, IMPLIED OR STATUTORY, INCLUDING, WITHOUT LIMITATION, THE IMPLIED WARRANTIES OF MERCHANTABILITY, SATISFACTORY QUALITY, NON-INFRINGEMENT OR FITNESS FOR A PARTICULAR PURPOSE WITH RESPECT TO THE DOCUMENT. For the avoidance of doubt, Arm makes no representation with respect to, and has undertaken no analysis to identify or understand the scope and content of, patents, copyrights, trade secrets, or other rights.

This document may include technical inaccuracies or typographical errors.

TO THE EXTENT NOT PROHIBITED BY LAW, IN NO EVENT WILL ARM BE LIABLE FOR ANY DAMAGES, INCLUDING WITHOUT LIMITATION ANY DIRECT, INDIRECT, SPECIAL, INCIDENTAL, PUNITIVE, OR CONSEQUENTIAL DAMAGES, HOWEVER CAUSED AND REGARDLESS OF THE THEORY OF LIABILITY, ARISING OUT OF ANY USE OF THIS DOCUMENT, EVEN IF ARM HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

This document consists solely of commercial items. You shall be responsible for ensuring that any use, duplication or disclosure of this document complies fully with any relevant export laws

and regulations to assure that this document or any portion thereof is not exported, directly or indirectly, in violation of such export laws. Use of the word "partner" in reference to Arm's customers is not intended to create or refer to any partnership relationship with any other company. Arm may make changes to this document at any time and without notice.

This document may be translated into other languages for convenience, and you agree that if there is any conflict between the English version of this document and any translation, the terms of the English version of the Agreement shall prevail.

The Arm corporate logo and words marked with ® or ™ are registered trademarks or trademarks of Arm Limited (or its affiliates) in the US and/or elsewhere. All rights reserved. Other brands and names mentioned in this document may be the trademarks of their respective owners. Please follow Arm's trademark usage guidelines at https://www.arm.com/company/policies/trademarks.

Copyright © 2023 Arm Limited (or its affiliates). All rights reserved.

Arm Limited. Company 02557590 registered in England.

110 Fulbourn Road, Cambridge, England CB1 9NJ.

(LES-PRE-20349|version 21.0)

Confidentiality Status

This document is Non-Confidential. The right to use, copy and disclose this document may be subject to license restrictions in accordance with the terms of the agreement entered into by Arm and the party that Arm delivered this document to.

Unrestricted Access is an Arm internal classification.

Product Status

The information in this document is Final, that is for a developed product.

Feedback on content

Information about how to give feedback on the content.

If you have comments on content then send an e-mail to support-systemready-acs@arm.com. Give:

- The title Arm® BSA ACS Bare-metal User Guide.
- The number 107935 0100 01 en.
- If applicable, the page number(s) to which your comments refer.

• A concise explanation of your comments.

Arm also welcomes general suggestions for additions and improvements.



Arm tests the PDF only in Adobe Acrobat and Acrobat Reader, and cannot guarantee the quality of the represented document when used with any other PDF reader.

Inclusive language commitment

Arm values inclusive communities. Arm recognizes that we and our industry have used language that can be offensive. Arm strives to lead the industry and create change.

This document includes language that can be offensive. We will replace this language in a future issue of this document.

To report offensive language in this document, email terms@arm.com.

Contents

1. Introduction	
1.1 Conventions	
1.2 Useful resources	3
1.3 Other information	8
2. Overview to BSA ACS	
2.1 Abbreviations	10
2.2 BSA ACS	10
2.3 ACS design	11
2.4 Steps to customize bare-metal	12
2.4.1 Test components	12
3. Execution of BSA ACS	14
3.1 SoC emulation environment	
3.1.1 PE	14
3.1.2 PCle	15
3.1.3 DMA	17
3.1.4 SMMU and device tests	18
3.1.5 GIC	21
3.1.6 Timer	22
3.1.7 Watchdog timer	23
3.1.8 Memory	23
4. Porting requirements	25
4.1 PAL implementation	25
4.1.1 PE	25
4.1.2 GIC	26
4.1.3 Timer	26
4.1.4 IOVIRT	26
4.1.5 PCle	27
4.1.6 SMMU	28
4.1.7 Peripheral	29
418 DMA	29

4.1.9 Exerciser	30
4.1.10 Miscellaneous	30
	00
5. BSA ACS flow	32
5.1 BSA ACS flow diagram	32
5.2 BSA test example flow	33
A. Revisions	35
A.1 Revisions	35

1. Introduction

1.1 Conventions

The following subsections describe conventions used in Arm documents.

Glossary

The Arm® Glossary is a list of terms used in Arm documentation, together with definitions for those terms. The Arm Glossary does not contain terms that are industry standard unless the Arm meaning differs from the generally accepted meaning.

See the Arm Glossary for more information: developer.arm.com/glossary.

Convention	Use
italic	Citations.
bold	Terms in descriptive lists, where appropriate.
monospace	Text that you can enter at the keyboard, such as commands, file and program names, and source code.
monospace <u>underline</u>	A permitted abbreviation for a command or option. You can enter the underlined text instead of the full command or option name.
<and></and>	Encloses replaceable terms for assembler syntax where they appear in code or code fragments. For example:
	MRC p15, 0, <rd>, <crn>, <crm>, <opcode_2></opcode_2></crm></crn></rd>
SMALL CAPITALS	Terms that have specific technical meanings as defined in the Arm® Glossary. For example, IMPLEMENTATION DEFINED, IMPLEMENTATION SPECIFIC, UNKNOWN, and UNPREDICTABLE.



Recommendations. Not following these recommendations might lead to system failure or damage.



Requirements for the system. Not following these requirements might result in system failure or damage.



Requirements for the system. Not following these requirements will result in system failure or damage.



An important piece of information that needs your attention.



A useful tip that might make it easier, better or faster to perform a task.



A reminder of something important that relates to the information you are reading.

1.2 Useful resources

This document contains information that is specific to this product. See the following resources for other useful information.

Access to Arm documents depends on their confidentiality:

- Non-Confidential documents are available at developer.arm.com/documentation. Each document link in the following tables goes to the online version of the document.
- Confidential documents are available to licensees only through the product package.

Arm product resources	Document ID	Confidentiality
Arm® BSA Architecture Compliance User Guide	102504	Non-Confidential
Arm® BSA Architecture Compliance Validation Methodology	102503	Non-Confidential



Arm tests its PDFs only in Adobe Acrobat and Acrobat Reader. Arm cannot guarantee the quality of its documents when used with any other PDF reader.

Adobe PDF reader products can be downloaded at http://www.adobe.com.

1.3 Other information

See the Arm® website for other relevant information.

- Arm® Developer.
- Arm® Documentation.

- Technical Support.
- Arm® Glossary.

2. Overview to BSA ACS

This chapter provides an overview on Arm BSA ACS, the ACS design, and steps to customize the bare-metal code.

2.1 Abbreviations

The following table lists the abbreviations used in this document.

Table 2-1: Abbreviations and expansions

Abbreviation	Expansion
ACS	Architecture Compliance Suite
BSA	Base System Architecture
DMA	Direct Memory Access
ECAM	Enhanced Configuration Access Mechanism
GIC	Generic Interrupt Controller
IORT	Input Output Remapping Table
IOVIRT	Input Output Virtualization
ITS	Interrupt Translation Service
MPIDR	Multiprocessor ID Register
MSI	Message-Signaled Interrupt
PAL	Platform Abstraction Layer
PCle	Peripheral Component Interconnect Express
PE	Processing Element
PMU	Performance Monitoring Unit
RC	Root Complex
RP	Root Port
SoC	System on Chip
SMC	Secure Monitor Call
SMMU	System Memory Management Unit
UART	Universal Asynchronous Receiver and Transmitter
UEFI	Unified Extensible Firmware Interface
VAL	Validation Abstraction Layer

2.2 BSA ACS

Arm specifies a hardware system architecture which is based on Arm 64-bit architecture that server system software such as operating systems, hypervisors, and firmware can rely on. This ensures

standard system architecture to enable a suitably built single OS image to run on all the hardware compliant with this specification.

Arm provides a test suite named Architecture Compliance Suite (ACS) which contains self-checking portable C-based test cases to verify the compliance of hardware platforms to Base System Architecture (BSA).

For more information on Arm BSA ACS, see the README.

2.3 ACS design

The ACS is designed in a layered architecture that consists of the following components:

- Platform Abstraction Layer (PAL) is a C-based, Arm-defined API that you can implement. It abstracts features whose implementation varies from one target system to another. Each test platform requires a PAL implementation of its own. PAL APIs are meant for the compliance test to reach or use other abstractions in the test platform such as the UEFI infrastructure and baremetal abstraction.
 - For each component, PAL implementation must populate a data structure which involves supplying SoC-specific information such as base addresses, IRQ numbers, capabilities of PE, PCIe, RC, SMMU, DMA, and others.
 - PAL also uses client drivers underneath to retrieve certain device-specific information and to configure the devices.
- Validation Abstraction Layer (VAL) provides an abstraction over PAL and does not change based on the platform. This layer uses PAL layer to achieve a certain functionality. The following example achieves read memory functionality.

```
val_pcie_read_cfg -> pal_pcie_read_cfg
```

- Test pool is a layer which contains a list of test cases implemented for each component.
- Application is the top-level layer which allocates memory for component-specific tables and executes the test cases for each component.

The ACS test components are classified as follows:

- PE
- GIC
- PCle
- Exerciser
- I/O virtualization
- SMMU
- Timer
- Watchdog
- Power-wake semantics

- Peripherals
- Memory

2.4 Steps to customize bare-metal

The following are the steps to customize the bare-metal code for different platforms.



The pal_baremetal reference code is located in pal_baremetal.

1. Create a directory under the pal_baremetal folder.

```
mkdir <platform name>
```

2. Copy the reference code from pal_baremetal/FVP/RDN2 folder to <platform_name>.

```
cp -r FVP/RDN2/ platform_name/
```

- 3. Port all the required APIs. For more details on the list of APIs, see the Porting requirements.
- 4. Modify the file platform_name/include/platform_override_fvp.h with platform-specific information. For more details on sample implementation, see the Execution of BSA ACS.

2.4.1 Test components

The following table lists the bare-metal components for each test implementation.

Table 2-2: Bare-metal components

Components	Files
PE	pal_pe.c
GIC	pal_gic.c
PCle	pal_pcie.c, pal_pcie_enumeration.c
Exerciser	pal_exerciser.c
IOVIRT	pal_iovirt.c
SMMU	pal_smmu.c
Timer and Watchdog	pal_timer_wd.c
Peripherals (UART and Memory)	pal_peripherals.c
DMA	pal_dma.c
Miscellaneous	pal_misc.c

Overview to BSA ACS



PAL implementation requires porting when the underlying platform design changes.

3. Execution of BSA ACS

This chapter provides information on the execution of the BSA ACS on a full-chip SoC emulation environment.

3.1 SoC emulation environment

Executing BSA ACS on a full-chip emulation environment requires implementation of PAL. This involves providing a collection of SoC-specific information such as capabilities, base addresses, IRQ numbers to the test logic.

In Unified Extensible Firmware Interface (UEFI) base systems, all the static information is present in UEFI tables and in U-Boot base systems, all the static information is present in Device Tree. The PAL implementation which is based on UEFI and U-Boot, uses the generated header file for populating data structures. For a bare-metal system, this information must be supplied in a tabular format which becomes easy for PAL API implementation.

3.1.1 PE

This section provides information on the number of PEs in the system.

PE-specific information

Tests contain comparison of Multiprocessor ID Register (MPIDR) values with actual values read from register. Such interrupts are generated for the Performance Monitoring Unit (PMU) lines and tested.

PLATFORM_OVERRIDE_PEx_MPIDR:

MPIDR register value represents the xth PE hierarchy (cluster, core).

PLATFORM_OVERRIDE_PEx_INDEX:

Represents the xth PE.

PLATFORM_OVERRIDE_PEx_PMU_GSIV:

PMU interrupt number for xth PE.

A platform with eight PEs is populated as follows:

```
#define PLATFORM_OVERRIDE_PE_CNT 0x8

#define PLATFORM_OVERRIDE_PE0_INDEX 0x0
#define PLATFORM_OVERRIDE_PE0_MPIDR 0x0
#define PLATFORM_OVERRIDE_PE0_PMU_GSIV 0x17

#define PLATFORM_OVERRIDE_PE1_INDEX 0x1
#define PLATFORM_OVERRIDE_PE1_MPIDR 0x100
#define PLATFORM_OVERRIDE_PE1_PMU_GSIV 0x17

#define PLATFORM_OVERRIDE_PE1_PMU_GSIV 0x2
```

```
#define PLATFORM OVERRIDE PE2 MPIDR
                                              0 \times 200
#define PLATFORM OVERRIDE PE2 PMU GSIV 0x17
#define PLATFORM OVERRIDE PE3 INDEX
                                              0x3
#define PLATFORM OVERRIDE PE3 MPIDR
                                              0x300
#define PLATFORM OVERRIDE PE3 PMU GSIV 0x17
#define PLATFORM OVERRIDE PE4 INDEX
                                              0 \times 4
#define PLATFORM OVERRIDE PE4 MPIDR
                                              0x10000
#define PLATFORM OVERRIDE PE4 PMU GSIV 0x17
#define PLATFORM OVERRIDE PE5 INDEX
#define PLATFORM_OVERRIDE_PE5_MPIDR
                                              0x10100
#define PLATFORM OVERRIDE PE5 PMU GSIV
#define PLATFORM OVERRIDE PE6 INDEX
                                              0x6
#define PLATFORM_OVERRIDE_PE6_MPIDR 0x10
#define PLATFORM_OVERRIDE_PE6_PMU_GSIV 0x17
                                              0x10200
#define PLATFORM_OVERRIDE_PE7_INDEX
#define PLATFORM_OVERRIDE_PE7_MPIDR
                                              0 \times 7
                                              0x10300
#define PLATFORM OVERRIDE PE7 PMU GSIV 0x17
```

Header file representation:

```
typedef struct {
  uint32_t num_of_pe;
} PE_INFO_HDR;

/**
@brief structure instance for PE entry
**/
typedef struct {
  uint32_t pe_num; //< PE Index
  uint32_t attr; //< PE attributes
  uint64_t mpidr; //< PE MPIDR
  uint32_t pmu_gsiv; //< PMU Interrupt ID
} PE_INFO_ENTRY;

typedef struct {
  PE_INFO_ENTRY;
  PE_INFO_ENTRY pe_info[];
} PE_INFO_TABLE;</pre>
```

3.1.2 PCle

This section provides information on the number of Peripheral Component Interconnect express (PCIe) root ports and the information required for PCIe enumeration.

PLATFORM_OVERRIDE_PCIE_BAR64_VAL:

The address required for 64-bit Prefetchable Memory Base.

PLATFORM_OVERRIDE_PCIE_BAR32NP_VAL:

The address required for 32-bit Non-Prefetchable Memory Base.

PLATFORM_OVERRIDE_PCIE_BAR32P_VAL:

The address required for 32-bit Prefetchable Memory Base.

Parameters required for the PCIe enumeration for a platform is populated as follows:

```
/* PCIe BAR config parameters*/

#define PLATFORM_OVERRIDE_PCIE_BAR64_VAL 0x500000000

#define PLATFORM_OVERRIDE_PCIE_BAR32NP_VAL 0x60700000

#define PLATFORM_OVERRIDE_PCIE_BAR32P_VAL 0x60000000
```

PLATFORM_OVERRIDE_NUM_ECAM:

Represents the number of Enhanced Configuration Access Mechanism (ECAM) regions in the system.

PLATFORM_OVERRIDE_PCIE_ECAM_BASE_ADDR_x:

ECAM base address: ECAM maps PCIe configuration space to a memory address. The memory address to the current configuration space must be provided here.

PLATFORM_OVERRIDE_PCIE_SEGMENT_GRP_NUM_x:

Segment number of the xth ECAM region.

PLATFORM_OVERRIDE_PCIE_START_BUS_NUM_x:

Starting bus number of the xth ECAM region.

PLATFORM_OVERRIDE_PCIE_END_BUS_NUM_x:

Ending bus number of the xth ECAM region.

A platform with one ECAM region is populated as follows:

```
/* PCIE platform config parameters */
#define PLATFORM_OVERRIDE_NUM_ECAM 1

/* Platform config parameters for ECAM_0 */
#define PLATFORM_OVERRIDE_PCIE_ECAM_BASE_ADDR_0 0x60000000
#define PLATFORM_OVERRIDE_PCIE_SEGMENT_GRP_NUM_0 0x0
#define PLATFORM_OVERRIDE_PCIE_START_BUS_NUM_0 0x0
#define PLATFORM_OVERRIDE_PCIE_END_BUS_NUM_0 0xff
```

```
typedef struct {
  uint64_t ecam_base; ///< ECAM Base address
  uint32_t segment_num; ///< Segment number of this ECAM
  uint32_t start_bus_num; ///< Start Bus number for this ecam space
  uint32_t end_bus_num; ///< Last Bus number
} PCIE_INFO_BLOCK;

typedef struct {
  uint32_t num_entries;
  PCIE_INFO_BLOCK block[];
} PCIE_INFO_TABLE;</pre>
```

3.1.2.1 PCIE device hierarchy table

This hierarchy table is used to obtain platform specific support such as DMA, P2P and so on.

Parameters to be populated for each PCIe device is as follows:

```
PLATFORM PCIE DEVX CLASSCODE 0x6040000
PLATFORM PCIE DEVX VENDOR ID. 0x13B5
PLATFORM PCIE DEVX DEV ID 0xDEF
PLATFORM PCIE DEVX BUS NUM 0
PLATFORM PCIE DEVX DEV NUM 1
PLATFORM PCIE DEVX FUNC NUM 0
PLATFORM PCIE DEVX SEG NUM 0
PLATFORM PCIE DEVX DMA SUPPORT 0
PLATFORM PCIE DEVX DMA COHERENT 0
PLATFORM PCIE DEVX DMA COHERENT 1
PLATFORM PCIE DEVX DMA 64BIT 0
PLATFORM PCIE DEVX BEHIND SMMU 1
PLATFORM PCIE DEVX ATC SUPPORT 0
```

Header file representation:

```
typedef struct {
  uint64_t class_code;
  uint32_t device_id;
  uint32_t vendor_id;
  uint32_t bus;
  uint32_t dev;
  uint32_t func;
  uint32_t seg;
  uint32_t dma_support;
  uint32_t dma_coherent;
  uint32_t dma_fo4bit;
  uint32_t dma_fo4bit;
  uint32_t atc_present;
  PERIPHERAL IRQ_MAP irq_map;
} PCIE_READ_BLOCK;
```

3.1.3 DMA

This section provides the configuration options for Direct Memory Access (DMA) controller-based tests. Additionally, it describes the parameters for the number of DMA bus Requesters, and DMA Requester attributes that can be customized.

3.1.3.1 Number of DMA controllers

Header file representation:

```
#define PLATFORM_OVERRIDE_DMA_CNT 0
```

PLATFORM_OVERRIDE_DMA_CNT:

Represents the number of DMA controllers in the system.

3.1.3.2 DMA Requester attributes

Header file representation:

The actual info stored in the above pointers are implementation-specific.

3.1.4 SMMU and device tests

This section provides an overview on SMMU and the device tests. It also provides information on the number of IOVIRT nodes, SMMUs, RC, Named component, PMCG, ITS blocks, I/O virtualization node-specific information, SMMU node-specific information, RC-specific information, and I/O virtual address mapping.

3.1.4.1 Number of IOVIRT Nodes

Parameters to be filled are:

```
#define IORT_NODE_COUNT 0x13
```

IORT_NODE_COUNT:

Represents the total number of Root Complex (RC), SMMU, ITS, PMCG, and other nodes represented in IORT structure.

3.1.4.2 Number of SMMUs

Parameters to be filled are:

```
#define IOVIRT_SMMUV3_COUNT 5
#define IOVIRT_SMMUV2_COUNT 0
```

SMMU_COUNT:

Represents the number of SMMUs in the system.

3.1.4.3 Number of RCs

Parameters to be filled are:

```
#define RC_COUNT 0x1
```

RC_COUNT:

Represents the number of RCs present in the system.

3.1.4.4 Number of PMCGs

Parameters to be filled are:

```
#define PMCG_COUNT 0x1
```

PMCG_COUNT:

Represents the number of Performance Monitor Counter Groups (PMCGs) present in the system.

3.1.4.5 Number of ITS blocks

Parameters to be filled are:

```
#define IOVIRT_ITS_COUNT 0x1
```

IOVIRT_ITS_COUNT:

Represents the number of Interrupt Translation Service (ITS) nodes in the system.

3.1.4.6 I/O virtualization node-specific information

```
typedef struct {
uint32_t type;
uint32_t num data map;
NODE DATA data;
uint32 t flags;
NODE DATA MAP data_map[];
}IOVIRT_BLOCK;

typedef union {
char name[MAX NAMED_COMP_LENGTH];
IOVIRT_RC_INFO_BLOCK rc;
IOVIRT_PMCG_INFO_BLOCK pmcg;
uint32_t its_count;
SMMU_INFO_BLOCK smmu;
}NODE_DATA;
```

3.1.4.7 SMMU node-specific information

Header file representation:

IOVIRT_SMMUV3_BASE_ADDRESS:

Represents the SMMU base address in the system.

3.1.4.8 Root Complex node specific information

Header file representation:

3.1.4.9 PMCG node-specific information

Header file representation:

```
typedef struct {
uint64_t base;
uint32_t overflow_gsiv;
uint32_t node_ref;
} IOVIRT_PMCG_INFO_BLOCK;
```

3.1.4.10 I/O virtual address mapping

```
typedef struct {
uint32_t input_base;
uint32_t id_count;
uint32_t output_base;
uint32_t output_ref;
}ID_MAP;
```

3.1.5 GIC

This section provides the parameters for Generic Interrupt Controller (GIC) specific test.

GIC-specific tests

Parameters to be filled are:

```
#define PLATFORM OVERRIDE GICD COUNT
                                                    0x1
#define PLATFORM OVERRIDE GICRD COUNT
                                                    0x1
#define PLATFORM_OVERRIDE_GICITS_COUNT
                                                    0 \times 1
#define PLATFORM_OVERRIDE_GICC_TYPE
                                                    0x1000
#define PLATFORM_OVERRIDE_GICD_TYPE
#define PLATFORM_OVERRIDE_GICC_GICRD_TYPE
                                                    0x1001
                                                   0x1002
#define PLATFORM OVERRIDE GICR GICRD TYPE
                                                   0x1003
#define PLATFORM_OVERRIDE_GICITS_TYPE
                                                    0x1004
#define PLATFORM_OVERRIDE_GICMSIFRAME_TYPE 0x1005
#define PLATFORM_OVERRIDE_GICH_TYPE 0x1006
#define PLATFORM_OVERRIDE_GICC_BASE
                                                   0x30000000
#define PLATFORM_OVERRIDE_GICD_BASE
#define PLATFORM_OVERRIDE_GICRD_BASE
                                                    0x30000000
                                                   0x300C0000
#define PLATFORM OVERRIDE GICITS BASE
                                                   0x30040000
#define PLATFORM_OVERRIDE_GICH_BASE
#define PLATFORM_OVERRIDE_GICITS_ID
                                                    0x2C010000
#define PLATFORM OVERRIDE GICIRD LENGTH
                                                    (0x20000*8)
```

```
typedef struct {
uint32_t gic_version;
uint32_t num_gicc;
uint32_t num_gicd;
uint32 t num gicrd;
uint32 t num gicits;
uint32 t num gich;
uint32 t num msiframes;
uint32_t gicc_type;
uint32_t gicd_type;
uint32 t gicrd type;
uint32_t gicrd_length;
uint32_t gicits_type;
uint64_t gicc_base[PLATFORM_OVERRIDE_GICC_COUNT];
uint64_t gicd_base[PLATFORM_OVERRIDE_GICD_COUNT];
uint64_t gicrd_base[PLATFORM_OVERRIDE_GICRD_COUNT];
uint64_t gicits_base[PLATFORM_OVERRIDE_GICITS_COUNT];
uint64 t gicits id[PLATFORM OVERRIDE GICITS COUNT];
uint64_t gich_base[PLATFORM_OVERRIDE_GICH_COUNT];
uint64 t gicmsiframe base[PLATFORM OVERRIDE GICMSIFRAME COUNT];
uint64 t gicmsiframe id[PLATFORM OVERRIDE GICMSIFRAME COUNT];
uint32_t gicmsiframe_flags[PLATFORM_OVERRIDE_GICMSIFRAME_COUNT];
uint32_t gicmsiframe_spi_count[PLATFORM_OVERRIDE_GICMSIFRAME_COUNT];
uint32_t gicmsiframe_spi_base[PLATFORM_OVERRIDE_GICMSIFRAME_COUNT];
} PLATFORM OVERRIDE GIC INFO TABLE;
```

3.1.6 Timer

This section provides the parameters for timer-specific tests.

3.1.6.1 Timer information

Parameters to be filled are:

```
#define PLATFORM_OVERRIDE_PLATFORM_TIMER_COUNT  0x2
#define PLATFORM_OVERRIDE_S_EL1_TIMER_GSIV  0x1D
#define PLATFORM_OVERRIDE_NS_EL1_TIMER_GSIV  0x1E
#define PLATFORM_OVERRIDE_NS_EL2_TIMER_GSIV  0x1A
#define PLATFORM_OVERRIDE_VIRTUAL_TIMER_GSIV  0x1B
#define PLATFORM_OVERRIDE_EL2_VIR_TIMER_GSIV  28
```

```
typedef struct {
    uint32 t s ell timer flag;
    uint32 t ns ell timer flag;
    uint32 t el2 timer flag;
    uint32 t el2 virt timer flag;
    uint32 t s ell timer gsIv;
    uint32 t ns ell timer gsiv;
    uint32 t virtual timer flag;
    uint32 t virtual timer flag;
    uint32 t virtual timer gsiv;
    uint32 t virtual timer gsiv;
    uint32 t virtual timer gsiv;
    uint32 t t num platform_timer;
    uint32 t num watchdog;
    uint32 t tsys timer status;
}TIMER_INFO_HDR;

typedef struct {
    uint32 t type;
    uint32 t type;
    uint32 t tymer count;
    uint64 t block_cntl base;
    uint8 t frame num[8];
    uint64 t GtCntBloBase[8];
    uint64 t GtCntBloBase[8];
    uint32 t virt gsiv[8];
    uint32 t virt gsiv[8];
    uint32 t flags[8];
}TIMER_INFO_GTBLOCK;

typedef struct {
    typedef struct {
    typedef struct {
        typedef struct {
            typedef struct {
            typedef struct {
            typedef struct {
            typedef struct {
            typedef struct {
            typedef struct {
            typedef struct {
            typedef struct {
            typedef struct {
            typedef struct {
            typedef struct {
            typedef struct {
            typedef struct {
            typedef struct {
            typedef struct {
            typedef struct {
            typedef struct {
            typedef struct {
            typedef struct {
            typedef struct {
            typedef struct {
            typedef struct {
            typedef struct {
            typedef struct {
            typedef struct {
            typedef struct {
            typedef struct {
            typedef struct {
            typedef struct {
            typedef struct {
            typedef struct {
            typedef struct {
            typedef struct {
            typedef struct {
            typedef struct {
            typedef struct {
            typedef struct {
            typedef struct {
                 typedef struct {
                  typedef struct {
```

3.1.7 Watchdog timer

This section provides the parameters for the number of watchdog timer tests and watchdog information.

Parameters to be filled are:

```
#define PLATFORM_OVERRIDE_WD_TIMER_COUNT 2
```

3.1.7.1 Watchdog information

The following is the list of watchdog timers present in the system:

- Watchdog timer number
- Control base
- Refresh base
- Interrupt number
- Flags

Header file representation:

3.1.8 Memory

This section provides information on the memory map in the system.

PLATFORM_OVERRIDE_MEMORY_ENTRY_COUNT:

Represents the number of memory range entries.

PLATFORM_OVERRIDE_MEMORY_ENTRYx_PHY_ADDR:

Represents the physical address of the xth memory entry.

PLATFORM_OVERRIDE_MEMORY_ENTRYx_VIRT_ADDR:

Represents the virtual address of the xth memory entry.

PLATFORM_OVERRIDE_MEMORY_ENTRYx_SIZE:

Represents the size of the xth memory entry.

PLATFORM_OVERRIDE_MEMORY_ENTRYx_TYPE:

Represents the type of the xth memory entry.

The following is an example for memory map.

```
#define PLATFORM OVERRIDE MEMORY ENTRY COUNT
                                                                                       0x4
#define PLATFORM OVERRIDE MEMORY ENTRYO PHY ADDR #define PLATFORM OVERRIDE MEMORY ENTRYO VIRT ADDR #define PLATFORM OVERRIDE MEMORY ENTRYO SIZE
                                                                                       0xC000000
                                                                                       0xC000000
                                                                                       0x4000000
#define PLATFORM_OVERRIDE_MEMORY_ENTRY0_TYPE
                                                                                      MEMORY TYPE DEVICE
#define PLATFORM_OVERRIDE_MEMORY_ENTRY1_PHY_ADDR
#define PLATFORM_OVERRIDE_MEMORY_ENTRY1_VIRT_ADDR
                                                                                       0 \times 1000 \overline{0}000
                                                                                       0x10000000
#define PLATFORM OVERRIDE MEMORY ENTRY1 SIZE
                                                                                       0xC170000
#define PLATFORM_OVERRIDE_MEMORY_ENTRY1_TYPE
#define PLATFORM_OVERRIDE_MEMORY_ENTRY2_PHY_ADDR
                                                                                      MEMORY_TYPE_NOT_POPULATED 0xFF600000
#define PLATFORM OVERRIDE MEMORY ENTRY2 VIRT ADDR
                                                                                       0xFF600000
#define PLATFORM OVERRIDE MEMORY ENTRY2 SIZE #define PLATFORM OVERRIDE MEMORY ENTRY2 TYPE #define PLATFORM OVERRIDE MEMORY ENTRY3 PHY ADDR
                                                                                      0x10000
                                                                                       MEMORY TYPE RESERVED
                                                                                       0 \times 800000000
#define PLATFORM_OVERRIDE_MEMORY_ENTRY3_VIRT_ADDR
#define PLATFORM_OVERRIDE_MEMORY_ENTRY3_SIZE
#define PLATFORM_OVERRIDE_MEMORY_ENTRY3_TYPE
                                                                                       0x80000000
                                                                                       0x7F000000
                                                                                       MEMORY TYPE NORMAL
```

```
typedef struct {
MEM_INFO_TYPE_e type;
uint64_t phy_addr;
uint64_t virt_addr;
uint64_t size;
uint64_t flags; //To Indicate Cacheablility etc..
}MEM_INFO_BLOCK;
```

4. Porting requirements

This chapter provides information on different PAL APIs in PE, GIC, timer, IOVIRT, PCIe, SMMU, peripheral, DMA, exerciser, and other miscellaneous APIs.

4.1 PAL implementation

PAL is a C-based, Arm-defined API that you can implement. Each test platform requires a PAL implementation of its own.

The bare-metal reference code provides a reference implementation for a subset of APIs. Additional code must be implemented to match the target SoC implementation under the tests.

There are two implementation types for the PAL APIs and are classified in the following tables:



- Yes: indicates that the implementation of this API is already present. Since the values are platform-specific, it must be taken from the platform configuration file
- Platform-specific: you must implement all the APIs that are marked as platform-specific.

4.1.1 PE

The following table lists the different types of APIs in PE.

Table 4-1: PE APIs and their details

API name	Function prototype	Implementation
create_info_table	<pre>void pal_pe_create_info_table(PE_INFO_TABLE *PeTable);</pre>	Yes
call_smc	<pre>void pal_pe_call_smc(ARM_SMC_ARGS *args);</pre>	Yes
execute_payload	<pre>void pal_pe_execute_payload(ARM_SMC_ARGS *args);</pre>	Yes
update_elr	<pre>void pal_pe_update_elr(void *context,uint64_toffset);</pre>	Platform- specific
get_esr	<pre>uint64_t pal_pe_get_esr(void *context);</pre>	Platform- specific
data_cache_ops_by_va	<pre>void pal_pe_data_cache_ops_by_va(uint64_t addr, uint32_t type);</pre>	Yes
get_far	<pre>uint64_t pal_pe_get_far(void *context);</pre>	Platform- specific
install_esr	<pre>uint32_t pal_pe_install_esr(uint32_t exception_type, void(*esr) (uint64_t, void *));</pre>	Platform- specific
get_num	uint32_t pal_pe_get_num();	Yes

API name	Function prototype	Implementation
psci_get_conduit		Platform- specific

4.1.2 GIC

The following table lists the different types of APIs in GIC.

Table 4-2: GIC APIs and their details

API name	Function prototype	Implementation
create_info_table	<pre>void pal_gic_create_info_table(GIC_INFO_TABLE* gic_info_table);</pre>	Yes
install_isr	<pre>uint32_t pal_gic_install_isr(uint32_t int_id, void(*isr)(void));</pre>	Platform- specific
end_of_interrupt	<pre>uint32_t pal_gic_end_of_interrupt(uint32_t int_id);</pre>	Platform- specific
request_irq	<pre>uint32_t pal_gic_request_irq(unsigned intirq_num, unsigned int mapped_ irq_num,void *isr);</pre>	Platform- specific
free_irq	<pre>void pal_gic_free_irq(unsigned int irq_num,unsigned int mapped_irq_num);</pre>	Platform- specific
set_intr_trigger	<pre>uint32_t pal_gic_set_intr_trigger(uint32_t int_idINTR_TRIGGER_ INFO_TYPE_etrigger_type);</pre>	Platform- specific

4.1.3 Timer

The following table lists the different types of APIs in timer.

Table 4-3: Timer APIs and their details

API name	Function prototype	Implementation
create_info_table	<pre>void pal_timer_create_info_table(TIMER_INFO_TABLE *timer_ info_table);</pre>	Yes
wd_create_info_table	<pre>void pal_wd_create_info_table(WD_INFO_TABLE *wd_table);</pre>	Yes
get_counter_frequency	uint64_t pal_timer_get_counter_frequency(void);	Yes

4.1.4 IOVIRT

The following table lists the different types of APIs in IOVIRT.

Table 4-4: IOVIRT APIs and their details

API name	Function prototype	Implementation
create_info_table	<pre>void pal_iovirt_create_info_table(IOVIRT_INFO_TABLE *iovirt);</pre>	Yes
unique_rid_strid_map	<pre>uint32_t pal_iovirt_unique_rid_strid_map(uint64_t rc_block);</pre>	Yes
check_unique_ctx_initd	<pre>uint32_t pal_iovirt_check_unique_ctx_intid(uint64_t smmu_block);</pre>	Yes

API name	Function prototype	Implementation
	<pre>uint64_t pal_iovirt_get_rc_smmu_base(IOVIRT_INFO_TABLE *iovirt, uint32_t rc_seg_num, uint32_t rid);</pre>	Yes

4.1.5 PCle

The following table lists the different types APIs in PCIe.

Table 4-5: PCIe APIs and their details

API name	Function prototype	Implementation
create_info_table	<pre>void pal_pcie_create_info_table (PCIE_INFO_TABLE *PcieTable);</pre>	Yes
read_cfg	<pre>uint32_t pal_pcie_read_cfg(uint32_t bdf, uint32_t offset, uint32_t *data);</pre>	Yes
get_msi_vectors	<pre>uint32_t pal_get_msi_vectors(uint32_t seg,uint32_ t bus, uint32_t dev, uint32_t fn, PERIPHERAL_ VECTOR_LIST**mvector);</pre>	Platform- specific
scan_bridge_devices_and_check_memtype	<pre>uint32_t pal_pcie_scan_bridge_devices_and_check_ memtype (uint32_t seg,uint32_t bus, uint32_t dev, uint32_tfn);</pre>	Yes
get_pcie_type	<pre>uint32_t pal_pcie_get_pcie_type(uint32_t seg,uint32_t bus, uint32_t dev, uint32_t fn);</pre>	Yes
p2p_support	<pre>uint32_t pal_pcie_p2p_support(void);</pre>	Yes
read_ext_cap_word	<pre>void pal_pcie_read_ext_cap_word(uint32_t seg, uint32_ t bus, uint32_t dev,uint32_t fn, uint32_t ext_cap_id, uint8_t offset, uint16_t *val);</pre>	Yes
get_bdf_wrapper	<pre>uint32_t pal_pcie_get_bdf_wrapper (uint32_t class_ code, uint32_t start_bdf);</pre>	Yes
bdf_to_dev	<pre>void *pal_pci_bdf_to_dev(uint32_t bdf);</pre>	Yes
pal_pcie_ecam_base	<pre>uint64_t pal_pcie_ecam_base(uint32_t seg,uint32_t bus, uint32_t dev, uint32_tfunc)</pre>	Yes
pci_cfg_read	<pre>uint32_t pal_pci_cfg_read(uint32_t bus, uint32_t dev, uint32_t func, uint32_t offset, uint32_t *value)</pre>	Yes
pci_cfg_write	<pre>void pal_pci_cfg_write(uint32_t bus, uint32_t dev, uint32_t func, uint32_t offset, uint32_t data)</pre>	Yes
program_bar_reg	<pre>void pal_pcie_program_bar_reg(uint32_tbus, uint32_t dev, uint32_t func)</pre>	Yes
enumerate_device	<pre>uint32_t pal_pcie_enumerate_device(uint32_t bus, uint32_t sec_bus)</pre>	Yes
enumerate	<pre>void pal_pcie_enumerate(void);</pre>	Yes
get_bdf	<pre>uint32_t pal_pcie_get_bdf(uint32_t ClassCode, uint32_t StartBdf)</pre>	Yes
increment_bus_dev	uint32_t pal_increment_bus_dev(uint32_t StartBdf)	Yes
get_base	<pre>uint64_t pal_pcie_get_base(uint32_t bdf, uint32_t bar_index)</pre>	Yes
io_read_cfg	<pre>uint32_t pal_pcie_io_read_cfg(uint32_t bdf, uint32_t offset, uint32_t *data) ;</pre>	Yes

API name	Function prototype	Implementation
io_write_cfg	<pre>void pal_pcie_io_write_cfg(uint32_t bdf, uint32_t offset, uint32_t data);</pre>	Yes
get_device_type	<pre>uint32_t pal_pcie_get_device_type(uint32_t seg, uint32_t bus, uint32_t dev, uint32_t fn);</pre>	Yes
get_snoop_bit	<pre>uint32_t pal_pcie_get_snoop_bit(uint32_t seg, uint32_t bus, uint32_t dev, uint32_t fn);</pre>	Yes
is_device_behind_smmu	<pre>uint32_t pal_pcie_is_device_behind_smmu(uint32_t seg, uint32_t bus, uint32_t dev, uint32_t fn);</pre>	Yes
get_dma_support	<pre>uint32_t pal_pcie_get_dma_support(uint32_t seg, uint32_t bus, uint32_t dev, uint32_t fn);</pre>	Yes
get_dma_coherent	<pre>uint32_t pal_pcie_get_dma_coherent(uint32_t seg, uint32_t bus, uint32_t dev, uint32_t fn);</pre>	Yes
ls_devicedma_64bit	<pre>uint32_t pal_pcie_is_devicedma_64bit(uint32_t seg, uint32_t bus, uint32_t dev, uint32_t fn);</pre>	Yes
get_legacy_irq_map	<pre>uint32_t pal_pcie_get_legacy_irq_map(uint32_t Seg, uint32_t Bus, uint32_t Dev, uint32_t Fn, PERIPHERAL_ IRQ_MAP *IrqMap);</pre>	Platform- specific
get_root_port_bdf	<pre>uint32_t pal_pcie_get_root_port_bdf(uint32_t *Seg, uint32_t *Bus, uint32_t *Dev, uint32_t *Func);</pre>	Yes
dev_p2p_support	<pre>uint32_t pal_pcie_dev_p2p_support(uint32_t seg, uint32_t bus, uint32_t dev, uint32_t fn);</pre>	Yes
is_cache_present	<pre>uint32_t pal_pcie_is_cache_present(uint32_t seg, uint32_t bus, uint32_t dev, uint32_t fn);</pre>	Yes
is_onchip_peripheral	<pre>uint32_t pal_pcie_is_onchip_peripheral(uint32_t bdf);</pre>	Platform- specific
check_device_list	<pre>uint32_t pal_pcie_check_device_list(void);</pre>	Yes
get_rp_transaction_frwd_support	<pre>uint32_t pal_pcie_get_rp_transaction_frwd_ support(uint32_t seg, uint32_t bus, uint32_t dev, uint32_t fn)</pre>	Platform- specific
check_device_valid	<pre>uint32_t pal_pcie_check_device_valid(uint32_t bdf);</pre>	Platform- specific
mem_get_offset	<pre>pal_pcie_mem_get_offset(uint32_t type);</pre>	Yes
device_driver_present	<pre>uint32_t pal_pcie_device_driver_present(uint32_t seg, uint32_t bus, uint32_t dev, uint32_t fn);</pre>	Platform- specific

4.1.6 SMMU

The following table lists the different types of APIs in SMMU.

Table 4-6: SMMU APIs and their details

API name	Function prototype	Implementation
check_device_iova	<pre>uint32_t pal_smmu_check_device_iova(void *port, uint64_t dma_addr);</pre>	Platform- specific
device_start_monitor_iova	<pre>void pal_smmu_device_start_monitor_iova(void *port);</pre>	Platform- specific

API name	Function prototype	Implementation
device_stop_monitor_iova	<pre>void pal_smmu_device_stop_monitor_iova(void *port);</pre>	Platform- specific
max_pasids	<pre>uint32_t pal_smmu_max_pasids(uint64_t smmu_base);</pre>	Yes
pa2iova	<pre>uint64_t pal_smmu_pa2iova(uint64_t smmu_base, unit64_t pa);</pre>	Platform- specific
smmu_disable	<pre>uint32_t pal_smmu_disable(uint64_t smmu_base);</pre>	Platform- specific
create_pasid_entry	<pre>uint32_t pal_smmu_create_pasid_entry(uint64_t smmu_base, uint32_t pasid);</pre>	Platform- specific

4.1.7 Peripheral

The following table lists the different types of APIs in peripheral.

Table 4-7: Peripheral APIs and their details

API name	Function prototype	Implementation
create_info_table	<pre>void pal_peripheral_create_info_table(PERIPHERAL_INFO_TABLE *per_info_table);</pre>	Yes
is_pcie	<pre>uint32_t pal_peripheral_is_pcie(uint32_t seg, uint32_t bus, uint32_t dev, uint32_t fn);</pre>	Yes
memory_create_info_table	<pre>void pal_memory_create_info_table(MEMORY_INFO_TABLE *memoryInfoTable);</pre>	Platform- specific
memory_ioremap	<pre>uint64_t pal_memory_ioremap(void *addr, uint32_t size, uint32_t attr);</pre>	Platform- specific
memory_unmap	<pre>void pal_memory_unmap(void *addr);</pre>	Platform- specific
memory_get_unpopulated_addr	<pre>uint64_t pal_memory_get_unpopulated_addr(uint64_t *addr, uint32_t instance)</pre>	Platform- specific

4.1.8 DMA

The following table lists the different types of APIs in DMA.

Table 4-8: DMA APIs and their details

API name	Function prototype	Implementation
create_info_table	<pre>void pal_dma_create_info_table(DMA_INFO_TABLE *dma_info_table);</pre>	Yes
start_from_device	<pre>uint32_t pal_dma_start_from_device(void *dma_target_buf, uint32_t length,void *host,void *dev);</pre>	Platform- specific
start_to_device	<pre>uint32_t pal_dma_start_to_device(void *dma_source_buf, uint32_t length, void *host, void *target, uint32_t timeout);</pre>	Platform- specific
mem_alloc	<pre>uint64_t pal_dma_mem_alloc(void *buffer, uint32_t length, void *dev, uint32_t flags);</pre>	Platform- specific
scsi_get_dma_addr	<pre>void pal_dma_scsi_get_dma_addr(void *port, void *dma_addr, uint32_t *dma_len);</pre>	Platform- specific

API name	Function prototype	Implementation
mem_get_attrs	<pre>int pal_dma_mem_get_attrs(void *buf, uint32_t *attr, uint32_t *sh)</pre>	Platform- specific
dma_mem_free	<pre>void pal_dma_mem_free(void *buffer, addr_tmem_dma, unsigned int length, void *port,unsigned int flags);</pre>	Platform- specific

4.1.9 Exerciser

The following table lists the different types of APIs in exerciser.

Table 4-9: Exerciser APIs and their details

API name	Function prototype	Implementation
get_ecsr_base	<pre>uint64_t pal_exerciser_get_ecsr_base(uint32_t Bdf,uint32_t BarIndex)</pre>	Platform- specific
get_pcie_config_offset	uint64_t pal_exerciser_get_pcie_config_offset(uint32_t Bdf)	Platform- specific
start_dma_direction	uint32_t pal_exerciser_start_dma_direction(uint64_t Base, EXERCISER_DMA_ATTRDirection)	Platform- specific
find_pcie_capability	uint32_t pal_exerciser_find_pcie_capability(uint32_t ID, uint32_t Bdf, uint32_t Value, uint32_t *Offset)	Platform- specific
set_param	<pre>uint32_t pal_exerciser_set_param(EXERCISER_PARAM_TYPE type, uint64_t value1, uint64_t value2, uint32_t bdf);</pre>	Platform- specific
get_param	<pre>uint32_t pal_exerciser_get_param(EXERCISER_PARAM_TYPE type, uint64_t *value1, uint64_t *value2, uint32_t bdf);</pre>	Platform- specific
set_state	<pre>uint32_t pal_exerciser_set_state(EXERCISER_STATE state, uint64_t *value, uint32_t bdf);</pre>	Platform- specific
get_state	<pre>uint32_t pal_exerciser_get_state(EXERCISER_STATE *state, uint32_t bdf);</pre>	Platform- specific
ops	<pre>uint32_t pal_exerciser_ops(EXERCISER_OPS ops,uint64_t param, uint32_t instance);</pre>	Platform- specific
get_data	<pre>uint32_t pal_exerciser_get_data(EXERCISER_DATA_TYPE type, exerciser_ data_t *data, uint32_tbdf, uint64_t ecam);</pre>	Platform- specific
is_bdf_exerciser	uint32_t pal_is_bdf_exerciser(uint32_t bdf)	Platform- specific
get_legacy_irq_map	uint32_t pal_exerciser_get_legacy_irq_map(uint32_t Seg, uint32_t Bus, uint32_t Dev, uint32_t Fn, PERIPHERAL_IRQ_MAP *IrqMap)	Platform- specific

4.1.10 Miscellaneous

The following table lists the different types of miscellaneous PAL APIs.

Table 4-10: Miscellaneous APIs and their details

API name	Function prototype	Implementation
mmio_read8	uint8_t pal_mmio_read8(uint64_t addr);	Yes
mmio_read16	<pre>uint16_t pal_mmio_read16(uint64_t addr);</pre>	Yes

API name	Function prototype	Implementation
mmio_read	uint32_t pal_mmio_read(uint64_t addr);	Yes
mmio_read64	uint64_t pal_mmio_read64(uint64_t addr);	Yes
mmio_write8	void pal_mmio_write8(uint64_t addr, uint8_t data);	Yes
mmio_write16	<pre>void pal_mmio_write16(uint64_t addr, uint16_t data);</pre>	Yes
mmio_write	<pre>void pal_mmio_write(uint64_t addr, uint32_t data);</pre>	Yes
mmio_write64	<pre>void pal_mmio_write64(uint64_t addr, uint64_t data);</pre>	Yes
print	<pre>void pal_print(char8_t *string, uint64_tdata);</pre>	Platform- specific
print_raw	<pre>void pal_print_raw(uint64_t addr, char *string, uint64_t data)</pre>	Yes
mem_free	<pre>void pal_mem_free(void *buffer);</pre>	Platform- specific
mem_compare	<pre>int pal_mem_compare(void *src,void *dest, uint32_t len);</pre>	Yes
mem_set	<pre>void pal_mem_set(void *buf, uint32_t size,uint8_t value);</pre>	Yes
mem_allocate_shared	<pre>void pal_mem_allocate_shared(uint32_t num_pe, uint32_t sizeofentry);</pre>	Yes
mem_get_shared_addr	<pre>uint64_t pal_mem_get_shared_addr(void);</pre>	Yes
mem_free_shared	<pre>void pal_mem_free_shared(void);</pre>	Yes
mem_alloc	<pre>void *pal_mem_alloc(uint32_t size);</pre>	Platform- specific
mem_virt_to_phys	<pre>void *pal_mem_virt_to_phys(void *va);</pre>	Platform- specific
mem_alloc_cacheable	<pre>void *pal_mem_alloc_cacheable(uint32_t Bdf, uint32_t Size, void **Pa);</pre>	Platform- specific
mem_free_cacheable	<pre>void pal_mem_free_cacheable(uint32_t Bdf, uint32_t Size, void *Va, void *Pa);</pre>	Platform- specific
mem_phys_to_virt	<pre>void *pal_mem_phys_to_virt (uint64_t Pa);</pre>	Platform- specific
strncmp	uint32_t pal_strncmp(char8_t *str1, char8_t *str2, uint32_t len);	Yes
memcpy	<pre>void *pal_memcpy(void *dest_buffer, void *src_buffer, uint32_t len);</pre>	Yes
time_delay_ms	<pre>uint64_t pal_time_delay_ms(uint64_t time_ms);</pre>	Platform- specific
page_size	<pre>uint32_t pal_mem_page_size();</pre>	Platform- specific
alloc_pages	<pre>void *pal_mem_alloc_pages (uint32 NumPages);</pre>	Platform- specific
free_pages	<pre>void pal_mem_free_pages (void *PageBase, uint32_t NumPages);</pre>	Platform- specific
mem_calloc	<pre>void *pal_mem_calloc(uint32_t num, uint32_t Size);</pre>	Platform- specific
aligned_alloc	<pre>void *pal_aligned_alloc(uint32_t alignment, uint32_t size);</pre>	Platform- specific
target_is_bm	uint32_t pal_target_is_bm()	Yes
mem_free_aligned	<pre>void pal_mem_free_aligned(void *buffer);</pre>	Platform- specific


5. BSA ACS flow

This chapter provides an overview of the BSA ACS flow diagram and BSA test example flow.

5.1 BSA ACS flow diagram

The following flow diagram shows the sequence of events from initialization of devices, initialization of BSA test data structures, and test case execution.

Figure 5-1: BSA flow diagram




5.2 BSA test example flow

If the device is Message-Signaled Interrupt (MSI) enabled, then the flag is set to MSI_ENABLED by the PAL layer. The test checks whether the device is of type endpoint and then checks if the flags are set to MSI_ENABLED.

The following flowchart shows the test that checks MSI support in a PCIe device.

Figure 5-2: BSA example flow diagram



Appendix A Revisions

This appendix describes the technical changes between released issues of this book.

A.1 Revisions

This section consists of all the technical changes between different versions of this document.

Table A-1: Issue 0100-01

Change	Location
First release.	-