	Z80 Alpha Plus				
	Original Memory Map (Z80 Alpha compatible)		·	Extended Memory Map (Alpha Plus mode)	
JP5 JP6 JP7 JP8	1-2 1-2 1-2 1-2			2-3 2-3 2-3 2-3	
ROM	2k	0000-07FF		8k	0000-1FFF
RAM Baixa	2k	0800-0FFF		24k	2000-7FFF
RAM Alta	32k	8000-FFFF		32k	8000-FFFF