## Hастройки BIOS IOWA-GX-466-128MB

Для функционирования СЧПУ APTA в BIOS материнской платы необходимо задать следующие настройки (указаны только настройки отличающиеся от значений «ПО\_УМОЛЧАНИЮ»).

Вход в меню настроек BIOS осуществляется нажатием DEL во время начальной загрузки системы (примерно от 1 до 6 секунды после подачи напряжения). Далее приводиться список параметров в порядке перечисления в меню параметров BIOS.

- Standart CMOS Features:
  - Drive A
    Halt On
    No Errors
- Advanced BIOS Features:
  - First Boot Device Disabled
    Second Boot Device HDD-0
- Advansed Chipset Features:
  - Video Memory Size 8M
- Integrated Peripherals:
  - IT8888 ISA DECODE IO
    - Decode I/O Space 0:
      - - Enable
      - - Slow Speed
      - - 300
      - - 4 Bytes
    - Decode I/O Space 1:
      - - Enable
      - - Slow Speed
      - - 180
      - 32 Bytes
    - Decode I/O Space 2:
      - Disabled
    - Decode I/O Space 3:
      - Disabled
    - Decode I/O Space 4:
      - - Disabled
    - Decode I/O Space 5:
      - - Disabled
  - Onboard Serial Port 1- 3F8
  - Onboard Serial Port 2- 2F8
  - Onboard Serial Port 3- 3E8
- Power Managment Setup:
  - AC Power mode AT