

E(rasmus) Mundus on Innovative Microwave Electronics and Optics



Introduction to lasers

Pr A. Desfarges-Berthelemot – Limoges University

Chapter 4: Features of laser emission














E(rasmus) Mundus on Innovative Microwave Electronics and Optics

I - Laser efficiency – output power



Only a small portion of the internal intensity (or power) determined by $P = Psat\left(\frac{\gamma_0}{\alpha_t} - 1\right)$ leaves the resonator in the form of the useful light (P_{out}).

The internal power (or intensity) is the sum of P1 and P2



Optimization of the output coupler coefficient \rightarrow see exercise



E((MINA

E(rasmus) Mundus on Innovative Microwave Electronics and Optics

To complete



E((

E(rasmus) Mundus on Innovative Microwave Electronics and Optics

To complete

Optimization of the output coupler coefficient \rightarrow see Tutorial 1


Comment: Laser efficiency $\rightarrow P_{out} = f(P_{pump}) \rightarrow see Tutorial 1$



E(rasmus) Mundus on Innovative Microwave Electronics and Optics

II - Spectral characteristics

- Threshold condition: $\gamma_0 > \alpha_t$
- Phase condition giving the longitudinal modes: $v_q = q \cdot \frac{c}{2,[L]}$






E(rasmus) Mundus on Innovative Microwave Electronics and Optics

Typical spectral characteristics of well-known lasers

	Δν Gain bandwidth	L (cavity)	c/2L	Number of modes*
He-Ne $(\lambda = 632 \text{ nm})$	1 GHz/ 1.3 pm	0,3 m	2 GHz	2;3 modes
Nd:YAG (λ = 1064 nm)	150 GHz/ 0.5 nm	1 m	150 MHz	1 000 modes
Ytterbium doped fiber $(\lambda = 1050 \text{ nm})$	2.7 THz/ ~10 nm	10 m	15 MHz	180.10 ³ modes

*





E(rasmus) Mundus on Innovative Microwave Electronics and Optics

To complete

III - Spatial characteristics

1. Definition of a transverse mode

Transverse mode: electromagnetic field distributions which reproduces itself after a full cavity round trip



E((A)A

E(rasmus) Mundus on Innovative Microwave Electronics and Optics

2. Autocollimation condition for free-space cavities


Case of the Gaussian beam



E(rasmus) Mundus on Innovative Microwave Electronics and Optics

3. Gaussian beam: TEM00 mode

- Lowest divergence beam




$$\alpha = \pi w_0^2 / \lambda = \text{Rayleigh length}$$

$$w^2(z) = w_0^2[1+z^2/\alpha^2] = beam radius$$

$$R(z) = z[1 + \alpha^2/z^2] = curvature radius$$

$$\theta = \lambda / \pi w_0$$
 = half divergence





E(rasmus) Mundus on Innovative Microwave Electronics and Optics


4. Other modes


Modes of free-space cavities:

Laguerre-Gauss modes: rotational symmetry Hermite-Gauss modes: cartesian symmetry



Free-space propagation invariant





Selection by diffracting obstacles + cavity geometry (phase matching on mirrors)



Minimum losses



E(rasmus) Mundus on Innovative Microwave Electronics and Optics

Multimode beam




Figure 1: Intensity profiles of a Gaussian beam (left) and a multimode laser beam (right). The latter exhibits more complicated variations of the intensity. Such multimode beams can be generated in lasers where the fundamental resonator modes are substantially smaller than the pumped region in the gain medium.

https://www.rp-photonics.com/beam_profilers.html







E(rasmus) Mundus on Innovative Microwave Electronics and Optics

Modes of fiber lasers: LPmn modes



Invariant propagation though the fiber





Multimode beam