ASCOM Interface Revisions

 Key:
 Member present
 Member absent from this interface

 Deprecated in some way, see member interface description
 Requirements revised, see member interface description

Camera					
Member	Platform 7 - 2024	Platform 6.5 - 2020	Platform 6.3 - 2017	Platform 6 - 2011	Platform 5 - 2008
Tiomber	ICameraV4	ICameraV3	ICameraV2	ICameraV2	ICamera
AbortExposure					Introduced
Action BayerOffsetX				Introduced Introduced	Absent Absent
BayerOffsetY				Introduced	Absent
BinX					Introduced
BinY					Introduced
CameraState					Introduced
CameraXSize					Introduced
CameraYSize CanAbortExposure					Introduced Introduced
CanAsymmetricBin					Introduced
CanFastReadout				Introduced	Absent
CanGetCoolerPower					Introduced
CanPulseGuide					Introduced
CanSetCCDTemperature					Introduced
CanStopExposure					Introduced
CCDTemperature CommandBlind	Denvested			Introduced	Introduced
CommandBlind CommandBool	Deprecated Deprecated			Introduced Introduced	Absent Absent
CommandString	Deprecated			Introduced	Absent
Connect	Introduced	Absent	Absent	Absent	Absent
Connected	Revised				Introduced
Connecting	Introduced	Absent	Absent	Absent	Absent
CoolerOn					Introduced
CoolerPower					Introduced
Description DeviceState	Introduced	Absort	Aboout	Absent	Introduced Absent
Disconnect	Introduced	Absent Absent	Absent Absent	Absent	Absent
Dispose	muoduced	Absent	Absent	Introduced	Absent
DriverInfo				Introduced	Absent
DriverVersion				Introduced	Absent
ElectronsPerADU					Introduced
ExposureMax		Introduced	Absent	Absent	Absent
ExposureMin		Introduced	Absent	Absent	Absent
ExposureResolution		Introduced	Absent	Absent	Absent
FastReadout FullWellCapacity		Introduced	Absent	Absent	Absent Introduced
Gain				Introduced	Absent
GainMax				Introduced	Absent
GainMin				Introduced	Absent
Gains				Introduced	Absent
HasShutter					Introduced
HeatSinkTemperature					Introduced
ImageArray Variant					Introduced
ImageArrayVariant ImageReady					Introduced Introduced
InterfaceVersion				Introduced	Absent
IsPulseGuiding					Introduced
LastExposureDuration					Introduced
LastExposureStartTime			Revised		Introduced
MaxADU					Introduced
MaxBinX					Introduced
MaxBinY Name				Introduced	Introduced Absent
NumX				ilitiouuceu	Introduced
NumY					Introduced
Offset		Introduced	Absent	Absent	Absent
OffsetMax		Introduced	Absent	Absent	Absent
OffsetMin		Introduced	Absent	Absent	Absent
Offsets		Introduced	Absent	Absent	Absent
PercentCompleted				Introduced	Absent
PixelSizeY PixelSizeY					Introduced
PulseGuide					Introduced Introduced
ReadoutMode				Introduced	Absent
ReadoutModes				Introduced	Absent
SensorName				Introduced	Absent
SensorType				Introduced	Absent
SetCCDTemperature					Introduced
SetupDialog					Introduced
StartExposure					Introduced
StartX StartY					Introduced Introduced
StopExposure					Introduced
SubExposureDuration		Introduced	Absent	Absent	Absent
				Introduced	Absent

CoverCalibrator]	
Mambay	Platform 7 - 2024	Platform 6.5 - 2020
Member	ICoverCalibratorV2	ICoverCalibratorV1
Action		Introduced
Brightness		Introduced
CalibratorChanging	Introduced	Absent
CalibratorOff		Introduced
CalibratorOn		Introduced
CalibratorState		Introduced
CloseCover		Introduced
CommandBlind	Deprecated	Introduced
CommandBool	Deprecated	Introduced
CommandString	Deprecated	Introduced
Connect	Introduced	Absent
Connected	Revised	Introduced
Connecting	Introduced	Absent
CoverMoving	Introduced	Absent
CoverState		Introduced
Description		Introduced
DeviceState	Introduced	Absent
Disconnect	Introduced	Absent
Dispose		Introduced
DriverInfo		Introduced
DriverVersion		Introduced
HaltCover		Introduced
InterfaceVersion		Introduced
MaxBrightness		Introduced
Name		Introduced
OpenCover		Introduced
SetupDialog		Introduced
SupportedActions		Introduced

Dome			
Member	Platform 7 - 2024	Platform 6 - 2011	Platform 3 - 2003
Member	IDomeV3	IDomeV2	IDome
AbortSlew	Revised		Introduced
Action		Introduced	Absent
Altitude			Introduced
AtHome			Introduced
AtPark			Introduced
Azimuth			Introduced
CanFindHome			Introduced
CanPark			Introduced
CanSetAltitude			Introduced
CanSetAzimuth			Introduced
CanSetPark			Introduced
CanSetShutter			Introduced
CanSlave			Introduced
CanSyncAzimuth			Introduced
CloseShutter			Introduced
CommandBlind	Deprecated		Introduced
CommandBool	Deprecated		Introduced
CommandString	Deprecated		Introduced
Connect	Introduced	Absent	Absent
Connected	Revised		Introduced
Connecting		Absent	Absent
Description			Introduced
DeviceState	Introduced	Absent	Absent
Disconnect	Introduced	Absent	Absent
Dispose		Introduced	Absent
DriverInfo			Introduced
DriverVersion			Introduced
FindHome			Introduced
nterfaceVersion			Introduced
Name			Introduced
OpenShutter			Introduced
Park			Introduced
SetPark			Introduced
SetupDialog			Introduced
ShutterStatus			Introduced
Slaved			Introduced
Slewing			Introduced
SlewToAltitude			Introduced
SlewToAzimuth			Introduced
SupportedActions			Absent
SyncToAzimuth			Introduced

FilerWheel			
Marshar	Platform 7 - 2024	Platform 6 - 2011	Platform 5 - 2008
Member	IFilterWheelV3	IFilterWheelV2	IFilterWheel
Action		Introduced	Absent
CommandBlind	Deprecated	Introduced	Absent
CommandBool	Deprecated	Introduced	Absent
CommandString	Deprecated	Introduced	Absent
Connect	Introduced	Absent	Absent
Connected	Revised		Introduced
Connecting	Introduced	Absent	Absent
Description		Introduced	Absent
DeviceState		Absent	Absent
Disconnect		Absent	Absent
Dispose		Introduced	Absent
DriverInfo		Introduced	Absent
DriverVersion		Introduced	Absent
FocusOffsets			Introduced
InterfaceVersion		Introduced	Absent
Name		Introduced	Absent
Names			Introduced
Position			Introduced
SetupDialog			Introduced
SupportedActions		Introduced	Absent

Focuser				
Member	Platform 7 - 2024	Platform 6.4 - 2018	Platform 6 - 2011	Platform 2 - 2002
Member	IFocuserV4	IFocuserV3	IFocuserV2	IFocuser
Absolute				Introduced
Action			Introduced	Absent
CommandBlind	Deprecated		Introduced	Absent
CommandBool	Deprecated		Introduced	Absent
CommandString	Deprecated		Introduced	Absent
Connect	Introduced	Absent	Absent	Absent
Connected	Revised		Introduced	Absent
Connecting	Introduced	Absent	Absent	Absent
Description			Introduced	Absent
DeviceState	Introduced	Absent	Absent	Absent
Disconnect	Introduced	Absent	Absent	Absent
Dispose			Introduced	Absent
DriverInfo			Introduced	Absent
DriverVersion			Introduced	Absent
Halt				Introduced
InterfaceVersion			Introduced	Absent
IsMoving				Introduced
Link	Deprecated	Deprecated	Deprecated	Introduced
MaxIncrement				Introduced
MaxStep				Introduced
Move		Revised		Introduced
Name			Introduced	Absent
Position				Introduced
SetupDialog				Introduced
StepSize				Introduced
SupportedActions			Introduced	Absent
TempComp				Introduced
TempCompAvailable				Introduced
Temperature				Introduced

ObservingConditions		
Member	Platform 7 - 2024	Platform 6.2 - 2015
Member	IObservingConditionsV2	IObservingConditions
Action		Introduced
AveragePeriod		Introduced
CloudCover		Introduced
CommandBlind	Deprecated	Introduced
CommandBool	Deprecated	Introduced
CommandString	Deprecated	Introduced
Connect	Introduced	Absent
Connected	Revised	Introduced
Connecting	Introduced	Absent
Description		Introduced
DeviceState	Introduced	Absent
DewPoint		Introduced
Disconnect	Introduced	Absent
Dispose		Introduced
DriverInfo		Introduced
DriverVersion		Introduced
Humidity		Introduced
InterfaceVersion		Introduced
Name		Introduced
Pressure		Introduced
RainRate		Introduced
Refresh		Introduced
SensorDescription		Introduced
SetupDialog		Introduced
SkyBrightness		Introduced
SkyQuality		Introduced
SkyTemperature		Introduced
StarFWHM		Introduced
SupportedActions		Introduced
Temperature		Introduced
TimeSinceLastUpdate		Introduced
WindDirection		Introduced
WindGust		Introduced
WindSpeed		Introduced

Rotator				
Member	Platform 7 - 2024	Platform 6.5 - 2020	Platform 6 - 2011	Platform 5 - 2008
Member	IRotatorV4	IRotatorV3	IRotatorV2	IRotator
Action			Introduced	Absent
CanReverse			Introduced	Absent
CommandBlind	Deprecated		Introduced	Absent
CommandBool	Deprecated		Introduced	Absent
CommandString	Deprecated		Introduced	Absent
Connect	Introduced	Absent	Absent	Absent
Connected	Revised			Introduced
Connecting	Introduced	Absent	Absent	Absent
Description			Introduced	Absent
DeviceState	Introduced	Absent	Absent	Absent
Disconnect	Introduced	Absent	Absent	Absent
Dispose			Introduced	Absent
DriverInfo			Introduced	Absent
DriverVersion			Introduced	Absent
Halt				Introduced
InterfaceVersion			Introduced	Absent
IsMoving		Revised		Introduced
MechanicalPosition		Introduced	Absent	Absent
Move		Revised		Introduced
MoveAbsolute		Revised		Introduced
MoveMechanical		Introduced	Absent	Absent
Name			Introduced	Absent
Position		Revised		Introduced
Reverse		Revised		Introduced
SetupDialog				Introduced
StepSize				Introduced
SupportedActions			Introduced	Absent
Sync		Introduced	Absent	Absent
TargetPosition		Revised		Introduced

SafetyMonitor			
Member	Platform 7 - 2024		Platform 6 - 2011
Member	ISafetyMonitorV3	ISafetyMonitorV2	ISafetyMonitor
Action			Introduced
CommandBlind	Deprecated		Introduced
CommandBool	Deprecated		Introduced
CommandString	Deprecated		Introduced
Connect	Introduced		Absent
Connected	Revised		Introduced
Connecting	Introduced	ISafetyMonitorV2 has been	Absent
Description		skipped to avoid confusion	Introduced
DeviceState	Introduced	because the Platform 6	Absent
Disconnect	Introduced	simulator from 2011 incorrectly	Absent
Dispose		returned the interface version as	Introduced
DriverInfo		2 instead of the correct value: 1.	Introduced
DriverVersion			Introduced
InterfaceVersion			Introduced
IsSafe			Introduced
Name			Introduced
SetupDialog			Introduced
SupportedActions			Introduced

Switch			
Member	Platform 7 - 2024	Platform 6.1 - 2014	Platform 5 - 2008
Member	ISwitchV3	ISwitchV2	ISwitch
Action		Introduced	Absent
CanWrite		Introduced	Absent
CommandBlind	Deprecated	Introduced	Absent
CommandBool	Deprecated	Introduced	Absent
CommandString	Deprecated	Introduced	Absent
Connect	Introduced	Absent	Absent
Connected	Revised		Introduced
Connecting	Introduced	Absent	Absent
Description			Introduced
DeviceState	Introduced	Absent	Absent
Disconnect	Introduced	Absent	Absent
Dispose		Introduced	Absent
DriverInfo			Introduced
DriverVersion			Introduced
GetSwitch			Introduced
GetSwitchDescription		Introduced	Absent
GetSwitchName			Introduced
GetSwitchValue		Introduced	Absent
InterfaceVersion			Introduced
MaxSwitch			Introduced
MaxSwitchValue		Introduced	Absent
MinSwitchValue		Introduced	Absent
Name			Introduced
SetAsync	Introduced	Absent	Absent
SetAsyncValue	Introduced	Absent	Absent
SetSwitch			Introduced
SetSwitchName		Introduced	Absent
SetSwitchValue		Introduced	Absent
SetupDialog			Introduced
StateChangeComplete	Introduced	Absent	Absent
SupportedActions		Introduced	Absent
SwitchStep		Introduced	Absent

Telescope				
Member	Platform 7 - 2024	Platform 6 - 2011	Platform 4 - 2004	Platform 1 to 3
Member	ITelescopeV4	ITelescopeV3	ITelescopeV2	ITelescope R&D
AbortSlew	Revised			Introduced
Action		Introduced	Absent	Absent
AlignmentMode Altitude				Introduced Introduced
ApertureArea			Introduced	Absent
ApertureDiameter			miloudou	Introduced
AtHome			Introduced	Absent
AtPark			Introduced	Absent
AxisRates			Introduced	Absent
Azimuth				Introduced
CanMaya Avia			Introduced	Introduced
CanMoveAxis CanPark			Introduced	Absent Introduced
CanPulseGuide				Introduced
CanSetDeclinationRate			Introduced	Absent
CanSetGuideRates			Introduced	Absent
CanSetPark				Introduced
CanSetPierSide			Introduced	Absent
CanSetRightAscensionRate			Introduced	Absent
CanSetTracking				Introduced
CanSlawAtAz	Revised		Industrial 1	Introduced
CanSlewAltAzAsync	Revised		Introduced	Absent
CanSlewAltAzAsync CanSlewAsync	Revised Revised		Introduced	Absent Introduced
CanSync	nevised			Introduced
CanSyncAltAz			Introduced	Absent
CanUnpark				Introduced
CommandBlind	Deprecated			Introduced
CommandBool	Deprecated			Introduced
CommandString	Deprecated			Introduced
Connect	Introduced	Absent	Absent	Absent
Connected	Revised			Introduced
Connecting	Introduced	Absent	Absent	Absent
Declination DeclinationRate	Revised			Introduced Introduced
Description	neviseu			Introduced
DestinationSideOfPier			Introduced	Absent
DeviceState	Introduced	Absent	Absent	Absent
Disconnect	Introduced	Absent	Absent	Absent
Dispose		Introduced	Absent	Absent
DoesRefraction			Introduced	Absent
DriverInfo				Introduced
DriverVersion			Introduced	Absent
EquatorialSystem	Davised		Introduced	Absent Introduced
FindHome FocalLength	Revised			Introduced
GuideRateDeclination			Introduced	Absent
GuideRateRightAscension			Introduced	Absent
InterfaceVersion			Introduced	Absent
IsPulseGuiding			Introduced	Absent
MoveAxis	Revised		Introduced	Absent
Name				Introduced
Park	Revised			Introduced
PulseGuide	Revised			Introduced
RightAscension	Davised			Introduced
RightAscensionRate SetPark	Revised			Introduced Introduced
SetupDialog				Introduced
SideOfPier			Introduced	Absent
SiderealTime				Introduced
SiteElevation				Introduced
SiteLatitude				Introduced
SiteLongitude				Introduced
Slewing				Introduced
SlewSettleTime				Introduced
SlewToAltAzAcyno	Deprecated		Introduced	Absent
SlewToCoordinates	Revised		Introduced	Absent
SlewToCoordinates SlewToCoordinatesAsync	Deprecated Revised			Introduced Introduced
SlewToTarget	Deprecated			Introduced
SlewToTargetAsync	Revised			Introduced
SupportedActions		Introduced	Absent	Absent
SyncToAltAz			Introduced	Absent
SyncToCoordinates				Introduced
Syncrocordinates				Introduced
SyncToTarget				
SyncToTarget TargetDeclination				Introduced
SyncToTarget TargetDeclination TargetRightAscension				Introduced
SyncToTarget TargetDeclination TargetRightAscension Tracking				Introduced Introduced
SyncToTarget TargetDeclination TargetRightAscension Tracking TrackingRate			Introduced	Introduced Introduced Absent
SyncToTarget TargetDeclination TargetRightAscension Tracking	Revised		Introduced Introduced	Introduced Introduced

Video		
Member	Platform 7 - 2024	Platform 6.1 - 2014
Member	IVideoV2	IVideo
Action		Introduced
BitDepth		Introduced
CameraState		Introduced
CanConfigureDeviceProperties		Introduced
CommandBlind	Introduced but Deprecated	Absent
CommandBool	Introduced but Deprecated	Absent
CommandString	Introduced but Deprecated	Absent
ConfiguureDeviceProperties		Introduced
Connect	Introduced	Absent
Connected	Revised	Introduced
Connecting	Introduced	Absent
Description		Introduced
DeviceState	Introduced	Absent
Disconnect	Introduced	Absent
Dispose		Introduced
DriverInfo		Introduced
DriverVersion		Introduced
ExposureMax		Introduced
ExposureMin		Introduced
FrameRate		Introduced
Gain		Introduced
GainMax		Introduced
GainMin		Introduced
Gains		Introduced
Gamma		Introduced
GammaMax		Introduced
GammaMin		Introduced
Height		Introduced
IntegrationRate		Introduced
InterfaceVersion		Introduced
LastVideoFrame		Introduced
Name		Introduced
PixelSizeX		Introduced
PixelSizeY		Introduced
SensorName		Introduced
SensorType		Introduced
SetupDialog		Introduced
StartRecordingVideoFile		Introduced
StartRecordingVideoFile StopRecordingVideoFile		Introduced
· · ·		Introduced
SupportedActions SupportedIntegrationPates		******
SupportedIntegrationRates		Introduced Introduced
VideoCaptureDeviceName		
VideoCodec		Introduced
VideoFileFormat		Introduced
VideoFramesBufferSize		Introduced
Width		Introduced