ASCOM Interface Revisions

 Key:
 Member present
 Member absent from this interface

 Deprecated in some way, see member interface description
 Requirements revised, see member interface description

Camera					
Member	Platform 7 - 2024	Platform 6.5 - 2020	Platform 6.3 - 2017	Platform 6 - 2011	Platform 5 - 2008
Pleniber	ICameraV4	ICameraV3	ICameraV2	ICameraV2	ICamera
AbortExposure					Introduced
Action				Introduced	Absent
BayerOffsetX				Introduced	Absent
BayerOffsetY				Introduced	Absent Introduced
BinX BinY					Introduced
CameraState					Introduced
CameraXSize					Introduced
CameraYSize					Introduced
CanAbortExposure					Introduced
CanAsymmetricBin					Introduced
CanFastReadout				Introduced	Absent
CanGetCoolerPower					Introduced
CanPulseGuide					Introduced
CanSetCCDTemperature					Introduced
CanStopExposure					Introduced
CCDTemperature					Introduced
CommandBlind	Deprecated			Introduced	Absent
CommandBool	Deprecated			Introduced	Absent
CommandString	Deprecated			Introduced	Absent
Connect	Introduced	Absent	Absent	Absent	Absent
Connected	Revised				Introduced
Connecting		Absent	Absent	Absent	Absent
CoolerOn					Introduced
CoolerPower					Introduced
Description					Introduced
DeviceState	Introduced	Absent	Absent	Absent	Absent
Disconnect	Introduced	Absent	Absent	Absent	Absent
Dispose				Introduced	Absent
Driver/orgion				Introduced Introduced	Absent
DriverVersion ElectronsPerADU				introduced	Absent Introduced
ExposureMax		Introduced	Absent	Absent	Absent
ExposureMin		Introduced	Absent	Absent	Absent
ExposureResolution		Introduced	Absent	Absent	Absent
FastReadout		Introduced	Absent	Absent	Absent
FullWellCapacity		miroduced	Absent	Absent	Introduced
Gain				Introduced	Absent
GainMax				Introduced	Absent
GainMin				Introduced	Absent
Gains				Introduced	Absent
HasShutter					Introduced
HeatSinkTemperature					Introduced
ImageArray					Introduced
ImageArrayVariant					Introduced
ImageReady					Introduced
InterfaceVersion					Absent
IsPulseGuiding					Introduced
LastError		Removed from into	erface		Introduced
LastExposureDuration					Introduced
LastExposureStartTime			Revised		Introduced
MaxADU					Introduced
MaxBinX					Introduced
MaxBinY					Introduced
Name				Introduced	Absent
NumX					Introduced
NumY				Indus december	Introduced
PercentCompleted				Introduced	Absent
PixelSizeX					Introduced
PixelSizeY PulseGuide					Introduced Introduced
ReadoutMode				Introduced	Absent
ReadoutModes				Introduced	Absent
SensorName				Introduced	Absent
SensorType				Introduced	Absent
SetCCDTemperature				maduced	Introduced
SetupDialog					Introduced
StartExposure					Introduced
StartX					Introduced
StartY					Introduced
StopExposure					Introduced
		Introduced	Absent	Absent	Absent
SubExposureDuration		IIIIIouuceu		Abscrit	Absent

CoverCalibrator]	
Mambay	Platform 7 - 2024	Platform 6.5 - 2020
Member	ICoverCalibratorV2	ICoverCalibratorV1
Action		Introduced
Brightness		Introduced
CalibratorChanging	Introduced	Absent
CalibratorOff		Introduced
CalibratorOn		Introduced
CalibratorState		Introduced
CloseCover		Introduced
CommandBlind	Deprecated	Introduced
CommandBool	Deprecated	Introduced
CommandString	Deprecated	Introduced
Connect	Introduced	Absent
Connected	Revised	Introduced
Connecting	Introduced	Absent
CoverMoving	Introduced	Absent
CoverState		Introduced
Description		Introduced
DeviceState	Introduced	Absent
Disconnect	Introduced	Absent
Dispose		Introduced
DriverInfo		Introduced
DriverVersion		Introduced
HaltCover		Introduced
InterfaceVersion		Introduced
MaxBrightness		Introduced
Name		Introduced
OpenCover		Introduced
SetupDialog		Introduced
SupportedActions		Introduced

Dome			
Member	Platform 7 - 2024	Platform 6 - 2011	Platform 3 - 2003
Member	IDomeV3	IDomeV2	IDome
AbortSlew	Revised		Introduced
Action		Introduced	Absent
Altitude			Introduced
AtHome			Introduced
AtPark			Introduced
Azimuth			Introduced
CanFindHome			Introduced
CanPark			Introduced
CanSetAltitude			Introduced
CanSetAzimuth			Introduced
CanSetPark			Introduced
CanSetShutter			Introduced
CanSlave			Introduced
CanSyncAzimuth			Introduced
CloseShutter			Introduced
CommandBlind	Deprecated		Introduced
CommandBool	Deprecated		Introduced
CommandString	Deprecated		Introduced
Connect	Introduced	Absent	Absent
Connected	Revised		Introduced
Connecting		Absent	Absent
Description			Introduced
DeviceState		Absent	Absent
Disconnect		Absent	Absent
Dispose			Absent
DriverInfo			Introduced
DriverVersion			Introduced
FindHome			Introduced
InterfaceVersion			Introduced
Name			Introduced
OpenShutter			Introduced
Park			Introduced
SetPark			Introduced
SetupDialog			Introduced
ShutterStatus			Introduced
Slaved			Introduced
Slewing			Introduced
SlewToAltitude			Introduced
SlewToAzimuth			Introduced
SupportedActions			Absent
SyncToAzimuth			Introduced

FilerWheel			
Manakan	Platform 7 - 2024	Platform 6 - 2011	Platform 5 - 2008
Member	IFilterWheelV3	IFilterWheelV2	IFilterWheel
Action		Introduced	Absent
CommandBlind	Deprecated	Introduced	Absent
CommandBool	Deprecated	Introduced	Absent
CommandString	Deprecated	Introduced	Absent
Connect	Introduced	Absent	Absent
Connected	Revised		Introduced
Connecting		Absent	Absent
Description		Introduced	Absent
DeviceState		Absent	Absent
Disconnect		Absent	Absent
Dispose		Introduced	Absent
DriverInfo		Introduced	Absent
DriverVersion		Introduced	Absent
FocusOffsets			Introduced
InterfaceVersion		Introduced	Absent
Name		Introduced	Absent
Names			Introduced
Position			Introduced
SetupDialog			Introduced
SupportedActions		Introduced	Absent

Focuser				
Member	Platform 7 - 2024	Platform 6.4 - 2018	Platform 6 - 2011	Platform 2 - 2002
Member	IFocuserV4	IFocuserV3	IFocuserV2	IFocuser
Absolute				Introduced
Action			Introduced	Absent
CommandBlind	Deprecated		Introduced	Absent
CommandBool	Deprecated		Introduced	Absent
CommandString	Deprecated		Introduced	Absent
Connect		Absent	Absent	Absent
Connected	Revised		Introduced	Absent
Connecting		Absent	Absent	Absent
Description			Introduced	Absent
DeviceState		Absent	Absent	Absent
Disconnect		Absent	Absent	Absent
Dispose			Introduced	Absent
DriverInfo			Introduced	Absent
DriverVersion			Introduced	Absent
Halt				Introduced
InterfaceVersion			Introduced	Absent
IsMoving				Introduced
Link	Deprecated	Deprecated	Deprecated	Introduced
MaxIncrement				Introduced
MaxStep				Introduced
Move		Revised		Introduced
Name			Introduced	Absent
Position				Introduced
SetupDialog				Introduced
StepSize				Introduced
SupportedActions			Introduced	Absent
TempComp				Introduced
TempCompAvailable				Introduced
Temperature				Introduced

ObservingConditions		
Member	Platform 7 - 2024	Platform 6.2 - 2015
Member	IObservingConditionsV2	IObservingConditions
Action		Introduced
AveragePeriod		Introduced
CloudCover		Introduced
CommandBlind	Deprecated	Introduced
CommandBool	Deprecated	Introduced
CommandString	Deprecated	Introduced
Connect	Introduced	Absent
Connected	Revised	Introduced
Connecting	Introduced	Absent
Description		Introduced
DeviceState	Introduced	Absent
DewPoint		Introduced
Disconnect	Introduced	Absent
Dispose		Introduced
DriverInfo		Introduced
DriverVersion		Introduced
Humidity		Introduced
InterfaceVersion		Introduced
Name		Introduced
Pressure		Introduced
RainRate		Introduced
Refresh		Introduced
SensorDescription		Introduced
SetupDialog		Introduced
SkyBrightness		Introduced
SkyQuality		Introduced
SkyTemperature		Introduced
StarFWHM		Introduced
SupportedActions		Introduced
Temperature		Introduced
TimeSinceLastUpdate		Introduced
WindDirection		Introduced
WindGust		Introduced
WindSpeed		Introduced

Rotator				
Member	Platform 7 - 2024	Platform 6.5 - 2020	Platform 6 - 2011	Platform 5 - 2008
Member	IRotatorV4	IRotatorV3	IRotatorV2	IRotator
Action			Introduced	Absent
CanReverse			Introduced	Absent
CommandBlind	Deprecated		Introduced	Absent
CommandBool	Deprecated		Introduced	Absent
CommandString	Deprecated		Introduced	Absent
Connect	Introduced	Absent	Absent	Absent
Connected	Revised			Introduced
Connecting	Introduced	Absent	Absent	Absent
Description			Introduced	Absent
DeviceState	Introduced	Absent	Absent	Absent
Disconnect	Introduced	Absent	Absent	Absent
Dispose			Introduced	Absent
DriverInfo			Introduced	Absent
DriverVersion			Introduced	Absent
Halt				Introduced
InterfaceVersion			Introduced	Absent
IsMoving		Revised		Introduced
MechanicalPosition		Introduced	Absent	Absent
Move		Revised		Introduced
MoveAbsolute		Revised		Introduced
MoveMechanical		Introduced	Absent	Absent
Name			Introduced	Absent
Position		Revised		Introduced
Reverse		Revised		Introduced
SetupDialog				Introduced
StepSize				Introduced
SupportedActions			Introduced	Absent
Sync		Introduced	Absent	Absent
TargetPosition		Revised		Introduced

SafetyMonitor			
Marshau	Platform 7 - 2024		Platform 6 - 2011
Member	ISafetyMonitorV3	ISafetyMonitorV2	ISafetyMonitor
Action			Introduced
CommandBlind	Deprecated		Introduced
CommandBool	Deprecated		Introduced
CommandString	Deprecated		Introduced
Connect	Introduced		Absent
Connected	Revised		Introduced
Connecting	Introduced	ISafetyMonitorV2 has been	Absent
Description		skipped to avoid confusion	Introduced
DeviceState	Introduced	because the Platform 6	Absent
Disconnect	Introduced	simulator from 2011 incorrectly	Absent
Dispose		returned the interface version as	Introduced
DriverInfo		2 instead of the correct value: 1.	Introduced
DriverVersion			Introduced
InterfaceVersion			Introduced
IsSafe			Introduced
Name			Introduced
SetupDialog			Introduced
SupportedActions			Introduced

Switch			
Manahan	Platform 7 - 2024	Platform 6.1 - 2014	Platform 5 - 2008
Member	ISwitchV3	ISwitchV2	ISwitch
Action		Introduced	Absent
CanWrite		Introduced	Absent
CommandBlind	Deprecated	Introduced	Absent
CommandBool	Deprecated	Introduced	Absent
CommandString	Deprecated	Introduced	Absent
Connect	Introduced	Absent	Absent
Connected	Revised		Introduced
Connecting	Introduced	Absent	Absent
Description			Introduced
DeviceState	Introduced	Absent	Absent
Disconnect	Introduced	Absent	Absent
Dispose		Introduced	Absent
DriverInfo			Introduced
DriverVersion			Introduced
GetSwitch			Introduced
GetSwitchDescription		Introduced	Absent
GetSwitchName			Introduced
GetSwitchValue		Introduced	Absent
InterfaceVersion			Introduced
MaxSwitch			Introduced
MaxSwitchValue		Introduced	Absent
MinSwitchValue		Introduced	Absent
Name			Introduced
SetAsync	Introduced	Absent	Absent
SetAsyncValue	Introduced	Absent	Absent
SetSwitch			Introduced
SetSwitchName		Introduced	Absent
SetSwitchValue		Introduced	Absent
SetupDialog			Introduced
StateChangeComplete	Introduced	Absent	Absent
SupportedActions		Introduced	Absent
SwitchStep		Introduced	Absent

AbortSlew Action AlignmentMode Altitude ApertureArea ApertureDiameter AtHome AtPark AxisRates Azimuth CanFindHome CanMoveAxis CanPark CanPulseGuide CansetDeclinationRate CanSetTightAscension CanSlewAttaz CanSlewAttaz CanUnpark CanSync CanSync CanSync CanSync CanSync CanSync CanSync CanSigm CanString Connect Connected Connected Connected Connected Connect Dispose DoesRefraction DriverInfo DriverVersion EquatorialSystem FindHome FocalLength Gunee RoalewAttay GuideRate Description DriverVersion EquatorialSystem FindHome FocalLength GuideRateRightAscension InterfaceVersion Ispuse InterfaceVersion Ispuse InterfaceVersion Ispuse InterfaceVersion InterfaceVersion InterfaceVersion InterfaceVersion InterfaceVersion InterfaceVersion InterfaceVersion InterfaceVersion Ispuse InterfaceVersion InterfaceVersi	Revised	Platform 6 - 2011 ITelescopeV3 Introduced Absent Absent	Platform 4 - 2004 ITelescopeV2 Absent Introduced Introduced	Platform 1 to 3 ITelescope R&D Introduced Absent Introduced Introduced Absent Absent Absent Absent Introduced Absent Absent Introduced Absent Introduced Absent Introduced
AbortSlew Action AlignmentMode Altitude ApertureArea ApertureDiameter AtHome AtPark AxisRates Azimuth CanFindHome CanMoveAxis CanPark CanPulseGuide CansetDeclinationRate CanSetPierSide CanSetPierSide CanSetTracking CanSlew CanSlewAttAz CanSlewAttAzAsync CanSlewAttaz CanSuprac CanSync CanSync CanSync CanSync CanSync CanSignidand CommandBlind CommandBlind CommandBring Connected Connected Connected Connected Connected Connected Disconnect Dispose DoesRefraction DriverInfo DriverVersion EquatorialSystem FindHome FocalLength GuideRateRightAscension InterfaceVersion IsPulseGuiding MoveAxis Name	Revised Revised Revised Revised Revised Revised Deprecated Deprecated Deprecated Introduced Revised	Introduced	Introduced	Introduced Absent Introduced Introduced Introduced Absent Introduced Absent Absent Introduced Introduced Introduced Introduced Introduced Introduced Introduced Absent Introduced Absent Introduced Absent Introduced Absent Introduced Absent Introduced
Action AlignmentMode Altitude ApertureArea ApertureDiameter AtHome AtPark AxisRates Azimuth CanFindHome CanMoveAxis CanPark CanPulseGuide CansetDeclinationRate CanSetBeclinationRate CanSetFark CanSetPark CanSetPierSide CanSetRightAscensionRate CanSlewAltAz CanslewAltAz CanslewAltAz CanslewAltAz CanslewAltAz CanslewAltAz Canunpark CommandBoid CommandBoid CommandBring Connect Connected Connected Connected Connected Connected Disconnect Dispose DoesRefraction DriverInfo DriverVersion EquatorialSystem FindHome FocalLength GuideRateRightAscension IlsPulseGuiding MoveAxis Name	Revised Revised Revised Revised Revised Deprecated Deprecated Introduced Revised Introduced	Absent	Introduced Introduced Introduced Introduced Introduced Introduced Introduced Introduced Introduced Introduced Introduced Introduced Introduced Introduced Introduced Introduced	Absent Introduced Introduced Absent Introduced Absent Absent Absent Introduced Introduced Introduced Introduced Introduced Introduced Introduced Absent Introduced Absent Introduced Absent Introduced Absent Introduced Absent Introduced
AlignmentMode Altitude ApertureArea ApertureDiameter AtHome AtPark AxisRates Azimuth CanFindHome CanMoveAxis CanPulseGuide CanSetDectinationRate CanSetBectinationRate CanSetPark CanSetPierSide CanSetRightAscensionRate CanSlewAltAz CanSlewAltAz CanSlewAltAz CanSlewAltAz CanSlewAltAz CanSuncAltAz CanSuncAltAz CanSuncAltaz CanOnect Connected Connected Connected Connected Dispose DoesRefraction DriverVersion EquatorialSystem FindHome FocalLength GuideRateRightAscension InterfaceVersion IsPulseGuidin MoveAxis Name	Revised Revised Revised Deprecated Deprecated Introduced Revised Introduced	Absent	Introduced Introduced Introduced Introduced Introduced Introduced Introduced Introduced Introduced Introduced Introduced Introduced Introduced Introduced Introduced Introduced	Introduced Introduced Absent Introduced Absent Absent Absent Introduced Introduced Introduced Introduced Introduced Absent Introduced Introduced Absent Absent Introduced Absent Introduced Absent Introduced
Altitude ApertureArea ApertureDiameter AtHome AtPark AxisRates Azimuth CanFindHome CanMoveAxis CanPutseGuide CanSetDectinationRate CansetPark CansetPark CansetPierSide CansetRightAscensionRate CanStewAttAzAsync CanSlewAttAzAsync CanSlewAttAz CanSumandBlind CommandBool CommandString Connect Connected Connected Connected Connected Disconnect Dispose DoesRefraction DriverInfo DriverVersion Equatorial System InterfaceVersion IsPutseGuiding MoveAxis Name AxisRates A	Revised Revised Revised Deprecated Deprecated Introduced Revised Introduced		Introduced	Introduced Absent Introduced Absent Absent Absent Introduced Introduced Introduced Introduced Introduced Introduced Introduced Absent Introduced Absent Introduced Absent Introduced Absent Introduced
ApertureArea ApertureDiameter AtHome AtPark AxisRates Azimuth CanFindHome CanMoveAxis CanPark CanPulseGuide CanSetDectinationRate CanSetPark CansetPierSide CanSetPierSide CanSetRightAscensionRate CanSlewAttAz CanslewAttAz CanslewAttAz CanslewAttAz CanslewAttAz CanslewAttAz CanslewAttay Cansync Cansync Cansync Cansync Cansync Cansync Cansync Cansync Canster Canupark CommandBind CommandBool CommandBool CommandBool CommandString Connect Connected Co	Revised Revised Revised Deprecated Deprecated Introduced Revised Introduced		Introduced	Absent Introduced Absent Absent Absent Introduced Introduced Introduced Introduced Introduced Introduced Introduced Introduced Absent Introduced Absent Introduced Absent Introduced
ApertureDiameter AtHome AtPark AxisRates Azimuth CanFindHome CanMoveAxis CanPark CanPulseGuide CansetDeclinationRate CansetPierSide CansetRightAscensionRate CanStewAttaz CanSlewAttaz CanSlewAttaz CanslewAttaz CanslewAttaz CanslewAttaz Cansupark Cansupark CanstemandBlind CommandBool CommandString Connect Connected Connected Connected Connected Connected Dispose DoesRefraction DriverInfo DriverVersion EquatorialSystem FindHome FocalLength GuideRateDeclination GuideRateDeclination IspulseGuiding MoveAxis Name	Revised Revised Revised Deprecated Deprecated Introduced Revised Introduced		Introduced	Introduced Absent Absent Introduced Introduced Introduced Introduced Introduced Absent Absent Introduced Absent Absent Introduced Absent Absent Introduced
AtHome AtPark AxisRates Azimuth CanFindHome CanMoveAxis CanPark CanPuseGuide CansetDeclinationRate CansetPierSide CansetPierSide CansetTracking CanSlew CanSlewAtxaync CanSlewAtxaync CanSlewAtxaync CanSlewAtxaync CanslewAttract Cansupark CommandBlind CommandBring Connect Connected Connected Connecting Declination DestinationSideOfPier DeviceState Disconnect Dispose DoesRefraction DriverInfo DriverVersion EquatorialSystem FindHome FocalLength GuideRate Pischesion IspulseGuiding MoveAxis Name	Revised Revised Revised Deprecated Deprecated Introduced Revised Introduced		Introduced Introduced Introduced Introduced Introduced Introduced Introduced Introduced Introduced Introduced Introduced Introduced Introduced Introduced	Absent Absent Absent Introduced Introduced Introduced Introduced Introduced Absent Absent Introduced Absent Introduced Absent Introduced Absent Introduced
AtPark AxisRates Azimuth CanFindHome CanMoveAxis CanPulseGuide CanSetDeclinationRate CanSetDeclinationRate CanSetPierSide CanSetRightAscensionRate CanSetTracking CanSlew CanSlewAttAz CanSlewAttAz CanSlewAttAz CanSumandBlind CommandBool CommandBool CommandString Cannect Connected Connected Connected Connected Connected Description DestinationSideOfPier DeviceState Dispose DoesRefraction DriverInfo DriverVersion EquatorialSystem FindHome FocalLength GuideRateDeclination IspulseGuiding MoveAxis Name	Revised Revised Revised Deprecated Deprecated Introduced Revised Introduced		Introduced Introduced Introduced Introduced Introduced Introduced Introduced Introduced Introduced Introduced Introduced Introduced Introduced Introduced	Absent Absent Introduced Introduced Introduced Introduced Introduced Introduced Introduced Introduced Absent Absent Introduced Absent Absent Introduced
AxisRates Azimuth CanFindHome CanMoveAxis CanPark CanPulseGuide CansetDeclinationRate CanSetDeclinationRate CanSetPierSide CanSetRightAscensionRate CanSetTracking CanSlew CanSlewAltAz CanslewAltAz CanslewAltAz CanslewAltAz CanslewAltAz CansumandBind CommandBool CommandString Connect Connected Connected Connecting Declination DestinationSideOfPier DeviceState Disconnect Dispose DoesRefraction DriverInfo DriverVersion EquatorialSystem FindHome FocalLength GuideRateDeclination IspulseGuiding MoveAxis Name	Revised Revised Revised Deprecated Deprecated Introduced Revised Introduced		Introduced	Absent Introduced Introduced Introduced Introduced Introduced Introduced Introduced Absent Absent Introduced Absent Absent Introduced
Azimuth CanFindHome CanMoveAxis CanPark CanPulseGuide CansetDeclinationRate CanSetGuideRates CanSetPark CanSetPierSide CanSetRightAscensionRate CanSlewAltAz CanSlewAltAz CanSlewAltAz CanSlewAltAz CanslewAltAz CanslewAltAz Cansync Canse Cansync Canse Cans	Revised Revised Revised Deprecated Deprecated Introduced Revised Introduced		Introduced Introduced Introduced Introduced Introduced Introduced Introduced Introduced Introduced Introduced	Introduced Absent Introduced Introduced Absent Absent Introduced Absent Introduced Absent Introduced
CanMoveAxis CanPark CanPulseGuide CanSetDeclinationRate CanSetGuideRates CanSetPark CanSetPierSide CanSetPierSide CanSetPightAscensionRate CanSetWatAzasync CanSlewAltAzAsync CanSlewAltAzAsync CanSlewAltAzAsync CanSwaync CanSync CanSyncAltAz CanUnpark CommandBind CommandBool CommandString Connect Connected Connected Connected Description DestinationRate Description DestinationSideOfPier DeviceState Disconnect Dispose DoesRefraction DriverInfo DriverVersion EquatorialSystem FindHome FocalLength GuideRateDeclination IsPulseGuiding MoveAxis Name	Revised Revised Revised Deprecated Deprecated Introduced Revised Introduced		Introduced Introduced Introduced Introduced Introduced Introduced Introduced Introduced Introduced	Absent Introduced Introduced Absent Absent Introduced Absent Introduced Absent Introduced
CanPark CanPulseGuide CanSetDeclinationRate CanSetGuideRates CanSetPark CanSetPierSide CanSetRightAscensionRate CanSetTracking CanSlew CanSlewAltAz CanSlewAltAz CanSlewAltAzAsync CanSlewAsync CanSync CanSyncAltAz CanUnpark CommandBlind CommandBring Connect Connected Connecting Declination DeclinationRate Description DestinationSideOfPier DeviceState Disconnect Dispose DoesRefraction DriverInfo DriverVersion EquatorialSystem FindHome FocalLength GuideRateDeclination GlideRateDeclination GlideRateRightAscension InterfaceVersion IspulseGuiding MoveAxis Name	Revised Revised Revised Deprecated Deprecated Introduced Revised Introduced		Introduced Introduced Introduced Introduced Introduced Introduced Introduced Introduced Introduced	Introduced Introduced Absent Absent Introduced Absent Absent Introduced
CanPutseGuide CanSetDectinationRate CanSetGuideRates CanSetPark CanSetPierSide CanSetRightAscensionRate CanStetRightAscensionRate CanStewAttAz CanSlewAttAz CanSlewAttAz CanSlewAttAz CanSlewAttAz CanSupark CanSync CanSync CanSync CanSync CanSync CanSync CanSync CanSupark CommandBlind CommandBring Connect Connected Connected Connecting Dectination DectinationRate Description DestrinationSideOfPier DeviceState Disconnect Dispose DoesRefraction DriverInfo DriverVersion EquatorialSystem FindHome FocalLength GuideRateDectlination GuideRateDectlination IspulseGuiding MoveAxis Name	Revised Revised Revised Deprecated Deprecated Introduced Revised Introduced		Introduced Introduced Introduced Introduced Introduced Introduced Introduced Absent	Introduced Absent Absent Introduced Absent Introduced Introduced Introduced Absent Absent Absent Introduced
CanSetDectinationRate CanSetGuideRates CanSetPark CanSetPierSide CanSetRightAscensionRate CanSetRightAscensionRate CanSlew CanSlewAttAz CanSlewAttAz CanSlewAttAz CanSlewAttAz CanSlewAttAz CanUnpark CommandBlind CommandBool CommandBring Connect Connected Connected Connecting Dectination DectinationSideOfPier DeviceState Disconnect Dispose DoesRefraction DriverInfo DriverVersion EquatorialSystem FindHome FocalLength GuideRateDeclination IspulseGuiding MoveAxis Name	Revised Revised Revised Deprecated Deprecated Introduced Revised Introduced		Introduced Introduced Introduced Introduced Introduced Introduced Introduced Absent	Absent Absent Introduced Absent Introduced Introduced Introduced Introduced Absent Absent Introduced
CanSetGuideRates CanSetPierSide CanSetRightAscensionRate CanSetRightAscensionRate CanSetRightAscensionRate CanSlew CanSlew CanSlewAttaz CanSlewAttaz CanSlewAttaz CanSlewAttaz CanSumattaz CanSumattaz CanUnpark CommandBuind CommandBool CommandString Connect Connected Connected Connecting Declination DestinationSideOfPier DeviceState Disconnect Dispose DoesRefraction DriverInfo DriverVersion EquatorialSystem FindHome FocalLength GuideRateDeclination IspulseGuiding MoveAxis Name	Revised Revised Revised Deprecated Deprecated Introduced Revised Introduced		Introduced Introduced Introduced Introduced Introduced Introduced Introduced Absent	Absent Introduced Absent Introduced Introduced Introduced Absent Absent Introduced
CanSetPark CanSetPierSide CanSetRightAscensionRate CanSetTracking CanSlew CanSlew CanSlewAttAz CanSlewAttAz CanSlewAttAz CanSumattAz CanSumattAz CanSumattAz CanSumattAz CanUnpark CommandBlind CommandBlind CommandString Connect Connected Connecting Declination DeclinationRate Description DestinationSideOfPier DeviceState Disconnect Dispose DoesRefraction DriverInfo DriverVersion EquatorialSystem FindHome FocalLength GuideRatePeclination InterfaceVersion IsPulseGuiding MoveAxis Name	Revised Revised Revised Deprecated Deprecated Introduced Revised Introduced		Introduced Introduced Introduced Introduced Introduced Introduced Absent	Introduced Absent Introduced Introduced Absent Absent Introduced
CanSetPierSide CanSetRightAscensionRate CanSetTracking CanSlew CanSlew CanSlewAltAz CanSlewAltAzAsync CanSlewAsync CanSync CanSyncAltAz CanUnpark CommandBlind CommandBool CommandString Connect Connected Connecting Declination DeclinationRate Description DestinationSideOfPier DeviceState Disconnect Dispose DoesRefraction DriverInfo DriverVersion EquatorialSystem FindHome FocalLength GuideRatePoctination IspulseGuiding MoveAxis Name	Revised Revised Revised Deprecated Deprecated Introduced Revised Introduced		Introduced Introduced Introduced Introduced Absent	Absent Introduced Introduced Absent Absent Introduced
CanSetRightAscensionRate CanSetTracking CanSlew CanSlewAltAz CanSlewAltAzAsync CanSlewAsync CanSyncAltAz CanSpyncAltAz CanUnpark CommandBlind CommandBool CommandString Connect Connected Connecting Declination Declination DestriationSideOfPier DeviceState Disconnect Dispose DoesRefraction DriverInfo DriverVersion EquatorialSystem FindHome FocalLength GuideRatePoctination IspulseGuiding MoveAxis Name	Revised Revised Revised Deprecated Deprecated Introduced Revised Introduced		Introduced Introduced Introduced Introduced Absent	Absent Introduced Introduced Absent Absent Introduced
CanSetTracking CanSlew CanSlewAltAz CanSlewAltAzAsync CanSlewAsync CanSync CanSync CanSyncAltAz CanUnpark CommandBlind CommandBool CommandString Connect Connected Connecting Declination DeclinationNate Description Destription Dispose DoesRefraction DriverInfo DriverVersion EquatorialSystem FindHome FocalLength GuideRateDeclination GuideRateRightAscension InterfaceVersion IsPulseGuiding MoveAxis Name	Revised Revised Revised Deprecated Deprecated Introduced Revised Introduced		Introduced Introduced Introduced Introduced Absent	Introduced Introduced Absent Absent Introduced Introduced Introduced Introduced Introduced Introduced Introduced Introduced Introduced
CanSlew CanSlewAltAz CanSlewAltAzAsync CanSlewAsync CanSync CanSyncAttAz CanUnpark CommandBlind CommandBlind CommandString Connect Connected Connecting Declination DeclinationRate Description DestinationSideOfPier DeviceState Disconnect Dispose DoesRefraction DriverInfo DriverVersion EquatorialSystem FindHome FocalLength GuideRateDeclination GlideRateRightAscension InterfaceVersion IspulseGuiding MoveAxis Name	Revised Revised Revised Deprecated Deprecated Introduced Revised Introduced		Introduced Introduced Absent	Introduced Absent Absent Introduced Introduced Introduced Introduced Introduced Introduced Introduced Introduced
CanSlewAltAz CanSlewAltAzAsync CanSync CanSync CanSyncAltAz CanUnpark CommandBlind CommandString Connect Connected Connecting Declination DeclinationRate Description DestinationSideOfPier DeviceState Disconnect Dispose DoesRefraction DriverInfo DriverVersion EquatorialSystem FindHome FocalLength GuideRateDeclination GuideRateRightAscension InterfaceVersion IspulseGuiding MoveAxis Name	Revised Revised Revised Deprecated Deprecated Introduced Revised Introduced		Introduced Introduced Absent	Absent Absent Introduced Introduced Absent Introduced Introduced Introduced Introduced Introduced Introduced
CanSlewAltAzAsync CanSlewAsync CanSync CanSyncAltAz CanUnpark CommandBlind CommandBool CommandString Connecte Connected Connecting Declination DeclinationRate Description DestinationSideOfPier DeviceState Disconnect Dispose DoesRefraction DriverVersion EquatorialSystem FindHome FocalLength GuideRateDeclination GuideRateRightAscension InterfaceVersion IsPulseGuiding MoveAxis Name	Revised Revised Deprecated Deprecated Introduced Revised Introduced		Introduced Introduced Absent	Absent Introduced Introduced Absent Introduced Introduced Introduced Introduced Introduced
CanSiewAsync CanSync CanSyncAltAz CanUnpark CommandBlind CommandBool CommandString Connect Connected Connecting Declination Declination Description DestinationSideOfPier DeviceState Disconnect Dispose DoesRefraction DriverVersion EquatorialSystem FindHome FocalLength GuideRateDeclination GuideRateRightAscension InterfaceVersion IsPulseGuiding MoveAxis Name	Deprecated Deprecated Deprecated Introduced Revised Introduced		Introduced	Introduced Introduced Absent Introduced Introduced Introduced Introduced Introduced
CanSync CanSyncAltAz CanUnpark CommandBind CommandBool CommandString Connect Connected Connected Connecting Declination DeclinationRate Description DestinationSideOfPier DeviceState Disconnect Dispose DoesRefraction DriverInfo DriverVersion EquatorialSystem FindHome FocalLength GuideRateRightAscension InterfaceVersion IsPulseGuiding MoveAxis Name	Deprecated Deprecated Deprecated Introduced Introduced		Absent	Introduced Absent Introduced Introduced Introduced Introduced
CanSyncAltAz CanUnpark CommandBlind CommandBool CommandString Connect Connected Connecting Declination DeclinationRate Description DestinationSideOfPier DeviceState Disconnect Dispose DoesRefraction DriverInfo DriverVersion EquatorialSystem FindHome FocalLength GuideRateRightAscension InterfaceVersion IsPulseGuiding MoveAxis Name	Deprecated Deprecated Introduced Revised Introduced		Absent	Absent Introduced Introduced Introduced Introduced
CanUnpark CommandBlind CommandBool CommandString Connect Connected Connecting Declination Declination Description DestriationSideOfPier DeviceState Disconnect Dispose DoesRefraction DriverInfo DriverVersion EquatorialSystem FindHome FocalLength GuideRatePectination InterfaceVersion IsPulseGuiding MoveAxis Name	Deprecated Deprecated Introduced Revised Introduced			Introduced Introduced Introduced
CommandBool CommandString Connect Connected Connected Connecting Declination Declination DestriationSideOfPier DesviceState Disconnect Dispose DoesRefraction DriverInfo DriverVersion EquatorialSystem FindHome FocalLength GuideRateDeclination GuideRateRightAscension InterfaceVersion IsPulseGuiding MoveAxis Name	Deprecated Deprecated Introduced Revised Introduced			Introduced Introduced
CommandString Connect Connected Connecting Declination Declination DestinationSideOfPier Desicate Disconnect Dispose DoesRefraction DriverInfo DriverVersion EquatorialSystem FindHome FocalLength GuideRateDeclination GuideRateRightAscension InterfaceVersion IspulseGuiding MoveAxis Name	Deprecated Introduced Revised Introduced			Introduced
Connect Connected Connecting Declination DeclinationRate Description DestinationSideOfPier DeviceState Disconnect Dispose DoesRefraction DriverInfo DriverVersion EquatorialSystem FindHome FocalLength GuideRateDeclination GuideRateRightAscension InterfaceVersion IsPulseGuiding MoveAxis Name	Introduced Revised Introduced			
Connected Connecting Declination DeclinationRate Description DestinationSideOfPier DeviceState Disconnect Disconnect Dispose DoesRefraction DriverInfo DriverVersion EquatorialSystem FindHome FocalLength GuideRateDeclination GuideRateRightAscension InterfaceVersion IsPulseGuiding MoveAxis Name	Revised Introduced			Absent
Connecting Declination DeclinationRate Description DestinationSideOfPier DeviceState Disconnect Dispose DoesRefraction DriverInfo DriverVersion EquatorialSystem FindHome FocalLength GuideRateDeclination GuideRateRightAscension InterfaceVersion IsPulseGuiding MoveAxis Name	Introduced	Absent	Ahsont	
Declination DeclinationRate Description DestinationSideOfPier DeviceState Disconnect Dispose DoesRefraction DriverInfo DriverVersion EquatorialSystem FindHome FocalLength GuideRateDeclination GuideRateRightAscension InterfaceVersion IsPulseGuiding MoveAxis Name		Absent	A heart	Introduced
DeclinationRate Description DestinationSideOfPier DeviceState Disconnect Dispose DoesRefraction DriverInfo DriverVersion EquatorialSystem FindHome FocalLength GuideRateDeclination GuideRateRightAscension InterfaceVersion IsPulseCuiding MoveAxis Name	Revised		Ausent	Absent
Description DestinationSideOfPier DeviceState Disconnect Dispose DoesRefraction DriverInfo DriverVersion EquatorialSystem FindHome FocalLength GuideRateDeclination GuideRateRightAscension InterfaceVersion IsPulseGuiding MoveAxis Name	Kevisea			Introduced
DestinationSideOfPier DeviceState Disconnect Dispose DoesRefraction DriverInfo DriverVersion EquatorialSystem FindHome FocalLength GuideRateDeclination GuideRateRightAscension InterfaceVersion IsPulseGuiding MoveAxis Name				Introduced Introduced
DeviceState Disconnect Dispose DoesRefraction DriverInfo DriverVersion EquatorialSystem FindHome FocalLength GuideRateDeclination GuideRateRightAscension InterfaceVersion IsPulseGuiding MoveAxis Name			Introduced	Absent
Disconnect Dispose DoesRefraction DriverInfo DriverVersion EquatorialSystem FindHome FocalLength GuideRateDeclination GuideRateRightAscension InterfaceVersion IsPulseGuiding MoveAxis Name	Introduced	Absent	Absent	Absent
Dispose DoesRefraction DriverInfo DriverVersion EquatorialSystem FindHome FocalLength GuideRateDeclination GuideRateRightAscension InterfaceVersion IsPulseGuiding MoveAxis Name	Introduced	Absent	Absent	Absent
DriverInfo DriverVersion EquatorialSystem FindHome FocalLength GuideRateDeclination GuideRateRightAscension InterfaceVersion IsPulseGuiding MoveAxis Name		Introduced	Absent	Absent
DriverVersion EquatorialSystem FindHome FocalLength GuideRateDeclination GuideRateRightAscension InterfaceVersion IsPulseGuiding MoveAxis Name			Introduced	Absent
EquatorialSystem FindHome FocalLength GuideRateDeclination GuideRateRightAscension InterfaceVersion IsPulseGuiding MoveAxis Name				Introduced
FindHome FocalLength GuideRateDeclination GuideRateRightAscension InterfaceVersion IsPulseGuiding MoveAxis Name			Introduced	Absent
FocalLength GuideRateDeclination GuideRateRightAscension InterfaceVersion IsPulseGuiding MoveAxis Name			Introduced	Absent
GuideRateDeclination GuideRateRightAscension InterfaceVersion IsPulseGuiding MoveAxis Name	Revised			Introduced
GuideRateRightAscension InterfaceVersion IsPulseGuiding MoveAxis Name				Introduced
InterfaceVersion IsPutseGuiding MoveAxis Name			Introduced	Absent
IsPulseGuiding MoveAxis Name			Introduced Introduced	Absent Absent
MoveAxis Name			Introduced	Absent
Name	Revised		Introduced	Absent
	nevioca		Introduced	Introduced
	Revised			Introduced
PulseGuide	Revised			Introduced
RightAscension				Introduced
RightAscensionRate	Revised			Introduced
SetPark				Introduced
SetupDialog				Introduced
SideOfPier			Introduced	Absent
SiderealTime				Introduced
SiteElevation				Introduced
SiteLatitude SiteLongitude				Introduced
SiteLongitude Slewing				Introduced Introduced
SlewSettleTime				Introduced
SlewToAltAz	Deprecated		Introduced	Absent
SlewToAltAzAsync	Revised		Introduced	Absent
SlewToCoordinates	Deprecated			Introduced
SlewToCoordinatesAsync	Revised			Introduced
SlewToTarget	Deprecated			Introduced
SlewToTargetAsync	Revised			Introduced
SupportedActions		Introduced	Absent	Absent
SyncToAltAz			Introduced	Absent
SyncToCoordinates				Introduced
SyncToTarget				Introduced
TargetDeclination TargetPightAssassion				Introduced
TargetRightAscension Tracking				Introduced
Tracking			Introduced	Introduced Absent
TrackingRate TrackingRates			Introduced	Absent
Unpark			mirouuseu	Introduced
UTCDate				Introduced

Video		
Member	Platform 7 - 2024	Platform 6.1 - 2014
Member	IVideoV2	IVideo
Action		Introduced
BitDepth		Introduced
CameraState		Introduced
CanConfigureDeviceProperties		Introduced
CommandBlind	Introduced but Deprecated	Absent
CommandBool	Introduced but Deprecated	Absent
CommandString	Introduced but Deprecated	Absent
ConfiguureDeviceProperties		Introduced
Connect	Introduced	Absent
Connected	Revised	Introduced
Connecting	Introduced	Absent
Description		Introduced
DeviceState	Introduced	Absent
Disconnect	Introduced	Absent
Dispose		Introduced
DriverInfo		Introduced
DriverVersion		Introduced
ExposureMax		Introduced
ExposureMin		Introduced
FrameRate		Introduced
Gain		Introduced
GainMax		Introduced
GainMin		Introduced
Gains		Introduced
Gamma		Introduced
GammaMax		Introduced
GammaMin		Introduced
Height		Introduced
IntegrationRate		Introduced
InterfaceVersion		Introduced
LastVideoFrame		Introduced
Name		Introduced
PixelSizeX		Introduced
PixelSizeY		Introduced
SensorName		Introduced
SensorType		Introduced
SetupDialog		Introduced
StartRecordingVideoFile		Introduced
StartRecordingVideoFile StopRecordingVideoFile		Introduced
· · ·		Introduced
SupportedActions SupportedIntegrationPates		******
SupportedIntegrationRates		Introduced Introduced
VideoCaptureDeviceName		
VideoCodec		Introduced
VideoFileFormat		Introduced
VideoFramesBufferSize		Introduced
Width		Introduced