

Figure 6.8: Transient versus steady-state response. The input to a linear system is shown in (a), and the corresponding output with x(0) = 0 is shown in (b). The output signal initially undergoes a transient before settling into its steady-state behavior.