## + send() + nrecv() + getLinkLayerAddress() + watchNetLink() + getPayloadOffset() + ~OSNetworkInterface()

## WindowsPCAPNetworkInterface

- handle
- local\_addr
- + send()
- + nrecv()
- + getLinkLayerAddress()
  + watchNetLink()
- + getPayloadOffset()
- + ~WindowsPCAPNetworkInterface() # WindowsPCAPNetworkInterface()