CommonTimestamper

version

- + HWTimestamper_init()
- + HWTimestamper_reset()
- + HWTimestamper final()
- + HWTimestamper_adjclockrate()
- + HWTimestamper_adjclockphase()
- + HWTimestamper_gettime()
- + HWTimestamper_get_extderror()
- + HWTimestamper PPS start()
- + HWTimestamper PPS stop()
- + getVersion()
- + CommonTimestamper()
- + ~CommonTimestamper()



WirelessTimestamper

- port

- + ~WirelessTimestamper()
- + setPort()
- + getPort()
- + getFwUpOffset()
- + requestTimingMeasurement()
 + requestTimingMeasurement()
- + timingMeasurementConfirmCB()
- + timeMeasurementIndicationCB()

WindowsWirelessTimestamper

- adapter
- system counter
- system_time
- device_time
- tsc hz
- initialized
- + WindowsWirelessTimestamper()
- + requestTimingMeasurement()
- + HWTimestamper_gettime()
- + HWTimestamper init()
- + setAdapter()
- + getAdapter()
- + ~WindowsWirelessTimestamper()