

ClockCounterClock

Reference Manual

Product Info	
Product Manager	Sven Meier
Author(s)	Sven Meier
Reviewer(s)	-
Version	1.9
Date	03.01.2023



Copyright Notice

Copyright © 2023 NetTimeLogic GmbH, Switzerland. All rights reserved. Unauthorized duplication of this document, in whole or in part, by any means, is prohibited without the prior written permission of NetTimeLogic GmbH, Switzerland

All referenced registered marks and trademarks are the property of their respective owners

Disclaimer

The information available to you in this document/code may contain errors and is subject to periods of interruption. While NetTimeLogic GmbH does its best to maintain the information it offers in the document/code, it cannot be held responsible for any errors, defects, lost profits, or other consequential damages arising from the use of this document/code.

NETTIMELOGIC GMBH PROVIDES THE INFORMATION, SERVICES AND PRODUCTS AVAILABLE IN THIS DOCUMENT/CODE "AS IS," WITH NO WARRANTIES WHATSOEVER. ALL EXPRESS WARRANTIES AND ALL IMPLIED WARRANTIES, INCLUDING WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, AND NON-INFRINGEMENT OF PROPRIETARY RIGHTS ARE HEREBY DISCLAIMED TO THE FULLEST EXTENT PERMITTED BY LAW. IN NO EVENT SHALL NETTIMELOGIC GMBH BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, CONSEQUENTIAL, SPECIAL AND EXEMPLARY DAMAGES, OR ANY DAMAGES WHATSOEVER, ARISING FROM THE USE OR PERFORMANCE OF THIS DOCUMENT/CODE OR FROM ANY INFORMATION, SERVICES OR PRODUCTS PROVIDED THROUGH THIS DOCUMENT/CODE, EVEN IF NETTIMELOGIC GMBH HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

IF YOU ARE DISSATISFIED WITH THIS DOCUMENT/CODE, OR ANY PORTION THEREOF, YOUR EXCLUSIVE REMEDY SHALL BE TO CEASE USING THE DOCUMENT/CODE.



Overview

NetTimeLogic's Clock (CLK) Counter Clock is a full hardware (FPGA) only implementation of an adjustable counter clock with PI servo loop and spread adjustment. The whole protocol algorithms and calculations are implemented in the core, no CPU is required. This allows running synchronization completely independent and standalone from the user application. The Adjustable Counter Clock has multiple selectable input adjustments: PTP, PPS, TOD, IRIG, RTC and REG. The time and settings can be configured either by signals or by an AXI4Lite-Slave Register interface.

Key Features:

- 32 bit second and 32 bit nanosecond counter clock with fractional extension
- Provides time for all other cores
- 1 millisecond pulse generator aligned with the counter clock
- Allows non-integer clock periods (fractions)
- Multiplexing of multiple adjustment inputs
- 6 different adjustment sources: PTP, PPS, TOD, IRIG, RTC and REG
- Evenly spread offset and drift correction over time (offset might be set hard in case of large offsets)
- Hard setting of time possible
- Individual hardware only PI servo loops for offset and drift correction (PI parameters individually configurable)
- Runtime changeable PI parameters
- Offset correction: min 1 ns/s, max 0.5 s/s
- Drift correction: min 1 ns/s, max 0.05 s/s
- Conversion of fractional adjustments into even spread clock adjustments
- AXI4Lite register set or static configuration
- Get time and set time as well as adjusting of offset and drift possible via registers as well.
- External clock source selection
- Correction logging for Offset and Drift
- Linux Driver (PHC)



Revision History

This table shows the revision history of this document.

Version	Date	Revision
0.1	28.12.2015	First draft
1.0	13.05.2016	First release
1.1	07.06.2016	Added structured types section
1.2	24.02.2017	Changed SNTP to RTC, added status interface and ExtSelect and CoreInfo type
1.3	20.12.2017	Added Fractional multiplication
1.4	09.01.2018	Added Holdover
1.5	09.03.2018	Added Driver
1.6	12.06.2018	Added Dynmic PI Servo Paramters and Loging registers
1.7	27.08.2020	Updated Clock Select Register
1.8	22.04.2022	Added DCF and NTP
1.9	03.01.2023	Added Vivado upgrade version description

Table 1: Revision History



Content

'	INTRODUCTION	0
1.1	Context Overview	8
1.2	Function	9
1.3	Architecture	10
2	CLOCK BASICS	12
2.1	Digital Counter Clock	12
2.2	Drift and Offset adjustments	12
3	REGISTER SET	14
3.1	Register Overview	14
3.2 3.2.	Register Descriptions 1 General	16 16
4	DESIGN DESCRIPTION	37
4.1	Top Level - Clk Clock	37
4.2 4.2. 4.2. 4.2. 4.2. 4.2.	.2 Clock Adjuster .3 Clock Counter .4 Clock Timer	51 51 57 63 65 67
4.3 4.3. 4.3.	Configuration example 1 Static Configuration 2 AXI Configuration	72 72 72
4.4		



5	RESOURCE USAGE	76
5.1	Intel/Altera (Cyclone V)	76
5.2	AMD/Xilinx (Artix 7)	76
6	DELIVERY STRUCTURE	77
7	TESTBENCH	78
7.1	Run Testbench	78
8	REFERENCE DESIGNS	79
8.1	Intel/Altera: Terasic SocKit	79
8.2	AMD/Xilinx: Digilent Arty	80
8.3	AMD/Xilinx: Vivado version	81



Definitions

Definitions	
Counter Clock	A counter based clock that count in the period of its fre-
Counter Clock	quency in nanoseconds
PI Servo Loop	Proportional-Integral servo loop, allows for smooth correc-
FI Selvo Loop	tions
Offset	Phase difference between clocks
Drift	Frequency difference between clocks

Table 2: Definitions

Abbreviations

Abbreviations	
AXI	AMBA4 Specification (Stream and Memory Mapped)
IRQ	Interrupt, Signaling to e.g. a CPU
PPS	Pulse Per Second
TS	Timestamp
CLK	Clock
CC	Counter Clock
ТВ	Testbench
LUT	Look Up Table
FF	Flip Flop
RAM	Random Access Memory
ROM	Read Only Memory
FPGA	Field Programmable Gate Array
VHDL	Hardware description Language for FPGA's

Table 3: Abbreviations



1 Introduction

1.1 Context Overview

The Adjustable Counter Clock is meant as a co-processor handling clock adjustments and a time generator.

It is designed to work with all synchronization cores from NetTimeLogic. All correction inputs are multiplexed and selectable. For each correction input it allows drift, offset and time corrections. The offset and drift values are filtered via a PI servo loop and evenly spread over time to allow smooth corrections.

It is the source of time for all other cores from NetTimelogic, not only the synchronization cores which will in the end adjust the Counter Clock but also for the Signal Timestampers and Signal Generators which work aligned with this Counter Clock. It contains an AXI4Lite slave for configuration, time setting, getting and adjusting from a CPU, this is however not required since the Adjustable Counter Clock can also be configured statically via signals/constants directly from within the FPGA.




Figure 1: Context Block Diagram



1.2 Function

The adjustable counter clock is, as the name says already, a counter clock in the second and nanosecond format that can be frequency and phase adjusted. It adds the clock period it runs on in nanoseconds every clock cycle. If the clock period is a non-integer value e.g. for 66MHz => 15.1515... ns the fractional part of the nanoseconds can be entered as a fraction e.g. for 66MHz => 10/66 => numerator = 10 and denumerator = 66. Every clock cycle a fraction counter is adding the numerator with an overflow at the denumerator value. At each overflow of the fraction counter it will add one additional nanosecond to the nanoseconds counter. This way no error is introduced because of non-integer periods. The nanosecond counter has an overflow at 1000000000 nanoseconds. At each overflow of the nanosecond counter it will add an additional second to the seconds counter.

For adjustments additional nanoseconds can be added or subtracted from the standard period to adjust frequency and phase and the time can be overwritten to hard set the clock to a new time when small offset adjustments are not suitable e.g. for the startup phase where a jump from the 1.1.1970 to the present is required. To minimize the counter widths in other cores e.g. for timeouts or other time periods which don't need nanosecond resolution a timer is used which generates a counter clock aligned timer event every millisecond e.g. for a period count of 1 second only 10 bits instead of 30 bits are needed.

An adjustment block takes the offset, drift and time adjustments as inputs and converts them into a combined adjustment which is then applied to the counter clock. The offset and drift is converted into evenly spread adjustments which allows smooth corrections on the clock without time jumps. E.g. a drift of 1ppm is adjusted as 1 ns every 5000000 clock cycles at 50MHz. Again the adjustment is made with fractional counter for minimal computational error introduction (max computational error 1ns/s). In parallel to the correction a quality computation done to mark the in-sync state of the clock if corrections are below a certain threshold for at least 5 corrections.

Before the adjustments are converted for the counter clock, the drift and offset adjustments are passing a PI servo loop for filtering and smoother adjustments. The PI servo loop parameter for the drift and offset adjustments can be chosen individually, since frequency changes might happen quite slowly where offset adjustments probably shall be done much faster. The PI servo loops results are feed back to the other cores for correcting of the next adjustments.

Since the Adjustable Counter Clock is the heart of a synchronization solution it can take several adjustment inputs from different cores as input. Only one adjustment



input is taken as source for corrections at the time. From the Registerset the multiplexer gets the selection of the current input or if in external mode a selection from outside can be done.

The Registerset allows reading the in-sync state, taking a snapshot of the time, overwriting the current time for e.g. the startup phase and also allows adjusting the drift and offset as an additional input to the multiplexer.

1.3 Architecture

The core is split up into different functional blocks for reduction of the complexity, modularity and maximum reuse of blocks. The interfaces between the functional blocks are kept as small as possible for easier understanding of the core.




Figure 2: Architecture Block Diagram

Register Set

This block allows reading status values and writing configuration.

Mux

This block is a multiplexer which forwards only one of the many possible adjustment inputs.

PI Servo Loop

This block contains two PI Servo Loops, one for the Offset and one for the Drift correction. The calculated values after the PI Servo are provided to the cores for the next calculations.

Adjustment



This block converts the adjustments in ratios or plain numbers to actual adjustments on the clock, smoothly spread over time. It also combines Drift and Offset adjustments and checks whether the clock is in sync.

Clock

This block is an adjustable counter clock with fractions. It provides the time used by all other cores.

1ms Timer

This block is one millisecond timer aligned with the clock. It generates a pulse every milliseconds. This is used by other cores to keep their counters small if only relative time is needed and millisecond resolution is sufficient.



2 Clock Basics

2.1 Digital Counter Clock

A digital counter clock is the most commonly used type of absolute time sources for digital systems. Its functionality is simple: every counter cycle it adds the period of the counter cycle to a counter. Optimally the counter period is an integer number which makes things easier. Normally such a counter clock is split into two counter parts, a sub seconds part and a seconds part, depending on the required resolution the sub second part is in nanoseconds, microseconds or milliseconds or even tens or hundreds of milliseconds. Once the sub seconds counter overflows e.g. 10^9 nanoseconds are reached, the seconds counter is incremented by one and the sub seconds counter is reset to the remainder if there is any.

The highest resolution can be achieved when the counter period is equal the clock period where the counter is run on, this is then normally a nanoseconds resolution, however with a quantitation of the clock period (this is what this core implements).

Figure 3: shows a typical high resolution counter clock with nanosecond resolution and a counter period equal the clock period and a clock of 50MHz which equals to a 20ns clock period.




Figure 3: Counter Clock

2.2 Drift and Offset adjustments

When a digital counter clock shall be synchronized there are two things that have to be adjusted which is frequency differences aka drift and phase differences aka offset. Normally the phase difference is only considered the phase within a second. But for absolute time also the correct second is important.



There are basically two possibilities how to adjust a digital counter clock. One is to keep the counter increment and adjust the clock frequency with e.g. load on a crystal oscillator where the load can be adjusted via a DAC. The second and the one used for this core, is to keep the clock frequency and adjust the counter increment. This has the advantages that it normally has a much higher resolution e.g. 1 ns/s and it doesn't require or relies on external hardware. To adjust drift or offset additional nanoseconds are added or subtracted from the standard increment of the period. Where the first solution implicitly generates a smooth adjustment, for the second this has to be calculated and explicitly done. E.g. for a 50 MHz counter clock an offset of +100 ns could be adjusted from one clock cycle to the next: $20 \Rightarrow 140 \Rightarrow 160 \Rightarrow \dots$ (including 20 ns for the next clock cycle) or it could for example be spread over the next 100 clock cycles: $20 \Rightarrow 41 \Rightarrow 62 \Rightarrow 73 \Rightarrow \dots$ which is a much smoother adjustment. The same applies to the drift which can also be set once in a period or evenly spread over time.

But why is a smooth adjustment important? If for example a PWM signal is generated from the counter clock then you don't want a time jump since the PWM would not be correct anymore, and this is exactly what would happen if the time is not corrected smoothly. The same applies for short time period measurements, these would measure wrong periods because of the adjustments.

However it is not always possible to adjust the time smoothly, e.g. at startup of a system the clock has to be adjusted by thousands of seconds to get to the time of day (TAI start with second 0 at midnight 1.1.1970) or if the adjustment is larger than the possible adjustment in a given period. This cannot be done smoothly in a reasonable time, therefore the time is then set with a time jump, and this also applies for the solution where the frequency of the clock is adjusted.

Also important is that the clock doesn't count backwards during adjustments. Data acquisition and measurement applications require for example a strongly monolithically increasing time. This requirement basically limits the maximal adjustment so the clock is still counting. E.g. at 50 MHz a norm period is 20 ns, the maximum adjustment is therefore +/-19ns per clock period so the clock would still count with lns per clock period.

All these mechanisms are implemented in this adjustable counter clock core.

When using the counter clock for signal timestamping or signal generation the quantization fault is still the clock period but with an accurate nanosecond resolution.



3 Register Set

This is the register set of the Adjustable Counter Clock. It is accessible via AXI4Lite Memory Mapped. All registers are 32bit wide, no burst access, no unaligned access, no byte enables, no timeouts are supported. Register address space is not contiguous. Register addresses are only offsets in the memory area where the core is mapped in the AXI inter connects. Non existing register access in the mapped memory area is answered with a slave decoding error.

3.1 Register Overview

Registerset Overview			
Name	Description	Offset	Access
Clk ClockControl Reg	Clock Read/Write Valid and Enabled Control Register	0x00000000	RW
Clk ClockStatus Reg	Clock Status Register	0x0000004	RO
Clk ClockSelect Reg	Clock Adjustment Multiplexer selection Register	0x0000008	RW
Clk ClockVersion Reg	Clock Version Register	0x000000C	RO
Clk ClockTimeValueL Reg	Clock current Time Nanosecond Register	0x0000010	RO
Clk ClockTimeValueH Reg	Clock current Time Second Register	0x0000014	RO
Clk ClockTimeAdjValueL Reg	Clock adjust Time Nanosecond Register	0x00000020	RW
Clk ClockTimeAdjValueH Reg	Clock adjust Time Second Register	0x00000024	RW
Clk ClockOffsetAdjValue Reg	Clock adjust Offset Nanosecond Register	0x0000030	RW
Clk ClockOffsetAdjInterval Reg	Clock adjust Offset Interval Nanosecond Register	0x0000034	RW
Clk ClockDirftAdjValue Reg	Clock adjust Drift Nanosecond Register	0x0000040	RW
Clk ClockDriftAdjInterval Reg	Clock adjust Drift Interval Nanosecond Register	0x00000044	RW
Clk ClockInSyncThreshold Reg	Clock adjust Drift Interval Nanosecond Register	0x0000050	RW
Clk_ClockServoOffsetFactorP_Reg	Clock Offset Servo P Factor Register	0x00000060	RW
Clk_ClockServoOffsetFactorl_Reg	Clock Offset Servo I Factor Register	0x0000064	RW

AdjCounterClock Reference Manual 1.9 Page 14 of 84



Clk_ClockServoDriftFactorP_Reg	Clock Drift Servo P Factor Register	0x00000068	RW
Clk_ClockServoDriftFactorl_Reg	Clock Drift Servo I Factor Register	0x0000006C	RW
Clk_ClockStatusOffset_Reg	Clock corrected Offset Register	0x00000070	RO
Clk_ClockStatusDrift_Reg	Clock corrected Drift Register	0x00000074	RO

AdjCounterClock Reference Manual 1.9



3.2 Register Descriptions

3.2.1 General

3.2.1.1 CLK Clock Control Register

Used for general control over the Adjustable Counter Clock. To get a new time snapshot the time read flag has to be set and the read done flag is asserted. Since most adjustment values are multi register values, set flags are available to mark validity of the whole value.

CI	c Clc	ockC	ont	rol	Reg																										
Reg	Reg Description																														
31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
TIME_READ_DONE	TIME_READ											ı											SERVO_VAL					DRIFT_VAL	OFFSET_VAL	TIME_VAL	ENABLE
RO	RW											RO																RW	RW	RW	RW
													F	Reset				0													
														Off	fset:	0x0(000														

Name	Description	Bits	Access
TIME_READ_DONE	Time Read done (autocleared)	Bit: 31	RO

AdjCounterClock Reference Manual 1.9 Page 16 of 84



TIME_READ	Time Read (autocleared)	Bit: 30	RW
-	Reserved, read 0	Bit: 29:9	RO
SERVO_VAL	Servo Parameters Valid (autocleared), shall only be set when the clock is disabled	Bit: 8	RW
-	Reserved, read 0	Bit: 7:4	RO
DRIFT_VAL	Drift Ajustment Valid (autocleared)	Bit: 3	RW
OFFSET_VAL	Offset Ajustment Valid (autocleared)	Bit: 2	RW
TIME_VAL	Time Ajustment Valid (autocleared)	Bit: 1	RW
ENABLE	Enable	Bit: 0	RW

AdjCounterClock Reference Manual 1.9



3.2.1.2 CLK Clock Status Register

Marks if the clock is in sync. In sync means 5 consecutive offset where below the threshold.

Clk	C	lock!	Stat	us R	eg																										
Reg	Reg Description																														
31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
															ı															IN_HOLDOVER	IN_SYNC
															RO															RO	RO
													F			0000		0													
														Of	fset:	0x00	004														

Name	Description	Bits	Access
-	Reserved, read 0	Bit: 31:2	RO
IN_HOLDOVER	In holdover, after in sync for N seconds no new adjustment	Bit: 1	RO
IN_SYNC	In sync; Last 5 corrections below threshold	Bit: 0	RO

AdjCounterClock Reference Manual 1.9 Page 18 of 84



3.2.1.3 CLK Clock Select Register

Which input adjustment shall be active. If external select is active the CLK_SELECTED field shows the actual selection

Clk ClockSelect Reg										
Reg Description										
31 30 29 28 27 26 25 24	23 22 21 20 19 18 17 16	15 14 13 12 11 10 9 8	7 6 5 4 3 2 1 0							
1	CLK_SELECTED	ı	CLK_SELECT							
RO	RO	RO	RW							
	Reset: 0x0	0000000								
	Offset:	0x0008	Offset: 0x0008							

Name	Description	Bits	Access
-	Reserved, read 0	Bit: 31:24	RO

AdjCounterClock Reference Manual 1.9 Page 19 of 84



CLK_SELECTED	Selected Source for Clock Adjustments: None = 0 Tod = 1 Irig = 2 Pps = 3 Ptp = 4 Rtc = 5 Dcf = 6 Ntp = 7 Regs = 254 Ext = 255	Bit: 23:16	RO
-	Reserved, read 0	Bit: 15:8	RO
CLK_SELECT	Source for Clock Adjustments: None = 0 Tod = 1 Irig = 2 Pps = 3 Ptp = 4 Rtc = 5 Dcf = 6 Ntp = 7 Regs = 254 Ext = 255	Bit: 7:0	RW

3.2.1.4 CLK Clock Version Register

Version of the IP core, even though is seen as a 32bit value, bits 31 down to 24 represent the major, bits 23 down to 16 the minor and bits 15 down to 0 the build numbers.

C	lk Cl	locl	kVer:	sion	Reg	J																									
Re	eg De	escr	iption																												
31	30	29	9 28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0

AdjCounterClock Reference Manual 1.9 Page 20 of 84



E AS O S	
₩ >	
RO	
Reset: 0xXXXXXXX	
Offset: 0x000C	


Name	Description	Bits	Access
VERSION	Version of the core	Bit: 31:0	RO

AdjCounterClock Reference Manual 1.9



3.2.1.5 CLK Clock Time Value Low Register

Time snapshot value nanosecond part.




Name	Description	Bits	Access
TIME_NS	Snapshoted Time Nanosecond	Bit: 31:0	RO

AdjCounterClock Reference Manual 1.9 Page 22 of 84



3.2.1.6 CLK Clock Time Value High Register

Time snapshot value second part.




Name	Description	Bits	Access
TIME_S	Snapshoted Time Second	Bit: 31:0	RO

AdjCounterClock Reference Manual 1.9 Page 23 of 84



3.2.1.7 CLK Clock Time Adjustment Value Low Register

Time adjustment nanoseconds part value. Will overwrite the clock.




Name	Description	Bits	Access
TIME_ADJ_NS	OverwriteTime Nanosecond	Bit: 31:0	RW

AdjCounterClock Reference Manual 1.9 Page 24 of 84



3.2.1.8 CLK Clock Time Adjustment Value High Register

Time adjustment seconds part value. Will overwrite the clock.




Name	Description	Bits	Access
TIME_ADJ_S	OverwriteTime Second	Bit: 31:0	RW

AdjCounterClock Reference Manual 1.9 Page 25 of 84



3.2.1.9 CLK Clock Offset Adjustment Value Register

Offset adjustment absolute value. A negative sign will slow down the clock, a positive sign therefore accelerates the clock to adjust the phase.




Name	Description	Bits	Access
OFFSET_SIGN	Sign of the Adjustment 0 positive, 1 negative	Bit: 31	RW
OFFSET_ADJ_NS	Offset Adjustment in Nanosecond	Bit: 30:0	RW

AdjCounterClock Reference Manual 1.9 Page 26 of 84



3.2.1.10 CLK Clock Offset Adjustment Interval Register

Offset adjustment interval. It defines the interval in which the offset shall be corrected. If the offset value is larger or equal the interval, the time will be set directly.




Name	Description	Bits	Access
OFFSET_ADJ_INTV_NS	Offset Adjustment Interval in Nanosecond	Bit: 31:0	RW

AdjCounterClock Reference Manual 1.9 Page 27 of 84



3.2.1.11CLK Clock Drift Adjustment Value Register

Drift adjustment value. Together with the drift interval this indicates a ratio of correction in the format ns per ns which means how many nanoseconds shall be corrected in the interval. A negative sign will slow down the clock, a positive sign therefore accelerates the clock.




Name	Description	Bits	Access
DRIFT_SIGN	Sign of the Adjustment 0 positice, 1 negative	Bit: 31	RW
DRIFT_ADJ_NS	Drift Adjustment in Nanosecond	Bit: 30:0	RW

AdjCounterClock Reference Manual 1.9 Page 28 of 84



3.2.1.12CLK Clock Drift Adjustment Interval Register

Drift adjustment interval. Together with the drift value this indicates a ratio of correction in the format ns per ns which means how many nanoseconds shall be corrected in the interval specified by this register.




Name	Description	Bits	Access
DRIFT_ADJ_INTV_NS	Drift Adjustment Interval in Nanosecond	Bit: 31:0	RW

AdjCounterClock Reference Manual 1.9 Page 29 of 84



3.2.1.13CLK Clock In Sync Threshold Register

Threshold of the in sync indication flag. After consecutive offset adjustments below the threshold the in sync flag is asserted. The threshold is in nanosecond and the default value is set via generic.



Name	Description	Bits	Access
THRESHOLD_NS	Threshold for InSync flag in Nanoseconds	Bit: 31:0	RW

AdjCounterClock Reference Manual 1.9 Page 30 of 84




3.2.1.14 CLK Clock Servo Offset Factor P Register

Proportional factor for the fractional offset multiplier. The Value is calculated the following way:

$(MulP*2^{16})/DivP$

After reset the value is defined by the generics.

This register is only available if the generic BypassServo_Gen is false and the generics FractionalMultiply_Gen and DynamicServo-Parameters_Gen are true.



Name	Description	Bits	Access
OFFSET_FACTOR_P	Fractional multiplication Factor Offset P: ((Mul*2^16)/Div)	Bit: 31:0	RW

AdjCounterClock Reference Manual 1.9 Page 31 of 84




3.2.1.15CLK Clock Servo Offset Factor I Register

Integral factor for the fractional offset multiplier. The Value is calculated the following way:

 $(MulI * 2^{16})/DivI$

After reset the value is defined by the generics.

This register is only available if the generic BypassServo_Gen is false and the generics FractionalMultiply_Gen and DynamicServo-Parameters_Gen are true.



Name	Description	Bits	Access
OFFSET_FACTOR_I	Fractional multiplication Factor Offset I: ((Mul*2^16)/Div)	Bit: 31:0	RW

AdjCounterClock Reference Manual 1.9 Page 32 of 84




3.2.1.16CLK Clock Servo Drift Factor P Register

Proportional factor for the fractional drift multiplier. The Value is calculated the following way:

$(MulP*2^{16})/DivP$

After reset the value is defined by the generics.

This register is only available if the generic BypassServo_Gen is false and the generics FractionalMultiply_Gen and DynamicServo-Parameters_Gen are true.



Name	Description	Bits	Access
DRIFT_FACTOR_P	Fractional multiplication Factor Drift P: ((Mul*2^16)/Div)	Bit: 31:0	RW

AdjCounterClock Reference Manual 1.9 Page 33 of 84




3.2.1.17 CLK Clock Servo Drift Factor I Register

Integral factor for the fractional drift multiplier. The Value is calculated the following way:

 $(MulI * 2^{16})/DivI$

After reset the value is defined by the generics.

This register is only available if the generic BypassServo_Gen is false and the generics FractionalMultiply_Gen and DynamicServo-Parameters_Gen are true.




Name	Description	Bits	Access
DRIFT_FACTOR_I	Fractional multiplication Factor Drift I: ((Mul*2^16)/Div)	Bit: 31:0	RW

AdjCounterClock Reference Manual 1.9 Page 34 of 84



3.2.1.18CLK Clock Status Offset Value Register

Last corrected offset in nanoseconds. This register is only available if the generic LogCorrections_Gen is true.




N	ame	Description	Bits	Access
0	FFSET_SIGN	Sign bit: 0 = positive, 1 = negative	Bit: 31	RO
0	FFSET_NS	Last corrected Offset value in Nanoseconds	Bit: 30:0	RO

AdjCounterClock Reference Manual 1.9 Page 35 of 84



3.2.1.19CLK Clock Status Drift Value Register

Last corrected drift in nanosecond. This register is only available if the generic LogCorrections_Gen is true.



Name	Description	Bits	Access
DRIFT_SIGN	Sign bit: 0 = positive, 1 = negative	Bit: 31	RO
DRIFT_NS	Last corrected Drift value in Nanoseconds/Second (ppb)	Bit: 30:0	RO

AdjCounterClock Reference Manual 1.9 Page 36 of 84



4 Design Description

The following chapters describe the internals of the Adjustable Counter Clock: starting with the Top Level, which is a collection of subcores, followed by the description of all subcores.

4.1 Top Level - Clk Clock

4.1.1.1 Parameters

The core must be parametrized at synthesis time. There are a couple of parameters which define the final behavior and resource usage of the core.

Name	Туре	Size	Description
StaticConfig_Gen	boolean	1	If Static Configuration or AXI is used: true = Static, false = AXI
ExtSelect_Gen	boolean	1	If external selection of correction shall be done or not: true = external selection is possible, false only selection via reg
ClockClkPeriodNano- second_Gen	natural	1	Clock Period in Nanosecond: Default for 50 MHz = 20 ns, if non-integer only the nanosec- onds part here
ClockClkPeriodFract- Num_Gen	natural	1	Fractional Clock Period Nu- merator (0 if integer)
ClockClkPeriod- FractDeNum_Gen	natural	1	Fractional Clock Period Denumerator (0 if integer)
ClockInSyncNanosec- ond_Gen	natural	1	Default value for the threshold when the clock is considered in sync in Nanoseconds Default 500 ns
ClockInHoldover TimeoutSecond_Gen	natural	1	Value after how many seconds after in Sync without



			new correction values it goes
			in holdover
			Default 3 s
LogCorrections_Gen	boolean	1	Log Correction values to registers
BypassServo_Gen	boolean	1	Bypass PI Servo loops, the input will directly be taken for calculations
FractionalMultiply _Gen_Gen	boolean	1	Use a fractional multiplication (uses DSP slices) instead of binary multiplication and divisions (default)
DynamicServo Parameters_Gen	boolean	1	Allow to change the PI Servo parameters at runtime
DriftMulP_Gen	natural	1	Drift Proportional part ratio Numerator
DriftDivP_Gen	natural	1	Drift Proportional part ratio Denumerator
DriftMull_Gen	natural	1	Drift Integral part ratio Nu- merator
DriftDivl_Gen	natural	1	Drift Integral part ratio Denu- merator
OffsetMulP_Gen	natural	1	Offset Proportional part ratio Numerator
OffsetDivP_Gen	natural	1	Offset Proportional part ratio Denumerator
OffsetMull_Gen	natural	1	Offset Integral part ratio Nu- merator
OffsetDivl_Gen	natural	1	Offset Integral part ratio De- numerator
AxiAddressRange Low_Gen	std_logic_vector	32	AXI Base Address
AxiAddressRange High_Gen	std_logic_vector	32	AXI Base Address plus Registerset Size Default plus OxFFFF
Sim_Gen	boolean	1	If in Testbench simulation mode:



	true = Simulation, false = Syn-
	thesis

Table 4: Parameters

If an integer clock period is used all fraction parameters have to be 0.

4.1.1.2 Structured Types

4.1.1.2.1 Clk_Time_Type

Defined in Clk_Package.vhd of library ClkLib

Type represents the time used everywhere. For this type overloaded operators + and - with different parameters exist.

Field Name	Туре	Size	Description
Second	std_logic_vector	32	Seconds of time
Nanosecond	std_logic_vector	32	Nanoseconds of time
Fraction	std_logic_vector 2	2	Fraction numerator (mostly
Traction	sta_logic_vector	ector 2	not used)
Sign	std logic	std logic 1	Positive or negative time, 1 =
Sign		'	negative, 0 = positive.
TimeJump	imeJump std logic	1	Marks when the clock makes a
- micoamp	1 3.00_10910		time jump (mostly not used)

Table 5: Clk_Time_Type

4.1.1.2.2 Clk_TimeAdjustment_Type

Defined in Clk_Package.vhd of library ClkLib

Type represents the time used everywhere. For this type overloaded operators + and - with different parameters exist.

Field Name	Туре	Size	Description		
TimeAdjustment	Clk_Time_Type	1	Time to adjust		
Interval std_logic_vector			Adjustment interval, for the drift correction this is the de-		
	32	drift correction this is the de-			
	32	numerator of the rate in nano-			
			seconds (TimeAdjustment		



every Interval = drift rate), for
offset correction this is the pe-
riod in which the time shall be
corrected(TimeAdjustment in
Interval), for setting the time
this has no mining.

Table 6: Clk_TimeAdjustment_Type

4.1.1.2.3 Clk_CoreInfo_Type

Defined in Clk_Package.vhd of library ClkLib

This is the type used for getting info about the cores state status.

Field Name	Туре	Size	Description
State	Clk_CoreState_T	1	State of the core: Unknown_E,
State	уре	I	Slave_E or Master_E
Accuracy	std_logic_vector	Ω	Accuracy of the core, higher is
Accuracy	std_logic_vector	8	better
Enabled	std_logic	1	If the core is enabled
InSync	std_logic	1	If the core is synchronized
Error	std_logic	1	If the core has an error

Table 7: Clk_CoreInfo_Type

4.1.1.2.4 Clk_ClockStaticConfig_Type

Defined in Clk_ClockAddrPackage.vhd of library ClkLib This is the type used for static configuration.

Field Name	Туре	Size	Description
TimeAdjustment	Clk_TimeAdjust- ment_Type	1	Set the time to this value
OffsetAdjustment	Clk_TimeAdjust- ment_Type	1	Do an offset adjustment with this value
DriftAdjustment	Clk_TimeAdjust- ment_Type	1	Do an drift adjustment with this value
ClockSelect	std_logic_vector	32	Which adjustment input shall be used:



			0 => None
			1 => Tod
			2 => Irig
			3 => Pps
			4 => Ptp
			5 => Rtc
			6 => Regs
			7 => Ext
InSyncThreshold	std_logic_vector	32	Threshold of the in sync flag indication in nanoseconds

Table 8: Clk_ClockStaticConfig_Type

4.1.1.2.5 Clk_ClockStaticConfigVal_Type

Defined in Clk_ClockAddrPackage.h of library ClkLib
This is the type used for valid flags of the static configuration.

Field Name	Туре	Size	Description
Enable_Val	std_logic	1	Enables the Clock
TimeAdjustment_Val	std_logic	1	Set the time
OffsetAdjustment_Val	std_logic	1	Start an offset adjustment
DriftAdjustment_Val	std_logic	1	Start a drift adjustment

Table 9: Clk_ClockStaticConfigVal_Type

4.1.1.2.6 Clk_ClockStaticStatus_Type

Defined in Clk_ClockAddrPackage.vhd of library ClkLib This is the type used for static status.

Field Name	Туре	Size	Description
CoreInfo	Clk_CoreInfo_ Type	1	Infor about the Cores state
ClockTime	Clk_Time_Type	1	Time of the Clock

Table 10: Clk_ClockStaticStatus_Type

4.1.1.2.7 Clk_ClockStaticStatusVal_Type



Defined in Clk_ClockAddrPackage.h of library ClkLib This is the type used for valid flags of the static status.

Field Name	Туре	Size	Description
ClockTime_Val	std_logic	1	Set the time

Table 11: Clk_ClockStaticStatusVal_Type

4.1.1.3 Entity Block Diagram




Figure 4: Adjustable Counter Clock

4.1.1.4 Entity Description

Clock Selector

This module multiplexes multiple adjustment inputs. Only one adjustment is active at the time. This can be selected by a configuration register. PTP, PPS, TOD, IRIG, RTC, REG and EXT (where the selection is feed from externally) are potential sources. The multiplexer can also be set to disable any adjustment input. See 4.2.1 for more details.

Clock Adjuster

This module contains the PI Servo loops for the Drift and Offset and the adjustment conversion. It takes the adjustment inputs and converts them into periodic small adjustments which are then set to the Counter Clock. E.g. a drift of 1ns per 1000ns is converted to a 1ns adjustment every 50 clock cycles at a frequency of 50MHz. For offset it works similar. E.g. 50ns shall be corrected in 2000ns which will be converted into 1ns every second clock cycle at 50MHz. The conversion of course also works for non-integer corrections with minimal error (1/- 1ns per correction cycle).



In addition it supervises the adjustments ad sets an InSync flag if 4 consecutive offset corrections were below a configurable threshold. See 4.2.2 for more details.

Clock Counter

This module is the heart of the core. It is a counter with nanosecond resolution in a 32 bit second and 32 bit nanosecond format. It can run with fractions to allow also non-integer clock periods. It normally adds the clock period to the nanoseconds counter every clock cycle but can add or subtract some extra nanosecond to do the clock adjustment. It also has an overwrite mode where the clock can be set. See 4.2.3 for more details.

Timer

This module creates a 1 millisecond timer event aligned with the Counter Clock. If the clock makes a jump in time this may lead to a loss of an event or to two events very close to each other.

See 4.2.4 for more details.

Registerset

This module is an AXI4Lite Memory Mapped Slave. It provides access to all registers and allows to configure the Adjustable Counter Clock. It can be configured to either run in AXI or StaticConfig mode. If in StaticConfig mode, the configuration of the resgisters is done via signals and can be easily done from within the FPGA without CPU. If in AXI mode, an AXI Master has to configure the Datasets with AXI writes to the registers, which is typically done by a CPU. It also provides a status interface which allows similar to the static configuration to supervise the status via signals.

See 4.2.5 for more details.

4.1.1.5 Entity Declaration

Name	Dir	Туре	Size	Description
		Generics		
General				
StaticConfig_Gen	-	boolean	1	If Static Configura- tion or AXI is used



				If external selection
ExtSelect_Gen	_	boolean	1	of sync source is
LAtSelect_Gell		boolean	'	used
Classicilis Davida di Naciona				
ClockClkPeriodNano-	-	natural	1	Clock Period in Na-
second_Gen				nosecond
ClockClkPeriodFract-				Fractional Clock Pe-
Num_Gen	-	natural	1	riod Numerator (0 if
				integer)
ClockClkPeriod-				Fractional Clock Pe-
FractDeNum_Gen	-	natural	1	riod Denumerator
TractDeNum_Gen				(0 if integer)
				Default value for the
ClockInSyncNanosec-		patural	1	threshold when the
ond_Gen	-	natural	'	clock is considered
				in sync
				Value after how
				many seconds after
ClockInHoldover				in Sync without new
TimeoutSecond_Gen	-	natural	1	correction values it
Timeodesecond_cen				goes in holdover
				Default 3 s
LogCorrections_Gen	-	boolean	1	Log corrections to
				registers
BypassServo_Gen	-	boolean	1	Bypass PI Servo
				loops
				Use a fractional mul-
				tiplication (uses DSP
FractionalMultiply	_	boolean	1	slices) instead of bi-
_Gen				nary multiplication
				and divisions (de-
				fault)
DynamicServo				Allow to change the
	-	boolean	1	PI Servo parameters
Parameters_Gen				at runtime
				Drift Proportional
DriftMulP_Gen	-	natural	1	part ratio Numera-
				tor



DriftDivP_Gen	-	natural	1	Drift Proportional part ratio Denumerator
DriftMull_Gen	-	natural	1	Drift Integral part ratio Numerator
DriftDivl_Gen	-	natural	1	Drift Integral part ratio Denumerator
OffsetMulP_Gen	-	natural	1	Offset Proportional part ratio Numerator
OffsetDivP_Gen	-	natural	1	Offset Proportional part ratio Denumerator
OffsetMull_Gen	-	natural	1	Offset Integral part ratio Numerator
OffsetDivl_Gen	ı	natural	1	Offset Integral part ratio Denumerator
AxiAddressRange Low_Gen	ı	std_logic_vector	32	AXI Base Address
AxiAddressRange High_Gen	-	std_logic_vector	32	AXI Base Address plus Registerset Size
Sim_Gen	-	boolean	1	If in Testbench simulation mode
		Ports		
System SysClk_ClkIn	in	std_logic	1	System Clock
SysRstN_RstIn	in	std_logic	1	System Reset
Config StaticConfig_DatIn	in	Clk_Clock StaticConfig_Type	1	Static Configuration
StaticConfig_ValIn	in	Clk_Clock StaticConfigVal _Type	1	Static Configuration valid
Status StaticStatus_DatOut	out	Clk_Clock StaticStatus_Type	1	Static Status



StaticStatus_ValOut	out	Clk_Clock StaticStatusVal _Type	1	Static Status valid
Timer Output Timer1ms_EvtOut AXI4 Lite Slave	out	std_logic	1	Single clock cycle event every millisec- ond aligned with the adjusted clock
AxiWriteAddrValid ValIn	in	std_logic	1	Write Address Valid
AxiWriteAddrReady _RdyOut	out	std_logic	1	Write Address Ready
AxiWriteAddrAddress _AdrIn	in	std_logic_vector	32	Write Address
AxiWriteAddrProt _DatIn	in	std_logic_vector	3	Write Address Protocol
AxiWriteDataValid _ValIn	in	std_logic	1	Write Data Valid
AxiWriteDataReady _RdyOut	out	std_logic	1	Write Data Ready
AxiWriteDataData _DatIn	in	std_logic_vector	32	Write Data
AxiWriteDataStrobe _DatIn	in	std_logic_vector	4	Write Data Strobe
AxiWriteRespValid _ValOut	out	std_logic	1	Write Response Valid
AxiWriteRespReady _RdyIn	in	std_logic	1	Write Response Ready
AxiWriteResp Response_DatOut	out	std_logic_vector	2	Write Response
AxiReadAddrValid _ValIn	in	std_logic	1	Read Address Valid
AxiReadAddrReady _RdyOut	out	std_logic	1	Read Address Ready
AxiReadAddrAddress _AdrIn	in	std_logic_vector	32	Read Address
AxiReadAddrProt _DatIn	in	std_logic_vector	3	Read Address Pro- tocol
AxiReadDataValid _ValOut	out	std_logic	1	Read Data Valid
AxiReadDataReady _RdyIn	in	std_logic	1	Read Data Ready
AxiReadData Response_DatOut	out	std_logic_vector	2	Read Data



AxiReadDataData _DatOut	out	std_logic_vector	32	Read Data Re- sponse
Adjustment Selector In	in	Clk_Select_Type	1	Which core shall be the source for the correction when Select_DatIn is external, this is feed from the outside
InSync Output			I	
InSync_DatOut	out	std_logic	1	Clock Adjustments were below a cer- tain level
InHoldover_DatOut	out	std_logic	1	No new Clock Adjustments after in Sync for a defined number of seconds
Time Output	·		ı	
ClockTime_DatOut	out	Clk_Time_Type	1	Adjusted Clock Time
ClockTime_ValOut	out	std_logic	1	Adjusted Clock Time valid
Time Adjustment Input				
TimeAdjustmentTod _DatIn	in	Clk_TimeAdjust- ment_Type	1	Calculated new Time from TOD core
TimeAdjustmentTod _ValIn	in	std_logic;	1	Calculated new Time from TOD core valid
TimeAdjustmentIrig _DatIn	in	Clk_TimeAdjust- ment_Type	1	Calculated new Time from IRIG core
TimeAdjustmentIrig _ValIn	in	std_logic;	1	Calculated new Time from IRIG core valid
TimeAdjustmentPps _DatIn	in	Clk_TimeAdjust- ment_Type	1	Calculated new Time from PPS core
TimeAdjustmentPps _ValIn	in	std_logic;	1	Calculated new Time from PPS core valid



Time a A alimeter and Dho		Clk_TimeAdjust-		Calculated new
TimeAdjustmentPtp DatIn	in	ment_Type	1	Time from PTP core
				Calculated new
TimeAdjustmentPtp	l in	std_logic;	1	Time from PTP core
_Valln	111	3.0910,	'	valid
		Clk TimeAdjust-		Calculated new
TimeAdjustmentRtc DatIn	in	ment_Type	1	Time from RTC core
		ment_rype		Calculated new
TimeAdjustmentRtc		atal la sia	1	
_Valln	in	std_logic;	1	Time from RTC core
				valid
TimeAdjustmentDcf	in	Clk_TimeAdjust-	1	Calculated new
_DatIn	1111	ment_Type		Time from DCF core
Time Additional ID 6				Calculated new
TimeAdjustmentDcf Valln	in	std_logic;	1	Time from DCF core
_+				valid
TimeAdjustmentNtp		Clk_TimeAdjust-	1	Calculated new
_DatIn	in	ment_Type	'	Time from NTP core
				Calculated new
TimeAdjustmentNtp	l in	std_logic;	1	Time from NTP core
	I IM	Jtd_logic,	'	THITIC HOITH ATT COIC
_Valln	I	sta_logic,	'	valid
			'	valid
_Valln	t	Clk_TimeAdjust-		
_Valln Offset Adjustment Inpu			1	valid
_Valln Offset Adjustment Inpu OffsetAdjustmentTod _DatIn	t	Clk_TimeAdjust-		valid Calculated new Off-
_Valln Offset Adjustment Inpu OffsetAdjustmentTod _DatIn OffsetAdjustmentTod	t	Clk_TimeAdjust-		valid Calculated new Offset from TOD core
_Valln Offset Adjustment Inpu OffsetAdjustmentTod _DatIn	t in	Clk_TimeAdjust- ment_Type	1	Valid Calculated new Offset from TOD core Calculated new Off-
_Valln Offset Adjustment Inpu OffsetAdjustmentTod _DatIn OffsetAdjustmentTod _Valln	t in in	Clk_TimeAdjust- ment_Type	1	Valid Calculated new Offset from TOD core Calculated new Offset from TOD core
_Valln Offset Adjustment Inpu OffsetAdjustmentTod _DatIn OffsetAdjustmentTod	t in	Clk_TimeAdjust- ment_Type std_logic;	1	Valid Calculated new Offset from TOD core Calculated new Offset from TOD core valid
_Valln Offset Adjustment Inpu OffsetAdjustmentTod _DatIn OffsetAdjustmentTod _Valln OffsetAdjustmentIrig	t in in	Clk_TimeAdjust- ment_Type std_logic; Clk_TimeAdjust-	1	valid Calculated new Offset from TOD core Calculated new Offset from TOD core valid Calculated new Offset of the core
_Valln Offset Adjustment Inpu OffsetAdjustmentTod _DatIn OffsetAdjustmentTod _Valln OffsetAdjustmentIrig _DatIn OffsetAdjustmentIrig _DatIn	t in in	Clk_TimeAdjust- ment_Type std_logic; Clk_TimeAdjust-	1	Valid Calculated new Offset from TOD core Calculated new Offset from TOD core valid Calculated new Offset from IRIG core
_Valln Offset Adjustment Inpu OffsetAdjustmentTod _DatIn OffsetAdjustmentTod _Valln OffsetAdjustmentIrig _DatIn	t in in	Clk_TimeAdjust- ment_Type std_logic; Clk_TimeAdjust- ment_Type	1 1	Calculated new Offset from TOD core Calculated new Offset from TOD core valid Calculated new Offset from IRIG core Calculated new Offset from IRIG core
_Valln Offset Adjustment Inpu OffsetAdjustmentTod _DatIn OffsetAdjustmentTod _Valln OffsetAdjustmentIrig _DatIn OffsetAdjustmentIrig _DatIn	t in in	Clk_TimeAdjust- ment_Type std_logic; Clk_TimeAdjust- ment_Type	1 1 1	Valid Calculated new Offset from TOD core Calculated new Offset from TOD core valid Calculated new Offset from IRIG core Calculated new Offset from IRIG core
_Valln Offset Adjustment Inpu OffsetAdjustmentTod _DatIn OffsetAdjustmentTod _Valln OffsetAdjustmentIrig _DatIn OffsetAdjustmentIrig _DatIn	t in in	Clk_TimeAdjust- ment_Type std_logic; Clk_TimeAdjust- ment_Type std_logic; Clk_TimeAdjust-	1 1	Calculated new Offset from TOD core Calculated new Offset from TOD core valid Calculated new Offset from IRIG core Calculated new Offset from IRIG core valid
_Valln Offset Adjustment Input OffsetAdjustmentTod _DatIn OffsetAdjustmentTod _Valln OffsetAdjustmentIrig _DatIn OffsetAdjustmentIrig _DatIn OffsetAdjustmentIrig _Valln OffsetAdjustmentIrig	t in in	Clk_TimeAdjust- ment_Type std_logic; Clk_TimeAdjust- ment_Type std_logic;	1 1 1	Calculated new Offset from TOD core Calculated new Offset from TOD core valid Calculated new Offset from IRIG core Calculated new Offset from IRIG core valid Calculated new Offset from IRIG core valid Calculated new Offset from PPS core
_Valln Offset Adjustment Input OffsetAdjustmentTod _DatIn OffsetAdjustmentTod _Valln OffsetAdjustmentIrig _DatIn OffsetAdjustmentIrig _DatIn OffsetAdjustmentIrig _Valln OffsetAdjustmentIrig	t in in in	Clk_TimeAdjust- ment_Type std_logic; Clk_TimeAdjust- ment_Type std_logic; Clk_TimeAdjust- ment_Type	1 1 1	Calculated new Offset from TOD core Calculated new Offset from TOD core valid Calculated new Offset from IRIG core Calculated new Offset from IRIG core valid Calculated new Offset from PPS core Calculated new Offset from PPS core Calculated new Offset from PPS core
Valln Offset Adjustment Input OffsetAdjustmentTodDatIn OffsetAdjustmentIridValln OffsetAdjustmentIrigDatIn OffsetAdjustmentIrigValln OffsetAdjustmentIrigValln	t in in	Clk_TimeAdjust- ment_Type std_logic; Clk_TimeAdjust- ment_Type std_logic; Clk_TimeAdjust-	1 1 1	Valid Calculated new Offset from TOD core Calculated new Offset from TOD core valid Calculated new Offset from IRIG core Calculated new Offset from IRIG core valid Calculated new Offset from PPS core Calculated new Offset from PPS core Calculated new Offset from PPS core
Valln Offset Adjustment Inpu OffsetAdjustmentTodDatIn OffsetAdjustmentIrigDatIn OffsetAdjustmentIrigValln OffsetAdjustmentIrigValln OffsetAdjustmentPpsDatIn OffsetAdjustmentPpsValln	t in in in	Clk_TimeAdjust- ment_Type std_logic; Clk_TimeAdjust- ment_Type std_logic; Clk_TimeAdjust- ment_Type std_logic;	1 1 1	Calculated new Offset from TOD core Calculated new Offset from TOD core valid Calculated new Offset from IRIG core Calculated new Offset from IRIG core valid Calculated new Offset from PPS core Calculated new Offset from PPS core Calculated new Offset from PPS core valid
_Valln Offset Adjustment Inpu OffsetAdjustmentTod _DatIn OffsetAdjustmentIrig _DatIn OffsetAdjustmentIrig _DatIn OffsetAdjustmentIrig _Valln OffsetAdjustmentPps _DatIn OffsetAdjustmentPps _DatIn	t in in in	Clk_TimeAdjust- ment_Type std_logic; Clk_TimeAdjust- ment_Type std_logic; Clk_TimeAdjust- ment_Type	1 1 1	Valid Calculated new Offset from TOD core Calculated new Offset from TOD core valid Calculated new Offset from IRIG core Calculated new Offset from IRIG core valid Calculated new Offset from PPS core Calculated new Offset from PPS core Calculated new Offset from PPS core



OffsetAdjustmentPtp _ValIn	in	std_logic;	1	Calculated new Off- set from PTP core valid
OffsetAdjustmentRtc _DatIn	in	Clk_TimeAdjust- ment_Type	1	Calculated new Off- set from RTC core
OffsetAdjustmentRtc _ValIn	in	std_logic;	1	Calculated new Off- set from RTC core valid
OffsetAdjustmentDcf _DatIn	in	Clk_TimeAdjust- ment_Type	1	Calculated new Off- set from DCF core
OffsetAdjustmentDcf _ValIn	in	std_logic;	1	Calculated new Off- set from DCF core valid
OffsetAdjustmentNtp _DatIn	in	Clk_TimeAdjust- ment_Type	1	Calculated new Off- set from NTP core
OffsetAdjustmentNtp _ValIn	in	std_logic;	1	Calculated new Off- set from NTP core valid
Offset Adjustment Out	out			
OffsetAdjustment _DatOut	out	Clk_TimeAdjust- ment_Type	1	Calculated new Off- set after the PI Servo loop
OffsetAdjustment _ValOut	out	std_logic;	1	Calculated new Off- set after the PI Servo loop valid
Drift Adjustment Input				
DriftAdjustmentTod _DatIn	in	Clk_TimeAdjust- ment_Type	1	Calculated new Drift from TOD core
DriftAdjustmentTod _ValIn	in	std_logic	1	Calculated new Drift from TOD core valid
DriftAdjustmentIrig _DatIn	in	Clk_TimeAdjust- ment_Type	1	Calculated new Drift from IRIG core
DriftAdjustmentIrig _ValIn	in	std_logic	1	Calculated new Drift from IRIG core valid
DriftAdjustmentPps _DatIn	in	Clk_TimeAdjust- ment_Type	1	Calculated new Drift from PPS core
DriftAdjustmentPps _ValIn	in	std_logic	1	Calculated new Drift from PPS core valid



DriftAdjustmentPtp		Clk_TimeAdjust-	1	Calculated new Drift
_DatIn	in	ment_Type	I	from PTP core
DriftAdjustmentPtp		std logic	1	Calculated new Drift
_Valln	in	sta_logic	'	from PTP core valid
DriftAdjustmentRtc		Clk_TimeAdjust-	1	Calculated new Drift
_DatIn	in	ment_Type	'	from RTC core
DriftAdjustmentRtc	:	std logic	1	Calculated new Drift
_Valln	in	314_10910	'	from RTC core valid
DriftAdjustmentDcf	:	Clk_TimeAdjust-	1	Calculated new Drift
_DatIn	in	ment_Type	'	from DCF core
DriftAdjustmentDcf	: 15	std logic	1	Calculated new Drift
_Valln	in		'	from DCF core valid
DriftAdjustmentNtp	:	Clk_TimeAdjust-	1	Calculated new Drift
_DatIn	in	ment_Type	'	from NTP core
DriftAdjustmentNtp	in	std logic	1	Calculated new Drift
_Valln	111		'	from NTP core valid
Drift Adjustment Outpu	it			
DriftAdjustment		Clk_TimeAdjust-	1	Calculated new Drift
_DatOut	out	ment_Type	1	after the PI Servo
				loop
Drift A divistment				Calculated new Drift
DriftAdjustment _ValOut	out	std_logic;	1	after the PI Servo
				loop valid

Table 12: Clock



4.2 Design Parts

The Adjustable Counter Clock core consists of a couple of subcores. Each of the subcores itself consist again of smaller function block. The following chapters describe these subcores and their functionality.

4.2.1 Clock Selector

4.2.1.1 Entity Block Diagram




Figure 5: Clock Selector

4.2.1.2 Entity Description

Mux Selector

This module multiplexes multiple adjustment inputs. Only one adjustment is active at the time. This can be selected by a configuration register. PTP, PPS, TOD, IRIG, RTC, REG and EXT (where the selection is feed from externally) are potential sources. The multiplexer can also be set to disable any adjustment input.

4.2.1.3 Entity Declaration

Name	Dir	Туре	Size	Description
		Generics		
General				
ExtSelect_Gen	ı	boolean	1	If external selection of sync source is used
		Ports		
System				
SysClk_ClkIn	in	std_logic	1	System Clock
SysRstN_RstIn	in	std_logic	1	System Reset
Adjustment Selector Ing	out			



ExtSelect_DatIn	in	Clk_Select_Type	1	Which core shall be the source for the correction when Select_DatIn is external, this is feed from the outside
Select_DatIn	in	Clk_Select_Type	1	Which core shall be the source for the correction
Adjustment Selector Ou	utput			
Selected_DatOut	out	Clk_Select_Type	1	Which core was selected as the source for the correction
Time Adjustment Input				
TimeAdjustmentTod _DatIn	in	Clk_TimeAdjust- ment_Type	1	Calculated new Time from TOD core
TimeAdjustmentTod _ValIn	in	std_logic;	1	Calculated new Time from TOD core valid
TimeAdjustmentIrig _DatIn	in	Clk_TimeAdjust- ment_Type	1	Calculated new Time from IRIG core
TimeAdjustmentIrig _ValIn	in	std_logic;	1	Calculated new Time from IRIG core valid
TimeAdjustmentPps _DatIn	in	Clk_TimeAdjust- ment_Type	1	Calculated new Time from PPS core
TimeAdjustmentPps _ValIn	in	std_logic;	1	Calculated new Time from PPS core valid
TimeAdjustmentPtp _DatIn	in	Clk_TimeAdjust- ment_Type	1	Calculated new Time from PTP core
TimeAdjustmentPtp _ValIn	in	std_logic;	1	Calculated new Time from PTP core valid
TimeAdjustmentRtc _DatIn	in	Clk_TimeAdjust- ment_Type	1	Calculated new Time from RTC core



				Calculated new
TimeAdjustmentRtc	l in	std_logic;	1	Time from RTC core
_Valln	""			valid
		Clk_TimeAdjust-		Calculated new
TimeAdjustmentDcf DatIn	in	ment_Type	1	Time from DCF core
		THERE_TYPE		Calculated new
TimeAdjustmentDcf		std_logic;	1	Time from DCF core
_Valln	in	sta_logic,		valid
		CII. Time A divist		Calculated new
TimeAdjustmentNtp	in	Clk_TimeAdjust-	1	
_DatIn		ment_Type		Time from NTP core
TimeAdjustmentNtp			1	Calculated new
_Valln	in	std_logic;	1	Time from NTP core
				valid
TimeAdjustmentReg	l in	Clk_TimeAdjust-	1	Calculated new
_DatIn	111	ment_Type		Time from Registers
				Calculated new
TimeAdjustmentReg _ValIn	in	std_logic;	1	Time from Registers
vaiii1				valid
T' A I' I I O I				
Time Adjustment Outpo	ut		1	
	Jt 	Clk TimeAdjust-		Calculated new
Time Adjustment Outpo TimeAdjustment DatOut	out	Clk_TimeAdjust- ment Type	1	Time from the se-
TimeAdjustment		Clk_TimeAdjust- ment_Type	1	Time from the se- lected core
TimeAdjustment _DatOut			1	Time from the se-
TimeAdjustment _DatOut TimeAdjustment			1	Time from the se- lected core
TimeAdjustment _DatOut	out	ment_Type		Time from the selected core Calculated new
TimeAdjustment _DatOut TimeAdjustment	out	ment_Type std_logic;		Time from the selected core Calculated new Time from the selected core valid
TimeAdjustment _DatOut TimeAdjustment _ValOut Offset Adjustment Inpu OffsetAdjustmentTod	out out t	ment_Type std_logic; Clk_TimeAdjust-		Time from the selected core Calculated new Time from the selected core valid Calculated new Off-
TimeAdjustment _DatOut TimeAdjustment _ValOut Offset Adjustment Input	out	ment_Type std_logic;	1	Time from the selected core Calculated new Time from the selected core valid Calculated new Offset from TOD core
TimeAdjustment _DatOut TimeAdjustment _ValOut Offset Adjustment Inpu OffsetAdjustmentTod _DatIn	out out t	ment_Type std_logic; Clk_TimeAdjust- ment_Type	1	Time from the selected core Calculated new Time from the selected core valid Calculated new Offset from TOD core Calculated new Off-
TimeAdjustment _DatOut TimeAdjustment _ValOut Offset Adjustment Inpu OffsetAdjustmentTod _DatIn OffsetAdjustmentTod	out out t	ment_Type std_logic; Clk_TimeAdjust-	1	Time from the selected core Calculated new Time from the selected core valid Calculated new Offset from TOD core Calculated new Offset from TOD core
TimeAdjustment _DatOut TimeAdjustment _ValOut Offset Adjustment Inpu OffsetAdjustmentTod _DatIn	out out t in	ment_Type std_logic; Clk_TimeAdjust- ment_Type std_logic;	1	Time from the selected core Calculated new Time from the selected core valid Calculated new Offset from TOD core Calculated new Offset from TOD core valid
TimeAdjustment _DatOut TimeAdjustment _ValOut Offset Adjustment Inpu OffsetAdjustmentTod _DatIn OffsetAdjustmentTod	out out t in	ment_Type std_logic; Clk_TimeAdjust- ment_Type	1 1	Time from the selected core Calculated new Time from the selected core valid Calculated new Offset from TOD core Calculated new Offset from TOD core
TimeAdjustment _DatOut TimeAdjustment _ValOut Offset Adjustment Inpu OffsetAdjustmentTod _DatIn OffsetAdjustmentTod _ValIn	out out t in	ment_Type std_logic; Clk_TimeAdjust- ment_Type std_logic;	1	Time from the selected core Calculated new Time from the selected core valid Calculated new Offset from TOD core Calculated new Offset from TOD core valid
TimeAdjustment _DatOut TimeAdjustment _ValOut Offset Adjustment Inpu OffsetAdjustmentTod _DatIn OffsetAdjustmentTod _ValIn OffsetAdjustmentIrig _DatIn	out out t in	ment_Type std_logic; Clk_TimeAdjust- ment_Type std_logic; Clk_TimeAdjust-	1 1	Time from the selected core Calculated new Time from the selected core valid Calculated new Offset from TOD core Calculated new Offset from TOD core valid Calculated new Offset from TOD core valid
TimeAdjustment _DatOut TimeAdjustment _ValOut Offset Adjustment Input OffsetAdjustmentTod _DatIn OffsetAdjustmentTod _ValIn OffsetAdjustmentIrig _DatIn OffsetAdjustmentIrig _DatIn	out out t in	ment_Type std_logic; Clk_TimeAdjust- ment_Type std_logic; Clk_TimeAdjust-	1 1	Time from the selected core Calculated new Time from the selected core valid Calculated new Offset from TOD core Calculated new Offset from TOD core valid Calculated new Offset from TOD core valid Calculated new Offset from IRIG core
TimeAdjustment _DatOut TimeAdjustment _ValOut Offset Adjustment Inpu OffsetAdjustmentTod _DatIn OffsetAdjustmentTod _ValIn OffsetAdjustmentIrig _DatIn	out out t in in	ment_Type std_logic; Clk_TimeAdjust- ment_Type std_logic; Clk_TimeAdjust- ment_Type	1 1 1	Time from the selected core Calculated new Time from the selected core valid Calculated new Offset from TOD core Calculated new Offset from TOD core valid Calculated new Offset from IRIG core Calculated new Offset from IRIG core
TimeAdjustment _DatOut TimeAdjustment _ValOut Offset Adjustment Inpu OffsetAdjustmentTod _DatIn OffsetAdjustmentTod _ValIn OffsetAdjustmentIrig _DatIn OffsetAdjustmentIrig _DatIn	out out t in in	ment_Type std_logic; Clk_TimeAdjust- ment_Type std_logic; Clk_TimeAdjust- ment_Type	1 1 1	Time from the selected core Calculated new Time from the selected core valid Calculated new Offset from TOD core Calculated new Offset from TOD core valid Calculated new Offset from IRIG core Calculated new Offset from IRIG core Calculated new Offset from IRIG core
TimeAdjustment _DatOut TimeAdjustment _ValOut Offset Adjustment Input OffsetAdjustmentTod _DatIn OffsetAdjustmentTod _ValIn OffsetAdjustmentIrig _DatIn OffsetAdjustmentIrig _DatIn	out out t in in	ment_Type std_logic; Clk_TimeAdjust- ment_Type std_logic; Clk_TimeAdjust- ment_Type std_logic;	1 1 1	Time from the selected core Calculated new Time from the selected core valid Calculated new Offset from TOD core Calculated new Offset from TOD core valid Calculated new Offset from IRIG core Calculated new Offset from IRIG core Calculated new Offset from IRIG core valid



OffsetAdjustmentPps _ValIn	in	std_logic;	1	Calculated new Off- set from PPS core valid
OffsetAdjustmentPtp _DatIn	in	Clk_TimeAdjust- ment_Type	1	Calculated new Off- set from PTP core
OffsetAdjustmentPtp _ValIn	in	std_logic;	1	Calculated new Off- set from PTP core valid
OffsetAdjustmentRtc _DatIn	in	Clk_TimeAdjust- ment_Type	1	Calculated new Off- set from RTC core
OffsetAdjustmentRtc _ValIn	in	std_logic;	1	Calculated new Off- set from RTC core valid
OffsetAdjustmentDcf _DatIn	in	Clk_TimeAdjust- ment_Type	1	Calculated new Off- set from DCF core
OffsetAdjustmentDcf _ValIn	in	std_logic;	1	Calculated new Off- set from DCF core valid
OffsetAdjustmentNtp _DatIn	in	Clk_TimeAdjust- ment_Type	1	Calculated new Off- set from NTP core
OffsetAdjustmentNtp _ValIn	in	std_logic;	1	Calculated new Off- set from NTP core valid
OffsetAdjustmentReg _DatIn	in	Clk_TimeAdjust- ment_Type	1	Calculated new Off- set from Registers
OffsetAdjustmentReg _ValIn	in	std_logic;	1	Calculated new Off- set from Registers valid
Offset Adjustment Out	out			Calaulate Lange Off
OffsetAdjustment _DatOut	out	Clk_TimeAdjust- ment_Type	1	Calculated new Off- set from the se- lected core
OffsetAdjustment _ValOut	out	std_logic;	1	Calculated new Off- set from the se- lected core valid
Drift Adjustment Input				
DriftAdjustmentTod _DatIn	in	Clk_TimeAdjust- ment_Type	1	Calculated new Drift from TOD core



DriftAdjustmentTod _ValIn	in	std_logic	1	Calculated new Drift from TOD core valid
DriftAdjustmentIrig _DatIn	in	Clk_TimeAdjust- ment_Type	1	Calculated new Drift from IRIG core
DriftAdjustmentIrig _ValIn	in	std_logic	1	Calculated new Drift from IRIG core valid
DriftAdjustmentPps _DatIn	in	Clk_TimeAdjust- ment_Type	1	Calculated new Drift from PPS core
DriftAdjustmentPps _ValIn	in	std_logic	1	Calculated new Drift from PPS core valid
DriftAdjustmentPtp _DatIn	in	Clk_TimeAdjust- ment_Type	1	Calculated new Drift from PTP core
DriftAdjustmentPtp _ValIn	in	std_logic	1	Calculated new Drift from PTP core valid
DriftAdjustmentRtc _DatIn	in	Clk_TimeAdjust- ment_Type	1	Calculated new Drift from RTC core
DriftAdjustmentRtc _Valln	in	std_logic	1	Calculated new Drift from RTC core valid
DriftAdjustmentDcf _DatIn	in	Clk_TimeAdjust- ment_Type	1	Calculated new Drift from DCF core
DriftAdjustmentDcf _Valln	in	std_logic	1	Calculated new Drift from DCF core valid
DriftAdjustmentNtp _DatIn	in	Clk_TimeAdjust- ment_Type	1	Calculated new Drift from NTP core
DriftAdjustmentNtp _ValIn	in	std_logic	1	Calculated new Drift from NTP core valid
DriftAdjustmentReg _DatIn	in	Clk_TimeAdjust- ment_Type	1	Calculated new Drift from Registers
DriftAdjustmentReg _ValIn	in	std_logic	1	Calculated new Drift from Registers valid
Drift Adjustment Outpu	it			
DriftAdjustment _DatOut	out	Clk_TimeAdjust- ment_Type	1	Calculated new Drift from the selected core
DriftAdjustment _ValOut	out	std_logic;	1	Calculated new Drift from the selected core valid

Table 13: Clock Selector





4.2.2 Clock Adjuster

4.2.2.1 Entity Block Diagram




Figure 6: Clock Adjuster

4.2.2.2 Entity Description

PI Servo Loops

This module contains two individual PI Servo loops; one for the Drift and one for Offset correction. Both P and I can be configured individually for each servo loop. The drift is summed up since the corrected drift is only the change to the current frequency of the clock. All PI calculated values are also made available to the other IP cores to do the correct calculations based on the real adjustments.

The multiplications and divisions needed by the PI Servo are either binary multiplications and divisions or made with a fractional multiplier based on the Fractional-Multiply_Gen generic.

$$OffsetOut = OffsetIn * \frac{OffsetMulP_{Gen}}{OffsetDivP_{Gen}} + \int OffsetIn * \frac{OffsetMulI_{Gen}}{OffsetDivI_{Gen}}$$

$$DriftOut = OldDrift + (DriftIn * \frac{DriftMulP_{Gen}}{DriftDivP_{Gen}} + \int DriftIn * \frac{DriftMulI_{Gen}}{DriftDivI_{Gen}})$$

The following servo loop parameters are used per default in the reference designs:

Offset: 3/4 P, 3/16 I
Drift: 3/4 P, 3/16 I

The servo loop parameters can be changed at runtime if the FractionalMultiply_Gen and DynamicServoParameters_Gen generic are true and no static config is done. In this case the PI Mul and Div generics are only used as the default values. The servo paramteres schall only be changed when the core is disabled.



Counter Adjuster

This module takes the adjustment inputs and converts them into periodic small adjustments which are then set to the Counter Clock. E.g. a drift of 1ns per 1000ns is converted to a 1ns adjustment every 50 clock cycles at a frequency of 50MHz. For offset it works similar. E.g. 50ns shall be corrected in 2000ns which will be converted into 1ns every second clock cycle at 50MHz. The conversion of course also works for non-integer corrections with minimal error (1/- 1ns per correction cycle). In addition it supervises the adjustments ad sets an InSync flag if 4 consecutive offset corrections were below a configurable threshold, a hard set on the clock will cause immediate InSync deasertion.

4.2.2.3 Entity Declaration

Name	Dir	Туре	Size	Description		
Generics						
General ClockClkPeriodNano- second_Gen	-	natural	1	Clock Period in Na- nosecond If in Testbench sim-		
Sim_Gen	-	boolean	1	ulation mode		
Clock Adjuster				\/alva aftaulaav		
ClockInHoldover TimeoutSecond_Gen	-	natural	1	Value after how many seconds after in Sync without new correction values it goes in holdover Default 3 s		
BypassServo_Gen	-	boolean	1	Bypass PI Servo loops		
FractionalMultiply _Gen	-	boolean	1	Use a fractional multiplication (uses DSP slices) instead of binary multiplication and divisions (default)		



DynamicServo Parameters_Gen	-	boolean	1	Allow to change the PI Servo parameters at runtime
DriftMulP_Gen	-	natural	1	Drift Proportional part ratio Numera- tor
DriftDivP_Gen	-	natural	1	Drift Proportional part ratio Denumerator
DriftMull_Gen	-	natural	1	Drift Integral part ratio Numerator
DriftDivl_Gen	-	natural	1	Drift Integral part ratio Denumerator
OffsetMulP_Gen	-	natural	1	Offset Proportional part ratio Numerator
OffsetDivP_Gen	-	natural	1	Offset Proportional part ratio Denumerator
OffsetMull_Gen	-	natural	1	Offset Integral part ratio Numerator
OffsetDivl_Gen	-	natural	1	Offset Integral part ratio Denumerator
		Ports		
System SysClk_ClkIn	in	std_logic	1	System Clock
SysRstN_RstIn	in	std_logic	1	System Reset
Enable Input Enable_EnaIn	in	std_logic	1	Enable Correction
Time Input ClockTime_DatIn	in	Clk_Time_Type	1	Adjusted Clock Time
ClockTime_ValIn	in	std_logic	1	Adjusted Clock Time valid
Adjustment Selector Ing Selected_DatIn Servo Parameters Input	in	Clk_Select_Type	1	Which core was selected as the source for the correction



ServoOffset FactorP_DatIn	in	std_logic_vector	32	Fractional Multiplier Offset P
ServoOffset Factorl_DatIn	in	std_logic_vector	32	Fractional Multiplier Offset I
ServoDrift FactorP_DatIn	in	std_logic_vector	32	Fractional Multiplier Drift P
ServoDrift Factorl_DatIn	in	std_logic_vector	32	Fractional Multiplier Drift I
Servo_Valln	in	std_logic	1	New Parameters valid
InSync Threshold Input				When the clock is
InSync Threshold_DatIn	in	std_logic_vector	32	considered InSync in Nanoseconds
InSync Output				
InSync_DatOut	out	std_logic	1	Clock Adjustments were below the threshold for at least 4 adjustment cycles
InHoldover_DatOut	out	std_logic	1	No new Clock Adjustments after in Sync for a defined number of seconds
Time Adjustment Input	l		ı	
TimeAdjustment _DatIn	in	Clk_TimeAdjust- ment_Type	1	Calculated new Time from selected core
TimeAdjustment _Valln	in	std_logic;	1	Calculated new Time from selected core valid
Offset Adjustment Inpu	t		1	Calculated as Off
OffsetAdjustment _DatIn	in	Clk_TimeAdjust- ment_Type	1	Calculated new Off- set from selected core
OffsetAdjustment _ValIn	in	std_logic;	1	Calculated new Off- set from selected core valid
Offset Adjustment Outp	out			



OffsetAdjustment _DatOut	out	Clk_TimeAdjust- ment_Type	1	Calculated new Off- set after the PI Servo loop
OffsetAdjustment _ValOut	out	std_logic;	1	Calculated new Off- set after the PI Servo loop valid
Drift Adjustment Input				
DriftAdjustment _DatIn	in	Clk_TimeAdjust- ment_Type	1	Calculated new Drift from selected core
DriftAdjustment _Valln	in	std_logic	1	Calculated new Drift from selected core valid
Drift Adjustment Outpu	it	I	1	
DriftAdjustment _DatOut	out	Clk_TimeAdjust- ment_Type	1	Calculated new Drift after the PI Servo loop
DriftAdjustment _ValOut	out	std_logic;	1	Calculated new Drift after the PI Servo loop valid
				· '
Drift Adjustment Sum (Dutput			
Drift Adjustment Sum C DriftAdjustmentSum _DatOut	Output out	Clk_TimeAdjust- ment_Type	1	Calculated new Drift after the PI Servo loop as sum with old
DriftAdjustmentSum _DatOut DriftAdjustmentSum _ValOut	out	Clk_TimeAdjust-	1	Calculated new Drift after the PI Servo loop as sum with
DriftAdjustmentSum _DatOut DriftAdjustmentSum	out	Clk_TimeAdjust- ment_Type		Calculated new Drift after the PI Servo loop as sum with old Calculated new Drift after the PI Servo loop as sum with old
DriftAdjustmentSum _DatOut DriftAdjustmentSum _ValOut	out	Clk_TimeAdjust- ment_Type		Calculated new Drift after the PI Servo loop as sum with old Calculated new Drift after the PI Servo loop as sum with old Calculated new Time from selected core to clock
DriftAdjustmentSum _DatOut DriftAdjustmentSum _ValOut Time Adjustment Output TimeAdjustment	out out out	Clk_TimeAdjust- ment_Type std_logic; Clk_TimeAdjust-	1	Calculated new Drift after the PI Servo loop as sum with old Calculated new Drift after the PI Servo loop as sum with old Calculated new Time from selected



				after PI servo and
				conversion to clock
				Calculated new
				counter adjustment
CountAdjust-	out	std_logic; 1	1	after PI servo and
ment_ValOut				conversion to clock
				valid

Table 14: Clock Adjuster



4.2.3 Clock Counter

4.2.3.1 Entity Block Diagram




Figure 7: Clock Counter

4.2.3.2 Entity Description

Counter Clock

This is the adjustable counter clock with nanosecond resolution in a 32 bit second and 32 bit nanosecond format. It can take any input frequency, also non integer values with fractions. It normally adds the clock period to the nanoseconds counter every clock cycle but can add or subtract some extra nanosecond to do the clock adjustment. It also has an overwrite mode where the clock can be set. When the nanosecond counter overflows to the next second the second counter is incremented and the increment is added to the nanosecond part and a billion subtracted to keep the remainder. If fractions are used, every clock cycle the fraction numerator is summed up and when reaching the denominator value an extra nanosecond is added. The time domain is TAI, so after every reset the clock starts from 1.1.1970 at midnight which represents second 0.

4.2.3.3 Entity Declaration

Name	Dir	Туре	Size	Description
		Generics		
Clock COunter				
ClockClkPeriodNano- second_Gen	-	natural	1	Clock Period in Na- nosecond
ClockClkPeriodFract- Num_Gen	-	natural	1	Fractional Clock Period Numerator (0 if integer)
ClockClkPeriod- FractDeNum_Gen	-	natural	1	Fractional Clock Period Denumerator (O if integer)
		Ports		



System				
SysClk_ClkIn	in	std_logic	1	System Clock
SysRstN_RstIn	in	std_logic	1	System Reset
Time Output				
ClockTime_DatOut	out	Clk_Time_Type	1	Adjusted Clock Time
ClockTime_ValOut	out	std_logic	1	Adjusted Clock Time valid
Time Adjustment Input				
TimeAdjustment _Dat	in	Clk_TimeAdjust- ment_Type	1	Overwrite Time
TimeAdjustment _Val	in	std_logic;	1	Overwrite Time valid
Counter Adjustment Inp	out			
CountAdjust- ment_DatIn	in	Clk_Count Adjustment_Type	1	Calculated new counter adjustment after PI servo and conversion to clock
CountAdjust- ment_ValIn	in	std_logic;	1	Calculated new counter adjustment after PI servo and conversion to clock valid, make correc- tion

Table 15: Clock Counter



4.2.4 Clock Timer

4.2.4.1 Entity Block Diagram




Figure 8: Clock Timer

4.2.4.2 Entity Description

1 Millisecond Timer

This module creates a single clock cycle pulse every millisecond aligned with the adjusted counter clock. This pulse is used by all NetTimeLogic's IP cores to calculate timeouts etc. If the counter clock makes a jump in time this can lead to a loss of a pulse or two pulses next to each other.

4.2.4.3 Entity Declaration

Name	Dir	Туре	Size	Description		
Generics						
General						
ClockClkPeriodNano-	_	 natural	1	Clock Period in Na-		
second_Gen		riatarai	'	nosecond		
Clock Adjuster						
TimerIntervalNano-				Timer Interval be-		
second_Gen	-	natural	1	tween two events in		
second_Gen				Nanosecond		
		Ports				
System						
SysClk_ClkIn	in	std_logic	1	System Clock		
SysRstN_RstIn	in	std_logic	1	System Reset		
Time Input						
Clastitions Datin	in	Clk_Time_Type	1	Adjusted Clock		
ClockTime_DatIn	1111	CIK_TITIE_TYPE	'	Time		
	in	std logic	1	Adjusted Clock		
ClockTime_ValIn	in	std_logic		Time valid		
Timer Output		1		1		



Timer_EvtOut	out	std_logic	1	Single clock cycle event every interval aligned with the ad- justed clock
--------------	-----	-----------	---	--

Table 16: Timer



4.2.5 Registerset

4.2.5.1 Entity Block Diagram




Figure 9: Registerset

4.2.5.2 Entity Description

Register Set

This module is an AXI4Lite Memory Mapped Slave. It provides access to all Registers and allows configuring the Adjustable Counter Clock. AXI4Lite only supports 32 bit wide data access, no byte enables, no burst, no simultaneous read and writes and no unaligned access. It can be configured to either run in AXI or StaticConfig mode. If in StaticConfig mode, the configuration of the Datasets is done via signals and can be easily done from within the FPGA without CPU. For each parameter a valid signal is available, the enable signal shall be set last (or simultaneously). To change parameters the clock has to be disabled and enabled again. If in AXI mode, an AXI Master has to configure the Datasets with AXI writes to the registers, which is typically done by a CPU. Parameters can in this case also be changed at runtime. For status supervision, similar to the static configuration the static status signals are available which allows to use the values also directly from within the FPGA without CPU.

4.2.5.3 Entity Declaration

Name	Dir	Туре	Size	Description	
Generics					
Register Set					
ClockInSyncNanosec- ond_Gen	-	natural	1	Default value for the threshold when the	



				clock is considered
				in sync
CtaticConfic Con		haalaan	1	If Static Configura-
StaticConfig_Gen	_	boolean	I	tion or AXI is used
				If external selection
ExtSelect_Gen	-	boolean	1	of sync source is
				used
LogCorrections_Gen	_	boolean	1	Log corrections to
2090011000010110_0011		8 9 9 1 9 9 1 9	·	registers
BypassServo_Gen	1	boolean	1	Bypass PI Servo
				loops
				Use a fractional mul-
				tiplication (uses DSP
FractionalMultiply	-	boolean	1	slices) instead of bi-
_Gen				nary multiplication
				and divisions (de-
				fault)
DynamicServo			1	Allow to change the
Parameters_Gen	-	boolean	1	PI Servo parameters
				at runtime
DriftMulD Con			1	Drift Proportional
DriftMulP_Gen	_	natural	1	part ratio Numera-
				tor Drift Proportional
DriftDivP_Gen		natural	1	part ratio Denumer-
DIIItDIVF_Gen		Haturai		ator
				Drift Integral part
DriftMull_Gen	-	natural	1	ratio Numerator
				Drift Integral part
DriftDivl_Gen	-	natural	1	ratio Denumerator
				Offset Proportional
OffsetMulP_Gen	-	natural	1	part ratio Numera-
				tor
				Offset Proportional
OffsetDivP_Gen	-	natural	1	part ratio Denumer-
				ator
Official Mulli Com		natural	1	Offset Integral part
OffsetMull_Gen	-	natural		ratio Numerator
		l	1	



OffsetDivl_Gen	-	natural	1	Offset Integral part ratio Denumerator
AxiAddressRange Low_Gen	-	std_logic_vector	32	AXI Base Address
AxiAddressRange High_Gen	-	std_logic_vector	32	AXI Base Address plus Registerset Size
		Ports		
System			1	Contain Charle
SysClk_ClkIn	in	std_logic	1	System Clock
SysRstN_RstIn	in	std_logic	1	System Reset
Config StaticConfig_DatIn	in	Clk_Clock StaticConfig_Type	1	Static Configuration
StaticConfig_ValIn	in	Clk_Clock StaticConfigVal _Type	1	Static Configuration valid
Status		Cll. Clask		Chatia Chatus
StaticStatus_DatOut	out	Clk_Clock StaticStatus_Type	1	Static Status
StaticStatus_ValOut	out	Clk_Clock StaticStatusVal _Type	1	Static Status valid
In Sync Input				
InSync_DatIn	in	std_logic	1	InSync flag
InHoldover_DatIn	in	std_logic	1	InHoldover flag
Time Input ClockTime_DatIn	in	Clk_Time_Type	1	Adjusted Clock Time
ClockTime_ValIn	in	std_logic	1	Adjusted Clock Time valid
AXI4 Lite Slave AxiWriteAddrValid _ValIn	in	std_logic	1	Write Address Valid
AxiWriteAddrReady _RdyOut	out	std_logic	1	Write Address Ready
AxiWriteAddrAddress AdrIn	in	std_logic_vector	32	Write Address
AxiWriteAddrProt _DatIn	in	std_logic_vector	3	Write Address Pro- tocol



AxiWriteDataValid	in	std_logic	1	Write Data Valid				
ValIn AxiWriteDataReady	out	std_logic	1	Write Data Ready				
_RdyOut AxiWriteDataData	in	std_logic_vector	32	Write Data				
_DatIn AxiWriteDataStrobe	in	std_logic_vector	4	Write Data Strobe				
_DatIn AxiWriteRespValid	out	std_logic	1	Write Response				
_ValOut				Valid Write Response				
AxiWriteRespReady _RdyIn	in	std_logic	1	Ready				
AxiWriteResp Response_DatOut	out	std_logic_vector	2	Write Response				
AxiReadAddrValid _ValIn	in	std_logic	1	Read Address Valid				
AxiReadAddrReady _RdyOut	out	std_logic	1	Read Address Ready				
AxiReadAddrAddress AdrIn	in	std_logic_vector	32	Read Address				
AxiReadAddrProt _DatIn	in	std_logic_vector	3	Read Address Pro- tocol				
AxiReadDataValid ValOut	out	std_logic	1	Read Data Valid				
AxiReadDataReady RdyIn	in	std_logic	1	Read Data Ready				
AxiReadData Response_DatOut	out	std_logic_vector	2	Read Data				
AxiReadDataData _DatOut	out	std_logic_vector	32	Read Data Response				
InSync Threshold Outpo	ut							
InSync Threshold_DatOut	out	std_logic_vector	32	When the clock is considered InSync in Nanoseconds				
Adjustment Selector Ou	Adjustment Selector Output							
Select_DatOut	out	Clk_Select_Type	1	Which core shall be the source for the correction				
Servo Parameters Output								
ServoOffset FactorP_DatOut	out	std_logic_vector	32	Fractional Multiplier Offset P				
ServoOffset Factorl_DatOut	out	std_logic_vector	32	Fractional Multiplier Offset I				
ServoDrift FactorP_DatOut	out	std_logic_vector	32	Fractional Multiplier Drift P				



ServoDrift Factorl_DatOut	out	std_logic_vector	32	Fractional Multiplier Drift I				
Servo_ValOut	out	std_logic	1	New Parameters valid				
Adjustment Selector Input								
Selected_DatIn	in	Clk_Select_Type	1	Which core was selected as the source for the correction				
Offset Adjustment Inpu	t							
OffsetAdjustment _DatIn	in	Clk_TimeAdjust- ment_Type	1	Calculated new Off- set from selected core				
OffsetAdjustment _ValIn	in	std_logic;	1	Calculated new Off- set from selected core valid				
Drift Adjustment Input	ı		Ī					
DriftAdjustment _DatIn	in	Clk_TimeAdjust- ment_Type	1	Calculated new Drift from selected core				
DriftAdjustment _Valln	in	std_logic	1	Calculated new Drift from selected core valid				
Time Adjustment Outpu	Time Adjustment Output							
TimeAdjustment _DatOut	out	Clk_TimeAdjust- ment_Type	1	New Time to set				
TimeAdjustment _ValOut	out	std_logic;	1	New Time to set valid				
Offset Adjustment Out	out							
OffsetAdjustment _DatOut	out	Clk_TimeAdjust- ment_Type	1	New Offset				
OffsetAdjustment _ValOut _Prift Adjustment Outpu	out	std_logic;	1	New Offset valid				
Drift Adjustment Outpu		Clk_TimeAdjust-		New Drift				
DriftAdjustment _DatOut	out	ment_Type	1					
DriftAdjustment _ValOut	out	std_logic;	1	New Drift valid				
Enable Output ClockEnable_DatOut	out	std_logic	1	Enable Adjustable Counter Clock				

Table 17: Registerset



4.3 Configuration example

In both cases the enabling of the core shall be done last, after or together with the configuration.

4.3.1 Static Configuration

```
constant ClkStaticConfig Con : Clk ClockStaticConfig Type := (
  TimeAdjustment
                                 => Clk_TimeAdjustment_Type_Rst_Con,
  OffsetAdjustment
                                 => Clk TimeAdjustment Type Rst Con,
                                 => Clk TimeAdjustment Type Rst Con,
  DriftAdjustment
  ClockSelect
                                 => Clk Select Tod Con,
                                 => x"000001F4" - +/- 500 ns
  InSyncThreshold
);
constant ClkStaticConfigVal Con : Clk ClockStaticConfigVal Type := (
  Enable Val
                                 => '1',
 TimeAdjustment Val
                                 => '0',
 OffsetAdjustment Val
                                 => '0',
  DriftAdjustment Val
                                 => '0'
);
```

Figure 10: Static Configuration

The ClockSelect and InSyncThreshold should be set before enabling, but can also be changed when enabled. TimeAdjustment, DriftAdjustment and OffsetAdjustment can only be set once the clock is enabled and only have an effect if ClockSelect is set to REG.

4.3.2 AXI Configuration

The following code is a simplified pseudocode from the testbench: The base address of the Clock is 0x10000000.

```
-- CLOCK
-- Config
-- select: REG
AXI WRITE 10000008 00000006
-- enable adjustable counter clock
AXI WRITE 10000000 00000001
-- set time: 97000000 nanoseconds
AXI WRITE 10000020 39D10680
-- set time: 2 seconds
AXI WRITE 10000024 00000002
-- set valid bits
AXI WRITE 10000000 00000003
-- select: TOD
AXI WRITE 10000008 00000001
-- in sync threshold: 500 ns
AXI WRITE 10000050 000001F4
```



Figure 11: AXI Configuration

The Clock Select and In Sync Threshold registers should be set before enabling but can also be changed when enabled. Time, Drift and Offset can only be set once the clock is enabled and only have an effect if Clock Select is set to REG. In the example the time is set first 2.97 seconds via register and then the TOD core selected for further adjustments.



4.4 Clocking and Reset Concept

4.4.1 Clocking

To keep the design as robust and simple as possible, the whole Ordinary Clock, including the Counter Clock and all other cores from NetTimeLogic are run in one clock domain. This is considered to be the system clock. Per default this clock is 50MHz. Where possible also the interfaces are run synchronous to this clock. For clock domain crossing asynchronous fifos with gray counters or message patterns with meat stability flip-flops are used. Clock domain crossings for the AXI interface is moved from the AXI slave to the AXI interconnect.

Clock	Frequency	Description		
System				
System Clock	50MHz (Default)	System clock where the CC runs on as well as the counter clock etc.		
AXI Interface	(Deladit)	well as the counter clock etc.		
AXI Clock	50MHz	Internal AXI bus clock, same as the sys-		
	(Default)	tem clock		

Table 18: Clocks

4.4.2Reset

In connection with the clocks, there is a reset signal for each clock domain. All resets are active low. All resets can be asynchronously set and shall be synchronously released with the corresponding clock domain. All resets shall be asserted for the first couple (around 8) clock cycles. All resets shall be set simultaneously and released simultaneously to avoid overflow conditions in the core. See the reference designs top file for an example of how the reset shall be handled.

Reset	Polarity	Description
System		
System Reset	Active low	Asynchronous set, synchronous release with the system clock
AXI Interface		



	Active low	Asynchronous set, synchronous release	
AXI Reset		with the AXI clock, which is the same as	
		the system clock	

Table 19: Resets



5 Resource Usage

Since the FPGA Architecture between vendors and FPGA families differ there is a split up into the two major FPGA vendors.

5.1 Intel/Altera (Cyclone V)

Configuration	FFs	LUTs	BRAMs	DSPs
Minimal (No PI Servo)	1868	3846	0	0
Maximal (With PI Servo)	3093	6484	0	0

Table 20: Resource Usage Intel/Altera

5.2 AMD/Xilinx (Artix 7)

Configuration	FFs	LUTs	BRAMs	DSPs
Minimal (No Pl Servo)	1872	3878	0	0
Maximal (With PI Servo)	3094	6744	0	0

Table 21: Resource Usage AMD/Xilinx



6 Delivery Structure

AXI -- AXI library folder

CLK -- CLK library folder -- CLK library cores

|-Doc -- CLK library cores documentations

|-Driver -- CLK library driver

|-Library -- CLK library component sources |-Package -- CLK library package sources

|-Refdesign -- CLK library cores reference designs

|-Testbench -- CLK library cores testbench sources and sim/log

COMMON -- COMMON library folder

PPS -- PPS library folder

SIM -- SIM library folder

|-Testbench -- SIM library testbench template sources



7 Testbench

The Clock testbench consist of 1 parse/port type: AXI.

For configuration and result checks an AXI read and write port is used. The time can be written and read back.




Figure 12: Testbench Framework

For more information on the testbench framework check the Sim_ReferenceManual documentation.

With the Sim parameter set the time base for timeouts are divided by 1000 to 100000 to speed up simulation time.

7.1 Run Testbench

 Run the general script first source XXX/SIM/Tools/source_with_args.tcl

2. Start the testbench with all test cases src XXX/CLK/Testbench/Core/ClkClock/Script/run Clk Clock Tb.tcl

3. Check the log file LogFile1.txt in the XXX/CLK/Testbench/Core/ClkClock/Log/folder for simulation results.



8 Reference Designs

The Adjustable Counter Clock reference design contains a PLL to generate all necessary clocks (cores are run at 50 MHz) and an instance of the Adjustable Counter Clock IP core. Optionally it also contains an instance of a PPS Master Clock IP core (has to be purchased separately). To instantiate the optional IP core, change the corresponding generic (PpsMasterAvailable_Gen) to true via the tool specific wizards.

The Reference Design is intended to run just standalone, show the instantiation and generate a PPS output. The PPS Master Clock is used to create a PPS output which is compensated for the output delay and has a configurable duty cycle, if not available an uncompensated PPS is directly generated out of the MSB of the Time. All generics can be adapted to the specific needs.




Figure 13: Reference Design

8.1 Intel/Altera: Terasic SocKit

The SocKit board is an FPGA board from Terasic Inc. with a Cyclone V SoC FPGA from Intel/Altera. (http://www.terasic.com.tw/cgi-bin/page/archive.pl?Language=English&CategoryNo=205&No=816)

- 1. Open Quartus 16.x
- 2. Open Project /CLK/Refdesign/Altera/SocKit/ClkClock/ClkClock.qpf
- 3. If the optional core PPS Master Clock is available add the files from the corresponding folders (PPS/Core, PPS/Library and PPS/Package)
- 4. Change the generics (PpsMasterAvailable_Gen) in Quartus (in the settings menu, not in VHDL) to true for the optional cores that are available.
- 5. Rerun implementation
- 6. Download to FPGA via JTAG






Figure 14: SocKit (source Terasic Inc)

For the ports on the HSMC connector the GPIO to HSMC adapter from Terasic Inc. was used.

8.2 AMD/Xilinx: Digilent Arty

The Arty board is an FPGA board from Digilent Inc. with an Artix7 FPGA from AMD/Xilinx. (http://store.digilentinc.com/arty-board-artix-7-fpga-development-board-for-makers-and-hobbyists/

- 1. Open Vivado 2019.1.
 - Note: If a different Vivado version is used, see chapter 8.3.
- 2. Run TCL script /CLK/Refdesign/Xilinx/Arty/ClkClock/ClkClock.tcl
 - a. This has to be run only the first time and will create a new Vivado Proiect
- 3. If the project has been created before open the project and do not rerun the project TCL
- 4. If the optional core PPS Master Clock is available add the files from the corresponding folders (PPS/Core, PPS/Library and PPS/Package) to the corresponding Library (PpsLib).



- 5. Change the generics (PpsMasterAvailable_Gen) in Vivado (in the settings menu, not in VHDL) to true for the optional cores that are available.
- 6. Rerun implementation
- 7. Download to FPGA via JTAG




Figure 15: Arty (source Digilent Inc)

8.3 AMD/Xilinx: Vivado version

The provided TCL script for creation of the reference-design project is targeting AMD/Xilinx Vivado 2019.1.

If a lower Vivado version is used, it is recommended to upgrade to Vivado 2019.1 or higher.

If a higher Vivado version is used, the following steps are recommended:

- Before executing the project creation TCL script, the script's references of Vivado 2019 should be manually replaced to the current Vivado version. For example, if version Vivado 2022 is used, then:
 - The statement occurrences:
 - set_property flow "Vivado Synthesis 2019" \$obj
 shall be replaced by:
 - set_property flow "Vivado Synthesis 2022 \$obj
 - The statement occurrences:
 set property flow "Vivado Implementation 2019" \$obj



shall be replaced by:

set property flow "Vivado Implementation 2022" \$obj

- After executing the project creation TCL script, the AMD/Xilinx IP cores, such as the Clocking Wizard core, might be locked and a version upgrade might be required. To do so:
 - 1. At "Reports" menu, select "Report IP Status".
 - 2. At the opened "IP Status" window, select "Upgrade Selected". The tool will upgrade the version of the selected IP cores.



A List of tables

Table 1:	Revision History	4
Table 2:	Definitions	7
Table 3:	Abbreviations	7
Table 4:	Parameters	39
Table 5:	Clk_Time_Type	39
Table 6:	Clk_TimeAdjustment_Type	40
Table 7:	Clk_CoreInfo_Type	40
Table 8:	Clk_ClockStaticConfig_Type	41
Table 9:	Clk_ClockStaticConfigVal_Type	41
Table 10:	Clk_ClockStaticStatus_Type	41
Table 11:	Clk_ClockStaticStatusVal_Type	42
Table 12:	Clock	50
Table 13:	Clock Selector	55
Table 14:	Clock Adjuster	62
Table 15:	Clock Counter	64
Table 16:	Timer	66
Table 17:	Registerset	71
Table 18:	Clocks	74
Table 19:	Resets	75
Table 20:	Resource Usage Intel/Altera	76
Table 21:	Resource Usage AMD/Xilinx	76
B List	of figures	
Figure 1:	Context Block Diagram	8
Figure 2:	Architecture Block Diagram	10
Figure 3:	Counter Clock	12
Figure 4:	Adjustable Counter Clock	42
Figure 5:	Clock Selector	51
Figure 6:	Clock Adjuster	57
Figure 7:	Clock Counter	63
Figure 8:	Clock Timer	65
Figure 9:	Registerset	67
Figure 10:	Static Configuration	72
Figure 11:	AXI Configuration	73
Figure 12:	Testbench Framework	78



Figure 13:	Reference Design	. 79
Figure 14:	SocKit (source Terasic Inc)	.80
Figure 15:	Arty (source Digilent Inc)	81