COOKWARE ACCESSORIES · AVAILABLE TO LICENSE

Pan Click

It clicks when your pan is ready.



Heating
Disc sits flat.

Ready
Dome pops up with a click.

65%
of US adults are concerned about PFAS in non-stick pans (Consumer Reports, 2025)

2025
Minnesota became the first US state to ban PFAS in cookware

The problem

- Cooks are leaving traditional non-stick for stainless steel and ceramic.
- Stainless sticks unless it's properly preheated. Ceramic loses its slickness when overheated.
- The only guide is flicking water into the pan and watching how it behaves.

How it works

- A coin-sized stainless disc sits in the pan while it heats.
- Inside is a bimetal snap disc, the part that switches off a kettle.
- At the set temperature the dome pops up with a click and shows its colour.
- It resets as it cools. No batteries.

Why license it

- Works with pans people already own.
- Two versions: "ready" for stainless, "too hot" for ceramic.
- Suits a thermometer or gadget range, or boxed with a pan.
- A demonstration anyone understands: one egg sticks, one slides.

Aaron Steele, inventor