

Power Transformer Protection Philosophy

Differential, REF, Overcurrent, Overfluxing, Inrush Management, and Coordinated Protection Layers

Prepared, reviewed, and issued by CESC

Website publication edition

Executive abstract

This white paper explains how a complete transformer protection philosophy should be structured across primary, backup, and abnormal-condition functions for grid stations and industrial substations. It retains the standard CESC publication structure while extending the technical content with practical engineering calculation examples, setting checks, and coordination notes that engineers can apply during design review, relay setting development, and project execution.

Document basis

Document type	Technical white paper
Primary basis	IEC 60255-187-1, IEC 60255-149, IEC 61869-2, IEC 60909, IEC 60076 series
Intended audience	Utilities, EPC contractors, industrial asset owners, and engineering teams
Publication note	Prepared in formal issuer style to demonstrate CESC engineering capability in studies, protection, digital integration, retrofit, and asset management.

Applicable references

Reference	Application in this paper
IEC 60255-187-1	Differential protection functional requirements context.
IEC 60255-149	Thermal and electrical relay function context for overload and overfluxing related functions.
IEC 61869-2	Current-transformer application basis.
IEC 60909	Short-circuit duty and study basis context.
IEC 60076 series	Transformer design, operation, insulation, temperature rise, and abnormal operating context.

Protection philosophy overview

A transformer should never rely on one function alone. Differential protection addresses internal phase faults, REF addresses earth faults near the neutral zone with high sensitivity, overcurrent and earth-fault functions provide graded backup, and overfluxing, temperature, pressure, Buchholz, and sudden pressure functions address abnormal operating conditions.

The strength of the design lies in coordination between these layers and in the correct application of CTs, VTs, vector-group compensation, and trip logic. A sound philosophy therefore combines equipment characteristics, network fault studies, relay functionality, and practical commissioning considerations rather than copying generic catalogue settings.

Main protection layers

Differential protection is normally the principal electrical protection for internal winding faults. Stability under through-fault conditions depends on CT performance, ratio compensation, vector-group treatment, tap range effect, and harmonic restraint or equivalent inrush security logic.

Restricted earth fault provides faster and more sensitive earth-fault coverage within the protected winding zone and is especially valuable on grounded-wye windings where low-level internal earth faults may not produce sufficient differential current for rapid main differential pickup.

Backup overcurrent and earth-fault protection must be graded with adjacent system protection and should not be set so aggressively that load security, transformer energization security, or feeder coordination is weakened.

Engineering calculation examples

The following simplified examples are included to make the white paper more practical. Final settings must always be confirmed against the project fault study, transformer data sheet, CT performance, and relay manufacturer implementation details.

1. Full-load current check

Example transformer: 25 MVA, 132/33 kV, ONAN/ONAF, vector group YNyn0. Three-phase rated current is checked from $I = S / (\sqrt{3} \times V)$.

HV side current: $I_{HV} = 25,000 \text{ kVA} / (1.732 \times 132 \text{ kV}) = \text{about } 109.4 \text{ A}$. LV side current: $I_{LV} = 25,000 \text{ kVA} / (1.732 \times 33 \text{ kV}) = \text{about } 437.4 \text{ A}$.

These values provide the first screening check for CT ratio selection, continuous thermal relay loading, and the reasonableness of pickup settings used in differential restraint, thermal overload, and backup overcurrent functions.

2. CT ratio reasonableness and differential balance

Assume HV CT ratio 150/1 A and LV CT ratio 500/1 A. At rated transformer load, the relay sees approximately $109.4/150 = 0.729 \text{ pu}$ of 1 A on the HV side and $437.4/500 = 0.875 \text{ pu}$ of 1 A on the LV side before relay vector and ratio compensation. The relay compensation must normalize the mismatch created by winding ratio and CT selections.

A practical engineering check is that expected standing spill current after relay compensation should remain comfortably below stage-1 differential pickup under normal loading, tap variation, and CT error. Where OLTC range is significant, the engineer should evaluate whether load current at extreme tap positions could produce a higher standing bias current and adjust slope and pickup accordingly.

3. Through-fault exposure and slope concept

Suppose the maximum external fault current on the 33 kV side from the short-circuit study is 12 kA. With a 500/1 A CT, this corresponds to about 24 A secondary through current. Under such events one CT may saturate earlier than the opposite side CT. Differential slope is therefore not arbitrary; it is the stability margin against unequal CT reproduction during high through faults.

For example, if worst-case spill current from CT saturation and mismatch assessment is estimated at 0.35 A secondary during an external fault, stage-1 pickup must remain above this value with adequate margin, while stage-2 or higher restraint region must remain secure at the corresponding bias current. This is why transformer differential settings cannot be finalized without short-circuit levels and CT class review.

4. REF sensitivity illustration

Assume the neutral CT and phase CTs are all 500/1 A and the minimum internal earth fault near neutral is estimated to produce only 600 A primary. The relay secondary operating quantity is then about $600/500 = 1.2 \text{ A}$, subject to spill path and stabilizing logic. A REF element with pickup around 0.15 to 0.25 A can therefore detect an internal earth fault that may be too low for dependable fast operation by the main differential element.

In practice, the engineer must also confirm neutral grounding arrangement, CT polarity, lead resistance, and stability for external earth faults. The message is that REF is not redundant; it materially improves sensitivity for winding earth faults inside the protected zone.

5. Overfluxing check using V/f

Overfluxing supervision is linked to the volts-per-hertz ratio. A simplified index is V/f. If a transformer designed for 132 kV at 50 Hz experiences 145 kV at 47.5 Hz, then V/f ratio relative to rated becomes $(145/47.5) / (132/50) = 1.157$, or about 115.7% of rated fluxing.

This simplified check immediately shows why prolonged operation at depressed frequency combined with elevated voltage can become more severe than a simple overvoltage event at nominal frequency. Protection philosophy should therefore define alarm and trip regions in line with transformer withstand capability and utility operating practice.

6. Backup overcurrent coordination check

Assume transformer LV full-load current is 437.4 A and downstream feeder protection clears maximum feeder faults in 0.35 s at the relevant current level. A transformer backup overcurrent element may, for example, be set above maximum continuous and permissible overload conditions while maintaining grading margin above downstream clearing. The exact margin depends on relay family, breaker interrupting time, and utility practice, but the engineering principle is clear: backup protection must support, not compete with, feeder protection.

This check is often overlooked in generic schemes. CESC philosophy is to verify both current and time grading against the actual downstream protection schedule and not to rely on nominal catalogue recommendations only.

Abnormal conditions and non-electrical protection

A complete philosophy also includes winding and oil temperature, pressure relief, Buchholz where applicable, oil level alarms, cooling failure, and OLTC alarms or trip criteria if monitored separately.

Good engineering practice is to document which functions alarm only, which functions trip instantly, and which functions trip with time delay or only under specific operating states. This trip matrix should be approved together with the cause-and-effect logic and SCADA indications before factory testing and site energization.

In brownfield projects, additional engineering attention is required for existing CT ratios, legacy wiring constraints, DC system limitations, and the need to preserve selectivity with installed upstream and downstream schemes.

Practical implementation notes

Protection philosophy should be tied to a clear relay function list, single-line diagram, CT/VT schedule, and trip matrix. The philosophy document becomes much more useful when each function is linked to purpose, operating criteria, alarm/trip action, and required interlocks.

Commissioning should include secondary injection, logic checks, inrush security verification where practical, CT polarity confirmation, REF zone confirmation, and end-to-end review of annunciation and trip paths. Site energization risk is materially reduced when philosophy, settings, and commissioning documentation are developed as one coordinated package.

For industrial substations and utility grid stations alike, the most common avoidable weaknesses are insufficient CT review, unverified differential compensation assumptions, poor grading with downstream feeders, and incomplete alarm/trip segregation for non-electrical transformer protections.

CESC engineering value added

CESC adds value by turning a generic protection narrative into a project-specific engineering package. This includes transformer protection philosophy, relay function allocation, CT and VT adequacy review, differential and REF applicability checks, backup grading strategy, trip matrix development, and interface definition with control, annunciation, SCADA, and disturbance recording systems.

CESC also supports practical execution by linking study outputs with implementable settings logic, factory and site test philosophy, retrofit constraints, and brownfield risk management. This is particularly valuable where utilities and EPC teams require a document that is technically defensible, construction-aware, and suitable for review by client engineers, consultants, and relay vendors.

Conclusion

A complete transformer protection philosophy is not only a list of relay functions. It is a coordinated engineering framework that links transformer characteristics, network studies, instrument transformer behaviour, abnormal operating conditions, trip logic, and field implementation requirements.

These website papers are structured to demonstrate how CESC approaches engineering subjects at system level, not only at equipment catalogue level. The intended message to clients is that CESC can define studies, design criteria, scheme architecture, implementation strategy, testing approach, and brownfield execution method across protection, control, digital integration, retrofit, and asset management scopes.