



RS manual

Table of contents

- How to use activation key?
- How to share network license?


How to use activation key?

First install SLP distributor.




Ps:
TCP port 2468 is for server and administration.
Which computer need to install the license.

How to use activation key?



It will open SLP distributor, a website.



How to use activation key?(Auto)

→ SLP Distributor for ABB

Add

To activate a new license, please enter an activation code.

Please ensure that the key is issued for a Distributor license.

Activation Key

[History](#) [Manual Activation](#)

This step is for administrator, not for student.

Enter your key and submit, it should be 25 words.(xxxxx-x....x-xxxxx)

PS:

After you submit the key, license would generate expire date.

Choose wisely the computer which you install license,
It is more complicate to remove the license to another computer.

If the key is correct, you would see this.

→ SLP Distributor for ABB

[Home](#) [Activation](#) [Products](#) [Usage](#) [Named Users](#)

Successfully installed a license for activation key [REDACTED].

Add

To activate a new license, please enter an activation code.

Please ensure that the key is issued for a Distributor license.

Activation Key

[History](#) [Manual Activation](#)

How to use activation key?(Manual)

→ SLP Distributor for ABB

Add

To activate a new license, please enter an activation code.

Please ensure that the key is issued for a Distributor license.

Activation Key

History [Manual Activation](#)

→ SLP Distributor for ABB

Choose wisely the computer which you install license,
It is more complicate to remove the license to another computer.

Generate Activation Request

Please enter an activation key.

Activation Key

Request Data

Install License

Please select a license file to install

No file chosen

The different of auto and manual are computer need to connect internet or not.
If auto install is succeed, then you don't need to use manual activation.

How to use activation key?(Manual)

→ SLP Distributor for ABB

If the key is correct, the request data would be generate.

A Manual Activation Request has been generated.

Generate Activation Request

Please enter an activation key.

Activation Key

Request Data

--BEGIN-REQUEST--
[Redacted]
--END-
REQUEST--

The format like this.

Install License

Please select a license file to install

No file chosen



Downloads

 2024-07-29_04-...
[Open file](#)

[See more](#)

Your activation key

How to use activation key?(Manual)



Rename the file to request.licreqx

How to use activation key?(Manual)

Go to <http://manualactivation.e.abb.com/>

The screenshot shows the ABB Manual Activation website on the left and a Windows File Explorer on the right. The website has a red ABB logo and a section titled "Manual product activation" with a list of 7 steps. A red box highlights the "Browse..." button under the "License Request File" section. A red arrow points from this button to the "request.licreqx" file in the File Explorer. The File Explorer shows a list of files, with "request.licreqx" (Text Document, 1 KB) highlighted. Below the File Explorer, a file upload dialog is open, showing the filename "request.licreqx" and the "Open" button highlighted with a red box.

Manual product activation

To perform a manual activation:

1. Select manual activation from the product on your computer
2. Store the License Request File where it is accessible for the product activation page
3. Upload the License Request File below
4. Press "Submit" to submit the License Request File to the activation service
5. The service will now process the License Request File and on completion will return a License File
6. Download the License File to your computer
7. Follow the information in your product on how to install the downloaded License File

The recommended procedure is to activate the product automatically over the internet (more information can be found in the product).

License Request File

Upload file

File Explorer:

File Name	Date Modified	File Type	Size
request.licreqx	7/29/2024 4:08 PM	Text Document	1 KB
RobotStudio_2024.2.1	7/29/2024 3:28 PM	Compressed (zipp...)	1,402,885 KB
RobotStudio_2024.2.1	7/29/2024 3:30 PM	File folder	
pycharm-professional-2023.2	8/18/2023 2:25 PM	Application	526,987 KB

File Upload Dialog:

File name: request.licreqx

File type: All files

Footer:

POPULAR LINKS: RobotStudio

ABB WEBSITES: Main page news

FOLLOW US: Facebook

How to use activation key?(Manual)

ion X ABB Manual Activation X +
e | https://manualactivation.e.abb.com

ABB

Manual product activation

To perform a manual activation:

1. Select manual activation from the product on your computer
2. Store the License Request File where it is accessible for the product activation page
3. Upload the License Request File below
4. Press "Submit" to submit the License Request File to the activation service
5. The service will now process the License Request File and on completion will return a License File
6. Download the License File to your computer
7. Follow the information in your product on how to install the downloaded License File

The recommended procedure is to activate the product automatically over the internet (more information can be found in the product).

License Request File

request.licreqx.txt

☐ 下載完成後不再顯示

POPULAR LINKS
RobotStudio

ABB WEBSITES
Main page news

FOLLOW US
Facebook

You would get a .bin file.

→ **SLP Distributor for ABB**

Generate Activation Request

Please enter an activation key.

Activation Key

Request Data

Install License

Please select a license file to install

No file chosen

9b63b6bd-19...46d7e5d0.bin

Upload .bin file

How to use activation key?(Manual)

Generate Activation Request

Please enter an activation key.

Activation Key

Request Data

Submit

Save File

Install License

Please select a license file to install

Choose File No file chosen

Install

Successfully installed a license.

If dashboard can see the product means license is in this computer.

SLP Distributor for ABB

Dashboard

Products

RobotStudio, 7.x. [Details](#) [Usage](#)]


SLP Distributor for ABB

Product details for RobotStudio, 7.x


[Hide licenses](#)
Licenses

Evaluation	Renewable	Expires	State	Activation Key	Revision	Distributor	Seat Based	Checkout Allowed	Requires Named Users	Detail
No	No	2025/7/23 上午 02:15:05	Valid		1	Yes	No	Yes	No	Less
Feature Limits										
Name		Concurrent Usage	Total Usage	Working Time	Expires					
Execute		100	-	-	2025/7/23 上午 02:15:05					
Premium		-	-	-	2025/7/23 上午 02:15:05					
SchoolEdition		-	-	-	2025/7/23 上午 02:15:05					

How to share network license?



How to share network license?



How to share network license?

RobotStudio License Server

Enter the host name or IP address of the server that manages your network licence keys

⑥ Enter 127.0.0.1 this is local IP connect to SLP

License server: 127.0.0.1

Open the server dashboard The server dashboard allows you to activate a network license key and monitor license usage.

⑦

Help Cancel < Back **Finish**

RobotStudio

You must restart RobotStudio to apply changes.
Do you want to restart now?

⑧

Yes No

Options

Licensing

You can see your license is updated.

License Management

✓ **RobotStudio license activated**
Expires 7/23/2025
View all information about licenses or activate a new RobotStudio license

Activate RobotStudio License **View Licenses**

Licenses

Installed licenses

Feature	Type	Expires	Status	Activation Key
Premium	Network	7/23/2025	Valid	
3D Printing PowerPac	Network	7/23/2025	Valid	
Arc Weld PowerPac	Network	7/23/2025	Valid	
Cutting PowerPac	Network	7/23/2025	Valid	
Dispensing PowerPac	Network	7/23/2025	Valid	
Machine Tending PowerPac	Network	7/23/2025	Valid	
Machine Tending PowerPac II	Network	7/23/2025	Valid	
Machining PowerPac	Network	7/23/2025	Valid	
Painting PowerPac	Network	7/23/2025	Valid	
Palletizing PowerPac	Network	7/23/2025	Valid	
Picking PowerPac	Network	7/23/2025	Valid	
PickMaster PowerPac	Network	7/23/2025	Valid	
Remote Laser Welding Power...	Network	7/23/2025	Valid	
Premium	Trial	8/18/2024	Valid	2AA7T-EPKNS-NYU3J-5KSJA-ESX39
3D Printing PowerPac	Trial	8/18/2024	Valid	2AA7T-EPKNS-NYU3J-5KSJA-ESX39
Arc Weld PowerPac	Trial	8/18/2024	Valid	2AA7T-EPKNS-NYU3J-5KSJA-ESX39
CATIA V5 Converter	Trial	8/18/2024	Valid	2AA7T-EPKNS-NYU3J-5KSJA-ESX39

Remove expired licenses... Close

How to share network license?

→ SLP Distributor for ABB

Home Activation Products Usage Named Users

Current usage of RobotStudio, 7.x

Total resources: 100

Allocated to	Remaining	Details
DESKTOP-OA5H8BS	89d 9h	Less
Leased Features		
Machine	Remaining	Features
DESKTOP-OA5H8BS	89d 9h	Execute,Premium,SchoolEdition
DESKTOP-3VBABJ4	1m 17s	Less
Leased Features		
User	Remaining	Features
user@DESKTOP-3VBABJ4	1m 17s	SchoolEdition

Resources available: 98

This is commuter license which is checked out.

← Server host