Lab 04: APR Practice

Requirement

1. Download lab04_soce_lab.tar.gz and decompress it. In case you didn't know how to do, here is the command:

   `tar -zxvf lab04_soce_lab.tar.gz`

2. Take a look at README and scan through the folders.

3. Perform the APR of the given design example by following the tutorial of Block Level APR Flow with SOC Encounter.

4. You should summarize the APR result in your report.

Submission of Lab Assignment due on Dec 18th, 2016 at 11:59PM

➔ Submit your code with a summary report.

➔ Make a demo scheduled by our TAs.