Course Contents

Unit-01: Introduction to Microprocessor

Unit-02: Intel 8085

Unit-03: Microoperations

Unit-04: Control Unit and Central Processing Unit

Unit-05: Fixed point Computer Arithmetic

Unit-06: Input and Output Organization

Unit-07: Memory Organization

Unit-08: Pipelining

Course Contents

Unit-03: Microoperations

Arithmetic Microoperations, Logic Microoperations, Shift Microoperations, Arithmetic Logic Shift Unit

Unit 3	Micro Operations	3 Hours
3.1	Arithmetic Micro Operations: Addition, Subtraction, Increment, Decrement, Hardware Implementation	1 Hour
3.2	Logic Micro Operations: AND, OR, NOT,NAND,NOR,XOR, Selective Set, Set(preset), selective Complement(toggling), Insert, Hardware Implementation	1 Hour
3.3	Shift Micro Operations: Logical, Circular and Arithmetic, Arithmetic Logic Shift Unit	1 Hour

Course Contents

Unit-03: Microoperations

- Register Transfer Language: Micro-operation, Register Transfer Language, Register Transfer, Control Function
- Arithmetic Micro Operations: Addition, Subtraction, Increment, Decrement, Hardware Implementation
- Logic Micro Operations: AND, OR, NOT, NAND, NOR, XOR, Selective Set, Set(preset), Selective Complement (toggling), Insert, Hardware Implementation
- Shift Micro Operations: Logical, Circular and Arithmetic, Arithmetic Logic Shift Unit

Microoperation:

- A digital system is an interconnection of digital hardware modules that accomplish a specific information-processing task.
- Digital systems are modular in nature, with modules containing registers, decoders, arithmetic elements, control logic, etc.
- These digital components are defined by the registers that they contain and the operations performed on their data. These operations are called microoperations.
- Microoperations are elementary operations performed on the information stored in one or more registers.
- The result of the operation may replace the previous binary of a register or may be transferred to another register. Examples of microoperations introduced are shift, count, clear load etc.

Microoperation:

> Examples of microoperations

TAI	TABLE 4-3 Arithmetic Microoperations				
Symbolic designation	Description				
$R3 \leftarrow R1 + R2$ $R3 \leftarrow R1 - R2$ $R2 \leftarrow \overline{R2}$ $R2 \leftarrow \overline{R2} + 1$ $R3 \leftarrow R1 + \overline{R2} + 1$ $R1 \leftarrow R1 + 1$ $R1 \leftarrow R1 - 1$	Contents of R1 plus R2 transferred to R3 Contents of R1 minus R2 transferred to R3 Complement the contents of R2 (1's complement) 2's complement the contents of R2 (negate) R1 plus the 2's complement of R2 (subtraction) Increment the contents of R1 by one Decrement the contents of R1 by one				

TABLE 4-7 Shift Microoperations				
Symbolic designation	Description			
$R \leftarrow \text{shl } R$ $R \leftarrow \text{shr } R$ $R \leftarrow \text{cil } R$ $R \leftarrow \text{cir } R$ $R \leftarrow \text{ashl } R$ $R \leftarrow \text{ashr } R$	Shift-left register R Shift-right register R Circular shift-left register R Circular shift-right register R Arithmetic shift-left R Arithmetic shift-right R			

Sixteen Logic Microoperations			
Microoperation	Name		
<i>F</i> ←0	Clear		
$F \leftarrow A \land B$	AND		
$F \leftarrow A \wedge \overline{B}$			
$F \leftarrow A$	Transfer A		
$F \leftarrow \overline{A} \wedge B$			
$F \leftarrow B$	Transfer B		
$F \leftarrow A \oplus B$	Exclusive-OR		
$F \leftarrow A \lor B$	OR		
$F \leftarrow \overline{A \vee B}$	NOR		
$F \leftarrow \overline{A \oplus B}$	Exclusive-NOR		
$F \leftarrow \overline{B}$	Complement B		
$F \leftarrow A \vee \overline{B}$	•		
$F \leftarrow \overline{A}$	Complement A		
$F \leftarrow \overline{A} \vee B$.		
$F \leftarrow \overline{A \wedge B}$	NAND		
$F \leftarrow \text{all 1's}$	Set to all 1's		

Hardware Organization:

The hardware organization of a digital computer is best defined by specifying:

- > The set of register that it contains and their function.
- The sequence of microoperations performed on the binary information stored in the registers.
- The control signals that initiate the sequence of microoperations.

Register Transfer Language:


- The Register Transfer Language is the symbolic representation of notations used to specify the sequence of micro-operations.
- In a computer system, data transfer takes place between <u>processor</u> registers and memory and between <u>processor</u> registers and inputoutput systems.
- It is possible to specify the sequence of microoperations in a computer by explaining every operation in words, but this procedure usually involves a lengthy descriptive explanation. It is more convenient to adopt a suitable symbology to describe the sequence of transfers between registers and the various arithmetic and logic microoperations associated with the transfers. The use of symbols instead of a narrative explanation provides an organized and concise manner for listing the microoperation sequences in registers and the control functions that initiate them.

Register Transfer Language:

- The symbolic notation used to describe the microoperation transfers among registers is called a register transfer language.
- The term "register transfer" implies the availability of hardware logic circuits that can perform a stated microoperation and transfer the result of the operation to the same or another register.

Example of RTL: Control Function

P: R2 ← R1



Register Transfer:

Registers are denoted by capital letters and are sometimes followed by numerals, e.g.,


- MAR Memory Address Register (holds addresses for the memory unit)
- PC Program Counter (holds the next instruction's address)
- IR Instruction Register (holds the instruction being executed)
- R1 Register1 (a CPU register)

We can indicate individual bits by placing them in parentheses, e.g.,

PC(8-15), R2(5), etc

Register Transfer:

a) Block Diagrams of Registers



b) Register Transfer Language Instructions:

Register Transfer

Simultaneous Transfer

Conditional Transfer (Control Function)

P: R2
$$\leftarrow$$
 R1 or If (P = 1) Then R2 \leftarrow R1


Conditional, Simultaneous Transfer

T:
$$R2 \leftarrow R1$$
, $R1 \leftarrow R2$

Basic Symbols for Register Transfer:

Symbol	Description	Examples
Letters (and numerals)	Denotes a register	MAR, R2
Parentheses ()	Denotes a part of a register	R2(0-7), R2(L)
Arrow →	Denotes Transfer of information	R2 ← R1
Comma ,	Separates 2 microoperations	$R2 \leftarrow R1, R1 \leftarrow R1$

Register Transfer and Hardware:



Bus and Memory Transfers:

The Bus

- A bus is a set of common wires that carries data between registers.
 - There is a separate wire for every bit in the registers.
 - There are also a set of control signals which determines which register is selected by the bus at a particular time.
- A bus can be constructed using multiplexer which enable a set of registers to share a common bus for data transfer.

Memory Transfer:

- There are two primary operations involving memory:
 - Read transferring data from memory
 - Write transferring data into memory
- ➤ To indicate in Register Transfer Language that we are moving data from a memory address to the data register, we write:

Read: DR ← M[AR]

This causes a transfer of information into DR from the memory word M selected by the address in AR.

To indicate in RTL that we are moving data from Register1 to a memory location, we write:

Write: M[AR] ← R1

Register Transfer Language: Micro-operations

Microoperations are classified into four categories:

- Register transfer microoperations (data moves from register to register)
- Arithmetic microoperations (perform arithmetic on data in registers)
- Logic microoperations (perform bit manipulation on data in registers)
- Shift microoperations (perform shift on data in registers)

Arithmetic Microoperations:

2.2 Arithmetic Microoperations: List of Arithmetic Microoperations, Binary Adder, Binary Adder-Subtractor, Binary Incrementer, Arithmetic Circuit

Arithmetic Microoperations:

Unlike register transfer microoperations, arithmetic microoperations change the information content.

The basic arithmetic microoperations are:

- addition
- subtraction
- > increment
- > decrement
- > shift

The write operation transfers the content of a data register to a memory word M selected by the address.

Arithmetic Microoperations:

- Assume that the input data are in register R1.
- \triangleright $\overline{R2}$ is the symbol for the 1's complement of R2.
- Adding 1 to the 1's complement produces the 2's complement.
- Adding the contents of R 1 to the 2's complement of R2 is equivalent to R1 R2.

$$R3 \leftarrow R1 + \overline{R2} + 1$$

Arithmetic Microoperations:

TABLE 4-3 Arithmetic Microoperations				
Symbolic designation	Description			
$R3 \leftarrow R1 + R2$ $R3 \leftarrow R1 - R2$ $R2 \leftarrow \overline{R2}$ $R2 \leftarrow \overline{R2} + 1$ $R3 \leftarrow R1 + \overline{R2} + 1$ $R1 \leftarrow R1 + 1$ $R1 \leftarrow R1 - 1$	Contents of R1 plus R2 transferred to R3 Contents of R1 minus R2 transferred to R3 Complement the contents of R2 (1's complement) 2's complement the contents of R2 (negate) R1 plus the 2's complement of R2 (subtraction) Increment the contents of R1 by one Decrement the contents of R1 by one			

Multiplication and division are not considered microoperations.

- Multiplication is implemented by a sequence of adds and shifts.
- Division is implemented by a sequence of substracts and shifts.

Logic Microoperations:

2.3 Logic Microoperations: List of Logic Microoperations, Hardware Implementation, Applications of Logic Microoperations.

Logic Microoperations:

Logic microoperations are binary operations performed on corresponding bits of two-bit strings. These operations consider each bit of the register separately and treat them as binary variables. For example, the exclusive-OR microoperation with the contents of two registers R1 and R2 is symbolized by the statement

```
    Example: P: R1 ← R1 ⊕ R2
    1010 Content of R1
    1100 Content of R2
    0110 Content of R1 after P = 1
```

Special Symbols used for logic operations:

 \wedge - AND \vee - OR \oplus - XOR and $\overline{R2}$

This avoids confusing AND with multiplication, OR with addition, etc.

Logic Microoperations: Special symbols

The + symbol has two meanings, it will be possible to distinguish between them by noting where the symbol occurs. When the symbol + occurs in a microoperation, it will denote an arithmetic plus. When it occurs in a control (or Boolean) function, it will denote an OR operation.

For example, in the statement

 $P + Q: R1 \leftarrow R2 + R3, R4 \leftarrow R5 V R6$

the + between P and Q is an OR operation between two binary variables of a control function. The + between R2 and R3 specifies an add microoperation. The OR microoperation is designated by the symbol V between registers R5 and R6.

Logic Microoperations: List of Logic Microoperations

	TABLE 4-5 Truth Tables for 16 Functions of Two Variables																
x	у	F ₀	<i>F</i> ₁	F ₂	<i>F</i> ₃	F ₄	<i>F</i> ₅	<i>F</i> ₆	F ₇	<i>F</i> ₈	F ₉	F ₁₀	F ₁₁	F ₁₂	F ₁₃	F ₁₄	F ₁₅
0	0	0	0	0	0	0	0	0	0	1	1	1	1	1 1 0	1	1	1
0	1	0	0	0	0	1	1	1	1	0	0	0	0	1	1	1	1
1	0	0	0	1	1	0	0	1	1	0	0	1	1	0	0	1	1
1	1	0	1	0	1	0	1	0	1	0	1	0	1	0	1	0	1

There are 16 different logic operations that can be performed with two binary variables. They can be determined from all possible truth tables obtained with two binary variables as shown in Table 4-5. The 16 Boolean functions of two variables x and y are expressed in algebraic form in the first column of Table 4-6.

$\mathbf{x} =$	0011
y =	0101
$F_{\mathbf{X}} =$	(Boolean Function)

TABLE 4-6 Sixteen Logic Microoperations				
Boolean function	Microoperation	Name		
$F_0 = 0$	<i>F</i> ←0	Clear		
$F_1 = xy$	$F \leftarrow A \land B$	AND		
$F_2 = xy'$	$F \leftarrow A \wedge \overline{B}$			
$F_3 = x$	$F \leftarrow A$	Transfer A		
$F_4 = x'y$	$F \leftarrow \overline{A} \wedge B$			
$F_5 = y$	$F \leftarrow B$	Transfer B		
$F_6 = x \oplus y$	$F \leftarrow A \oplus B$	Exclusive-OR		
$F_7 = x + y$	$F \leftarrow A \lor B$	OR		
$F_8 = (x + y)'$	$F \leftarrow \overline{A \vee B}$	NOR		
$F_9 = (x \oplus y)'$	$F \leftarrow \overline{A \oplus B}$	Exclusive-NOR		
$F_{10}=y'$	$F \leftarrow \overline{B}$	Complement B		
$F_{11}=x+y'$	$F \leftarrow A \vee \overline{B}$	-		
$F_{12}=x'$	$F \leftarrow \overline{A}$	Complement A		
$F_{13}=x'+y$	$F \leftarrow \overline{A} \lor B$	-		
$F_{14}=(xy)'$	$F \leftarrow \overline{A \wedge B}$	NAND		
$F_{15}=1$	$F \leftarrow \text{all 1's}$	Set to all 1's		

Shift Microoperations:

2.4 Shift Microoperations: Logical Shift, Circular shift, Arithmetic Shift, Hardware Implementation of Shifter.

TABLE 4-7 Shift Microoperations				
Symbolic designation	Description			
$R \leftarrow \text{shl } R$ $R \leftarrow \text{shr } R$ $R \leftarrow \text{cil } R$ $R \leftarrow \text{cir } R$ $R \leftarrow \text{ashl } R$ $R \leftarrow \text{ashr } R$	Shift-left register R Shift-right register R Circular shift-left register R Circular shift-right register R Arithmetic shift-left R Arithmetic shift-right R			

Shift Microoperations:

- Shift microoperations are used for serial transfer of data. They are also used in conjunction with arithmetic, logic, and other dataprocessing operations.
- The contents of a register can be shifted to the left or the right. At the same time that the bits are shifted, the first flip-flop receives its binary information from the serial input. During a shift-left operation the serial input transfers a bit into the rightmost position. During a shift-right operation the serial input transfers a bit into the leftmost position.
- The information transferred through the serial input determines the type of shift.
- There are three types of shifts:
 - 1. logical, 2. circular, 3. arithmetic

Shift Microoperations:

There are three types of shifts:

- 1. Logical shift microoperations
 - a. Logical shift-left
 - b. Logical shift-right
- 2. Circular shift microoperations
 - a. Circular shift-left
 - b. Circular shift-right
- 3. Arithmetic shift microoperations
 - a. Arithmetic shift-left
 - b. Arithmetic shift-right


TABLE 4-7	Shift Microoperations
Symbolic designation	Description
$R \leftarrow \text{shl } R$ $R \leftarrow \text{shr } R$ $R \leftarrow \text{cil } R$ $R \leftarrow \text{cir } R$ $R \leftarrow \text{ashl } R$ $R \leftarrow \text{ashr } R$	Shift-left register R Shift-right register R Circular shift-left register R Circular shift-right register R Arithmetic shift-left R Arithmetic shift-right R

Shift Microoperations:


R1 ← shl R1 R2 ← shr R2

TABLE 4-7 Shift Microoperations				
Symbolic designation	Description			
$R \leftarrow \text{shl } R$ $R \leftarrow \text{shr } R$ $R \leftarrow \text{cil } R$ $R \leftarrow \text{cir } R$ $R \leftarrow \text{cir } R$ $R \leftarrow \text{ashl } R$ $R \leftarrow \text{ashr } R$	Shift-left register R Shift-right register R Circular shift-left register R Circular shift-right register R Arithmetic shift-left R Arithmetic shift-right R			


Logical shift-left Microoperations:




Logical shift-right Microoperations:



Circular left shift Microoperations:



Circular right shift Microoperations:



Arithmetic shift Microoperations:


An arithmetic shift is a microoperation that shifts a signed binary number to the left or right. An arithmetic shift-left multiplies a signed binary number by 2. An arithmetic shift-right divides the number by 2. Arithmetic shifts must leave the sign bit unchanged because the sign of the number remains the same when it is multiplied or divided by 2. The leftmost bit in a register holds the sign bit, and the remaining bits hold the number.

 Arithmetic Shift Left Microoperations: Every bit gets shifted towards left. The left most bit (MSB) represents the sign hence it doesn't participate in shifting process normally.

Ex.1-

 $R1 \leftarrow 14$ $R1 \leftarrow Ashl(R1)$

Here register R1 gets a decimal value 14. We can express it in not more than 4 bits. But we better is to use a relatively larger register. We'll use a 6-bit register.




After shifting here we get: (011100)₂ which is equal to (28)₁₀

Ex.2-

$$R1 \leftarrow -14$$

 $R1 \leftarrow Ashl (R1)$

Here register R1 gets a decimal value (-14). We'll calculate 2's compliment of (+14) and then we'll shift it.




After shifting here we get: (100100), which is already in 2's compliment and equal to (-28).

Arithmetic Shift Right Microoperation

Every bit gets shifted towards right. The right most bit (LSB) gets lost and the sign bit is copied to the MSB-1 position. Again in this case, the sign bit remains the same.

```
R1 \leftarrow 13
 R1 \leftarrow Ashr (R1)
```

Here register R1 gets a decimal value 13. Again we'll use a relatively larger 6-bit register.




After shifting here we get: (000110)2

In Decimal which is: $(6)_{10} OR \{ 13 / 2 \}$

$$R1 \leftarrow -13$$

 $R1 \leftarrow Ashr (R1)$

Here register R1 gets a decimal value (-13). We'll calculate 2's compliment of (+13) and then we'll shift it.



After shifting here we get: $(111001)_2$ which is already in 2's compliment and equal to (-7).

NOTE: Every negative number is taken already in 2's compliment representation.