Assignment report Lesson 2

*** Qemu emulator support the versatilepb platform that contains arm926ej-s core**

*** UART0 → the first serial port that works as a terminal in adders 0x101f1000.**

*** UARTDR →used a transmit when writing in the register and receiver when reading bytes placed in 0x0**

1- C Cood (app.c , uart.c , uart.h)

* uart.c →



* uart.h →



* app.c →



2- startup



3- linker script



4- object-files (app.o , uart.o ,startup.o)

MINGW32:/h/Lesson_2

```
Abotaleb@DESKTOP-RBI99BO MINGW32 /h/Lesson_2
$ export PATH=../ARM/bin/:$PATH

Abotaleb@DESKTOP-RBI99BO MINGW32 /h/Lesson_2
$ arm-none-eabi-gcc.exe -c -g -I . -mcpu=arm926ej-s app.c -o app.o

Abotaleb@DESKTOP-RBI99BO MINGW32 /h/Lesson_2
$ arm-none-eabi-gcc.exe -c -g -I . -mcpu=arm926ej-s uart.c -o uart.o

Abotaleb@DESKTOP-RBI99BO MINGW32 /h/Lesson_2
$ arm-none-eabi-as.exe -g  -mcpu=arm926ej-s startup.s -o startup.0
startup.s: Assembler messages:
startup.s: Warning: end of file not at end of a line; newline inserted
```

5-bin utilities(objdump[-h→section headers , -D → disassemble])

***app.o with debug**

```
Abotaleb@DESKTOP-RBI99BO MINGW32 /h/Lesson_2
$ arm-none-eabi-objdump.exe -h app.o

app.o:     file format elf32-littlearm

Sections:
Idx Name          Size      VMA       LMA       File off  Algn
  0 .text         0000001c  00000000  00000000  00000034  2**2
                  CONTENTS, ALLOC, LOAD, RELOC, READONLY, CODE
  1 .data         00000064  00000000  00000000  00000050  2**2
                  CONTENTS, ALLOC, LOAD, DATA
  2 .bss          00000000  00000000  00000000  000000b4  2**0
                  ALLOC
  3 .rodata       00000064  00000000  00000000  000000b4  2**2
                  CONTENTS, ALLOC, LOAD, READONLY, DATA
  4 .debug_info   00000091  00000000  00000000  00000118  2**0
                  CONTENTS, RELOC, READONLY, DEBUGGING
  5 .debug_abbrev 00000061  00000000  00000000  000001a9  2**0
                  CONTENTS, READONLY, DEBUGGING
  6 .debug_aranges 00000020  00000000  00000000  0000020a  2**0
                  CONTENTS, RELOC, READONLY, DEBUGGING
  7 .debug_line   00000035  00000000  00000000  0000022a  2**0
                  CONTENTS, RELOC, READONLY, DEBUGGING
  8 .debug_str    000000ac  00000000  00000000  0000025f  2**0
                  CONTENTS, READONLY, DEBUGGING
  9 .comment      0000007f  00000000  00000000  0000030b  2**0
                  CONTENTS, READONLY
 10 .debug_frame  0000002c  00000000  00000000  0000038c  2**2
                  CONTENTS, RELOC, READONLY, DEBUGGING
 11 .ARM.attributes 00000032  00000000  00000000  000003b8  2**0
                  CONTENTS, READONLY
```

*** app.o without debug**

MINGW32:/h/Lesson_2

```
$

Abotaleb@DESKTOP-RBI99BO MINGW32 /h/Lesson_2
$ arm-none-eabi-objdump.exe -h app.o

app.o:     file format elf32-littlearm

Sections:
Idx Name          Size      VMA       LMA       File off  Algn
  0 .text         00000018  00000000  00000000  00000034  2**2
                  CONTENTS, ALLOC, LOAD, RELOC, READONLY, CODE
  1 .data         00000064  00000000  00000000  0000004c  2**2
                  CONTENTS, ALLOC, LOAD, DATA
  2 .bss          00000000  00000000  00000000  000000b0  2**0
                  ALLOC
  3 .rodata       00000064  00000000  00000000  000000b0  2**2
                  CONTENTS, ALLOC, LOAD, READONLY, DATA
  4 .comment      00000012  00000000  00000000  00000114  2**0
                  CONTENTS, READONLY
  5 .ARM.attributes 00000032  00000000  00000000  00000126  2**0
                  CONTENTS, READONLY

Abotaleb@DESKTOP-RBI99BO MINGW32 /h/Lesson_2
$
```

*** uart.o with debug**

*** uart.o without debug**

```
Abotaleb@DESKTOP-RBI99BO MINGW32 /h/Lesson_2
$ arm-none-eabi-objdump.exe -h uart.o

uart.o:     file format elf32-littlearm

Sections:
Idx Name          Size      VMA       LMA       File off  Algn
  0 .text         00000054  00000000  00000000  00000034  2**2
                  CONTENTS, ALLOC, LOAD, READONLY, CODE
  1 .data         00000000  00000000  00000000  00000088  2**0
                  CONTENTS, ALLOC, LOAD, DATA
  2 .bss          00000000  00000000  00000000  00000088  2**0
                  ALLOC
  3 .debug_info   00000057  00000000  00000000  00000088  2**0
                  CONTENTS, RELOC, READONLY, DEBUGGING
  4 .debug_abbrev 00000051  00000000  00000000  000000df  2**0
                  CONTENTS, READONLY, DEBUGGING
  5 .debug_aranges 00000020  00000000  00000000  00000130  2**0
                  CONTENTS, RELOC, READONLY, DEBUGGING
  6 .debug_line   00000039  00000000  00000000  00000150  2**0
                  CONTENTS, RELOC, READONLY, DEBUGGING
  7 .debug_str    0000009b  00000000  00000000  00000189  2**0
                  CONTENTS, READONLY, DEBUGGING
  8 .comment      0000007f  00000000  00000000  00000224  2**0
                  CONTENTS, READONLY
  9 .debug_frame  00000030  00000000  00000000  000002a4  2**2
                  CONTENTS, RELOC, READONLY, DEBUGGING
 10 .ARM.attributes 00000032  00000000  00000000  000002d4  2**0
                  CONTENTS, READONLY
```

MINGW32:/h/Lesson_2

```
Abotaleb@DESKTOP-RBI99BO MINGW32 /h/Lesson_2
$ arm-none-eabi-gcc.exe -c -I . -mcpu=arm926ej-s uart.c -o uart.o

Abotaleb@DESKTOP-RBI99BO MINGW32 /h/Lesson_2
$ arm-none-eabi-objdump.exe -h uart.o

uart.o:     file format elf32-littlearm

Sections:
Idx Name          Size      VMA       LMA       File off  Algn
  0 .text         00000050  00000000  00000000  00000034  2**2
                  CONTENTS, ALLOC, LOAD, READONLY, CODE
  1 .data         00000000  00000000  00000000  00000084  2**0
                  CONTENTS, ALLOC, LOAD, DATA
  2 .bss          00000000  00000000  00000000  00000084  2**0
                  ALLOC
  3 .comment      00000012  00000000  00000000  00000084  2**0
                  CONTENTS, READONLY
  4 .ARM.attributes 00000032  00000000  00000000  00000096  2**0
                  CONTENTS, READONLY

Abotaleb@DESKTOP-RBI99BO MINGW32 /h/Lesson_2
$
```

* startup.o with debug

* startup.o without debug

```
botaleb@DESKTOP-RBI99BO MINGW32 /h/Lesson_2
 arm-none-eabi-objdump.exe -h startup.o

tartup.o:     file format elf32-littlearm

ections:
dx Name          Size      VMA       LMA       File off  Algn
 0 .text         00000010  00000000  00000000  00000034  2**2
                 CONTENTS, ALLOC, LOAD, RELOC, READONLY, CODE
 1 .data         00000000  00000000  00000000  00000044  2**0
                 CONTENTS, ALLOC, LOAD, DATA
 2 .bss          00000000  00000000  00000000  00000044  2**0
                 ALLOC
 3 .debug_line   0000003a  00000000  00000000  00000044  2**0
                 CONTENTS, RELOC, READONLY, DEBUGGING
 4 .debug_info   00000026  00000000  00000000  0000007e  2**0
                 CONTENTS, RELOC, READONLY, DEBUGGING
 5 .debug_abbrev 00000014  00000000  00000000  000000a4  2**0
                 CONTENTS, READONLY, DEBUGGING
 6 .debug_aranges 00000020  00000000  00000000  000000b8  2**3
                 CONTENTS, RELOC, READONLY, DEBUGGING
 7 .debug_str    00000025  00000000  00000000  000000d8  2**0
                 CONTENTS, READONLY, DEBUGGING
 8 .ARM.attributes 00000022  00000000  00000000  000000fd  2**0
                 CONTENTS, READONLY

botaleb@DESKTOP-RBI99BO MINGW32 /h/Lesson_2
```

MINGW32:/h/Lesson_2

```
Abotaleb@DESKTOP-RBI99BO MINGW32 /h/Lesson_2
$ arm-none-eabi-as.exe -mcpu=arm926ej-s startup.s -o startup.o
startup.s: Assembler messages:
startup.s: Warning: end of file not at end of a line; newline inserted

Abotaleb@DESKTOP-RBI99BO MINGW32 /h/Lesson_2
$ arm-none-eabi-objdump.exe -h startup.o

startup.o:     file format elf32-littlearm

Sections:
Idx Name          Size      VMA       LMA       File off  Algn
  0 .text         00000010  00000000  00000000  00000034  2**2
                  CONTENTS, ALLOC, LOAD, RELOC, READONLY, CODE
  1 .data         00000000  00000000  00000000  00000044  2**0
                  CONTENTS, ALLOC, LOAD, DATA
  2 .bss          00000000  00000000  00000000  00000044  2**0
                  ALLOC
  3 .ARM.attributes 00000022  00000000  00000000  00000044  2**0
                  CONTENTS, READONLY

Abotaleb@DESKTOP-RBI99BO MINGW32 /h/Lesson_2
$
```

6- symbol table (app.o , uart.o , startup.o)

```
Abotaleb@DESKTOP-RBI99BO MINGW32 /h/Lesson_2
$ arm-none-eabi-nm.exe app.o
00000000 T main
00000000 D string_buffer
00000000 R string_buffer2
         U Uart_sent_string

Abotaleb@DESKTOP-RBI99BO MINGW32 /h/Lesson_2
$ arm-none-eabi-nm.exe uart.o
00000000 T Uart_sent_string

Abotaleb@DESKTOP-RBI99BO MINGW32 /h/Lesson_2
$ arm-none-eabi-nm.exe startup.o
         U main
00000000 T reset
         U stack_top
00000008 t stop
```

7- linking and getting the binary file (learn-in-depth.bin)

```
Abotaleb@DESKTOP-RBI99BO MINGW32 /h/Lesson_2
$ arm-none-eabi-ld.exe -T linker-skript.ld app.o startup.o uart.o -o learn-in-depth.elf

Abotaleb@DESKTOP-RBI99BO MINGW32 /h/Lesson_2
$ arm-none-eabi-objcopy.exe -O binary learn-in-depth.elf learn-in-depth.bin

Abotaleb@DESKTOP-RBI99BO MINGW32 /h/Lesson_2
$
```

8-sections of learn-in-depth.elf

```
Abotaleb@DESKTOP-RBI99BO MINGW32 /h/Lesson_2
$ arm-none-eabi-objdump.exe -h learn-in-depth.elf

learn-in-depth.elf:     file format elf32-littlearm

Sections:
Idx Name          Size      VMA       LMA       File off  Algn
  0 .startup      00000010  00010000  00010000  00010000  2**2
                  CONTENTS, ALLOC, LOAD, READONLY, CODE
  1 .text         00000068  00010010  00010010  00010010  2**2
                  CONTENTS, ALLOC, LOAD, READONLY, CODE
  2 .rodata       00000064  00010078  00010078  00010078  2**2
                  CONTENTS, ALLOC, LOAD, READONLY, DATA
  3 .data         00000064  000100dc  000100dc  000100dc  2**2
                  CONTENTS, ALLOC, LOAD, DATA
  4 .ARM.attributes 0000002e  00000000  00000000  00010140  2**0
                  CONTENTS, READONLY
  5 .comment      00000011  00000000  00000000  0001016e  2**0
                  CONTENTS, READONLY
```

9-symbol table for learn-in-depth.elf

```
Abotaleb@DESKTOP-RBI99BO MINGW32 /h/Lesson_2
$ arm-none-eabi-nm.exe learn-in-depth.elf
00010010 T main
00010000 T reset
00011140 D stack_top
00010008 t stop
000100dc D string_buffer
00010078 R string_buffer2
00010028 T Uart_sent_string
```

10- run the program in the Qemu simulator

```
Abotaleb@DESKTOP-RBI99BO MINGW32 /h/Lesson_2
$ ../qemu/qemu-system-arm -M versatilepb -m 128M -nographic -kernel learn-in-depth.bin
learn-in-depth:Abdallah
Abotaleb@DESKTOP-RBI99BO MINGW32 /h/Lesson_2
$
```