


AID32A

Exploded diagram and parts list



No	Part Number	Parts name	Quantity
1	1070801326	Cooktop Panel	1
2	0070400055	Pad	6
3	0070900567	Induction Coil(180mm)	1
4	0070900639	Induction Coil(150mm)	1
5	0070600059	spring	6
6	0070900199	Thermistor	2
7	0070900178	fan	2
8	0070900876	Main PCB	2
9	0070900864	Power PCB	1
10	0070900863	EMC PCB	1
11	0070900878	Display PCB	1
12	0070200128	Buckle	1
13	0070900652	Supply cord	1
14	0070200125	Bottom case	1
15	0070100313	Stove fixtures	4
16	0070900695	Main PCB and Power PCB Connecting Wire I	1
17	0070900696	Main PCB and Power PCB Connecting Wire II	1
18	0070900697	EMC PCB and Power PCB Connecting Wire II	1
19	0070900698	EMC PCB and Power PCB Connecting Wire I	1
20	0070900236	Magnetic ring	1
Computer board replacement, first batch order DD231212XFF04, serial number 012402501-012402550			