LAB2

1- Compiling the c files, getting the object files, linking all files with startup file and linker script file, and the generate the binary file using Makefile command.

```
Abdo Halem@Halem-Lab /cygdrive/d/Engineering/Embedded_Systems/Eng Kerolos_Diploma/Lectures/Unit3/Lesson3/Lab2

$ make
arm-none-eabi-gcc -c -gdwarf-2 -mcpu=cortex-m3 -mthumb -I . main.c -o main.o
arm-none-eabi-gcc -c -gdwarf-2 -mcpu=cortex-m3 -mthumb -I . startup.c -o startup.o
arm-none-eabi-ld -T linker_script.ld main.o startup.o -o learn-in-depth_cortex_m3.elf -Map=Map_file.map
arm-none-eabi-objcopy -O binary learn-in-depth_cortex_m3.elf learn-in-depth_cortex_m3.bin
========Build is Done========

Abdo Halem@Halem-Lab /cygdrive/d/Engineering/Embedded_Systems/Eng Kerolos_Diploma/Lectures/Unit3/Lesson3/Lab2

$ |
```

2- analyze memory sections of each file.

```
Abdo Halem@Halem-Lab /cygdrive/d/Engineering/Embedded_Systems/Eng Kerolos_Diploma/Lectures/Unit3/Lesson3/Lab2
$ arm-none-eabi-objdump -h main.o
           file format elf32-littlearm
main.o:
Sections:
Idx Name
                                    LMA
                                              File off
                                                        Alan
                                              00000034
 0 .text
                 000000b0
                          00000000 00000000
                 CONTENTS, ALLOC, LOAD, RELOC, READONLY, CODE
                                              000000e4
                                                        2**2
 1 .data
                 00000008 00000000 00000000
                 CONTENTS, ALLOC, LOAD, DATA
                 00000000 00000000 00000000
                                              000000ec 2**0
 2 .bss
                 ALLOC
 3 .rodata
                 00000004 00000000 00000000
                                              000000ec 2**2
                 CONTENTS, ALLOC, LOAD, READONLY, DATA
 4 .debug_info
                 0000016e 00000000 00000000 000000f0 2**0
                 CONTENTS, RELOC, READONLY, DEBUGGING
 5 .debug_abbrev 000000ee 00000000 00000000
                                              0000025e 2**0
                 CONTENTS, READONLY, DEBUGGING
 6 .debug_loc
                 00000038
                           00000000
                                    00000000
                                              0000034c 2**0
                 CONTENTS, READONLY, DEBUGGING
                                               00000384
 7 .debug_aranges 00000020 00000000 00000000
                 CONTENTS, RELOC, READONLY, DEBUGGING
 8 .debug_line
                 0000009c 00000000 00000000 000003a4
                 CONTENTS, RELOC, READONLY, DEBUGGING
 9 .debug_str
                 0000014b 00000000 00000000 00000440
                 CONTENTS, READONLY, DEBUGGING
                                    00000000 0000058b
 10 .comment
                 00000012
                          00000000
                 CONTENTS, READONLY
11 .ARM.attributes 00000033 00000000 00000000 0000059d 2**0
                 CONTENTS, READONLY
12 .debug_frame 0000002c 00000000 00000000 000005d0 2**2
                 CONTENTS, RELOC, READONLY, DEBUGGING
```

```
Abdo Halem@Halem-Lab /cygdrive/d/Engineering/Embedded_Systems/Eng Kerolos_Diploma/Lectures/Unit3/Lesson3/Lab2
 arm-none-eabi-objdump -h startup.o
               file format elf32-littlearm
startup.o:
Sections:
Idx Name
                             VMA
                                       LMA
                                                 File off
                                                            Algn
                  Size
 0 .text
                             00000000
                  000000c4
                                       00000000
                                                 00000034
                  CONTENTS,
                            ALLOC, LOAD, RELOC,
                                                 READONLY.
                                                           CODE
 1 .data
                  00000000
                            00000000 00000000
                                                 000000f8
                                                            2**0
                            ALLOC, LOAD, DATA
                  CONTENTS,
 2 .bss
                  00000000
                            00000000
                                       00000000
                                                 000000f8
                                                           2**0
                  ALLOC
                  0000001c
                            00000000 00000000
                                                 000000f8
 3 .vectors
                                                            2**2
                            ALLOC, LOAD, RELOC, 00000000 00000000
                  CONTENTS,
                                                 DATA
 4 .debug_info
                  00000167
                                                 00000114
                                                            2**0
                  CONTENTS,
                            RELOC, READONLY, DEBUGGING
 5 .debug_abbrev
                  000000c0
                             00000000
                                       00000000
                                                 0000027b
                                                            2**0
                            READONLY,
                  CONTENTS,
                                       DEBUGGING
 6 .debug_loc
                                                 0000033b 2**0
                  00000064
                            00000000
                                       00000000
                             READONLY,
                  CONTENTS,
                                       DEBUGGING
 7 .debug_aranges 00000020
                             00000000
                                       00000000
                                                  0000039f
                                                             2**0
                  CONTENTS,
                            RELOC, READONLY, DEBUGGING
 8 .debug_line
                  000000ad
                            00000000 00000000 000003bf
                                                            2**0
                  CONTENTS,
                            RELOC, READONLY, DEBUGGING
 9 .debug_str
                  00000172
                            00000000
                                       00000000
                                                 0000046c
                                                            2**0
                            READONLY,
                                       DEBUGGING
                  CONTENTS,
10 .comment
                  00000012
                            00000000
                                       00000000
                                                 000005 de
                                                            2**0
                            READONLY
                  CONTENTS,
                              00000000 00000000 000005f0 2**0
11 .ARM.attributes 00000033
                  CONTENTS,
                            READONLY
12 .debug_frame
                  0000004c
                            00000000 00000000 00000624
                  CONTENTS, RELOC, READONLY, DEBUGGING
Abdo Halem@Halem-Lab /cygdrive/d/Engineering/Embedded_Systems/Eng Kerolos_Diploma/Lectures/Unit3/Lesson3/Lab2
```

```
Abdo Halem@Halem-Lab /cygdrive/d/Engineering/Embedded_Systems/Eng Kerolos_Diploma/Lectures/Unit3/Lesson3/Lab2
 arm-none-eabi-objdump -h learn-in-depth_cortex_m3.elf
                                   file format elf32-littlearm
learn-in-depth_cortex_m3.elf:
Sections:
                                                 File off
Idx Name
                  Size
                            VMA
                                       IMA
                                                            Alan
   .text
                  00000194
                            08000000
                                       08000000
                                                 000080000
                                                            2**2
                  CONTENTS,
                            ALLOC, LOAD, READONLY, CODE
                  80000000
                            20000000 08000194
 1 .data
                                                 00010000
                            ALLOC, LOAD, DATA
20000008 0800019
                  CONTENTS,
 2 .bss
                  000003e8
                                      0800019c
                                                 00010008
                                                           2**0
                  ALLOC
 3 .debug_info
                  000002d5
                            00000000
                                       00000000
                                                 00010008
                                                            2**0
                  CONTENTS.
                            READONLY.
                                       DEBUGGING
 4 .debug_abbrev 000001ae
                            00000000
                                       00000000
                                                 000102dd
                                                           2**0
                            READONLY,
                  CONTENTS,
                                       DEBUGGING
 5 .debug_loc
                  0000009c
                            00000000
                                       00000000
                                                 0001048b
                                                           2**0
                  CONTENTS,
                            READONLY,
                                       DEBUGGING
 6 .debug_aranges 00000040
                             00000000
                                        00000000
                                                  00010527
                                                            2**0
                            READONLY,
                  CONTENTS,
                                       DEBUGGING
 7 .debug_line
                  00000149
                            00000000
                                       00000000
                                                 00010567
                                                            2**0
                  CONTENTS,
                            READONLY,
                                       DEBUGGING
 8 .debug_str
                  0000018e
                            00000000
                                       00000000
                                                 000106b0
                                                           2**0
                            READONLY,
                  CONTENTS,
                                       DEBUGGING
 9 .comment
                  00000011
                            00000000
                                       00000000
                                                 0001083e 2**0
                  CONTENTS.
                            READONI Y
10 .ARM.attributes 00000033
                              00000000
                                        00000000
                                                  0001084f 2**0
                  CONTENTS, READONLY
11 .debug_frame
                            00000000
                                       00000000 00010884
                                                           2**7
                  00000078
                  CONTENTS, READONLY, DEBUGGING
Abdo Halem@Halem-Lab /cygdrive/d/Engineering/Embedded_Systems/Eng Kerolos_Diploma/Lectures/Unit3/Lesson3/Lab2
```

3- Getting the symbol table of each file.

```
Abdo Halem@Halem-Lab /cygdrive/d/Engineering/Embedded_Systems/Eng Kerolos_Diploma/Lectures/Unit3/Lesson3/Lab2
$ arm-none-eabi-nm main.o
00000000 R const_variables
00000004 D g_variables
00000000 T main
00000000 D R ODR
Abdo Halem@Halem-Lab /cygdrive/d/Engineering/Embedded_Systems/Eng Kerolos_Diploma/Lectures/Unit3/Lesson3/Lab2
$ arm-none-eabi-nm startup.o
         U _E_bss
U _E_DATA
U _E_text
         U _S_bss
         U _S_DATA
U _stack_top
00000000 W Bus_Fault_Handler
00000000 T Default_Handler
00000000 W H_Fault_Handler
         U main
00000000 W MM_Fault_Handler
00000000 W NMI_Handler
0000000c T Reset_Handler
00000000 W Usage_Fault_Handler
00000000 D vectors
Abdo Halem@Halem-Lab /cygdrive/d/Engineering/Embedded_Systems/Eng Kerolos_Diploma/Lectures/Unit3/Lesson3/Lab2
$ arm-none-eabi-nm learn-in-depth_cortex_m3.elf
20000008 B _E_bss
20000008 D _E_DATA
08000194 T _E_text
20000008 B _S_bss
20000000 D _S_DATA
200003f0 B _stack_top
080000cc W Bus_Fault_Handler
08000190 T const_variables
080000cc T Default_Handler
20000004 D g_variables
080000cc W H_Fault_Handler
0800001c T main
080000cc W MM_Fault_Handler
080000cc W NMI_Handler
20000000 D R_ODR
080000d8 T Reset_Handler
080000cc W Usage_Fault_Handler
08000000 T vectors
Abdo Halem@Halem-Lab /cygdrive/d/Engineering/Embedded_Systems/Eng Kerolos_Diploma/Lectures/Unit3/Lesson3/Lab2
```

4- Analyze the final elf file.

```
Abdo Halem@Halem-Lab /cygdrive/d/Engineering/Embedded_Systems/Eng Kerolos_Diploma/Lectures/Unit3/Lesson3/Lab2
$ arm-none-eabi-readelf -a learn-in-depth_cortex_m3.elf
ELF Header:
          7f 45 4c 46 01 01 01 00 00 00 00 00 00 00 00 00
 Magic:
  Class:
                                       ELF32
  Data:
                                       2's complement, little endian
                                       1 (current)
  Version:
 OS/ABI:
                                       UNIX - System V
  ABI Version:
                                       EXEC (Executable file)
  Type:
 Machine:
                                       ARM
                                       0x1
  Version:
  Entry point address:
                                       0x8000000
  Start of program headers:
                                       52 (bytes into file)
                                       67996 (bytes into file)
  Start of section headers:
                                       0x5000002, has entry point, Version5 EABI
  Flags:
  Size of this header:
                                       52 (bytes)
  Size of program headers:
                                       32 (bytes)
  Number of program headers:
  Size of section headers:
                                      40 (bytes)
                                      16
  Number of section headers:
  Section header string table index: 13
Section Headers:
  [Nr] Name
                                                                   ES Flg Lk Inf Al
                                                     Off
                                           Addr
                                                            Size
  [ 0]
                                           00000000 000000 000000 00
                          NULL
                                                                            0
                                                                                0
                                                                                  0
   1] .text
                          PROGBITS
                                           08000000 008000 000194 00
                                                                           0
                                                                                0
                                                                                   4
                                                                       AX
   2] .data
                                           20000000 010000 000008 00
                          PROGBITS
                                                                       WA
                                                                                0
   3] .bss
                          NOBITS
                                           20000008 010008 0003e8 00
                                                                        WA
                                                                           0
                                           00000000 010008 0002d5 00
                                                                            0
                                                                                0
   4] .debug_info
                          PROGBITS
                                           00000000 0102dd 0001ae 00
                                                                            0
                                                                                0
   5] .debug_abbrev
                          PROGBITS
   6] .debug_loc
                          PROGBITS
                                           00000000 01048b 00009c 00
                                                                            0
                                                                                0
   7] .debug_aranges
                          PROGBITS
                                           00000000 010527 000040 00
                                                                            0
                                                                                0
                                           00000000 010567 000149 00
    8] .debug_line
                          PROGBITS
                                                                            0
                                                                                0
                                           00000000 0106b0 00018e 01
      .debug_str
                                                                                0
   9]
                          PROGBITS
                                                                       MS
                                                                           0
  [10] .comment
                                           00000000 01083e 000011 01
                          PROGBITS
                                                                       MS
                                                                           0
                                                                                0
                                           00000000 01084f 000033 00
  [11] .ARM.attributes
                          ARM_ATTRIBUTES
                                                                            0
                                                                                0
                                                                                   1
  [12] .debug_frame
                          PROGBITS
                                           00000000 010884 000078 00
                                                                            0
  [13] .shstrtab
                          STRTAB
                                           00000000 0108fc 00009d 00
                                                                            0
                                                                                0
                          SYMTAB
                                           00000000 010c1c 000290 10
                                                                               23
                                                                                   4
  [14] .symtab
  [15] .strtab
                          STRTAB
                                           00000000 010eac 0000e9 00
                                                                            0
                                                                                0
(ey to Flags:
 W (write), A (alloc), X (execute), M (merge), S (strings)
 I (info), L (link order), G (group), T (TLS), E (exclude), x (unknown) O (extra OS processing required) o (OS specific), p (processor specific)
There are no section groups in this file.
Program Headers:
                 Offset
                           VirtAddr
                                       PhysAddr
                                                  FileSiz MemSiz Flg Align
  Type
 LOAD
                  0x008000 0x08000000 0x08000000 0x00194 0x00194 R E 0x8000
 LOAD
                  0x010000 0x20000000 0x08000194 0x00008 0x003f0 RW 0x8000
 Section to Segment mapping:
  Segment Sections...
   00
          .text
          .data .bss
   01
```

```
Program Headers:
                 Offset
                           VirtAddr
                                      PhysAddr
                                                  FileSiz MemSiz Flg Align
  Type
 LOAD
                 0x008000 0x08000000 0x08000000 0x00194 0x00194 R E 0x8000
 LOAD
                 0x010000 0x20000000 0x08000194 0x00008 0x003f0 RW
                                                                      0x8000
 Section to Segment mapping:
  Segment Sections...
          .text
  00
  01
          .data .bss
There is no dynamic section in this file.
There are no relocations in this file.
There are no unwind sections in this file.
Symbol table '.symtab' contains 41 entries:
           Value
                 Size Type
  Num:
                                Bind
                                       Vis
                                                 Ndx Name
     0: 00000000
                     O NOTYPE
                               LOCAL
                                       DEFAULT
                                                 UND
                     O SECTION LOCAL
     1: 08000000
                                       DEFAULT
                                                   1
                     O SECTION LOCAL
                                                   2
     2: 20000000
                                       DEFAULT
     3: 20000008
                     0
                       SECTION LOCAL
                                       DEFAULT
                                                   3
                     O SECTION LOCAL
     4: 00000000
                                       DEFAULT
                                                   4
     5: 00000000
                     O SECTION LOCAL
                                       DEFAULT
                                                   5
     6: 00000000
                     O SECTION LOCAL
                                       DEFAULT
                                                   6
                     O SECTION LOCAL
                                                   7
     7: 00000000
                                       DEFAULT
                     O SECTION LOCAL
                                       DEFAULT
     8: 00000000
                                                   8
     9: 00000000
                     O SECTION LOCAL
                                       DEFAULT
                                                   9
   10: 00000000
                     O SECTION LOCAL
                                       DEFAULT
                                                  10
   11: 00000000
                     O SECTION LOCAL
                                       DEFAULT
                                                  11
                     O SECTION LOCAL
   12: 00000000
                                       DEFAULT
                                                  12
                                                 ABS startup.c
   13: 00000000
                     O FILE
                                LOCAL
                                       DEFAULT
   14: 080000cc
                     O NOTYPE
                                LOCAL
                                       DEFAULT
                                                   1 $t
   15: 08000000
                     O NOTYPE
                                LOCAL
                                       DEFAULT
                                                   1 $d
                                LOCAL
                                       DEFAULT
   16: 0000003c
                     O NOTYPE
                                                  12 $d
                                LOCAL
   17: 00000000
                     0
                       FILE
                                       DEFAULT
                                                 ABS main.c
                                LOCAL
    18: 20000000
                     0
                       NOTYPE
                                       DEFAULT
                                                   2 $d
    19: 08000190
                       NOTYPE
                                LOCAL
                                       DEFAULT
                                                   1
                                                     $d
                     0
                                LOCAL
                                       DEFAULT
    20: 0800001c
                     O NOTYPE
                                                   1 $t
    21: 00000010
                     O NOTYPE
                                LOCAL
                                       DEFAULT
                                                  12 $d
    22: 00000000
                     O FILE
                                LOCAL
                                       DEFAULT
                                                 ABS
    23: 080000cd
                    10 FUNC
                                WEAK
                                       DEFAULT
                                                   1 NMI_Handler
    24: 08000190
                     3 OBJECT
                                GLOBAL DEFAULT
                                                   1 const_variables
```

25: 080000cd

26: 080000cd

27: 20000008

28: 20000004

29: 080000cd

30: 080000d9

31: 200003f0

32: 20000008

33: 080000cd

34: 20000008

35: 0800001d

36: 20000000

37: 080000cd

38: 20000000

39: 08000194

10 FUNC

10 FUNC

10 FUNC

10 FUNC

174 FUNC

10 FUNC

182 FUNC

O NOTYPE

3 OBJECT

O NOTYPE

O NOTYPE

O NOTYPE

4 OBJECT

O NOTYPE

O NOTYPE

WEAK

WEAK

WEAK

WEAK

DEFAULT

DEFAULT

DEFAULT

DEFAULT

GLOBAL DEFAULT

1 Bus_Fault_Handler

1 H_Fault_Handler

1 MM_Fault_Handler

Default_Handler

1 Usage_Fault_Handler

2 q_variables

3 _stack_top

_E_DATA

_S_bss

1 main

2 R_ODR

2 _S_DATA

1 _E_text

2

1

3

1 Reset_Handler

3 _E_bss

```
Abdo Halem@Halem-Lab /cygdrive/d/Engineering/Embedded_Systems/Eng Kerolos_Diploma/Lectures/Unit3/Lesson3/Lab2
 arm-none-eabi-objdump -h learn-in-depth_cortex_m3.elf
learn-in-depth_cortex_m3.elf:
                                 file format elf32-littlearm
Sections:
Idx Name
                           VMA
                                     IMA
                                               File off
                                                        Algn
                 Size
 0 .text
                 00000194
                           08000000 08000000
                                              000080000
                 CONTENTS, ALLOC, LOAD, READONLY, CODE
                 80000000
                                                        2**2
 1 .data
                           20000000 08000194
                                              00010000
                 CONTENTS, ALLOC, LOAD, DATA
                 000003e8 20000008 0800019c 00010008 2**0
 2 .bss
                 ALLOC
                 000002d5
 3 .debug_info
                           00000000
                                     00000000
                                              00010008 2**0
                 CONTENTS, READONLY, DEBUGGING
 4 .debug_abbrev 000001ae 00000000 00000000 000102dd 2**0
                 CONTENTS, READONLY, DEBUGGING
                                    00000000 0001048b 2**0
 5 .debug_loc
                 0000009c 00000000
                 CONTENTS, READONLY, DEBUGGING
 6 .debug_aranges 00000040 00000000 00000000
                                               00010527 2**0
                 CONTENTS, READONLY, DEBUGGING
  7 .debug_line
                 00000149 00000000
                                     00000000 00010567
                                                        2**0
                 CONTENTS, READONLY, DEBUGGING
  8 .debug_str
                 0000018e
                           00000000
                                     00000000
                                              000106b0
                                                        2**0
                 CONTENTS, READONLY, DEBUGGING
  9 .comment
                 00000011 00000000
                                     00000000 0001083e 2**0
                 CONTENTS, READONLY
 10 .ARM.attributes 00000033 00000000 00000000 0001084f 2**0
                 CONTENTS, READONLY
                00000078 00000000 00000000 00010884 2**2
 11 .debug_frame
                 CONTENTS, READONLY, DEBUGGING
Abdo Halem@Halem-Lab /cygdrive/d/Engineering/Embedded_Systems/Eng Kerolos_Diploma/Lectures/Unit3/Lesson3/Lab2
```