

Agenda

- Unsigned Arithmetic Continue...
 - Addition & Subtraction
 - Multiplication
 - Division





Unsigned Addition and Subtraction

- Adding unsigned numbers in binary is quite easy. Addition is done exactly like adding decimal numbers, except that you have only two digits (0 and 1).
- The only number facts to remember are that

```
0+0 = 0, with carry=0, so result = 00<sub>2</sub>
1+0 = 1, with carry=0, so result = 01<sub>2</sub>
0+1 = 1, with carry=0, so result = 01<sub>2</sub>
1+1 = 0, with carry=1, so result = 10<sub>2</sub>
```

 Note that the result is two bits, the rightmost bit is called the sum, and the left bit is called the carry



Unsigned Addition and Subtraction...cont

• To add the numbers $06_{10}=0110_2$ and $07_{10}=0111_2$ (answer= $13_{10}=1101_2$) we can write out the calculation (the results of any carry is shown along the top row, in italics).

Decimal	Unsigned Binary
1 (carry)	110 (carry)
06	0110
<u>+07</u>	+0111
13	1101

• The only difficulty adding unsigned binary numbers occurs when you add numbers that are too large. Consider 13+5.

Decimal	Unsigned Binary
0 (carry)	1101(carry)
13	1101
<u>+05</u>	+0101
18	10010

• The result is a 5 bit number. So the carry bit from adding the two most significant bits represents a results that overflows (because the sum is too big to be represented with the same number of bits as the two addends). The same problem can occur with decimal numbers: if you add the two digit decimal numbers 65 and 45, the result is 110 which is too large to be represented in 2 digits.



Signed Addition and Subtraction

 Adding signed numbers is not significantly different from adding unsigned numbers. Recall that signed 4 bit numbers (2's complement) can represent numbers between -8 and 7. To see how this addition works, consider three examples.

Decimal	Signed Binary		
-2 +3 1	1110(carry) 1110 +0011 0001		

Decimal	Signed Binary		
-5 <u>+3</u> -2	0011 (carry) 1011 +0011 1110		

Decimal	Signed Binary
-4 -3 -7	1100 (carry) 1100 +1101 1001

In this case the extra carry from the most significant bit has no meaning.



Signed Addition and Subtraction...cont


• With signed numbers there are two ways to get an overflow – if the result is greater than 7, or less than -8. Let's consider these occurrences now.

Decimal	Signed Binary
6 <u>+3</u> 9	110 (carry) 0110 +0011 1001
Decimal	Signed Binary

 Obviously both of these results are incorrect, but in this case overflow is harder to detect. But you can see that if two numbers with the same sign (either positive or negative) are added and the result has the opposite sign, an overflow has occurred.




Integer Addition



- Overflow if result out of range
 - Adding +ve and -ve operands, no overflow
 - Adding two +ve operands
 - Overflow if result sign is 1
 - Adding two –ve operands
 - Overflow if result sign is 0

Hardware for Addition and Subtraction



OF = overflow bit

SW = Switch (select addition or subtraction)

Multiplication

SATS UNIVERSE COST

How about this algorithm:

```
result = 0;
While first number > 0 {
  add second number to result;
  decrement first number;
}
```


- Does it work? What is the complexity?
- Can you think of a better approach?
- Lets do an example 1001 x 100
 - What is this in decimal?

Multiplication - longhand algorithm



- Just like you learned in school
- For each digit, work out partial product (easy for binary!)
- Take care with place value (column)
- Add partial products
- How to do it efficiently?


Example of shift and add multiplication




Length of product is the sum of operand lengths

How many steps?

How do we implement this in hardware?









Iteration	Step	Multiplier	Multiplicand	Product
0	Initial values	0011	0000 0010	0000 0000



Using 4-bit numbers to save space, multiply $2_{\rm ten} \times 3_{\rm ten}$, or $0010_{\rm two} \times 0011_{\rm two}$.

Iteration	Step	Multiplier	Multiplicand	Product
0	Initial values	0011	0000 0010	0000 0000
1	1a: 1 ⇒ Prod = Prod + Mcand	0011	0000 0010	0000 0010
I				1120121104100 1 2012 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1



Using 4-bit numbers to save space, multiply $2_{\rm ten} \times 3_{\rm ten}$, or $0010_{\rm two} \times 0011_{\rm two}$.

Iteration	Step	Multiplier	Multiplicand	Product
0	Initial values	0011	0000 0010	0000 0000
1	1a: 1 ⇒ Prod = Prod + Mcand	0011	0000 0010	0000 0010
	2: Shift left Multiplicand	0011	0000 0100	0000 0010



Step	Multiplier	Multiplicand	Product
Initial values	0011	0000 0010	0000 0000
1a: 1 ⇒ Prod = Prod + Mcand	0011	0000 0010	0000 0010
2: Shift left Multiplicand	0011	0000 0100	0000 0010
3: Shift right Multiplier	0001	0000 0100	0000 0010
	Initial values 1a: 1 ⇒ Prod = Prod + Mcand 2: Shift left Multiplicand	Initial values 0011 1a: 1 ⇒ Prod = Prod + Mcand 0011 2: Shift left Multiplicand 0011	Initial values 0011 0000 0010 1a: 1 ⇒ Prod = Prod + Mcand 0011 0000 0010 2: Shift left Multiplicand 0011 0000 0100



Iteration	Step	Multiplier	Multiplicand	Product
0	Initial values	0011	0000 0010	0000 0000
1	1a: 1 ⇒ Prod = Prod + Mcand	0011	0000 0010	0000 0010
	2: Shift left Multiplicand	0011	0000 0100	0000 0010
	3: Shift right Multiplier	0001	0000 0100	0000 0010
2	1a: 1 ⇒ Prod = Prod + Mcand	0001	0000 0100	0000 0110



Iteration	Step	Multiplier	Multiplicand	Product
0	Initial values	0011	0000 0010	0000 0000
1	1a: 1 ⇒ Prod = Prod + Mcand	0011	0000 0010	0000 0010
	2: Shift left Multiplicand	0011	0000 0100	0000 0010
	3: Shift right Multiplier	0001	0000 0100	0000 0010
2	1a: 1 ⇒ Prod = Prod + Mcand	0001	0000 0100	0000 0110
	2: Shift left Multiplicand	0001	0000 1000	0000 0110



Iteration	Step	Multiplier	Multiplicand	Product
0	Initial values	0011	0000 0010	0000 0000
1	1a: 1 ⇒ Prod = Prod + Mcand	0011	0000 0010	0000 0010
	2: Shift left Multiplicand	0011	0000 0100	0000 0010
	3: Shift right Multiplier	0001	0000 0100	0000 0010
2	1a: 1 ⇒ Prod = Prod + Mcand	0001	0000 0100	0000 0110
	2: Shift left Multiplicand	0001	0000 1000	0000 0110
	3: Shift right Multiplier	0000	0000 1000	0000 0110



Iteration	Step	Multiplier	Multiplicand	Product
0	Initial values	0011	0000 0010	0000 0000
1	1a: 1 ⇒ Prod = Prod + Mcand	0011	0000 0010	0000 0010
	2: Shift left Multiplicand	0011	0000 0100	0000 0010
	3: Shift right Multiplier	0001	0000 0100	0000 0010
2	1a: 1 ⇒ Prod = Prod + Mcand	0001	0000 0100	0000 0110
	2: Shift left Multiplicand	0001	0000 1000	0000 0110
	3: Shift right Multiplier	0000	0000 1000	0000 0110
3	1: 0 ⇒ No operation	0000	0000 1000	0000 0110



Iteration	Step	Multiplier	Multiplicand	Product
0	Initial values	0011	0000 0010	0000 0000
1	1a: 1 ⇒ Prod = Prod + Mcand	0011	0000 0010	0000 0010
	2: Shift left Multiplicand	0011	0000 0100	0000 0010
	3: Shift right Multiplier	0001	0000 0100	0000 0010
2	1a: 1 ⇒ Prod = Prod + Mcand	0001	0000 0100	0000 0110
	2: Shift left Multiplicand	0001	0000 1000	0000 0110
	3: Shift right Multiplier	0000	0000 1000	0000 0110
3	1: 0 ⇒ No operation	0000	0000 1000	0000 0110
	2: Shift left Multiplicand	0000	0001 0000	0000 0110
I	Long Long Long Long Long Long Long Long			



Iteration	Step	Multiplier	Multiplicand	Product
0	Initial values	0011	0000 0010	0000 0000
1	1a: 1 ⇒ Prod = Prod + Mcand	0011	0000 0010	0000 0010
	2: Shift left Multiplicand	0011	0000 0100	0000 0010
	3: Shift right Multiplier	0001	0000 0100	0000 0010
2	1a: 1 ⇒ Prod = Prod + Mcand	0001	0000 0100	0000 0110
	2: Shift left Multiplicand	0001	0000 1000	0000 0110
	3: Shift right Multiplier	0000	0000 1000	0000 0110
3	1: 0 ⇒ No operation	0000	0000 1000	0000 0110
	2: Shift left Multiplicand	0000	0001 0000	0000 0110
	3: Shift right Multiplier	0000	0001 0000	0000 0110



Iteration	Step	Multiplier	Multiplicand	Product
0	Initial values	0011	0000 0010	0000 0000
1	1a: 1 ⇒ Prod = Prod + Mcand	0011	0000 0010	0000 0010
	2: Shift left Multiplicand	0011	0000 0100	0000 0010
	3: Shift right Multiplier	0001	0000 0100	0000 0010
2	1a: 1 ⇒ Prod = Prod + Mcand	0001	0000 0100	0000 0110
	2: Shift left Multiplicand	0001	0000 1000	0000 0110
	3: Shift right Multiplier	0000	0000 1000	0000 0110
3	1: 0 ⇒ No operation	0000	0000 1000	0000 0110
	2: Shift left Multiplicand	0000	0001 0000	0000 0110
	3: Shift right Multiplier	0000	0001 0000	0000 0110
4	1: 0 ⇒ No operation	0000	0001 0000	0000 0110
	O. O. B. I. B. M. W. II	0000	2012 2022	



Iteration	Step	Multiplier	Multiplicand	Product
0	Initial values	0011	0000 0010	0000 0000
1	1a: 1 ⇒ Prod = Prod + Mcand	0011	0000 0010	0000 0010
	2: Shift left Multiplicand	0011	0000 0100	0000 0010
	3: Shift right Multiplier	0001	0000 0100	0000 0010
2	1a: 1 ⇒ Prod = Prod + Mcand	0001	0000 0100	0000 0110
	2: Shift left Multiplicand	0001	0000 1000	0000 0110
	3: Shift right Multiplier	0000	0000 1000	0000 0110
3	1: 0 ⇒ No operation	0000	0000 1000	0000 0110
	2: Shift left Multiplicand	0000	0001 0000	0000 0110
	3: Shift right Multiplier	0000	0001 0000	0000 0110
4	1: 0 ⇒ No operation	0000	0001 0000	0000 0110
	2: Shift left Multiplicand	0000	0010 0000	0000 0110



Iteration	Step	Multiplier	Multiplicand	Product
0	Initial values	0011	0000 0010	0000 0000
1	1a: 1 ⇒ Prod = Prod + Mcand	0011	0000 0010	0000 0010
	2: Shift left Multiplicand	0011	0000 0100	0000 0010
	3: Shift right Multiplier	0001	0000 0100	0000 0010
2	1a: 1 ⇒ Prod = Prod + Mcand	0001	0000 0100	0000 0110
	2: Shift left Multiplicand	0001	0000 1000	0000 0110
	3: Shift right Multiplier	0000	0000 1000	0000 0110
3	1: 0 ⇒ No operation	0000	0000 1000	0000 0110
	2: Shift left Multiplicand	0000	0001 0000	0000 0110
	3: Shift right Multiplier	0000	0001 0000	0000 0110
4	1: 0 ⇒ No operation	0000	0001 0000	0000 0110
	2: Shift left Multiplicand	0000	0010 0000	0000 0110
	3: Shift right Multiplier	0000	0010 0000	0000 0110

Unsigned Multiplication (12 x 9)


Iteration	Result	Multiplier (Q)	Multiplicand (A)	Operation
0	0000 0000	1100	0000 1001	Initialization
1	0000 0000	1100 0110	0001 0010 0001 0010	Shift left B Shift right Q
2	0000 0000	0110 0011	0010 0100 0010 0100	Shift left B Shift right Q
3	0010 0100 0010 0100 0010 0100	0011 0011 0001	0010 0100 0100 1000 0100 1000	Add B to A Shift left B Shift right Q
4	0110 1100 0110 1100 0110 1100	100 0001 100		Add B to A Shift left B Shift right Q

Unsigned Multiplication (12 x 9)

Iteration	Result	Multiplier (Q)	Multiplicand (A)	Operation
				L




Optimized Multiplier



- One cycle per partial-product addition
 - That's ok, if frequency of multiplications is low




Faster Multiplier



- Can be pipelined
 - Several multiplication performed in parallel

Division




n-bit operands yield *n*-bit quotient and remainder


Check for 0 divisor




- Long division approach
 - If divisor ≤ dividend bits
 - 1 bit in quotient, subtract
 - Otherwise
 - O bit in quotient, bring down next dividend bit
- Restoring division
 - Do the subtract, and if remainder goes < 0, add divisor back
- Signed division
 - Divide using absolute values
 - Adjust sign of quotient and remainder as required













Iteration	Step	Quotient	Divisor	Remainder
0	Initial Value	0000	0010 0000	0000 0111



Iteration	Step	Quotient	Divisor	Remainder
0	Initial Value	0000	0010 0000	0000 0111
	Rem = Rem - Div	0000	0010 0000	1110 0111



Iteration	Step	Quotient	Divisor	Remainder
0	Initial Value	0000	0010 0000	0000 0111
1	Rem = Rem – Div Rem < 0 \rightarrow +Div, shift 0 into Q	0000	0010 0000 0010 0000	1110 0111 0000 0111



Iteration	Step	Quotient	Divisor	Remainder
0	Initial Value	0000	0010 0000	0000 0111
1	Rem = Rem − Div Rem < 0 → +Div, shift 0 into Q Shift Div right	0000 0000	0010 0000 0010 0000 0001 0000	1110 0111 0000 0111 0000 0111



Iteration	Step	Quotient	Divisor	Remainder
0	Initial Value	0000	0010 0000	0000 0111
1	Rem = Rem − Div Rem < 0 → +Div, shift 0 into Q Shift Div right	0000 0000	0010 0000 0010 0000 0001 0000	1110 0111 0000 0111 0000 0111
	Rem = Rem - Div	0000	0001 0000	1111 0111



Iteration	Step	Quotient	Divisor	Remainder
0	Initial Value	0000	0010 0000	0000 0111
1	Rem = Rem − Div Rem < 0 → +Div, shift 0 into Q Shift Div right	0000 0000	0010 0000 0010 0000 0001 0000	1110 0111 0000 0111 0000 0111
2	Rem = Rem - Div Rem < 0 → +Div, shift 0 into Q	0000 0000	0001 0000 0001 0000	1111 0111 0000 0111



Iteration	Step	Quotient	Divisor	Remainder
0	Initial Value	0000	0010 0000	0000 0111
1	Rem = Rem − Div Rem < 0 → +Div, shift 0 into Q Shift Div right	0000 0000	0010 0000 0010 0000 0001 0000	1110 0111 0000 0111 0000 0111
2	Rem = Rem − Div Rem < 0 → +Div, shift 0 into Q Shift Div right	0000 0000	0001 0000 0001 0000 0000 1000	1111 0111 0000 0111 0000 0111



Iteration	Step	Quotient	Divisor	Remainder
0	Initial Value	0000	0010 0000	0000 0111
1	Rem = Rem − Div Rem < 0 → +Div, shift 0 into Q Shift Div right	0000 0000	0010 0000 0010 0000 0001 0000	1110 0111 0000 0111 0000 0111
2	Rem = Rem − Div Rem < 0 → +Div, shift 0 into Q Shift Div right	0000 0000	0001 0000 0001 0000 0000 1000	1111 0111 0000 0111 0000 0111
3	Same steps as 1	0000	0000 0100	0000 0111



Iteration	Step	Quotient	Divisor	Remainder
0	Initial Value	0000	0010 0000	0000 0111
1	Rem = Rem − Div Rem < 0 → +Div, shift 0 into Q Shift Div right	0000 0000	0010 0000 0010 0000 0001 0000	1110 0111 0000 0111 0000 0111
2	Rem = Rem − Div Rem < 0 → +Div, shift 0 into Q Shift Div right	0000 0000	0001 0000 0001 0000 0000 1000	1111 0111 0000 0111 0000 0111
3	Same steps as 1	0000	0000 0100	0000 0111
	Rem = Rem - Div	0000	0000 0100	0000 0011



Iteration	Step	Quotient	Divisor	Remainder
0	Initial Value	0000	0010 0000	0000 0111
1	Rem = Rem − Div Rem < 0 → +Div, shift 0 into Q Shift Div right	0000 0000	0010 0000 0010 0000 0001 0000	1110 0111 0000 0111 0000 0111
2	Rem = Rem − Div Rem < 0 → +Div, shift 0 into Q Shift Div right	0000 0000	0001 0000 0001 0000 0000 1000	1111 0111 0000 0111 0000 0111
3	Same steps as 1	0000	0000 0100	0000 0111
4	Rem = Rem – Div Rem >= $0 \rightarrow$, shift 1 into Q	0000 0001	0000 0100 0000 0100	0000 0011 0000 0011




Iteration	Step	Quotient	Divisor	Remainder
0	Initial Value	0000	0010 0000	0000 0111
1	Rem = Rem − Div Rem < 0 → +Div, shift 0 into Q Shift Div right	0000 0000	0010 0000 0010 0000 0001 0000	1110 0111 0000 0111 0000 0111
2	Rem = Rem − Div Rem < 0 → +Div, shift 0 into Q Shift Div right	0000 0000	0001 0000 0001 0000 0000 1000	1111 0111 0000 0111 0000 0111
3	Same steps as 1	0000	0000 0100	0000 0111
4	Rem = Rem − Div Rem >= 0 →, shift 1 into Q Shift Div right	0000 0001 0001	0000 0100 0000 0100 0000 0010	0000 0011 0000 0011 0000 0011



Iteration	Step	Quotient	Divisor	Remainder
0	Initial Value	0000	0010 0000	0000 0111
1	Rem = Rem − Div Rem < 0 → +Div, shift 0 into Q Shift Div right	0000 0000	0010 0000 0010 0000 0001 0000	1110 0111 0000 0111 0000 0111
2	Rem = Rem − Div Rem < 0 → +Div, shift 0 into Q Shift Div right	0000 0000	0001 0000 0001 0000 0000 1000	1111 0111 0000 0111 0000 0111
3	Same steps as 1	0000	0000 0100	0000 0111
4	Rem = Rem − Div Rem >= 0 →, shift 1 into Q Shift Div right	0000 0001 0001	0000 0100 0000 0100 0000 0010	0000 0011 0000 0011 0000 0011
5	Same steps as 4	0011	0000 0001	0000 0001



Optimized Divider



- One cycle per partial-remainder subtraction
- Looks a lot like a multiplier!
 - Same hardware can be used for both

Aside – cost of these operations



- We'd like to be able to finish these operations quickly
 - Usually in one cycle!
- How do we implement add?
 - Remember the 1 bit full adder?
- How many adds do we need for a multiply?
- Specialized logic circuits are used to implement these functionalities quickly (e.g., carry look-ahead adders, loop unrolled multiplication)