

GRIFOLS Diagnostic Grifols, S.A.	Reference:	REGD-0010049		
	Version:	2.0; Most-Recent; Effective; CURRENT		
	Status:	Effective	Purpose:	Uncontrolled Copy
Class:	Control del Diseño		Effective date:	19-Dec-2014
Title:	SM DG57-DG517. DISABLE-ENABLE 'C' HARD DISK UNIT SOFTWARE PROTECTION			

DG-57 / DG-517 Service Manual

DISABLE/ENABLE 'C:' HARD DISK UNIT SOFTWARE PROTECTION

Procedure description

This procedure describes how to enable and disable C: hard disk unit software protection.

Unit C: should be protected by default. Every time the computer is restarted, C: unit will do it with its initial configuration and all previous data stored during a session with enabled protection will be erased.

When initializing under disabled hard disk protection mode, the system will be vulnerable to viruses. It is recommended to install only files which have previously been scanned with a virus scanner.

Note: Hard disk protection disabling is only needed to perform permanent changes.

Note 2: Document REGD-0010049_v2 is added to DG-57 project and replaces document REGD-0010049_v1 for DG-517 project.

GRIFOLS Diagnostic Grifols, S.A.	Reference:	REGD-0010049		
	Version:	2.0; Most-Recent; Effective; CURRENT		
	Status:	Effective	Purpose:	Uncontrolled Copy
Class:	Control del Diseño		Effective date:	19-Dec-2014
Title:	SM DG57-DG517. DISABLE-ENABLE 'C' HARD DISK UNIT SOFTWARE PROTECTION			


EQUIPMENT

1.	1. Computer Matrox 4sight GP
----	------------------------------

SET UP


1.	PC turned on
----	--------------

PROCEDURE 1. Checking hard disk protection status.

Process	Expected Results
1. Execute <i>OSConfig.exe</i> application found in <i>C:\Windows</i> and select 'Write Filter' tab. 'Write Filter Status' window indicates hard disk protection status: DISABLED= Disabled Protection. ENABLED= Active protection.  Picture 1	---

GRIFOLS Diagnostic Grifols, S.A.	Reference:	REGD-0010049		
	Version:	2.0; Most-Recent; Effective; CURRENT		
	Status:	Effective	Purpose:	Uncontrolled Copy
Class:	Control del Diseño		Effective date:	19-Dec-2014
Title:	SM DG57-DG517. DISABLE-ENABLE 'C' HARD DISK UNIT SOFTWARE PROTECTION			

PROCEDURE 2. Disabling and enabling hard disk protection.

Process	Expected Results
1. Execute <i>OSConfig.exe</i> application found in <i>C:\Windows</i> and select 'Write Filter' tab. - If "Write Filter Status"= ENABLED select 'DISABLE EWF' to disable protection. - If "Write Filter Status"= DISABLED select 'ENABLE EWF' to enable protection.  Picture 2 In both cases 'accept' button must be selected.	---
2. A new window will appear asking to reboot PC, press Accept button	---
3. Once the PC is rebooted, check that the Write Filter Status has changed as indicated in the previous step.	---

GRIFOLS Diagnostic Grifols, S.A.	Reference:	REGD-0010049		
	Version:	2.0; Most-Recent; Effective; CURRENT		
	Status:	Effective	Purpose:	Uncontrolled Copy
Class:	Control del Diseño		Effective date:	19-Dec-2014
Title:	SM DG57-DG517. DISABLE-ENABLE 'C' HARD DISK UNIT SOFTWARE PROTECTION			

DOCUMENT CHANGE HISTORY

Document change history			
Version	Date	Change	Rationale
1.0	November 2011	NA	1st version of the document
2.0	December 2014	DG57 project is added to the document title	Use of Matrox 4Sight GP for DG57
2.0	December 2014	OSConfig.exe substitutes XPconfig.exe and the corresponding pictures are changed	Use of Windows 7 Embedded