

Washing Machine Installation Guide

1. Before Installation

- Place the washing machine on a solid, level surface with enough space for ventilation and access.
- Remove all transport bolts and packing materials before operating the machine.
- Check the machine, power cord, inlet hose, and drain hose for visible damage.

2. Positioning and Leveling

- Place the machine on a stable floor that can support the appliance and its load.
- Adjust the leveling feet until the machine stands firmly without rocking.
- Leave sufficient clearance around the machine so doors, hoses, and controls can be accessed safely.

3. Water Connection

- Connect the inlet hose securely to the appropriate water supply tap.
- Tighten the connection by hand and check for leaks after opening the water supply.
- Do not bend or crush the inlet hose.

4. Drain Connection

- Connect the drain hose securely to a suitable drain point.
- Ensure the hose is positioned according to the recommended height and is not kinked.
- Run a short test cycle and inspect the drain connection for leaks.

5. Electrical Connection

- Connect the appliance to a properly grounded electrical outlet matching the machine's rated voltage.
- Do not use a damaged power cord, loose outlet, or unsuitable extension arrangement.
- Keep the electrical connection away from standing water.

6. First Test Run

- Confirm that transport bolts have been removed and all connections are secure.
- Run an empty rinse or short wash cycle to check water intake, drainage, vibration, and leaks.
- If abnormal noise, excessive vibration, or leakage occurs, stop the machine and inspect the installation.